

FOREWORD

This manual contains an introductory description on the SUZUKI GSX1300R and procedures for its inspection/service and overhaul of its main components.

Other information considered as generally known is not included.

Read the GENERAL INFORMATION section to familiarize yourself with the motorcycle and its maintenance. Use this section as well as other sections to use as a guide for proper inspection and service.

This manual will help you know the motorcycle better so that you can assure your customers of fast and reliable service.

** This manual has been prepared on the basis of the latest specifications at the time of publication. If modifications have been made since then, differences may exist between the content of this manual and the actual motorcycle.*

** Illustrations in this manual are used to show the basic principles of operation and work procedures. They may not represent the actual motorcycle exactly in detail.*

** This manual is written for persons who have enough knowledge, skills and tools, including special tools, for servicing SUZUKI motorcycles. If you do not have the proper knowledge and tools, ask your authorized SUZUKI motorcycle dealer to help you.*

▲ WARNING

Inexperienced mechanics or mechanics without the proper tools and equipment may not be able to properly perform the services described in this manual.

Improper repair may result in injury to the mechanic and may render the motorcycle unsafe for the rider and passenger.

SUZUKI MOTOR CORPORATION

TABLE OF CONTENTS

Precautions.....	00-i
Precautions	00-1
General Information	0-i
General Information	0A-1
Maintenance and Lubrication	0B-1
Service Data.....	0C-1
Engine	1-i
Precautions	1-1
Engine General Information and Diagnosis	1A-1
Emission Control Devices	1B-1
Engine Electrical Devices.....	1C-1
Engine Mechanical.....	1D-1
Engine Lubrication System	1E-1
Engine Cooling System.....	1F-1
Fuel System	1G-1
Ignition System.....	1H-1
Starting System.....	1I-1
Charging System.....	1J-1
Exhaust System	1K-1
Suspension.....	2-i
Precautions	2-1
Suspension General Diagnosis.....	2A-1
Front Suspension.....	2B-1
Rear Suspension.....	2C-1
Wheels and Tires	2D-1
Driveline / Axle	3-i
Precautions	3-1
Drive Chain / Drive Train / Drive Shaft	3A-1
Brake	4-i
Precautions	4-1
Brake Control System and Diagnosis	4A-1
Front Brakes.....	4B-1
Rear Brakes	4C-1
Transmission / Transaxle	5-i
Precautions	5-1
Manual Transmission	5B-1
Clutch	5C-1
Steering.....	6-i
Precautions	6-1
Steering General Diagnosis	6A-1
Steering / Handlebar	6B-1
Body and Accessories.....	9-i
Precautions	9-1
Wiring Systems	9A-1
Lighting Systems.....	9B-1
Combination Meter / Fuel Meter / Horn.....	9C-1
Exterior Parts	9D-1
Body Structure	9E-1

SUPPLEMENTS

GSX1300RK9

10

Section 00

Precautions

CONTENTS

Precautions	00-1	General Precautions	00-1
Precautions.....	00-1	Precautions for Electrical Circuit Service	00-2
Warning / Caution / Note.....	00-1		

Precautions

Precautions

Warning / Caution / Note

B815H20000001

Please read this manual and follow its instructions carefully. To emphasize special information, the symbol and the words WARNING, CAUTION and NOTE have special meanings. Pay special attention to the messages highlighted by these signal words.

WARNING

Indicates a potential hazard that could result in death or injury.

CAUTION

Indicates a potential hazard that could result in motorcycle damage.

NOTE

Indicates special information to make maintenance easier or instructions clearer.

Please note, however, that the warnings and cautions contained in this manual cannot possibly cover all potential hazards relating to the servicing, or lack of servicing, of the motorcycle. In addition to the WARNINGS and CAUTIONS stated, you must use good judgement and basic mechanical safety principles. If you are unsure about how to perform a particular service operation, ask a more experienced mechanic for advice.

General Precautions

B815H20000002

WARNING

- Proper service and repair procedures are important for the safety of the service mechanic and the safety and reliability of the motorcycle.
- When 2 or more persons work together, pay attention to the safety of each other.
- When it is necessary to run the engine indoors, make sure that exhaust gas is forced outdoors.
- When working with toxic or flammable materials, make sure that the area you work in is well ventilated and that you follow all of the material manufacturer's instructions.
- Never use gasoline as a cleaning solvent.

- To avoid getting burned, do not touch the engine, engine oil, radiator and exhaust system until they have cooled.
- After servicing the fuel, oil, water, exhaust or brake systems, check all lines and fittings related to the system for leaks.

CAUTION

- If parts replacement is necessary, replace the parts with Suzuki Genuine Parts or their equivalent.
- When removing parts that are to be reused, keep them arranged in an orderly manner so that they may be reinstalled in the proper order and orientation.
- Be sure to use special tools when instructed.
- Make sure that all parts used in reassembly are clean. Lubricate them when specified.
- Use the specified lubricant, bond or sealant.
- When removing the battery, disconnect the negative (-) cable first and then the positive (+) cable.
- When reconnecting the battery, connect the positive (+) cable first and then the negative (-) cable, and replace the terminal cover on the positive (+) terminal.
- When performing service to electrical parts, if the service procedures do not require use of battery power, disconnect the negative (-) cable the battery.
- When tightening the cylinder head or case bolts and nuts, tighten the larger sizes first. Always tighten the bolts and nuts diagonally from the inside toward outside and to the specified tightening torque.
- Whenever you remove oil seals, gaskets, packing, O-rings, locking washers, self-locking nuts, cotter pins, circlips and certain other parts as specified, be sure to replace them with new ones. Also, before installing these new parts, be sure to remove any left over material from the mating surfaces.

- **Never reuse a circlip.** When installing a new circlip, take care not to expand the end gap larger than required to slip the circlip over the shaft. After installing a circlip, always ensure that it is completely seated in its groove and securely fitted.
- **Use a torque wrench to tighten fasteners to the specified torque.** Wipe off grease and oil if a thread is smeared with them.
- **After reassembling, check parts for tightness and proper operation.**
- **To protect the environment, do not unlawfully dispose of used motor oil, engine coolant and other fluids: batteries, and tires.**
- **To protect Earth's natural resources, properly dispose of used motorcycle and parts.**

Precautions for Electrical Circuit Service


B815H20000003

When handling the electrical parts or servicing the FI and ABS systems, observe the following points for the safety of the systems.

Electrical Parts


Connector / Coupler

- When connecting a connector, be sure to push it in until a click is felt.




- With a lock type coupler, be sure to release the lock when disconnecting, and push it in fully to engage the lock when connecting.
- When disconnecting the coupler, be sure to hold the coupler body and do not pull the lead wires.
- Inspect each terminal on the connector/coupler for looseness or bending.
- Push in the coupler straightly. An angled or skewed insertion may cause the terminal to be deformed, possibly resulting in poor electrical contact.
- Inspect each terminal for corrosion and contamination. The terminals must be clean and free of any foreign material which could impede proper terminal contact.


- Before refitting the sealed coupler, make sure its seal rubber is positioned properly. The seal rubber may possibly come off the position during disconnecting work and if the coupler is refitted with the seal rubber improperly positioned, it may result in poor water sealing.



- Inspect each lead wire circuit for poor connection by shaking it by hand lightly. If any abnormal condition is found, repair or replace.



- When taking measurements at electrical connectors using a tester probe, be sure to insert the probe from the wire harness side (rear) of the connector/coupler.




1. Coupler	2. Probe
------------	----------

- When connecting meter probe from the terminal side of the coupler (where connection from harness side not being possible), use extra care not to force and cause the male terminal to bend or the female terminal to open. Connect the probe as shown to avoid opening of female terminal. Never push in the probe where male terminal is supposed to fit.

00-3 Precautions:

- Check the male connector for bend and female connector for excessive opening. Also check the coupler for locking (looseness), corrosion, dust, etc.




I649G1000030-02

3. Coupler	4. Probe	"A": Where male terminal fits
------------	----------	-------------------------------

Clamp


- Clamp the wire harness at such positions as indicated in "Wiring Harness Routing Diagram in Section 9A (Page 9A-5)".
- Bend the clamp properly so that the wire harness is clamped securely.
- In clamping the wire harness, use care not to allow it to hang down.
- Do not use wire or any other substitute for the band type clamp.



I718H1000001-02

Fuse

- When a fuse is blown, always investigate the cause to correct it and then replace the fuse.
- Do not use a fuse of different capacity.
- Do not use wire or any other substitute for the fuse.




I649G1000001-02

Switch

Never apply grease material to switch contact points to prevent damage.


ECM / Various sensors

- Since each component is a high-precision part, great care should be taken not to apply any severe impacts during removal and installation.




I310G1000007-01

- Be careful not to touch the electrical terminals of the electronic parts (ECM, etc.). The static electricity from your body may damage them.



I310G1000008-01

- When disconnecting and connecting the coupler, make sure to turn OFF the ignition switch, or electronic parts may get damaged.




1. Ignition switch

I815H1000001-01


Battery

- Battery connection in reverse polarity is strictly prohibited. Such a wrong connection will damage the components of the FI and ABS systems instantly when reverse power is applied.




I718H1000004-01

- Removing any battery terminal of a running engine is strictly prohibited. The moment such removal is made, damaging counter electromotive force will be applied to the electronic unit which may result in serious damage.



I310G1000011-01

- Before measuring voltage at each terminal, check to make sure that battery voltage is 11 V or higher. Terminal voltage check with a low battery voltage will lead to erroneous diagnosis.



I310G1000012-02

- Never connect any tester (voltmeter, ohmmeter, or whatever) to the electronic unit when its coupler is disconnected. Otherwise, damage to electronic unit may result.
- Never connect an ohmmeter to the electronic unit with its coupler connected. If attempted, damage to ECM or sensors may result.
- Be sure to use a specified voltmeter/ohmmeter. Otherwise, accurate measurements may not be obtained and personal injury may result.

Electrical Circuit Inspection Procedure

While there are various methods for electrical circuit inspection, described here is a general method to check for open and short circuit using an ohmmeter and a voltmeter.


Open circuit check

Possible causes for the open circuit are as follows. As the cause can exist in the connector/coupler or terminal, they need to be checked carefully.

- Loose connection of connector/coupler
- Poor contact of terminal (due to dirt, corrosion or rust, poor contact tension, entry of foreign object etc.)
- Wire harness being open.
- Poor terminal-to-wire connection.

When checking system circuits including an electronic control unit such as ECM, ABS control unit/HU, etc., it is important to perform careful check, starting with items which are easier to check.

- Disconnect the negative (–) cable from the battery.
- Check each connector/coupler at both ends of the circuit being checked for loose connection. Also check for condition of the coupler lock if equipped.




I718H1000005-02

1. Sensor

"A": Check for loose connection

00-5 Precautions:


- 3) Using a test male terminal, check the female terminals of the circuit being checked for contact tension.
- Check each terminal visually for poor contact (possibly caused by dirt, corrosion, rust, entry of foreign object, etc.). At the same time, check to make sure that each terminal is fully inserted in the coupler and locked.
- If contact tension is not enough, rectify the contact to increase tension or replace. The terminals must be clean and free of any foreign material which could impede proper terminal contact.



I649G1000027-02

"B": Check contact tension by inserting and removing.
"C": Check each terminal for bend and proper alignment.

- 4) Using continuity inspect or voltage check procedure as described below, inspect the wire harness terminals for open circuit and poor connection. Locate abnormality, if any.




I649G1000028-02

"D": Looseness of crimping
"E": Open
"F": Thin wire (A few strands left)


Continuity check

- 1) Measure resistance across coupler "B" (between "A" and "C" in figure).
- If no continuity is indicated (infinity or over limit), the circuit is open between terminals "A" and "C".



I705H1000006-02

- 2) Disconnect the coupler "B" and measure resistance between couplers "A" and "B-1".
- If no continuity is indicated, the circuit is open between couplers "A" and "B-1". If continuity is indicated, there is an open circuit between couplers "B-2" and "C" or an abnormality in coupler "B-2" or coupler "C".



I705H1000010-02

Voltage check

If voltage is supplied to the circuit being checked, voltage check can be used as circuit check.

- 1) With all connectors/couplers connected and voltage applied to the circuit being checked, measure voltage between each terminal and body ground.
- 2) If measurements were taken as shown in the figure and results were listed in the following, it means that the circuit is open between terminals "A" and "B".

Voltage between

"A" and body ground: Approx. 5 V

"B" and body ground: Approx. 5 V

"C" and body ground: 0 V



- 3) Also, if measured values are as listed following, a resistance (abnormality) exists which causes the voltage drop in the circuit between terminals "A" and "B".

Voltage between

"A" and body ground: Approx. 5 V

"B" and body ground: Approx. 5 V – 2 V voltage drop

"C" and body ground: 3 V – 2 V voltage drop



I705H1000007-01



Short circuit check (Wire harness to ground)

- 1) Disconnect the negative (–) cable from the battery.
- 2) Disconnect the connectors/couplers at both ends of the circuit to be checked.

NOTE

If the circuit to be checked branches to other parts as shown, disconnect all connectors/couplers of those parts. Otherwise, diagnosis will be wrong.

- 3) Measure resistance between terminal at one end of circuit ("A" terminal in figure) and body ground. If continuity is indicated, there is a short circuit to ground between terminals "A" and "C".




I705H1000008-01

"D": To other parts	"E": Other parts
---------------------	------------------

00-7 Precautions:

- 4) Disconnect the connector/coupler included in circuit (coupler "B") and measure resistance between terminal "A" and body ground. If continuity is indicated, the circuit is shorted to the ground between terminals "A" and "B".



I705H1000009-02


"D": To other parts

Using The Multi-Circuit Testers

- Use the Suzuki multi-circuit tester set.
- Use well-charged batteries in the tester.
- Be sure to set the tester to the correct testing range.

Special tool

TOOL (A): 09900-25008 (Multi-circuit tester set)




I649G1000024-03

Using the testers

- Incorrectly connecting the (+) and (–) probes may cause the inside of the tester to be burned.
- If the voltage and current are not known, make measurements using the highest range.
- When measuring the resistance with the multi-circuit tester (1), ∞ will be shown as 10.00 M Ω and "1" flashes in the display.
- Check that no voltage is applied before making the measurement. If voltage is applied the tester may be damaged.
- After using the tester, turn the power off.

Special tool

TOOL : 09900-25008 (Multi-circuit tester set)




I649G1000002-02

NOTE

- When connecting the multi-circuit tester, use the needle pointed probe to the back side of the lead wire coupler and connect the probes of tester to them.
- Use the needle pointed probe to prevent the rubber of the water proof coupler from damage.
- When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent the terminal damage or terminal bend.

Special tool

TOOL (A): 09900-25009 (Needle pointed probe set)



I649G1000025-03

Section 0

General Information

CONTENTS

General Information	0A-1	Spark Plug Replacement	0B-9
General Description	0A-1	Spark Plug Inspection and Cleaning	0B-9
Symbols	0A-1	Fuel Line Inspection	0B-10
Abbreviations	0A-1	Engine Oil and Filter Replacement	0B-10
SAE-to-Former SUZUKI Term	0A-2	Throttle Cable Play Inspection and	
Vehicle Side View	0A-3	Adjustment	0B-12
Vehicle Identification Number	0A-4	Throttle Valve Synchronization	0B-12
Fuel and Oil Recommendation	0A-4	Evaporative Emission Control System	
Engine Coolant Recommendation	0A-5	Inspection (E-33 only)	0B-13
BREAK-IN Procedures	0A-5	PAIR System Inspection	0B-13
Cylinder Identification	0A-5	Cooling System Inspection	0B-13
Country and Area Codes	0A-6	Clutch System Inspection	0B-14
Wire Color Symbols	0A-6	Clutch Hose Replacement	0B-15
Warning, Caution and Information Labels		Clutch Fluid Replacement	0B-15
Location	0A-7	Drive Chain Inspection and Adjustment	0B-15
Component Location	0A-8	Drive Chain Cleaning and Lubricating	0B-17
Electrical Components Location	0A-8	Brake System Inspection	0B-17
Specifications	0A-10	Tire Inspection	0B-19
Specifications	0A-10	Steering System Inspection	0B-20
Special Tools and Equipment	0A-12	Front Fork Inspection	0B-20
Special Tool	0A-12	Rear Suspension Inspection	0B-20
Maintenance and Lubrication	0B-1	Chassis Bolt and Nut Inspection	0B-21
Precautions	0B-1	Compression Pressure Check	0B-23
Precautions for Maintenance	0B-1	Oil Pressure Check	0B-23
General Description	0B-1	SDS Check	0B-23
Recommended Fluids and Lubricants	0B-1	Specifications	0B-23
Scheduled Maintenance	0B-1	Tightening Torque Specifications	0B-23
Periodic Maintenance Schedule Chart	0B-1	Special Tools and Equipment	0B-24
Lubrication Points	0B-2	Recommended Service Material	0B-24
Repair Instructions	0B-3	Special Tool	0B-24
Air Cleaner Element Replacement	0B-3	Service Data	0C-1
Air Cleaner Element Inspection	0B-3	Specifications	0C-1
Exhaust Pipe Bolt and Muffler Bolt Inspection	0B-3	Service Data	0C-1
Valve Clearance Inspection and Adjustment	0B-4	Tightening Torque List	0C-9

General Information

General Description

Symbols

B815H20101001

Listed in the table below are the symbols indicating instructions and other information necessary for servicing.
The meaning of each symbol is also included in the table.

Symbol	Definition
	Torque control required. Data beside it indicate specified torque.
	Apply oil. Use engine oil unless otherwise specified.
	Apply molybdenum oil solution. (Mixture of engine oil and SUZUKI MOLY PASTE in a ratio of 1:1).
	Apply SUZUKI SUPER GREASE "A" or equivalent. 99000-25010
	Apply SUZUKI MOLY PASTE or equivalent. 99000-25140
	Apply SUZUKI SILICONE GREASE or equivalent. 99000-25100
	Apply SUZUKI BOND "1207B" or equivalent. 99000-31140
	Apply THREAD LOCK SUPER "1303" or equivalent. 99000-32030
	Apply THREAD LOCK SUPER "1322" or equivalent. 99000-32110
	Apply THREAD LOCK SUPER "1360" or equivalent. 99000-32130
	Use engine coolant or equivalent. 99000-99032-11X
	Use fork oil or equivalent. 99000-99044-L01
	Apply MUFFLER SEAL LOCTITE "5920" (commercially available) or equivalent.
	Apply or use brake fluid.
	Use special tool.
	Do not reuse.
	Note on reassembly.

Abbreviations

B815H20101002

A:

ABDC: After Bottom Dead Center

AC: Alternating Current

ACL: Air Cleaner, Air Cleaner Box

API: American Petroleum Institute

ATDC: After Top Dead Center

ATM Pressure: Atmospheric Pressure, Atmospheric Pressure Sensor (APS, AP Sensor)

A/F: Air Fuel Mixture

B:

BBDC: Before Bottom Dead Center

BTDC: Before Top Dead Center

B+: Battery Positive Voltage

BARO: Barometric pressure (Atmospheric pressure)

C:

CKP Sensor: Crankshaft Position Sensor (CKPS)

CKT: Circuit

CLP Switch: Clutch Lever Position Switch (Clutch Switch)

CMP Sensor: Camshaft Position Sensor (CMPS)

CO: Carbon Monoxide

CPU: Central Processing Unit

D:

DC: Direct Current

DMC: Dealer Mode Coupler

DOHC: Double Over Head Camshaft

DRL: Daytime Running Light

DTC: Diagnostic Trouble code

E:

ECM: Engine Control Module Engine Control Unit (ECU) (FI Control Unit)

ECT Sensor: Engine Coolant Temperature Sensor (ECTS)

Water Temp. Sensor (WTS)

EVAP: Evaporative Emission

F:
FI: Fuel Injection, Fuel Injector
FP: Fuel pump
FPR: Fuel Pressure Regulator
FP Relay: Fuel Pump Relay
G:
GEN: Generator
GND: Ground
GP Switch: Gear Position Switch
H:
HC: Hydrocarbons
HO2 sensor: Heated Oxygen Sensor (HO2S)
I:
IAP Sensor: Intake Air Pressure Sensor (IAPS)
IAT Sensor: Intake Air Temperature Sensor (IATS)
IG: Ignition
ISC Valve: Idle Speed Control Valve (ISCV)
J:
JASO: Japanese Automobile Standards Organization
L:
LCD: Liquid Crystal Display
LED: Light Emitting Diode (Malfunction Indicator Lamp)
LH: Left Hand
M:
MAL-CODE: Malfunction Code (Diagnostic Code)
Max: Maximum
MIL: Malfunction Indicator Lamp (LED)
Min: Minimum
N:
NOx: Nitrogen Oxides
O:
OHC: Over Head Camshaft
OPS: Oil Pressure Switch
P:
PAIR: Pulsed Secondary Air Injection
PCM: Power Control Module
PCV: Positive Crankcase Ventilation (Crankcase Breather)
R:
RH: Right Hand
ROM: Read Only Memory
S:
SAE: Society of Automotive Engineers
SDS: Suzuki Diagnosis System
STC System: Secondary Throttle Control System (STCS)
STP Sensor: Secondary Throttle Position Sensor (STPS)
ST Valve: Secondary Throttle Valve (STV)
STV Actuator: Secondary Throttle Valve Actuator (STVA)
T:
TO Sensor: Tip-over Sensor (TOS)
TP Sensor: Throttle Position Sensor (TPS)
TPC Valve: Tank Pressure Control Valve (TPCV)

SAE-to-Former SUZUKI Term

B815H20101012

This list shows SAE (Society of Automotive Engineers) J1930 terms and abbreviations which may be used in this manual in compliance with SAE recommendations, as well as their former SUZUKI names.

Ex. SAE term (Abbreviation): Former SUZUKI term

A:

Air Cleaner (ACL): Air Cleaner, Air Cleaner Box

B:

Barometric Pressure (BARO): Barometric Pressure, Atmospheric Pressure (APS, AP Sensor)

Battery Positive Voltage (B+): Battery Voltage, +B

C:

Camshaft Position Sensor (CMP Sensor): Camshaft Position Sensor (CMPS)

Crankshaft Position Sensor (CKP Sensor):

Crankshaft Position Sensor (CKPS), Crank Angle

D:

Data Link Connector (DLC): Dealer Mode Coupler

Diagnostic Test Mode (DTM): —

Diagnostic Trouble Code (DTC): Diagnostic Code, Malfunction Code

E:

Electronic Ignition (EI): —

Engine Control Module (ECM): Engine Control Module (ECM), FI Control Unit, Engine Control Unit (ECU)

Engine Coolant Level (ECL): Coolant Level

Engine Coolant Temperature (ECT): Coolant Temperature, Engine Coolant Temperature, Water Temperature

Engine Speed (RPM): Engine Speed (RPM)

Evaporative Emission (EVAP): Evaporative Emission

Evaporative Emission Canister (EVAP Canister): — (Canister)

F:

Fan Control (FC): —

Fuel Level Sensor: Fuel Level Sensor, Fuel Level Gauge

Fuel Pump (FP): Fuel Pump (FP)

G:

Generator (GEN): Generator

Ground (GND): Ground (GND, GRD)

H:

Hydrocarbons (HC): Hydrocarbons

Heated Oxygen Sensor (HO2S): Heated Oxygen Sensor (HO2S), O2 sensor

I:

Ignition Control Module (ICM): —

Intake Air Temperature (IAT): Intake Air Temperature (IAT), Air Temperature

Idle Speed Control (ISC): —

Ignition Control (IC): Electronic Spark Advance (ESA)

Ignition Control Module (ICM): —

Intake Air Temperature (IAT): Intake Air Temperature (IAT), Air Temperature

0A-3 General Information:

M:

Malfunction Indicator Lamp (MIL): LED Lamp, Malfunction Indicator Lamp (MIL)

Manifold Absolute Pressure (MAP): Intake Air Pressure (IAP), Intake Vacuum

Mass Air Flow (MAF): Air Flow

O:

On-Board Diagnostic (OBD): Self-Diagnosis Function, Diagnostic

Open Loop (OL): —

P:

Power Control Module (PCM): —

Programmable Read Only Memory (PROM): —

Pulsed Secondary Air Injection (PAIR): Pulse Air Control (PAIR)

Purge Valve (Purge Valve): Purge Valve (SP Valve)

R:

Random Access Memory (RAM): —

Read Only Memory (ROM): ROM

S:

Secondary Air Injection (AIR): —

Secondary Throttle Control System (STCS): STC System (STCS)

Secondary Throttle Valve (STV): ST Valve (STV)

Secondary Throttle Valve Actuator (STVA): STV Actuator (STVA)

T:

Throttle Body (TB): Throttle Body (TB)

Throttle Body Fuel Injection (TBI): Throttle Body Fuel Injection (TBI)

Throttle Position Sensor (TP Sensor): TP Sensor (TPS)

Tank Pressure Control Valve: TPC Valve (TPCV)

V:

Voltage Regulator (VR): Voltage Regulator

Volume Air Flow (VAF): Air Flow

Vehicle Side View


B815H20101003

NOTE

Difference between illustrations and actual motorcycles may exist depending on the markets.


SUZUKI GSX1300R (2008-model)

Right Side



I815H1010001-02

Left Side




I815H1010002-02


Vehicle Identification Number

B815H20101004

The frame serial number or V.I.N. (Vehicle Identification Number) "A" is stamped on the right side of the steering head pipe. The engine serial number "B" is located on the upper crankcase. These numbers are required especially for registering the machine and ordering spare parts.



I815H1010003-01



I815H1010004-01

Fuel and Oil Recommendation

B815H20101005

Fuel (For USA and Canada)

Use only unleaded gasoline of at least 90 pump octane (R/2 + M/2).

Gasoline containing MTBE (Methyl Tertiary Butyl Ether), less than 10% ethanol, or less than 5% methanol with appropriate cosolvents and corrosion inhibitor is permissible.

Fuel (For Other Countries)

Gasoline used should be graded 95 octane (Research Method) or higher. Unleaded gasoline is recommended.


Engine Oil (For USA)

Oil quality is a major contributor to your engine's performance and life. Always select good quality engine oil.

Suzuki recommends the use of SUZUKI PERFORMANCE 4 MOTOR OIL or equivalent engine oil. Use of SF/SG or SH/SJ in API with MA in JASO. Suzuki recommends the use of SAE 10W-40 engine oil. If SAE 10W-40 engine oil is not available, select an alternative according to the chart.

Engine Oil (For Other Countries)

Oil quality is a major contributor to your engine's performance and life. Always select good quality engine oil. Use of SF/SG or SH/SJ in API with MA in JASO. Suzuki recommends the use of SAE 10W-40 engine oil. If SAE 10W-40 engine oil is not available, select an alternative according to the chart.



I310G1010005-01

Brake Fluid

Specification and classification: DOT 4

⚠ WARNING

Since the brake system of this motorcycle is filled with a glycol-based brake fluid by the manufacturer, do not use or mix different types of fluid such as silicone-based and petroleum-based fluid for refilling the system, otherwise serious damage will result.

Do not use any brake fluid taken from old or used or unsealed containers.

Never reuse brake fluid left over from a previous servicing, which has been stored for a long period.

Front Fork Oil

Use fork oil L01 or equivalent fork oil.

Engine Coolant Recommendation

B815H20101006

Engine Coolant

Use an anti-freeze/engine coolant compatible with an aluminum radiator, mixed with distilled water only.

Water for mixing

Use distilled water only. Water other than distilled water can corrode and clog the aluminum radiator.

Anti-freeze / Engine coolant

The engine coolant perform as a corrosion and rust inhibitor as well as anti-freeze. Therefore, the engine coolant should be used at all times even though the atmospheric temperature in your area does not go down to freezing point.

Suzuki recommends the use of SUZUKI COOLANT anti-freeze/engine coolant. If this is not available, use an equivalent which is compatible with an aluminum radiator.

Liquid amount of water / Engine coolant

Solution capacity (total)

2 950 ml (3.1/2.6 US/Imp qt)

For engine coolant mixture information, refer to "Engine Coolant Description in Section 1F (Page 1F-1)".

⚠ CAUTION

Mixing of anti-freeze/engine coolant should be limited to 60%. Mixing beyond it would reduce its efficiency. If the anti-freeze/engine coolant mixing ratio is below 50%, rust inhabiting performance is greatly reduced. Be sure to mix it above 50% even though the atmospheric temperature does not go down to the freezing point.

BREAK-IN Procedures

B815H20101007

During manufacture only the best possible materials are used and all machined parts are finished to a very high standard but it is still necessary to allow the moving parts to "BREAK-IN" before subjecting the engine to maximum stresses. The future performance and reliability of the engine depends on the care and restraint exercised during its early life. The general rules are as follows.

- 1) Keep to these break-in engine speed limits:

Speed limits

Initial 800 km (500 miles): Below 5 500 r/min

Up to 1 600 km (1 000 miles): Below 8 000 r/min


Over 1 600 km (1 000 miles): Below 11 000 r/min

- 2) Upon reaching an odometer reading of 1 600 km (1 000 miles) you can subject the motorcycle to full throttle operation. However, do not exceed 11 000 r/min at any time.

Cylinder Identification

B815H20101008

The four cylinders of this engine are identified as #1, 2, 3 and #4 cylinder, as counted from left to right (as viewed by the rider on the seat).



I815H1010005-02

Country and Area Codes

B815H20101009

The following codes stand for the applicable country(-ies) and area(-s).

Code	Country or Area	Effective Frame No.
GSX1300R K8 (E-02)	U.K.	JS1CK111200100001 –
GSX1300R K8 (E-19)	E.U.	JS1CK111100100001 –
GSX1300RUF K8 (E-19)	E.U.	JS1CK211100100001 –
GSX1300R K8 (E-03)	U.S.A (Except for California)	JS1GX72A 82100001 –
GSX1300R K8 (E-24)	Australia	JS1CK111300100001 –
GSX1300R K8 (E-28)	Canada	JS1GX72A 82100001 –
GSX1300R K8 (E-33)	California (U.S.A)	JS1GX72A 82100001 –


Wire Color Symbols

B815H20101010

Symbol	Wire Color	Symbol	Wire Color
B	Black	Bl/Y	Blue with Yellow tracer
Bl	Blue	Br/B	Brown with Black tracer
Br	Brown	G/B	Green with Black tracer
Dbr	Dark brown	G/Y	Green with Yellow tracer
Dg	Dark green	Gr/B	Gray with Black tracer
G	Green	Gr/R	Gray with Red tracer
Gr	Gray	Gr/W	Gray with White tracer
Lbl	Light blue	Gr/Y	Gray with Yellow tracer
Lg	Light green	O/G	Orange with Green tracer
O	Orange	O/R	Orange with Red tracer
P	Pink	O/W	Orange with White tracer
R	Red	O/Y	Orange with Yellow tracer
W	White	P/B	Pink with Black tracer
Y	Yellow	P/W	Pink with White tracer
B/Bl	Black with Blue tracer	R/B	Red with Black tracer
B/Br	Black with Brown tracer	R/Bl	Red with Blue tracer
B/G	Black with Green tracer	W/B	White with Black tracer
B/Lg	Black with Light green tracer	W/Bl	White with Blue tracer
B/O	Black with Orange tracer	W/G	White with Green tracer
B/R	Black with Red tracer	W/R	White with Red tracer
B/W	Black with White tracer	W/Y	White with Yellow tracer
B/Y	Black with Yellow tracer	Y/B	Yellow with Black tracer
Bl/B	Blue with Black tracer	Y/Bl	Yellow with Blue tracer
Bl/G	Blue with Green tracer	Y/R	Yellow with Red tracer
Bl/W	Blue with White tracer	Y/W	Yellow with White tracer

Warning, Caution and Information Labels Location

B815H20101011




I815H1010008-01

1. Noise label (For E-03, 24, 33)	15. General warning label (French) (For GSX1300RUF E-19)
2. Information label (For E-03, 28, 33)	16. General warning label (English/French) (For E-28)
3. Vacuum hose routing label (For E-33)	17. General warning label (French/German/Italian/Swedish) (For E-19)
4. Fuel caution label (For E-02, 24)	18. ICES Canada label (For E-28)
5. Fuel information label	19. I.D. plate (For E-02, 19, 24)
6. Manual notice label (For E-03, 33)	20. I.D. label (For GSX1300RUF E-19)
7. Screen label (English) (For E-02, 03, 24, 28, 33)	21. Safety plate (For E-03, 28, 33)
8. Screen label (French) (For E-28, GSX1300RUF E-19)	[A]: Frame (RH)
9. Screen label (French/German/Italian/Swedish) (For E-19)	[B]: Rear fender, front
10. Steering warning label (English) (For E-03, 33)	[C]: Upper panel
11. Steering warning label (French/German/English) (For E-02, 19, 24, 28)	[D]: Swingarm
12. Tire information label (English) (For E-03, 33)	[E]: Frame (LH)
13. Tire information label (French/German/English) (For E-02, 19, 24, 28)	
14. General warning label (English) (For E-02, 03, 24, 33)	

Component Location


Electrical Components Location

B815H20103001



I815H1010007-02

1. STV actuator	7. PAIR control solenoid valve	13. Starter motor
2. STP sensor	8. Cooling fan (RH)	14. GP switch
3. TP sensor	9. IAP sensor	15. HO2 sensor
4. CMP sensor	10. Drive mode selector	16. Oil pressure switch
5. ISC valve	11. TO sensor	
6. Ignition coil	12. Regulator/Rectifier	



I815H1010006-03

17. Turn signal/Side-stand relay	25. ECT sensor	33. Horn
18. Fuse box	26. Ignition switch	34. Cooling fan (LH)
19. Cooling fan relay	27. AP sensor	35. IAT sensor
20. Secondary fuel injector	28. Battery	36. CKP sensor
21. Primary fuel injector	29. Mode select switch coupler	37. Speed sensor
22. Fuel level gauge	30. ECM	38. Side-stand switch
23. Fuel pump	31. Fuel pump relay	39. Generator
24. EVAP system purge control solenoid valve (E-33 only)	32. Starter relay/Main fuse	

Specifications

Specifications

B815H20107001

NOTE

These specifications are subject to change without notice.

Dimensions and dry mass

Item	Specification	Remark
Overall length	2 190 mm (86.2 in)	
Overall width	735 mm (28.9 in)	
Overall height	1 165 mm (48.9 in)	
Wheelbase	1 480 mm (52.3 in)	
Ground clearance	120 mm (4.7 in)	
Seat height	805 mm (31.7 in)	
Dry mass	221 kg (487 lbs)	E-33
	220 kg (485 lbs)	Others

Engine

Item	Specification	Remark
Type	4-stroke, Liquid-cooled, DOHC	
Number of cylinders	4	
Bore	81.0 mm (3.189 in)	
Stroke	65.0 mm (2.559 in)	
Displacement	1 340 cm ³ (81.8 cu. in)	
Compression ratio	12.5 : 1	
Fuel system	Fuel injection system	
Air cleaner	Paper element	
Starter system	Electric	
Lubrication system	Wet sump	
Idle speed	1 150 ± 100 r/min	

Drive train

Item	Specification	Remark
Clutch	Wet multi-plate type	
Transmission	6-speed constant mesh	
Gearshift pattern	1-down, 5-up	
Primary reduction ratio	1.596 (83/52)	
Gear ratios	Low	2.615 (34/13)
	2nd	1.937 (31/16)
	3rd	1.526 (29/19)
	4th	1.285 (27/21)
	5th	1.136 (25/22)
	Top	1.043 (24/23)
Final reduction ratio	2.388 (43/18)	
Drive chain	RK GB50GSV Z4, 114 links	

Chassis

Item	Specification	Remark
Front suspension	Inverted telescopic, coil spring, oil damped	
Rear suspension	Link type, coil spring, oil damped	
Front suspension stroke	120 mm (4.7 in)	
Rear wheel travel	140 mm (5.5 in)	
Caster	23° 25'	
Tail	93 mm (3.7 in)	
Steering angle	30° (right & left)	
Turning radius	3.3 m (10.8 ft)	
Front brake	Disc brake, twin	
Rear brake	Disc brake	
Front tire size	120/70ZR17M/C (58W), tubeless	
Rear tire size	190/50ZR17M/C (73W), tubeless	

Electrical

Item	Specification	Remark
Ignition type	Electronic ignition (Transistorized)	
Ignition timing	5° B.T.D.C. at 1 150 r/min	
Spark plug	NGK CR9EIA-9 or DENSO IU27D	
Battery	12 V 36 kC (10 Ah)/10 HR	
Generator	Three-phase A.C. generator	
Main fuse	30 A	
Fuse	15/15/15/10/10/10/10 A	
Headlight	High	12 V 65 W (H9)
	Low	12 V 55 W (H7)
Position/Parking light	12 V 5 W x 2	
Brake light/Tailight	LED	
License plate light	12 V 5 W	
Turn signal light	12 V 21 W	
Speedometer light	LED	
Tachometer light	LED	
Fuel level indicator light	LED	
Turn signal indicator light	LED	
Neutral indicator light	LED	
High beam indicator light	LED	
Engine coolant temperature indicator light	LED	
Oil pressure indicator light	LED	
FI indicator light	LED	
Engine R.P.M. indicator light	LED	


























Capacities

Item	Specification	Remark
Fuel tank	20 L (5.3/4.4 US/Imp gal)	E-33
	21 L (5.5/4.6 US/Imp gal)	Others
Engine oil	Oil change	3 100 ml (3.3/2.7 US/Imp qt)
	With filter change	3 300 ml (3.5/2.9 US/Imp qt)
	Overhaul	4 000 ml (4.2/3.5 US/Imp qt)
Engine coolant	2.95 L (3.1/2.6 US/Imp qt)	
























Special Tools and Equipment























Special Tool

B815H20108001






				
09900-06104 Snap ring pliers	09900-06107 Snap ring pliers	09900-06108 Snap ring pliers	09900-18740 Hexagon socket (24 mm)	09900-20102 Vernier calipers (1/20 mm, 200 mm)
				
09900-20202 Micrometer (1/100 mm, 25 – 50 mm)	09900-20204 Micrometer (75 – 100 mm)	09900-20205 Micrometer (0 – 25 mm)	09900-20530 Cylinder gauge set	09900-20602 Dial gauge (1/1000 mm, 1 mm)
				
09900-20605 Dial calipers (1/100 mm, 10 – 34 mm)	09900-20607 Dial gauge (1/100 mm, 10 mm)	09900-20701 Magnetic stand	09900-20803 Thickness gauge	09900-20805 Tire depth gauge
				
09900-21304 V-block (100 mm)	09900-22301 Plastigauge (0.025 – 0.076 mm)	09900-22302 Plastigauge (0.051 – 0.152 mm)	09900-22403 Small bore gauge (18 – 35 mm)	09900-25008 Multi-circuit tester set
				
09900-25009 Needle pointed probe set	09900-28630 TPS test wire harness	09904-41010 SDS set	09910-60611 Universal clamp wrench	09913-50121 Oil seal remover

0A-13 General Information:

 <p>09913-70210 Bearing installer set</p>	 <p>09915-40610 Oil filter wrench</p>	 <p>09915-63311 Compression gauge attachment</p>	 <p>09915-64512 Compression gauge</p>	 <p>09915-74521 Oil pressure gauge hose</p>
 <p>09915-74540 Oil pressure gauge attachment</p>	 <p>09915-77331 Meter (for high pressure)</p>	 <p>09916-10911 Valve lapper set</p>	 <p>09916-14510 Valve spring compressor</p>	 <p>09916-14522 Valve spring compressor attachment</p>
 <p>09916-34542 Reamer handle</p>	 <p>09916-34570 Valve guide reamer (5.0 mm)</p>	 <p>09916-34580 Valve guide reamer (10.8 mm)</p>	 <p>09916-44310 Valve guide remover/installer</p>	 <p>09916-53350 Attachment</p>
 <p>09916-74521 Holder body</p>	 <p>09916-74550 Band (Piston diam.: 73 – 85 mm)</p>	 <p>09916-84511 Valve adjuster driver</p>	 <p>09917-47011 Vacuum pump gauge</p>	 <p>09919-28620 Sleeve protector</p>
 <p>09920-34830 Starter clutch holder</p>	 <p>09920-53740 Clutch sleeve hub holder</p>	 <p>09921-20240 Bearing remover set</p>	 <p>09922-22711 Drive chain cutting and joining tool</p>	 <p>09923-74511 Bearing remover</p>

 <p>09924-84510 Bearing installer set</p>	 <p>09924-84521 Bearing installer set</p>	 <p>09925-18011 Steering bearing installer</p>	 <p>09930-10121 Spark plug wrench set</p>	 <p>09930-11920 Torx bit (JT40H)</p>
 <p>09930-11930 Torx bit (JT30H)</p>	 <p>09930-11940 Bit holder</p>	 <p>09930-11950 Torx wrench</p>	 <p>09930-30104 Rotor remover slide shaft</p>	 <p>09930-30450 Rotor remover bolt</p>
 <p>09930-44530 Rotor holder</p>	 <p>09930-73140 Starter torque limiter socket</p>	 <p>09930-73170 Starter torque limiter holder</p>	 <p>09930-82720 Mode select switch</p>	 <p>09940-14911 Steering stem nut wrench</p>
 <p>09940-14960 Steering nut wrench socket</p>	 <p>09940-14970 Swingarm pivot thrust adjuster socket wrench</p>	 <p>09940-14990 Engine mounting thrust adjuster socket wrench</p>	 <p>09940-30221 Front fork assembling tool</p>	 <p>09940-40211 Fuel pressure gauge adapter</p>
 <p>09940-40220 Fuel pressure gauge hose attachment</p>	 <p>09940-52841 Inner rod holder</p>	 <p>09940-52861 Front fork oil seal installer</p>	 <p>09940-92720 Spring scale</p>	 <p>09940-94922 Front fork spring stopper plate</p>

0A-15 General Information:

 <p>09940-94930 Front fork spacer holder</p>	 <p>09941-34513 Steering race installer</p>	 <p>09941-54911 Bearing outer race remover</p>	 <p>09941-74911 Steering bearing installer</p>	 <p>09943-74111 Fork oil level gauge</p>
 <p>99565-01010-012 CD-ROM Ver.12</p>				

Maintenance and Lubrication

Precautions

Precautions for Maintenance

B815H20200001

The "Periodic Maintenance Schedule Chart" lists the recommended intervals for all the required periodic service work necessary to keep the motorcycle operating at peak performance and economy. Maintenance intervals are expressed in terms of kilometers, miles and months for your convenience.

IMPORTANT: The periodic maintenance intervals and service requirements have been established in accordance with EPA regulations. Following these instructions will ensure that the motorcycle will not exceed emission standards and it will also ensure the reliability and performance of the motorcycle.

NOTE

More frequent servicing may be required on motorcycles that are used under severe conditions.

General Description

Recommended Fluids and Lubricants

B815H20201001

Refer to "Fuel and Oil Recommendation in Section 0A (Page 0A-4)" and "Engine Coolant Recommendation in Section 0A (Page 0A-5)".

Scheduled Maintenance

Periodic Maintenance Schedule Chart

B815H20205001

NOTE

I = Inspect and clean, adjust, replace or lubricate as necessary.

R = Replace.

T = Tighten.

Item	Interval					
	km	1 000	6 000	12 000	18 000	24 000
	miles	600	4 000	7 500	11 000	14 500
	months	2	12	24	36	48
Air cleaner element	—	I	I	I	R	I
Exhaust pipe bolts and muffler bolts	T	—	T	—	—	T
Valve clearance	—	—	—	—	—	I
Spark plugs	—	I	R	I	R	R
Fuel line	—	I	I	I	I	I
Engine oil	R	R	R	R	R	R
Engine oil filter	R	—	—	R	—	—
Throttle cable play	I	I	I	I	I	I
Throttle valve synchronization	I (E-33 only)	—	I	—	I	I
Evaporative emission control system (E-33 only)	—	—	I	—	I	I
PAIR (air supply) system	—	—	I	—	I	I
Engine coolant	Replace every 2 years.					
Radiator hoses	—	I	I	I	I	I
Clutch fluid	—	I	I	I	I	I
Clutch hose	Replace every 2 years.					
	—	I	I	I	I	I
	Replace every 4 years.					
Drive chain	I	I	I	I	I	I
	Clean and lubricate every 1 000 km (600 miles).					

0B-2 Maintenance and Lubrication:

Item	Interval					
	km	1 000	6 000	12 000	18 000	24 000
	miles	600	4 000	7 500	11 000	14 500
	months	2	12	24	36	48
Brakes						
Brake fluid		—				
		Replace every 2 years.				
Brake hoses		—				
		Replace every 4 years.				
Tires		—				
Steering			—		—	
Front forks		—	—		—	
Rear suspension		—	—		—	
Chassis bolts and nuts		T	T	T	T	T


Lubrication Points

B815H20205002

Proper lubrication is important for smooth operation and long life of each working part of the motorcycle.
Major lubrication points are indicated as follows.

NOTE

- Before lubricating each part, clean off any rusty spots and wipe off any grease, oil, dirt or grime.
- Lubricate exposed parts which are subject to rust, with a rust preventative spray whenever the motorcycle has been operated under wet or rainy conditions.



I815H1020050-01

1. Clutch lever holder	6. Brake lever holder
2. Gearshift lever pivot	7. Brake pedal pivot and footrest pivot
3. Side-stand pivot and spring hook	 : Apply oil.
4. Footrest pivot	 : Apply grease.
5. Drive chain	

Repair Instructions

Air Cleaner Element Replacement

B815H20206001

Replace air cleaner element

Every 18 000 km (11 000 miles, 36 months)

Refer to "Air Cleaner Element Removal and Installation in Section 1D (Page 1D-6)".

Air Cleaner Element Inspection

B815H20206002

Inspect air cleaner element

Every 6 000 km (4 000 miles, 12 months)

Inspection


- 1) Remove the air cleaner element. Refer to "Air Cleaner Element Removal and Installation in Section 1D (Page 1D-6)".
- 2) Inspect the air cleaner element for clogging. If it is clogged with dirt, replace it with a new one.

⚠ CAUTION

Do not blow the air cleaner element with compressed air.


NOTE

If driving under dusty conditions, replace the air cleaner element more frequently. Make sure that the air cleaner is in good condition at all times. The life of the engine depends largely on this component.



I815H1020001-01

- 3) After finishing the air cleaner element inspection, reinstall the removed parts.
- 4) Drain water from the air cleaner box by removing the drain plug (1).



I815H1020002-01

- 5) Reinstall the drain plug.

Exhaust Pipe Bolt and Muffler Bolt Inspection

B815H20206003

Tighten exhaust pipe bolts and muffler bolts

Initially at 1 000 km (600 miles, 2 months) and every 12 000 km (7 500 miles, 24 months) thereafter

Check the exhaust pipe bolts and muffler bolts to the specified torque.


Tightening torque

Exhaust pipe bolt (a): 23 N·m (2.3 kgf-m, 16.5 lb-ft)

Exhaust pipe mounting bolt (b): 23 N·m (2.3 kgf-m, 16.5 lb-ft)

Muffler connecting bolt (c): 23 N·m (2.3 kgf-m, 16.5 lb-ft)

Muffler mounting bolt (d): 25 N·m (2.5 kgf-m, 18.0 lb-ft)



I815H1020003-04

Valve Clearance Inspection and Adjustment

B815H20206004

Inspect valve clearance

Initially every 24 000 km (14 500 miles, 48 months)

Inspection


Valve clearance adjustment must be checked and adjusted, a) at the time of periodic inspection, b) when the valve mechanism is serviced, and c) when the camshafts are removed for servicing.

- 1) Remove the side cowlings. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".
- 3) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation in Section 1D (Page 1D-6)".
- 4) Remove the right side cowling bracket (1).




I815H1020004-01

- 5) Disconnect the right cooling fan lead wire coupler (2) and horn lead wire coupler (3).



I815H1020005-03

- 6) Remove the ignition coil/caps (4) and spark plugs. Refer to "Ignition Coil / Plug Cap and Spark Plug Removal and Installation in Section 1H (Page 1H-6)".
- 7) Remove the PAIR control solenoid valve (5) and PAIR hoses. Refer to "PAIR Control Solenoid Valve Removal and Installation in Section 1B (Page 1B-10)".
- 8) Disconnect the ISC valve coupler (6) and CMP sensor coupler (7).



I815H1020006-01

- 9) Loosen the throttle body clamp screws at the intake pipe side. Refer to "Throttle Body Removal and Installation in Section 1D (Page 1D-10)".
- 10) Move the throttle body assembly backward.



I815H1020008-01

- 11) Remove the cylinder head cover. Refer to "Engine Top Side Disassembly in Section 1D (Page 1D-27)".

NOTE


The valve clearance specification of intake and exhaust valve is different.

Valve clearance (When cold)

IN.: 0.08 – 0.18 mm (0.003 – 0.007 in)

EX.: 0.18 – 0.28 mm (0.007 – 0.011 in)


- 12) Remove the valve timing inspection cap (10) and starter clutch cover cap (11).



I815H1020009-01


NOTE

- The cam must be at positions, "A" or "B", when checking or adjusting the valve clearance. Clearance readings should not be taken with the cam in any other position than these two positions.
- The valve clearance should be taken when each cylinder is at Top Dead Center (TDC) of compression stroke.
- The clearance specification is for COLD state.
- To turn the crankshaft for valve clearance checking, be sure to use a wrench, and rotate in the normal running direction.




I823H1020007-01

- 13) Turn the crankshaft clockwise to bring the line "C" on the starter clutch to the slit "D" of valve timing inspection hole and also to bring the notches "E" on the left end of both camshafts (EX and IN) to the positions as shown in the figure.



I815H1020010-01




I815H1020011-01


- 14) Measure the clearance of valves "F". If the clearance is out of specification, adjust it to the specified range.

Special tool

TOOL (A): 09900-20803 (Thickness gauge)



I815H1020012-01




I815H1020013-01

- 15) Turn the crankshaft clockwise 360° (one full rotation) and position the notches “E” on the left end of both camshafts to the positions as shown in the figure.




I815H1020014-01




I815H1020015-01

- 16) Measure the clearances of the remaining valves “G” and adjust them if necessary.



I815H1020016-01



I815H1020017-01


Measuring position	Notch “E” position	
	Exhaust camshaft	Intake camshaft
“F”	← FWD 	← FWD 
“G”	← FWD 	← FWD 

I815H1020049-01

Adjustment


The clearance is adjusted by replacing the existing tappet shim with a thicker or thinner shim.

- 1) Remove the intake or exhaust camshaft. Refer to “Engine Top Side Disassembly in Section 1D (Page 1D-27)”.
- 2) Remove the tappet (1) and shim (2) by fingers or magnetic hand.



I815H1020018-01

- 3) Check the figures printed on the shim. These figures indicate the thickness of the shim, as illustrated.




I823H1020072-01

- 4) Select a replacement shim that will provide a clearance within the specified range. For the purpose of this adjustment, a total of 25 sizes of tappet shim are available ranging from 2.30 to 3.50 mm in steps of 0.05 mm.
- 5) Fit the selected shim (2) to the valve stem end, with numbers toward tappet. Be sure to check shim size with micrometer to ensure its size.

NOTE

- Be sure to apply engine oil to tappet shim top and bottom faces.
- When seating the tappet shim, be sure the figure printed surface faces the tappet.



I718H1020002-02

TAPPET SHIM SELECTION TABLE [INTAKE]
TAPPET SHIM NO. (12892-41C00-XXX)

MEASURED VALVE CLEARANCE (mm)		Option												TAPPET SHIM SET (12800-41810)												
		SUFFIX NO.	230	235	240	245	250	255	260	265	270	275	280	285	290	295	300	305	310	315	320	325	330	335	340	345
PRESENT SHIM SIZE (mm)		2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20	3.25	3.30	3.35	3.40	3.45	3.50
0.00 – 0.02																										
0.03 – 0.07																										
0.08 – 0.18																										
0.19 – 0.25																										
0.26 – 0.30																										
0.31 – 0.35																										
0.36 – 0.40																										
0.41 – 0.45																										
0.46 – 0.50																										
0.51 – 0.55																										
0.56 – 0.60																										
0.61 – 0.65																										
0.66 – 0.70																										
0.71 – 0.75																										
0.76 – 0.80																										
0.81 – 0.85																										
0.86 – 0.90																										
0.91 – 0.95																										
0.96 – 1.00																										
1.01 – 1.05																										
1.06 – 1.10																										
1.11 – 1.15																										
1.16 – 1.20																										
1.21 – 1.25																										
1.26 – 1.30																										
1.31 – 1.35																										
1.36 – 1.40																										

HOW TO USE THIS CHART:

I.

Measure valve clearance. “ENGINE IS COLD”

II.

Measure present shim size.

III.

Match clearance in vertical column with present shim size in horizontal column.

EXAMPLE

SPECIFIED CLEARANCE/NO ADJUSTMENT REQUIRED

(INTAKE SIDE)

HOW TO USE THIS CHART:

- Measure valve clearance. "ENGINE IS COLD"
- Measure present shim size.
- Match clearance in vertical column with present shim size in horizontal column.

EXAMPLE

Valve clearance is 0.23 mm
Present shim size 2.70 mm
Shim size to be used 2.80 mm

(EXHAUST SIDE)

TAPPET SHIM SELECTION TABLE [EXHAUST]
TAPPET SHIM NO. (12892-41C00-XXX)

MEASURED VALVE CLEARANCE (mm)		Option															TAPPET SHIM SET (12800-41810)										
		SUFFIX NO.	230	235	240	245	250	255	260	265	270	275	280	285	290	295	300	305	310	315	320	325	330	335	340	345	350
PRESENT SHIM SIZE (mm)		2.30	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20	3.25	3.30	3.35	3.40	3.45	3.50
0.00 – 0.02							2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20	3.25	3.30
0.03 – 0.07							2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20	3.25	3.30
0.08 – 0.12							2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20	3.25	3.30
0.13 – 0.17							2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20	3.25	3.30
0.18 – 0.28																											
0.29 – 0.35							2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20	3.25	3.30	3.35	3.40
0.36 – 0.40							2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20	3.25	3.30	3.35	3.40	3.50
0.41 – 0.45							2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20	3.25	3.30	3.35	3.40	3.45	3.50
0.46 – 0.50							2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20	3.25	3.30	3.35	3.40	3.45	3.50	3.50
0.51 – 0.55							2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20	3.25	3.30	3.35	3.40	3.45	3.50	3.50	3.50
0.56 – 0.60							2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20	3.25	3.30	3.35	3.40	3.45	3.50	3.50	3.50	3.50
0.61 – 0.65							2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20	3.25	3.30	3.35	3.40	3.45	3.50	3.50	3.50	3.50	3.50
0.66 – 0.70							2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20	3.25	3.30	3.35	3.40	3.45	3.50	3.50	3.50	3.50	3.50	3.50
0.71 – 0.75							2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20	3.25	3.30	3.35	3.40	3.45	3.50	3.50	3.50	3.50	3.50	3.50	3.50
0.76 – 0.80							2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20	3.25	3.30	3.35	3.40	3.45	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50
0.81 – 0.85							2.90	2.95	3.00	3.05	3.10	3.15	3.20	3.25	3.30	3.35	3.40	3.45	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50
0.86 – 0.90							2.95	3.00	3.05	3.10	3.15	3.20	3.25	3.30	3.35	3.40	3.45	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50
0.91 – 0.95							3.00	3.05	3.10	3.15	3.20	3.25	3.30	3.35	3.40	3.45	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50
0.96 – 1.00							3.05	3.10	3.15	3.20	3.25	3.30	3.35	3.40	3.45	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50
1.01 – 1.05							3.10	3.15	3.20	3.25	3.30	3.35	3.40	3.45	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50
1.06 – 1.10							3.15	3.20	3.25	3.30	3.35	3.40	3.45	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50
1.11 – 1.15							3.20	3.25	3.30	3.35	3.40	3.45	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50
1.16 – 1.20							3.25	3.30	3.35	3.40	3.45	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50
1.21 – 1.25							3.30	3.35	3.40	3.45	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50
1.26 – 1.30							3.35	3.40	3.45	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50
1.31 – 1.35							3.40	3.45	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50
1.36 – 1.40							3.45	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50
1.41 – 1.45							3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50
1.46 – 1.50							3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50	3.50

HOW TO USE THIS CHART:

I. Measure valve clearance. "ENGINE IS COLD"

II. Measure present shim size.

III. Match clearance in vertical column with present shim size in horizontal column.

EXAMPLE

HOW TO USE THIS CHART:

- I. Measure valve clearance. "ENGINE IS COLD"
- II. Measure present shim size.
- III. Match clearance in vertical column with present shim size in horizontal column.

EXAMPLE

Valve clearance is	0.38 mm
Present shim size	2.90 mm
Shim size to be used	3.05 mm

- 6) Install the camshafts and cam chain tension adjuster. Refer to "Engine Top Side Assembly in Section 1D (Page 1D-31)".
- 7) Rotate the engine so that the tappet is depressed fully. This will squeeze out oil trapped between the shim and the tappet that could cause an incorrect measurement, then check the clearance again to confirm that it is within the specified range.
- 8) After finishing the tappet clearance adjustment, reinstall the removed parts. Refer to "Engine Top Side Assembly in Section 1D (Page 1D-31)".

Spark Plug Replacement

B815H20206005

Replace spark plug

Every 12 000 km (7 500 miles, 24 months)

Refer to "Ignition Coil / Plug Cap and Spark Plug Removal and Installation in Section 1H (Page 1H-6)".

Spark Plug Inspection and Cleaning

B815H20206006

Inspect spark plug

Every 6 000 km (4 000 miles, 12 months)

Heat Range

- 1) Remove the spark plugs. Refer to "Ignition Coil / Plug Cap and Spark Plug Removal and Installation in Section 1H (Page 1H-6)".
- 2) Check spark plug heat range by observing electrode color. If the electrode of the spark plug is wet appearing or dark color, replace the spark plug with hotter type one. If it is white or glazed appearing, replace the spark plug with colder type one.

Heat range

	Hot type	Standard	Cold type
NGK	CR8EIA-9	CR9EIA-9	CR10EIA-9
ND	IU24D	IU27D	IU31D

- 3) After finishing the spark plug inspection, reinstall the removed parts.

Tightening torque

Spark plug: 11 N·m (1.1 kgf-m, 8.0 lb-ft)

Spark Plug Gap


- 1) Remove the spark plugs. Refer to "Ignition Coil / Plug Cap and Spark Plug Removal and Installation in Section 1H (Page 1H-6)".
- 2) Measure the spark plug gap using a wire gauge. If it is not within the specification, replace the spark plug.

⚠ CAUTION

- To prevent the damage of iridium center electrode, use a wire gauge to check the gap.
- Never adjust the spark plug gap.

Spark plug gap

0.8 – 0.9 mm (0.031 – 0.035 in)



I823H1020005-01

- 3) After finishing the spark plug inspection, reinstall the removed parts.

Tightening torque

Spark plug: 11 N·m (1.1 kgf-m, 8.0 lb-ft)

Electrodes Condition

- 1) Remove the spark plugs. Refer to "Ignition Coil / Plug Cap and Spark Plug Removal and Installation in Section 1H (Page 1H-6)".
- 2) Check the worn or burnt condition of the electrodes. If it is extremely worn or burnt, replace the spark plug. And also replace the spark plug if it has a broken insulator, or damaged thread.

⚠ CAUTION

Confirm the thread size and reach when replacing the plug. If the reach is too short, carbon will be deposited on the screw portion of the plug hole and engine damage may result.

- 3) After finishing the spark plug inspection, reinstall the removed parts.

Tightening torque

Spark plug: 11 N·m (1.1 kgf-m, 8.0 lb-ft)

Fuel Line Inspection

B815H20206007

Inspect fuel line


Every 6 000 km (4 000 miles, 12 months)

Inspect the fuel line in the following procedures:

- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".
- 2) Inspect the fuel feed hose (1) for damage and fuel leakage. If any defects are found, the fuel feed hose must be replaced.

▲ WARNING

When disconnecting the fuel feed hose from California model, drain fuel from the fuel tank first to prevent fuel leakage.



I815H1020019-01

- 3) After finishing the fuel feed hose inspection, reinstall the removed parts.

Engine Oil and Filter Replacement

B815H20206008

Replace engine oil

Initially at 1 000 km (600 miles, 2 months) and every 6 000 km (4 000 miles, 12 months) thereafter


Replace oil filter

Initially at 1 000 km (600 miles, 2 months) and every 18 000 km (11 000 miles, 36 months) thereafter


Oil should be changed while the engine is warm. Oil filter replacement at the above intervals, should be done together with the engine oil change.

Engine Oil Replacement

- 1) Place the motorcycle on the side-stand.
- 2) Place an oil pan below the engine, and drain engine oil by removing the oil drain plug (1) and filler cap (2).



I815H1020020-01



I815H1020021-01


- 3) Tighten the oil drain plug (1) to the specified torque.

⚠ CAUTION

Replace the gasket washer with a new one.


Tightening torque

Oil drain plug (a): 23 N·m (2.3 kgf-m, 16.5 lb-ft)



I815H1020022-01

- 4) Pour new oil through the oil filler. When performing an oil change (without oil filter replacement), the engine will hold about 3.1 L (3.3/2.7 US/Imp qt) of oil. Use of SF/SG or SH/SJ in API with MA in JASO.
- 5) Start up the engine and allow it to run for several minutes at idling speed.
- 6) Turn off the engine and wait about three minutes.
- 7) Hold the motorcycle vertically and check the oil level through the inspection window (3). If the oil level is below the "L" line, add oil to the "F" line. If the level is above the "F" line, drain the oil until the level reaches the "F" line.




I815H1020023-01

Oil Level Inspection

- 1) Place the motorcycle on the side-stand.
- 2) Start up the engine and allow it to run for several minutes at idle speed.

- 3) Turn off the engine and wait about three minutes.
- 4) Hold the motorcycle vertically and check the oil level through the inspection window (1). If the level is below "L" line, add oil to "F" line. If the level is above "L" line, drain oil to "F" line.




I815H1020024-01

Oil Filter Replacement

- 1) Drain engine oil as described in the engine oil replacement procedure.
- 2) Remove the right side cowling. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 3) Remove the oil filter (2) using the special tool.

Special tool

TOOL (A): 09915-40610 (Oil filter wrench)



I815H1020025-01

- 4) Apply engine oil lightly to the O-ring of new oil filter, before installation.

⚠ CAUTION

ONLY USE A GENUINE SUZUKI MOTORCYCLE OIL FILTER.

Other manufacturer's oil filters may differ in thread specifications (thread diameter and pitch), filtering performance and durability which may lead to engine damage or oil leaks. Also, do not use a genuine Suzuki automobile oil filter on this motorcycle.

- 5) Install the new oil filter. Turn it by hand until you feel that the oil filter O-ring contacts the oil filter mounting surface. Then, tighten the oil filter two full turns (or to specified torque) using the special tool.

NOTE


To properly tighten the oil filter, use the special tool. Never tighten the oil filter by hand only.

Special tool

 (A): 09915-40610 (Oil filter wrench)

Tightening torque

Oil filter (a): 20 N·m (2.0 kgf-m, 14.5 lb-ft)



I823H1020041-01

- 6) Add new engine oil and check the oil level is as described in the engine oil replacement procedure.

Necessary amount of engine oil

Oil change: 3 100 ml (3.3/2.7 US/lmp qt)

Oil and filter change: 3 300 ml (3.5/2.9 US/lmp qt)

Engine overhaul: 4 000 ml (4.2/3.5 US/lmp qt)

Throttle Cable Play Inspection and Adjustment

B815H20206009


Inspect throttle cable play

Initially at 1 000 km (600 miles, 2 months) and every 6 000 km (4 000 miles, 12 months) thereafter

Inspect and adjust the throttle cable play "a" as follows:


Throttle cable play "a"

2.0 – 4.0 mm (0.08 – 0.16 in)



I815H1020026-01

- 1) Loosen the lock-nut (1) of the throttle pulling cable (2).
- 2) Turn the adjuster (3) in or out until the throttle cable play "a" (at the throttle grip) is between 2 – 4 mm (0.08 – 0.16 in).
- 3) Tighten the lock-nut (1) while holding the adjuster (3).



I815H1020027-01

⚠ WARNING

After the adjustment is completed, check that handlebar movement does not raise the engine idle speed and that the throttle grip returns smoothly and automatically.

Throttle Valve Synchronization

B815H20206010

Inspect throttle valve synchronization

Initially at 1 000 km (600 miles, 2 months) (E-33 only) and every 12 000 km (7 500 miles, 24 months)

Inspect the throttle valve synchronization periodically. Refer to "Throttle Valve Synchronization in Section 1D (Page 1D-16)".

Evaporative Emission Control System Inspection (E-33 only)

B815H20206011

Inspect evaporative emission control system Every 12 000 km (7 500 miles, 24 months)

Inspect the evaporative emission control system periodically (E-33 only).

PAIR System Inspection

B815H20206012

Inspect PAIR system Every 12 000 km (7 500 miles, 24 months)

Inspect the PAIR (air supply) system periodically. Refer to "PAIR System Inspection in Section 1B (Page 1B-11)".

Cooling System Inspection


B815H20206013

Inspect cooling system Every 6 000 km (4 000 miles, 6 months)


Replace engine coolant Every 2 years

Engine Coolant Level Inspection

- 1) Hold the motorcycle vertically.
- 2) Check the engine coolant level by observing the "F" and "L" lines on the engine coolant reservoir tank. If the level is below the "L" line, add engine coolant to the "F" line from the engine coolant reservoir tank filler (1) behind the right side cowling. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".



I815H1020028-01



I815H1020029-01


Engine Coolant Change

Refer to "Engine Coolant Description in Section 1F (Page 1F-1)".

⚠ WARNING


Do not open the radiator cap when the engine is hot, as you may be injured by escaping hot liquid or vapor. Engine coolant may be harmful if swallowed or if it comes in contact with skin or eyes. If engine coolant gets into the eyes or in contact with the skin, flush thoroughly with plenty of water. If swallowed, induce vomiting and call physician immediately.

- 1) Remove the side cowling. Refer to "Cooling Circuit Inspection in Section 1F (Page 1F-4)".
- 2) Remove the radiator cap (1).



I815H1020030-01

- 3) Drain engine coolant by disconnecting the water pump inlet hose (2).



I815H1020031-01


- 4) Flush the radiator with fresh water if necessary.
- 5) Reconnect the water pump inlet hose.
- 6) Pour the specified engine coolant up to the radiator inlet.

Engine coolant capacity (excluding reservoir) 2 700 ml (2.9/2.4 US/Imp qt)

- 7) Bleed air from the cooling circuit.
- 8) After changing engine coolant, reinstall the removed parts.

Air Bleeding From the Cooling Circuit

- 1) Remove the right cowling. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.
- 2) Add engine coolant up to the radiator inlet.
- 3) Support the motorcycle upright.
- 4) Slowly swing the motorcycle, right and left, to bleed the air trapped in the cooling circuit.
- 5) Add engine coolant up to the radiator inlet.
- 6) Start up the engine and bleed air from the radiator inlet completely.
- 7) Add engine coolant up to the radiator inlet.
- 8) Repeat the procedures 5) to 6) until no air bleeds from the radiator inlet.
- 9) Lift and support the fuel tank. Refer to “Fuel Tank Removal and Installation in Section 1G (Page 1G-9)”.
- 10) Loosen the air bleeder bolt (1) and check the engine coolant flows out.



I815H1020032-01

- 11) Tighten the air bleeder bolt securely.
- 12) Close the radiator cap securely.
- 13) After warming up and cooling down the engine several times, add the engine coolant up to the full level of the reservoir.

⚠ CAUTION

Make sure that the radiator is filled with engine coolant up to the reservoir full level.

- 14) Reinstall the removed parts.

Radiator Hose Inspection

Check the radiator hoses for crack, damage or engine coolant leakage. Refer to “Water Hose Inspection in Section 1F (Page 1F-7)”.

Clutch System Inspection

B815H20206014

Inspect clutch hose and clutch fluid

Every 6 000 km (4 000 miles, 12 months)


⚠ WARNING

The clutch system of this motorcycle is filled with a glycol-based brake fluid. Do not use or mix different types of fluid such as silicone-based or petroleum-based. Do not use any brake fluid taken from old, used or unsealed containers. Never reuse brake fluid left over from the last servicing or stored for a long period of time. Check the clutch hose and hose joints for cracks and fluid leakage.

Clutch Fluid Level Check

- 1) Keep the motorcycle upright and place the handlebars straight.
- 2) Check the clutch fluid level by observing the lower limit line on the clutch fluid reservoir. When the clutch fluid level is below the lower limit line, replenish with clutch fluid that meets the following specification.


BF: Brake fluid (DOT 4)



I815H1020033-01

Clutch Hose Inspection

- 1) Remove the left side cowling. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Lift and support the fuel tank. Refer to "Air Cleaner Box Removal and Installation in Section 1D (Page 1D-6)".
- 3) Inspect the clutch hose for crack, damage or clutch fluid leakage. If it is damaged, replace the clutch hose with a new one.



I815H1020034-01



I815H1020051-03

- 4) After finishing the clutch hose inspection, reinstall the removed parts.

Clutch Hose Replacement

B815H20206015

Replace clutch hose

Every 4 years

Refer to "Clutch Hose Removal and Installation in Section 5C (Page 5C-5)".

Clutch Fluid Replacement

B815H20206016

Replace clutch fluid

Every 2 years

Refer to "Clutch Fluid Replacement in Section 5C (Page 5C-4)".

Air Bleeding from Clutch Fluid Circuit

Refer to "Air Bleeding from Clutch Fluid Circuit in Section 5C (Page 5C-4)".

Drive Chain Inspection and Adjustment

B815H20206017

Inspect drive chain


Initially at 1 000 km (600 miles, 2 months) and every 6 000 km (4 000 miles, 12 months) thereafter

Drive Chain Visual Check

- 1) With the transmission in neutral, support the motorcycle using a jack and turn the rear wheel slowly by hand.
- 2) Remove the engine sprocket cover. Refer to "Engine Sprocket Removal and Installation in Section 3A (Page 3A-2)".
- 3) Visually check the drive chain for the possible defects listed as follows. If any defects are found, the drive chain must be replaced. Refer to "Drive Chain Replacement in Section 3A (Page 3A-7)".
 - Loose pins
 - Damaged rollers
 - Dry or rusted links
 - Kinked or binding links
 - Excessive wear
 - Improper chain adjustment
 - Missing O-ring seals

NOTE


When replacing the drive chain, replace the drive chain and sprockets as a set.



I649G1020032-02

1. O-ring seal	2. Grease
----------------	-----------

- 4) Inspect the sprocket cover protector (3). If any defects are found, replace the protector.




I815H1020035-01

- 5) Install the removed parts.

Drive Chain Length Inspection

- 1) Loosen the axle nut (1).
- 2) Loosen the chain adjuster lock-nuts (2).
- 3) Give tension to the drive chain fully by turning both chain adjuster bolts (3).




I815H1020036-01

- 4) Count out 21 pins (20 pitches) on the chain and measure the distance between the two points. If the distance exceeds the service limit, the chain must be replaced.

Drive chain 20-pitch length

Service limit: 319.4 mm (12.57 in)



I649G1020034-02

- 5) After finishing the drive chain length inspection, adjust the drive chain slack.

Drive Chain Slack Adjustment

- 1) Support the motorcycle with a jack.
- 2) Loosen the axle nut (1).
- 3) Loosen the chain adjuster lock-nuts (2).


- 4) Loosen or tighten both chain adjuster bolts (3) until there is 20 – 30 mm (0.8 – 1.2 in) of slack "a" at the middle of the chain between the engine and rear sprockets as shown in the figure.

⚠ CAUTION


The reference marks "A" on both sides of the swingarm and the edge of each chain adjuster must be aligned to ensure that the front and rear wheels are correctly aligned.

Drive chain slack "a"

Standard: 20 – 30 mm (0.8 – 1.2 in)



I815H1020037-01



I649G1020036-02

- 5) After adjusting the drive chain, tighten the axle nut (1) to the specified torque.

Tightening torque

Rear axle nut: 100 N·m (10.0 kgf-m, 72.5 lb-ft)

- 6) Tighten both chain adjuster lock-nuts (2) securely.
- 7) Recheck the drive chain slack after tightening the axle nut.

Drive Chain Cleaning and Lubricating

B815H20206018

Clean and lubricate drive chain

Every 1 000 km (600 miles)

Clean and lubricate the drive chain in the following procedures:

- 1) Clean the drive chain with kerosine. If the drive chain tends to rust quickly, the intervals must be shortened.

⚠ CAUTION


Do not use trichloroethylene, gasoline or any similar solvent.

These fluids have too great a dissolving power for this chain and they can damage the O-rings. Use only kerosine to clean the drive chain.

- 2) After cleaning and drying the chain, oil it with a heavyweight motor oil.

⚠ CAUTION

- **Do not use any oil sold commercially as "drive chain oil". Such oil can damage the O-rings.**
- **The standard drive chain is a RK GB50GSVZ4. SUZUKI recommends to use this standard drive chain as a replacement.**



I815H1020038-01

Brake System Inspection

B815H20206019

Inspect brake system

Initially at 1 000 km (600 miles, 2 months) and every 6 000 km (4 000 miles, 12 months) thereafter

Inspect brake hose and brake fluid

Every 6 000 km (4 000 miles, 12 months)


⚠ WARNING

- **The brake system of this motorcycle is filled with a glycol-based brake fluid. Do not use or mix different types of fluid such as silicone-based and petroleum-based fluids. Do not use any brake fluid taken from old, used or unsealed containers. Never reuse brake fluid left over from the last servicing or stored for a long period of time.**
- **Brake fluid, if it leaks, will interfere with safe running and immediately discolor painted surfaces. Check the brake hoses and hose joints for cracks and oil leakage before riding.**


Brake Fluid Level Check

- 1) Keep the motorcycle upright and place the handlebars straight.
- 2) Check the brake fluid level by observing the lower limit lines on the front and rear brake fluid reservoirs. When the brake fluid level is below the lower limit line, replenish with brake fluid that meets the following specification.

BF: Brake fluid (DOT 4)



I815H1020039-01





I815H1020040-01

Brake Pads Check



The extent of brake pad wear can be checked by observing the grooved limit line "A" on the pad. When the wear exceeds the grooved limit line, replace the pads with new ones. Refer to "Front Brake Pad Replacement in Section 4B (Page 4B-2)" and "Rear Brake Pad Replacement in Section 4C (Page 4C-2)".

⚠ CAUTION

Replace the brake pad as a set, otherwise braking performance will be adversely affected.



I815H1420002-01



I815H1430002-02

Front and Rear Brake Hose Inspection

Inspect the brake hoses and hose joints for crack, damage or brake oil leakage. If any defects are found, replace the brake hose with a new one. Refer to "Front Brake Hose Removal and Installation in Section 4A (Page 4A-8)" and "Rear Brake Hose Removal and Installation in Section 4A (Page 4A-8)".



I815H1020043-01



I815H1020044-01

Brake Pedal Height Inspection and Adjustment

- 1) Inspect the brake pedal height "a" between the pedal top face and footrest.
Adjust the brake pedal height if necessary.


Brake pedal height "a"

Standard: 50 – 60 mm (2.0 – 2.4 in)

- 2) Loosen the lock-nut (1).
- 3) Turn the push rod (2) until the brake pedal becomes 50 – 60 mm (2.0 – 2.4 in) "a" below the top of the footrest.
- 4) Tighten the lock-nut (1) securely.

Tightening torque

Rear master cylinder rod lock-nut (a): 18 N·m (1.8 kgf-m, 13.0 lb-ft)



I815H1020045-02

Brake Hose Replacement

Replace brake hose

Every 4 years

Refer to "Front Brake Hose Removal and Installation in Section 4A (Page 4A-8)" and "Rear Brake Hose Removal and Installation in Section 4A (Page 4A-8)".

Brake Fluid Replacement

Replace brake fluid

Every 2 years

Refer to "Brake Fluid Replacement in Section 4A (Page 4A-6)".

Air Bleeding from Brake Fluid Circuit

Refer to "Air Bleeding from Brake Fluid Circuit in Section 4A (Page 4A-4)".

Rear Brake Light Switch Adjustment

Refer to "Rear Brake Light Switch Inspection and Adjustment in Section 4A (Page 4A-4)".

Tire Inspection

B815H20206020

Inspect tire

Every 6 000 km (4 000 miles, 12 months)

Tire Tread Condition

Operating the motorcycle with excessively worn tires will decrease riding stability and consequently invite a dangerous situation. It is highly recommended to replace a tire when the remaining depth of tire tread reaches the following specification.


Special tool

 : 09900-20805 (Tire depth gauge)

Tire tread depth (Service limit)

Front: 1.6 mm (0.06 in)

Rear: 2.0 mm (0.08 in)




I310G1020068-02

Tire Pressure

If the tire pressure is too high or too low, steering will be adversely affected and tire wear increased. Therefore, maintain the correct tire pressure for good roadability or shorter tire life will result. Cold inflation tire pressure is as follows.

Cold inflation tire pressure

	Solo riding			Dual riding		
	kPa	kgf/cm ²	psi	kPa	kgf/cm ²	psi
Front	290	2.90	42	290	2.90	42
Rear	290	2.90	42	290	2.90	42



I310G1020069-02

CAUTION

The standard tire fitted on this motorcycle is 120/70 ZR17 M/C (58W) for front and 190/50 ZR17 M/C (73W) for rear. The use of tires other than those specified may cause instability. It is highly recommended to use the specified tires.

Tire type

BRIDGESTONE

- Front: BT015F RADIAL M
- Rear: BT015R RADIAL M

Steering System Inspection

B815H20206021

Inspect steering system

Initially at 1 000 km (600 miles, 2 months) and every 12 000 km (7 500 miles, 24 months) thereafter

Steering should be adjusted properly for smooth turning of handlebars and safe running. Overtighten steering prevents smooth turning of the handlebars and too loose steering will cause poor stability.

- 1) Check that there is no play in the front fork.
- 2) Support the motorcycle so that the front wheel is off the ground, with the wheel facing straight ahead, grasp the lower fork tubes near the axle and pull forward.

If play is found, readjust the steering. Refer to "Steering Tension Adjustment in Section 6B (Page 6B-12)".



I815H1020046-01

Front Fork Inspection

B815H20206022

Inspect front fork

Every 12 000 km (7 500 miles, 24 months)

Inspect the front forks for oil leakage, scoring or scratches on the outer surface of the inner tubes. Replace any defective parts, if necessary. Refer to "Front Fork Disassembly and Assembly in Section 2B (Page 2B-6)".



I815H1020047-01

Rear Suspension Inspection

B815H20206023

Inspect rear suspension

Every 12 000 km (7 500 miles, 24 months)

Inspect the rear shock absorber for oil leakage and check that there is no play in the swingarm. Replace any defective parts, if necessary. Refer to "Rear Shock Absorber / Cushion Lever Removal and Installation in Section 2C (Page 2C-3)", "Cushion Lever Removal and Installation in Section 2C (Page 2C-6)" and "Swingarm / Cushion Rod Removal and Installation in Section 2C (Page 2C-8)".



I815H1020048-01



I815H1020052-02


Chassis Bolt and Nut Inspection

B815H20206024

Tighten chassis bolt and nut


Initially at 1 000 km (600 miles, 2 months) and every 6 000 km (4 000 miles, 12 months) thereafter

Check that all chassis bolts and nuts are tightened to their specified torque.




I815H1020053-01

- | | | |
|---|-----|---|
| 1 | (a) | Steering stem head nut 90 N·m (9.0 kgf-m, 65.0 lb-ft) |
| 2 | (b) | Handlebar holder mounting bolt 35 N·m (3.5 kgf-m, 25.5 lb-ft) |




I815H1020054-01

- | | | |
|---|-----|--|
| 3 | (c) | Front fork cap bolt 23 N·m (2.3 kgf-m, 16.5 lb-ft) |
| 4 | (c) | Front fork upper clamp bolt 23 N·m (2.3 kgf-m, 16.5 lb-ft) |
| 5 | (c) | Front fork lower clamp bolt 23 N·m (2.3 kgf-m, 16.5 lb-ft) |




I815H1020055-02

- | | | |
|---|-----|---|
| 6 | (d) | Front brake master cylinder mounting bolt 10 N·m (1.0 kgf-m, 7.0 lb-ft) |
| 7 | (c) | Union bolt (Front brake) 23 N·m (2.3 kgf-m, 16.5 lb-ft) |




I815H1020056-01

- | | | |
|---|-----|--|
| 8 | (d) | Clutch master cylinder mounting bolt 10 N·m (1.0 kgf-m, 7.0 lb-ft) |
| 9 | (c) | Union bolt (Clutch) 23 N·m (2.3 kgf-m, 16.5 lb-ft) |




I815H1020057-01

- | | | |
|----|-----|---|
| 10 | (e) | Rear shock absorber mounting nut (Upper) 50 N·m (5.0 kgf-m, 36.0 lb-ft) |
|----|-----|---|




I815H1020058-01

- | | | |
|----|-----|---|
| 11 | (e) | Rear shock absorber mounting nut (Lower) 50 N·m (5.0 kgf-m, 36.0 lb-ft) |
| 12 | (f) | Cushion lever mounting nut 78 N·m (7.8 kgf-m, 56.5 lb-ft) |
| 13 | (f) | Cushion rod mounting nut 78 N·m (7.8 kgf-m, 56.5 lb-ft) |




I815H1020059-02

14		(c)	Union bolt (Front brake) 23 N-m (2.3 kgf-m, 16.5 lb-ft)
15		(g)	Front axle bolt 100 N-m (10.0 kgf-m, 72.5 lb-ft)
16		(c)	Brake disc bolt (Front) 23 N-m (2.3 kgf-m, 16.5 lb-ft)
17		(c)	Front axle pinch bolt 23 N-m (2.3 kgf-m, 16.5 lb-ft)
18		(h)	Front brake caliper mounting bolt 39 N-m (3.9 kgf-m, 28.0 lb-ft)
19		(i)	Air bleeder valve (Front brake) 7.5 N-m (0.75 kgf-m, 5.5 lb-ft)




I815H1020060-01

20		(c)	Union bolt (Rear brake) 23 N-m (2.3 kgf-m, 16.5 lb-ft)
21		(i)	Air bleeder valve (Rear brake) 7.5 N-m (0.75 kgf-m, 5.5 lb-ft)
22		(j)	Rear brake caliper mounting bolt 17 N-m (1.7 kgf-m, 12.5 lb-ft)
23		(k)	Rear brake caliper sliding pin 33 N-m (3.3 kgf-m, 24.0 lb-ft)




I815H1020062-02

24		(b)	Brake disc bolt (Rear) 35 N-m (3.5 kgf-m, 25.5 lb-ft)
25		(g)	Rear axle nut 100 N-m (10.0 kgf-m, 72.5 lb-ft)




I815H1020061-03

26		(c)	Union bolt (Rear brake) 23 N-m (2.3 kgf-m, 16.5 lb-ft)
27		(c)	Front footrest bolt 23 N-m (2.3 kgf-m, 16.5 lb-ft)
28		(d)	Rear brake master cylinder mounting bolt 10 N-m (1.0 kgf-m, 7.0 lb-ft)
29		(l)	Rear brake master cylinder rod lock-nut 18 N-m (1.8 kgf-m, 13.0 lb-ft)




I815H1020063-01

30		(c)	Union bolt (clutch) 23 N-m (2.3 kgf-m, 16.5 lb-ft)
31		(m)	Air bleeder valve (clutch) 6 N-m (0.6 kgf-m, 4.5 lb-ft)



I815H1020064-04

32		(n)	Swingarm pivot shaft 15 N-m (1.5 kgf-m, 11.0 lb-ft)
33		(a)	Swingarm pivot lock-nut 90 N-m (9.0 kgf-m, 65.0 lb-ft)
34		(g)	Swingarm pivot nut 100 N-m (10.0 kgf-m, 72.5 lb-ft)



I815H1020065-02

35  Rear sprocket nut 60 N·m (6.0 kgf-m, 43.5 lb-ft)

Compression Pressure Check

B815H20206025

Refer to “Compression Pressure Check in Section 1D (Page 1D-3)”.

Oil Pressure Check

B815H20206026

Refer to “Oil Pressure Check in Section 1E (Page 1E-5)”.

SDS Check

B815H20206027

Refer to “SDS Check in Section 1A (Page 1A-17)”.

Specifications

Tightening Torque Specifications

B815H20207001

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
Exhaust pipe bolt	23	2.3	16.5	☞ (Page 0B-3)
Exhaust pipe mounting bolt	23	2.3	16.5	☞ (Page 0B-3)
Muffler connecting bolt	23	2.3	16.5	☞ (Page 0B-3)
Muffler mounting bolt	25	2.5	18.0	☞ (Page 0B-3)
Spark plug	11	1.1	8.0	☞ (Page 0B-9) / ☞ (Page 0B-9) / ☞ (Page 0B-9)
Oil drain plug	23	2.3	16.5	☞ (Page 0B-11)
Oil filter	20	2.0	14.5	☞ (Page 0B-12)
Rear axle nut	100	10.0	72.5	☞ (Page 0B-16)
Rear master cylinder rod lock-nut	18	1.8	13.0	☞ (Page 0B-18)

NOTE

The specified tightening torque is also described in the following.
“Chassis Bolt and Nut Inspection (Page 0B-21)”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Tightening Torque List in Section 0C (Page 0C-9)”.

Special Tools and Equipment

Recommended Service Material

B815H20208001




Material	SUZUKI recommended product or Specification		Note
Brake fluid	DOT 4	—	(Page 0B-14) / (Page 0B-17)

NOTE

Required service material is also described in the following.
“Lubrication Points (Page 0B-2)”

Special Tool

B815H20208002

09900–20803 Thickness gauge (Page 0B-5) 	09900–20805 Tire depth gauge (Page 0B-19) 
09915–40610 Oil filter wrench (Page 0B-11) / (Page 0B-12) 	

Service Data

Specifications

Service Data

B815H20307001

Valve + Guide

Unit: mm (in)

Item	Standard		Limit
Valve diam.	IN.	33 (1.30)	—
	EX.	27.5 (1.08)	—
Valve clearance (when cold)	IN.	0.08 – 0.18 (0.003 – 0.007)	—
	EX.	0.18 – 0.28 (0.007 – 0.011)	—
Valve guide to valve stem clearance	IN.	0.010 – 0.037 (0.0004 – 0.0015)	—
	EX.	0.030 – 0.057 (0.0012 – 0.0022)	—
Valve guide I.D.	IN. & EX.	5.000 – 5.012 (0.1969 – 0.1973)	—
Valve stem O.D.	IN.	4.975 – 4.990 (0.1959 – 0.1965)	—
	EX.	4.955 – 4.970 (0.1951 – 0.1957)	—
Valve stem deflection	IN. & EX.	—	0.25 (0.010)
Valve stem runout	IN. & EX.	—	0.05 (0.002)
Valve seat width	IN. & EX.	0.9 – 1.1 (0.035 – 0.043)	—
Valve head radial runout	IN. & EX.	—	0.03 (0.001)
Valve spring free length	IN. & EX.	—	42.3 (1.67)
Valve spring tension	IN. & EX.	Approx. 137 N (14.0 kgf, 30.8 lbs) at length 36.6 mm (1.44 in)	—

Camshaft + Cylinder Head

Unit: mm (in)

Item	Standard		Limit
Cam height	IN.	36.98 – 37.02 (1.456 – 1.457)	36.68 (1.444)
	EX.	36.58 – 36.62 (1.440 – 1.442)	36.28 (1.428)
Camshaft journal oil clearance	IN. & EX.	0.032 – 0.066 (0.0013 – 0.0026)	0.150 (0.0059)
Camshaft journal holder I.D.	IN. & EX.	24.012 – 24.025 (0.9454 – 0.9459)	—
Camshaft journal O.D.	IN. & EX.	23.959 – 23.980 (0.9433 – 0.9441)	—
Camshaft runout	—		0.10 (0.004)
Cam chain pin (at arrow “3”)	15th pin		—
Cylinder head distortion	—		0.20 (0.008)

0C-2 Service Data:**Cylinder + Piston + Piston Ring**

Unit: mm (in)

Item	Standard			Limit
Compression pressure	1 400 – 1 800 kPa (14 – 18 kgf/cm ² , 199 – 256 psi)			1 000 kPa (10 kgf/cm ² , 142 psi)
Compression pressure difference	—			200 kPa (2 kgf/cm ² , 28 psi)
Piston-to-cylinder clearance	0.035 – 0.045 (0.0014 – 0.0018)			0.120 (0.0047)
Cylinder bore	81.000 – 81.015 (3.1890 – 3.1896)			No nicks or Scratches
Piston diam.	80.960 – 80.975 (3.1874 – 3.1880) Measure 15 mm (0.6 in) from the skirt end.			80.880 (3.1842)
Cylinder distortion	—			0.20 (0.008)
Piston ring free end gap	1st	—	Approx. 6.5 (0.26)	5.2 (0.20)
	2nd	2T	Approx. 9.0 (0.35)	7.2 (0.28)
Piston ring end gap	1st	—	0.06 – 0.18 (0.002 – 0.007)	0.50 (0.020)
	2nd	2T		
Piston ring-to-groove clearance	1st	—		0.180 (0.0071)
	2nd	—		0.150 (0.0059)
Piston ring groove width	1st	0.83 – 0.85 (0.0327 – 0.0335)		—
		1.30 – 1.32 (0.0512 – 0.0520)		
	2nd	1.01 – 1.03 (0.0398 – 0.0406)		—
	Oil	2.01 – 2.03 (0.0791 – 0.0799)		—
Piston ring thickness	1st	0.76 – 0.81 (0.0299 – 0.0319)		—
		1.08 – 1.10 (0.0425 – 0.0433)		
	2nd	0.97 – 0.99 (0.0382 – 0.0390)		—
Piston pin bore	18.002 – 18.008 (0.7087 – 0.7090)			18.030 (0.7098)
Piston pin O.D.	17.996 – 18.000 (0.7085 – 0.7087)			17.980 (0.7079)

Conrod + Crankshaft

Unit: mm (in)

Item	Standard		Limit
Conrod small end I.D.	18.010 – 18.018 (0.7091 – 0.7094)		18.040 (0.7102)
Conrod big end side clearance	0.10 – 0.20 (0.004 – 0.008)		0.3 (0.012)
Conrod big end width	20.95 – 21.00 (0.825 – 0.827)		—
Crank pin width	21.10 – 21.15 (0.831 – 0.833)		—
Conrod big end oil clearance	0.032 – 0.056 (0.0013 – 0.0022)		0.080 (0.0031)
Crank pin O.D.	37.976 – 38.000 (1.4951 – 1.4960)		—
Crankshaft journal oil clearance	0.010 – 0.028 (0.0004 – 0.0011)		0.080 (0.0031)
Crankshaft journal O.D.	39.982 – 40.000 (1.5741 – 1.5748)		—
Crankshaft thrust bearing thickness	Right side	2.425 – 2.450 (0.0955 – 0.0965)	—
	Left side	2.350 – 2.500 (0.0925 – 0.0984)	—
Crankshaft thrust clearance	0.055 – 0.110 (0.0022 – 0.0043)		—
Crankshaft runout	—		0.05 (0.002)

Oil Pump

Item	Standard	Limit
Oil pressure (at 60 °C, 140 °F)	200 – 500 kPa (2.0 – 5.0 kgf/cm ² , 28.4 – 71.1 psi) at 3 000 r/min	—

Clutch

Unit: mm (in)

Item	Standard		Limit
Clutch drive plate thickness	No. 1	2.92 – 3.08 (0.115 – 0.121)	2.62 (0.103)
	No. 2 & 3	3.72 – 3.88 (0.146 – 0.153)	3.42 (0.135)
Clutch drive plate claw width	No. 1	13.85 – 13.96 (0.542 – 0.550)	13.05 (0.514)
	No. 2 & 3	13.90 – 14.00 (0.547 – 0.551)	13.10 (0.516)
Clutch driven plate distortion	—		0.10 (0.004)
Clutch spring free length	37.13 (1.462)		35.3 (1.39)
Clutch master cylinder bore	14.000 – 14.043 (0.5512 – 0.5529)		—
Clutch master cylinder piston diam.	13.957 – 13.984 (0.5495 – 0.5506)		—
Clutch release cylinder bore	33.600 – 33.662 (1.3228 – 1.3253)		—
Clutch release cylinder piston diam.	33.550 – 33.575 (1.3209 – 1.3218)		—
Clutch fluid type	Brake fluid DOT 4		—

Drive Train

Unit: mm (in) Except ratio

Item		Standard	Limit
Primary reduction ratio		1.596 (83/52)	—
Final reduction ratio		2.388 (43/18)	—
Gear ratios	Low	2.615 (34/13)	—
	2nd	1.937 (31/16)	—
	3rd	1.526 (29/19)	—
	4th	1.285 (27/21)	—
	5th	1.136 (25/22)	—
	Top	1.043 (24/23)	—
Shift fork to groove clearance		0.1 – 0.3 (0.004 – 0.012)	0.5 (0.02)
Shift fork groove width		5.0 – 5.1 (0.197 – 0.201)	—
Shift fork thickness		4.8 – 4.9 (0.189 – 0.193)	—
Drive chain	Type	RK GB50GSVZ4	—
	Links	114 links	—
	20-pitch length	—	319.4 (12.57)
Drive chain slack (on side-stand)		20 – 30 (0.8 – 1.2)	—
Gearshift lever height		50 – 60 (2.0 – 2.4)	—

0C-4 Service Data:**Thermostat + Radiator + Fan + Coolant**

Item	Standard/Specification		Note
Thermostat valve opening temperature	Approx. 82 °C (180 °F)		—
Thermostat valve lift	Over 8 mm (0.31 in) and at 95 °C (203 °F)		—
ECT sensor resistance	20 °C (68 °F)	Approx. 2.45 kΩ	—
	50 °C (122 °F)	Approx. 0.811 kΩ	—
	80 °C (176 °F)	Approx. 0.318 kΩ	—
	110 °C (230 °F)	Approx. 0.142 kΩ	—
Radiator cap valve opening pressure	93 – 123 kPa (0.93 – 1.23 kgf/cm ² , 13.2 – 17.5 psi)		—
Cooling fan operating temperature	OFF → ON	Approx. 105 °C (221 °F)	—
	ON → OFF	Approx. 100 °C (212 °F)	—
Engine coolant type	Use an anti-freeze/coolant compatible with aluminum radiator, mixed with distilled water only, at the ratio of 50:50.		—
Engine coolant including reserve	Reserve tank side	Approx. 250 ml (0.3/0.2 US/lmp qt)	—
	Engine side	Approx. 2 700 ml (2.9/2.4 US/lmp qt)	—

Injector + Fuel Pump + Fuel Pressure Regulator

Item	Specification	Note
Injector resistance	11 – 13 Ω at 20 °C (68 °F)	
Fuel pump discharge amount	220 ml (7.4/7.7 US/lmp oz) and more/10 sec.	
Fuel pressure regulator operating set pressure	Approx. 300 kPa (3.0 kgf/cm ² , 43 psi)	

FI Sensors

Item	Standard/Specification		Note
CKP sensor resistance	180 – 280 Ω		
CKP sensor peak voltage	3.0 V and more		When cranking
IAP sensor input voltage	4.5 – 5.5 V		
IAP sensor output voltage	Approx. 2.7 V at idle speed		
TP sensor input voltage	4.5 – 5.5 V		
TP sensor output voltage	Closed	Approx. 1.1 V	
	Opened	Approx. 4.3 V	
ECT sensor input voltage	4.5 – 5.5 V		
ECT sensor output voltage	0.15 – 4.85 V		
ECT sensor resistance	Approx. 2.45 k Ω at 20 °C (68 °F)		
IAT sensor input voltage	4.5 – 5.5 V		
IAT sensor output voltage	0.15 – 4.85 V		
IAT sensor resistance	Approx. 2.58 k Ω at 20 °C (68 °F)		
AP sensor input voltage	4.5 – 5.5 V		
AP sensor output voltage	Approx. 3.6 V at 100 kPa (760 mmHg)		
TO sensor resistance	16.5 – 22.3 k Ω		
TO sensor voltage	Normal	0.4 – 1.4 V	
	Leaning	3.7 – 4.4 V	When leaning 65°
GP switch voltage	0.6 V and more		From 1st to Top
Injector voltage	Battery voltage		
Ignition coil primary peak voltage	80 V and more		When cranking
HO2 sensor output voltage	0.3 V and less at idle speed		
	0.6 V and more at 3 000 r/min		
HO2 sensor heater resistance	Approx. 8 Ω at 23 °C (73 °F)		
PAIR control solenoid valve resistance	20 – 24 Ω at 20 – 30 °C (68 – 86 °F)		
STP sensor input voltage	4.5 – 5.5 V		
STP sensor output voltage	Closed	Approx. 0.5 V	
	Opened	Approx. 3.9 V	
STVA resistance	Approx. 6.5 Ω		
EVAP system purge control solenoid valve resistance	Approx. 32 Ω at 20 °C (68 °F)		E-33 only
ISC valve resistance	Approx. 80 Ω at 20 °C (68 °F)		

0C-6 Service Data:**Throttle Body**

Item	Specification
Bore size	44 mm (1.73 in)
I.D. No.	15H1 (For E-33), 15H0 (For the others)
Idle r/min	1 150 ± 100 r/min
Throttle cable play	2.0 – 4.0 mm (0.08 – 0.16 in)

Electrical

Unit: mm

Item			Specification	Note
Firing order			1 · 2 · 4 · 3	
Spark plug			Type	NGK: CR9EIA-9 DENSO: IU27D
			Gap	0.8 – 0.9 (0.031 – 0.035)
Spark performance			Over 8 (0.3) at 1 atm.	
CKP sensor resistance			180 – 280 Ω	
CKP sensor peak voltage			3.0 V and more	When cranking
Ignition coil resistance			Primary	1.0 – 1.9 Ω
			Secondary	10.0 – 16.2 kΩ
Ignition coil primary peak voltage			80 V and more	When cranking
Generator coil resistance			0.2 – 0.7 Ω	
Generator maximum output			Approx. 400 W at 5 000 r/min	
Generator no-load voltage (When engine is cold)			70 V (AC) and more at 5 000 r/min	
Regulated voltage			13.5 – 15.5 V at 5 000 r/min	
Starter motor brush length			Standard	12.0 (0.47)
			Limit	8.5 (0.33)
Starter torque limiter slip torque			33.3 – 52.0 N·m (3.3 – 5.2 kgf-m, 24.0 – 37.5 lb-ft)	
Starter relay resistance			3 – 5 Ω	
Battery	Type designation		YTX12-BS	
	Capacity		12 V 36 kC (10 Ah)/10 HR	
	Standard electrolyte S.G.		1.320 at 20 °C (68 °F)	
Fuse size	Headlight	HI	10 A	
		LO	10 A	
	Signal		10 A	
	Ignition		15 A	
	Fuel		10 A	
	Fan (LH)		15 A	
	Fan (RH)			
	Main		30 A	

Wattage

Unit: W

Item		Specification	
		E-02, 19, 24	The other countries
Headlight	HI	65	←
	LO	55	←
Position/Parking light		5 x 2	←
Brake light/Taillight		LED	←
Turn signal light		21 x 4	←
License plate light		5	←
Tachometer light		LED	←
Speedometer light		LED	←
Turn signal indicator light		LED	←
High beam indicator light		LED	←
Neutral position indicator light		LED	←
Oil pressure indicator light		LED	←
FI indicator light		LED	←
Engine coolant temp. indicator light		LED	←
Fuel level indicator light		LED	←
Engine R.P.M. indicator light		LED	←
Immobilizer indicator light		LED	—

Brake + Wheel

Unit: mm (in)

Item	Standard			Limit
Rear brake pedal height	50 – 60 (2.0 – 2.4)			—
Brake disc thickness	Front	5.3 – 5.7 (0.21 – 0.22)		5.0 (0.20)
	Rear			
Brake disc runout	—			0.30 (0.012)
Master cylinder bore	Front	14.000 – 14.043 (0.5512 – 0.5529)		—
	Rear	12.700 – 12.743 (0.5000 – 0.5017)		—
Master cylinder piston diam.	Front	13.957 – 13.984 (0.5495 – 0.5506)		—
	Rear	12.657 – 12.684 (0.4983 – 0.4994)		—
Brake caliper cylinder bore	Front	Leading	30.280 – 30.330 (1.1921 – 1.1941)	—
		Trailing	32.080 – 32.130 (1.2630 – 1.2650)	—
	Rear	38.180 – 38.256 (1.5031 – 1.5061)		—
	Brake caliper piston diam.	Front	Leading	30.167 – 30.200 (1.1877 – 1.1890)
Trailing			31.967 – 32.000 (1.2585 – 1.2598)	—
Rear		38.098 – 38.148 (1.4999 – 1.5019)		—
Brake fluid type	DOT 4			—
Wheel rim runout	Axial	—		2.0 (0.08)
	Radial			
Wheel rim size	Front	17 M/C x MT 3.50		—
	Rear	17 M/C x MT 6.00		—
Wheel axle runout	Front	—		0.25 (0.010)
	Rear			

Tire

Item	Standard			Limit
Cold inflation tire pressure (Solo/Dual riding)	Front	290 kPa (2.90 kgf/cm ² , 42 psi)		—
	Rear			
Tire size	Front	120/70 ZR17M/C (58 W)		—
	Rear	190/50 ZR17M/C (73 W)		—
Tire type	Front	BRIDGESTONE BT015F RADIAL M		—
	Rear	BRIDGESTONE BT015R RADIAL M		—
Tire tread depth (Recommended depth)	Front	—		1.6 mm (0.06 in)
	Rear	—		2.0 mm (0.08 in)

0C-8 Service Data:**Suspension**

Unit: mm (in)

Item	Standard		Limit
Front fork stroke	120 (4.7)		—
Front fork spring free length	263 (10.4)		257 (10.1)
Front fork oil level (Without spring, outer tube fully compressed)	95 (3.7)		—
Front fork oil type	SUZUKI FORK OIL L01 or an equivalent fork oil		—
Front fork oil capacity (Each leg)	532 ml (18.0/18.7 US/Imp oz)		—
Front fork inner tube O.D	43 (1.7)		—
Front fork spring adjuster	3-1/2 grooves from top		—
Front fork damping force adjuster	Rebound	8 clicks out from stiffest position	—
	Compression		—
Rear shock absorber spring pre-set length	195 (7.7)		—
Rear shock absorber damping force adjuster	Rebound	12 clicks out from stiffed postion	—
	Compression	8 clicks out from stiffed postion	—
Rear wheel travel	140 (5.5)		—
Swingarm pivot shaft runout	—		0.3 (0.01)

Fuel + Oil

Item	Specification		Note
Fuel type	Use only unleaded gasoline of at least 90 pump octane (R/2 + M/2). Gasoline containing MTBE (Methyl Tertiary Butyl Ether), less than 10% ethanol, or less than 5% methanol with appropriate cosolvents and corrosion inhibitor is permissible.		E-03, 28, 33
	Gasoline used should be graded 95 octane or higher. An unleaded gasoline type is recommended.		Others
	Fuel tank capacity	Including reserve	20 L (5.3/4.4 US/Imp gal)
21 L (5.5/4.6 US/Imp gal)			Others
Engine oil type	SAE 10W-40, API SF/SG or SH/SJ with JASO MA		
Engine oil capacity	Change	3 100 ml (3.3/2.7 US/Imp qt)	
	Filter change	3 300 ml (3.5/2.9 US/Imp qt)	
	Overhaul	4 000 ml (4.2/3.5 US/Imp qt)	

Tightening Torque List

Engine

Item		N·m	kgf·m	lb·ft
Exhaust pipe bolt		23	2.3	16.5
Exhaust pipe mounting bolt		23	2.3	16.5
Muffler mounting bolt		25	2.5	18.0
Muffler connecting bolt		23	2.3	16.5
Muffler joint nut		25	25	18.0
Speed sensor rotor bolt		28	2.8	20.0
Engine sprocket nut		145	14.5	105.0
Speed sensor bolt		6.5	0.65	4.7
Engine mounting bolt		55	5.5	40.0
Engine mounting nut		75	7.5	54.0
Engine mounting thrust adjuster		10	1.0	7.0
Engine mounting thrust adjuster lock-nut		45	4.5	32.5
Engine mounting pinch bolt		35	3.5	25.5
Cylinder head cover bolt		14	1.4	10.0
Spark plug		11	1.1	8.0
Cam chain guide No. 2 bolt		10	1.0	7.0
Camshaft journal holder bolt		10	1.0	7.0
Cam chain tension adjuster mounting bolt		10	1.0	7.0
Cylinder head side bolt		14	1.4	10.0
Cam chain tensioner bolt		23	2.3	16.5
Cylinder head bolt	[M6]	10	1.0	7.0
	[M10]	Initial	25	2.5
		Final	52	5.2
Cylinder nut	[M6]	10	1.0	7.0
Water inlet connector bolt		10	1.0	7.0
Oil hose union bolt		18	1.8	13.0
Clutch cover bolt		10	1.0	7.0
Clutch sleeve hub nut		150	15.0	108.5
Clutch spring set bolt		10	1.0	7.0
Clutch spring support bolt		23	2.3	16.5
Starter clutch cover bolt		10	1.0	7.0
Starter torque limiter cover bolt		10	1.0	7.0
Starter clutch cover cap		10	1.0	7.0
Valve timing inspection cap		23	2.3	16.5
Starter clutch bolt		55	5.5	40.0
Generator cover bolt		10	1.0	7.0
Generator rotor bolt		120	12.0	87.0
Generator stator set bolt		11	1.1	8.0
Gearshift cover bolt		10	1.0	7.0
Gearshift cam stopper bolt		10	1.0	7.0
Gearshift cam stopper plate bolt		13	1.3	9.5
Gearshift arm stopper bolt		19	1.9	13.5
Oil pressure switch		14	1.4	10.0
Crankcase bolt	[M6]	11	1.1	8.0
	[M8]	26	2.6	19.0
	[M10]	50	5.0	36.0
Oil gallery plug	[M6] and [M8]	10	1.0	7.0
	[M10]	18	1.8	13.0
	[M14]	23	2.3	16.5
	[M16]	35	3.5	25.5
Oil drain plug		23	2.3	16.5
Piston cooling oil jet bolt		10	1.0	7.0
Oil jet (For generator)		5	0.5	3.5
Oil pump mounting bolt		10	1.0	7.0
Conrod bearing cap bolt	Initial	21	2.1	15.0
	Final		90°	

0C-10 Service Data:

Item			N-m	kgf-m	lb-ft
Bearing retainer screw			8	0.8	6.0
Cam chain guide retainer screw			8	0.8	6.0
Balancer shaft arm bolt			10	1.0	7.0
Balancer cover bolt			10	1.0	7.0
Balancer pipe bolt			10	1.0	7.0
Oil strainer bolt			10	1.0	7.0
Oil pan bolt			10	1.0	7.0
Oil pipe bolt (Camshaft housing)			10	1.0	7.0
Oil pipe bolt	[M6]		10	1.0	7.0
Oil pipe union bolt	[M14]		24	2.4	17.5
Oil filter			20	2.0	14.5
PAIR reed valve cover bolt			11	1.1	8.0
Cam chain tension adjuster service cap			23	2.3	16.5
Water jacket plug			11	1.1	8.0
Crankshaft journal bolt	[M9]	Initial	18	1.8	13.0
Crankshaft journal bolt		Final	32	3.2	23.0
Balancer shaft mounting bolt			10	1.0	7.0
PCV cover bolt			10	1.0	7.0
PCV reed valve cover bolt			10	1.0	7.0
Main oil gallery plug	[M6]		35	3.5	25.5
Oil pressure switch lead wire bolt			1.5	0.15	1.1
Speed sensor mounting bolt			6.5	0.65	4.7

FI System

Item			N-m	kgf-m	lb-ft
CKP sensor mounting bolt			6.5	0.65	4.7
HO2 sensor			25	2.5	18.0
CMP sensor bolt			10	1.0	7.0
TP sensor mounting screw			3.5	0.35	2.5
STP sensor mounting screw			3.5	0.35	2.5
ISC valve mounting screw			2	0.2	1.5
Fuel delivery pipe mounting screw			3.5	0.35	2.5
GP switch mounting bolt			6.5	0.65	4.7
Fuel pump mounting bolt			10	1.0	7.0
IAT sensor mounting screw			5.5	0.55	4.0

Cooling System

Item			N-m	kgf-m	lb-ft
Impeller securing bolt			8	0.8	6.0
Water pump case screw			6	0.6	4.5
Water pump mounting bolt			10	1.0	7.0
Thermostat cover bolt			10	1.0	7.0
Oil cooler hose bolt			10	1.0	7.0
ECT sensor			18	1.8	13.0

Chassis




Item			N-m	kgf-m	lb-ft
Steering stem head nut			90	9.0	65.0
Steering stem lock-nut			80	8.0	58.0
Steering damper bolt			23	2.3	16.5
Steering damper nut			23	2.3	16.5
Front fork upper clamp bolt			23	2.3	16.5
Front fork lower clamp bolt			23	2.3	16.5
Front fork cap bolt			23	2.3	16.5
Front fork inner rod lock-nut			15	1.5	11.0
Front fork damper rod bolt			23	2.3	16.5
Front axle bolt			100	10.0	72.5
Front axle pinch bolt			23	2.3	16.5
Handlebar holder mounting nut			35	3.5	25.5

Item	N·m	kgf·m	lb·ft
Handlebar clamp bolt	10	1.0	7.0
Master cylinder holder bolt (Upper and Lower)	10	1.0	7.0
Front brake caliper mounting bolt	39	3.9	28.0
Front brake caliper housing bolt	22	2.2	16.0
Front brake pad mounting pin	15	1.5	11.0
Brake hose union bolt	23	2.3	16.5
Clutch master cylinder mounting bolt	10	1.0	7.0
Clutch hose union bolt	23	2.3	16.5
Air bleeder valve (Front)	7.5	0.75	5.5
Air bleeder valve (Rear)	7.5	0.75	5.5
Brake disc bolt (Front)	23	2.3	16.5
Brake disc bolt (Rear)	35	3.5	25.5
Rear brake caliper mounting bolt	17	1.7	12.5
Rear brake pad mounting pin	15	1.5	11.0
Rear brake master cylinder mounting bolt	10	1.0	7.0
Rear brake master cylinder rod lock-nut	18	1.8	13.0
Rear brake caliper sliding pin	33	3.3	24.0
Brake lever pivot bolt	6	0.6	4.5
Brake lever pivot bolt lock-nut	6	0.6	4.5
Swingarm pivot shaft	15	1.5	11.0
Swingarm pivot nut	100	10.0	72.5
Swingarm pivot lock-nut	90	9.0	65.0
Cushion lever mounting nut	78	7.8	56.5
Cushion rod mounting nut	78	7.8	56.5
Rear shock absorber mounting nut	50	5.0	36.0
Rear axle nut	100	10.0	72.5
Rear sprocket nut	60	6.0	43.5
Rear master cylinder rod lock-nut	18	1.8	13.0
Air bleeder valve (Clutch)	6	0.6	4.5
Clutch master cylinder holder bolt	10	1.0	7.0
Clutch lever pivot bolt	1.0	0.1	0.7
Clutch lever pivot bolt lock-nut	6.0	0.6	4.5
Clutch release mounting bolt	10	1.0	7.0

Tightening Torque Chart

For other bolts and nuts not listed in the preceding page, refer to this chart:

Bolt Diameter “a” (mm)	Conventional or “4” marked bolt			“7” marked bolt		
	N·m	kgf·m	lb·ft	N·m	kgf·m	lb·ft
4	1.5	0.15	1.0	2.3	0.23	1.5
5	3	0.3	2.0	4.5	0.45	3.0
6	5.5	0.55	4.0	10	1.0	7.0
8	13	1.3	9.5	23	2.3	16.5
10	29	2.9	21.0	50	5.0	36.0
12	45	4.5	32.5	85	8.5	61.5
14	65	6.5	47.0	135	13.5	97.5
16	105	10.5	76.0	210	21.0	152.0
18	160	16.0	115.5	240	24.0	173.5



I649G1030001-04

1. Conventional bolt

2. “4” marked bolt

3. “7” marked bolt

Section 1

Engine

CONTENTS

Precautions	1-1	
Precautions.....	1-1	
Precautions for Engine.....	1-1	
Engine General Information and		
Diagnosis	1A-1	
General Description	1A-1	
Injection Timing Description	1A-1	
Self-Diagnosis Function	1A-2	
Schematic and Routing Diagram.....	1A-3	
FI System Wiring Diagram	1A-3	
Terminal Alignment of ECM Coupler.....	1A-5	
Component Location	1A-6	
FI System Parts Location.....	1A-6	
Diagnostic Information and Procedures.....	1A-8	
Engine Symptom Diagnosis.....	1A-8	
Self-Diagnostic Procedures	1A-12	
Use of SDS Diagnosis Reset Procedures.....	1A-14	
Show Data When Trouble (Displaying Data at		
the Time of DTC)	1A-15	
SDS Check	1A-17	
DTC Table.....	1A-20	
Fail-Safe Function Table	1A-22	
FI System Troubleshooting	1A-24	
Malfunction Code and Defective Condition		
Table	1A-25	
DTC "C11" (P0340) CMP Sensor Circuit		
Malfunction.....	1A-28	
DTC "C12" (P0335): CKP Sensor Circuit		
Malfunction.....	1A-30	
DTC "C13" (P0105-H/L): IAP Sensor Circuit		
Malfunction.....	1A-33	
DTC "C14" (P0120-H/L): TP Sensor Circuit		
Malfunction.....	1A-40	
DTC "C15" (P0115-H/L): ECT Sensor Circuit		
Malfunction.....	1A-47	
DTC "C21" (P0110-H/L): IAT Sensor Circuit		
Malfunction.....	1A-52	
DTC "C22" (P01450-H/L): AP Sensor Circuit		
Malfunction.....	1A-57	
DTC "C23" (P1651-H/L): TO Sensor Circuit		
Malfunction.....	1A-64	
DTC "C24" (P0351), "C25" (P0352), "C26"		
(P0353) or "C27" (P0354): Ignition System		
Malfunction.....	1A-71	
DTC "C28" (P1655): Secondary Throttle		
Valve Actuator (STVA) Malfunction.....	1A-71	
DTC "C29" (P1654-H/L): Secondary Throttle		
Position Sensor (STPS) Circuit Malfunction....	1A-75	
DTC "C31" (P0705): GP Switch Circuit		
Malfunction.....	1A-82	
DTC "C32" (P0201), "C33" (P0202), "C34"		
(P0203) or "C35" (P0204): Primary Fuel		
Injector Circuit Malfunction.....	1A-84	
DTC "C36" (P1764), "C37" (P1765), "C38"		
(P1766) or "C39" (P1767): Secondary Fuel		
Injector Circuit Malfunction.....	1A-88	
DTC "C40" (P0505 / P0506 / P0507): ISC		
Valve Circuit Malfunction.....	1A-92	
DTC "C41" (P0230-H/L): FP Relay Circuit		
Malfunction.....	1A-97	
DTC "C41" (P2505): ECM Power Input Signal		
Malfunction.....	1A-100	
DTC "C42" (P1650): IG Switch Circuit		
Malfunction.....	1A-102	
DTC "C44" (P0130/P0135): HO2 Sensor		
(HO2S) Circuit Malfunction	1A-102	
DTC "C49" (P1656): PAIR Control Solenoid		
Valve Circuit Malfunction.....	1A-108	
DTC "C60" (P0480): Cooling Fan Relay		
Circuit Malfunction.....	1A-112	
DTC "C62" (P0443): EVAP System Purge		
Control Solenoid Valve Circuit Malfunction		
(E-33 only).....	1A-115	
Specifications	1A-118	
Service Data.....	1A-118	
Special Tools and Equipment	1A-119	
Special Tool	1A-119	
Emission Control Devices	1B-1	
Precautions.....	1B-1	
Precautions for Emission Control Devices	1B-1	
General Description	1B-1	
Fuel Injection System Description.....	1B-1	
Crankcase Emission Control System		
Description	1B-2	

Exhaust Emission Control System		STP Sensor Removal and Installation	1C-8
Description	1B-3	STV Actuator Inspection	1C-9
Noise Emission Control System Description	1B-6	STV Actuator Removal and Installation	1C-9
Evaporative Emission Control System		ISC Valve Inspection	1C-9
Diagram (Only for E-33)	1B-7	ISC Valve Removal and Installation	1C-9
Schematic and Routing Diagram	1B-8	ISC Valve Preset and Opening Initialization	1C-9
EVAP Canister Hose Routing Diagram (Only		HO2 Sensor Inspection	1C-10
for E-33)	1B-8	HO2 Sensor Removal and Installation	1C-10
Repair Instructions	1B-9	GP Switch Inspection	1C-10
Heated Oxygen Sensor (HO2S) Removal and		GP Switch Removal and Installation	1C-10
Installation	1B-9	Specifications	1C-11
Heated Oxygen Sensor (HO2S) Inspection	1B-9	Service Data	1C-11
PAIR Reed Valve Removal and Installation	1B-9	Tightening Torque Specifications	1C-12
PAIR Control Solenoid Valve Removal and		Special Tools and Equipment	1C-12
Installation	1B-10	Recommended Service Material	1C-12
PAIR System Inspection	1B-11	Special Tool	1C-12
Crankcase Breather (PCV) Hose Inspection	1B-12		
Crankcase Breather (PCV) Hose / Reed		Engine Mechanical	1D-1
Valve / Cover Removal and Installation	1B-12	Schematic and Routing Diagram	1D-1
Crankcase Breather (PCV) Cover Inspection ...	1B-13	Camshaft and Sprocket Assembly Diagram	1D-1
Evaporative Emission Control System		Throttle Cable Routing Diagram	1D-2
Removal and Installation (Only for E-33)	1B-14	Diagnostic Information and Procedures	1D-3
Evaporative Emission Control System		Engine Mechanical Symptom Diagnosis	1D-3
Inspection (For E-33 only)	1B-15	Compression Pressure Check	1D-3
Specifications	1B-17	Repair Instructions	1D-4
Service Data	1B-17	Engine Components Removable with the	
Tightening Torque Specifications	1B-17	Engine in Place	1D-4
Special Tools and Equipment	1B-18	Air Cleaner Element Removal and Installation ...	1D-6
Recommended Service Material	1B-18	Air Cleaner Box Removal and Installation	1D-6
Special Tool	1B-18	Air Cleaner Element Inspection and Cleaning ...	1D-7
		Throttle Cable Removal and Installation	1D-7
Engine Electrical Devices	1C-1	Throttle Cable Inspection	1D-7
Precautions	1C-1	Throttle Cable Play Inspection and	
Precautions for Engine Electrical Device	1C-1	Adjustment	1D-7
Component Location	1C-1	Throttle Body Components	1D-8
Engine Electrical Components Location	1C-1	Throttle Body Construction	1D-9
Diagnostic Information and Procedures	1C-1	Throttle Body Removal and Installation	1D-10
Engine Symptom Diagnosis	1C-1	Throttle Body Disassembly and Assembly	1D-12
Repair Instructions	1C-2	Throttle Body Inspection and Cleaning	1D-16
ECM Removal and Installation	1C-2	ISC Valve Visual Inspection	1D-16
CMP Sensor Inspection	1C-2	Throttle Valve Synchronization	1D-16
CMP Sensor Removal and Installation	1C-2	ISC Valve Reset	1D-18
CKP Sensor Inspection	1C-2	TP Reset	1D-19
CKP Sensor Removal and Installation	1C-2	Engine Assembly Removal	1D-19
IAP Sensor Inspection	1C-3	Engine Assembly Installation	1D-24
IAP Sensor Removal and Installation	1C-3	Engine Top Side Disassembly	1D-27
TP Sensor Inspection	1C-3	Engine Top Side Assembly	1D-31
TP Sensor Removal and Installation	1C-3	Camshaft Inspection	1D-42
TP Sensor Adjustment	1C-4	Camshaft Sprocket / Bearing Inspection	1D-44
ECT Sensor Removal and Installation	1C-5	Cam Chain Tension Adjuster Inspection	1D-45
ECT Sensor Inspection	1C-5	Cam Chain Guide Removal and Installation ...	1D-46
IAT Sensor Removal and Installation	1C-6	Cam Chain Guide Inspection	1D-46
IAT Sensor Inspection	1C-6	Cam Chain Tensioner Inspection	1D-46
AP Sensor Inspection	1C-6	Cylinder Head Disassembly and Assembly ...	1D-47
AP Sensor Removal and Installation	1C-6	Cylinder Head Related Parts Inspection	1D-52
TO Sensor Inspection	1C-6	Valve Guide Replacement	1D-56
TO Sensor Removal and Installation	1C-7	Valve Seat Repair	1D-57
STP Sensor Inspection	1C-7	Cylinder Disassembly and Assembly	1D-58
STP Sensor Adjustment	1C-7	Cylinder Inspection	1D-59

Piston Ring Removal and Installation	1D-60	General Description	1F-1
Piston and Piston Ring Inspection	1D-61	Engine Coolant Description.....	1F-1
Engine Bottom Side Disassembly	1D-63	Schematic and Routing Diagram	1F-2
Engine Bottom Side Assembly	1D-71	Cooling Circuit Diagram	1F-2
Crank Balancer Disassembly and Assembly	1D-88	Water Hose Routing Diagram	1F-3
Crank Balancer Inspection	1D-89	Diagnostic Information and Procedures	1F-4
Conrod Removal and Installation	1D-89	Engine Cooling Symptom Diagnosis	1F-4
Conrod and Crankshaft Inspection	1D-91	Repair Instructions	1F-4
Conrod Crank Pin Bearing Inspection and Selection	1D-92	Cooling Circuit Inspection	1F-4
Crankshaft Journal Bearing Inspection and Selection	1D-94	Radiator Cap Inspection.....	1F-5
Crankshaft Thrust Clearance Inspection and Selection	1D-96	Radiator Inspection and Cleaning	1F-5
Specifications	1D-98	Radiator / Cooling Fan Motor Removal and Installation	1F-6
Service Data	1D-98	Water Hose Inspection.....	1F-7
Tightening Torque Specifications.....	1D-100	Water Hose Removal and Installation.....	1F-8
Special Tools and Equipment	1D-101	Radiator Reservoir Tank Removal and Installation	1F-8
Recommended Service Material.....	1D-101	Radiator Reservoir Tank Inspection.....	1F-8
Special Tool	1D-102	Cooling Fan Inspection	1F-8
Engine Lubrication System	1E-1	Cooling Fan Relay Inspection	1F-9
Precautions.....	1E-1	ECT Sensor Removal and Installation	1F-9
Precautions for Engine Oil	1E-1	ECT Sensor Inspection	1F-9
Schematic and Routing Diagram.....	1E-1	Thermostat Cover / Thermostat Removal and Installation	1F-9
Engine Lubrication System Chart Diagram	1E-1	Thermostat Inspection.....	1F-10
Engine Lubrication Circuit Diagram.....	1E-3	Water Pump Components.....	1F-11
Diagnostic Information and Procedures.....	1E-5	Water Pump Construction	1F-12
Engine Lubrication Symptom Diagnosis	1E-5	Water Pump Removal and Installation.....	1F-12
Oil Pressure Check	1E-5	Water Pump Disassembly and Assembly	1F-13
Repair Instructions	1E-6	Water Pump Related Parts Inspection	1F-16
Engine Oil and Filter Replacement	1E-6	Specifications	1F-17
Engine Oil Level Inspection	1E-6	Service Data.....	1F-17
Oil Pan / Oil Strainer / Oil Pressure Regulator Removal and Installation.....	1E-6	Tightening Torque Specifications.....	1F-18
Oil Pressure Regulator / Oil Strainer Inspection.....	1E-7	Special Tools and Equipment	1F-18
Oil Cooler / Oil Cooler Hose Inspection and Cleaning.....	1E-8	Recommended Service Material	1F-18
Oil Cooler / Oil Cooler Hose Removal and Installation	1E-8	Special Tool	1F-18
Oil Pressure Switch Removal and Installation	1E-9	Fuel System	1G-1
Oil Pressure Switch Inspection	1E-10	Precautions.....	1G-1
Oil Jet / Oil Gallery Jet Removal and Installation.....	1E-10	Precautions for Fuel System	1G-1
Oil Jet / Oil Gallery Jet Inspection.....	1E-12	General Description	1G-2
Oil Pump Removal and Installation	1E-12	Fuel Injection System Description.....	1G-2
Oil Pump Inspection	1E-13	Schematic and Routing Diagram	1G-3
Specifications.....	1E-14	Fuel Tank Drain Hose and Breather Hose Routing Diagram	1G-3
Service Data	1E-14	Diagnostic Information and Procedures	1G-4
Tightening Torque Specifications.....	1E-14	Fuel System Diagnosis	1G-4
Special Tools and Equipment	1E-15	Repair Instructions	1G-5
Recommended Service Material.....	1E-15	Fuel Pressure Inspection	1G-5
Special Tool	1E-15	Fuel Pump Inspection	1G-6
Engine Cooling System	1F-1	Fuel Discharge Amount Inspection	1G-6
Precautions.....	1F-1	Fuel Pump Relay Inspection	1G-7
Precautions for Engine Cooling System.....	1F-1	Fuel Hose Inspection	1G-7
Precautions for Engine Coolant	1F-1	Fuel Level Gauge Inspection	1G-7
		Fuel Tank Construction	1G-8
		Fuel Tank Heat Shield Construction	1G-9
		Fuel Tank Removal and Installation.....	1G-9
		Fuel Pump Components	1G-11
		Fuel Pump Disassembly and Assembly.....	1G-12

Fuel Mesh Filter Inspection and Cleaning.....	1G-14	Turn Signal / Side-stand Relay Removal and Installation	1I-7
Fuel Injector / Fuel Delivery Pipe / T-joint Removal and Installation.....	1G-14	Side-stand / Ignition Interlock System Parts Inspection.....	1I-8
Fuel Injector Inspection and Cleaning.....	1G-14	Starter Torque Limiter / Starter Clutch Removal and Installation.....	1I-10
Specifications.....	1G-15	Starter Torque Limiter Inspection.....	1I-12
Service Data.....	1G-15	Starter Clutch Inspection.....	1I-12
Tightening Torque Specifications.....	1G-15	Starter Button Inspection.....	1I-13
Special Tools and Equipment.....	1G-16	Specifications.....	1I-13
Recommended Service Material	1G-16	Service Data.....	1I-13
Special Tool	1G-16	Tightening Torque Specifications.....	1I-13
Ignition System.....	1H-1	Special Tools and Equipment	1I-14
General Description	1H-1	Recommended Service Material	1I-14
Immobilizer Description (For E-02, 19, 24)	1H-1	Special Tool	1I-14
Drive Mode Selector Description.....	1H-2	Charging System.....	1J-1
Schematic and Routing Diagram.....	1H-3	Schematic and Routing Diagram	1J-1
Ignition System Diagram.....	1H-3	Charging System Diagram	1J-1
Ignition System Components Location.....	1H-3	Component Location	1J-1
Diagnostic Information and Procedures.....	1H-4	Charging System Components Location.....	1J-1
Ignition System Symptom Diagnosis.....	1H-4	Diagnostic Information and Procedures.....	1J-1
No Spark or Poor Spark.....	1H-5	Charging System Symptom Diagnosis.....	1J-1
Repair Instructions	1H-6	Battery Runs Down Quickly	1J-2
Ignition Coil / Plug Cap and Spark Plug Removal and Installation.....	1H-6	Repair Instructions	1J-3
Spark Plug Inspection and Cleaning	1H-7	Battery Cushion Rubber Attachment Construction	1J-3
Ignition Coil / Plug Cap Inspection	1H-7	Battery Current Leakage Inspection.....	1J-4
CKP Sensor Inspection.....	1H-10	Regulated Voltage Inspection	1J-4
CKP Sensor Removal and Installation.....	1H-11	Generator Inspection.....	1J-5
Engine Stop Switch Inspection.....	1H-11	Generator Removal and Installation.....	1J-6
Ignition Switch Inspection.....	1H-12	Regulator / Rectifier Construction	1J-9
Ignition Switch Removal and Installation.....	1H-12	Regulator / Rectifier Removal and Installation ..	1J-10
Drive Mode Selector Inspection	1H-13	Regulator / Rectifier Inspection	1J-10
Immobilizer Antenna Removal and Installation (For E-02, 19, 24)	1H-14	Battery Components	1J-11
Specifications.....	1H-14	Battery Charging	1J-11
Service Data.....	1H-14	Battery Removal and Installation	1J-14
Tightening Torque Specifications.....	1H-14	Battery Visual Inspection.....	1J-14
Special Tools and Equipment.....	1H-15	Specifications.....	1J-15
Recommended Service Material	1H-15	Service Data.....	1J-15
Special Tool	1H-15	Tightening Torque Specifications.....	1J-15
Starting System	1I-1	Special Tools and Equipment	1J-16
Schematic and Routing Diagram.....	1I-1	Recommended Service Material	1J-16
Starting System Diagram	1I-1	Special Tool	1J-16
Component Location	1I-1	Exhaust System.....	1K-1
Starting System Components Location.....	1I-1	Precautions.....	1K-1
Diagnostic Information and Procedures.....	1I-1	Precautions for Exhaust System	1K-1
Starting System Symptom Diagnosis.....	1I-1	Repair Instructions	1K-2
Starter Motor Will Not Run	1I-2	Exhaust System Construction	1K-2
Starter Motor Runs But Does Not Crank The Engine.....	1I-2	Exhaust Pipe / Muffler Removal and Installation	1K-3
Repair Instructions	1I-3	Exhaust System Inspection.....	1K-7
Starter Motor Components.....	1I-3	Specifications.....	1K-8
Starter Motor Removal and Installation.....	1I-4	Tightening Torque Specifications.....	1K-8
Starter Motor Disassembly and Assembly	1I-4	Special Tools and Equipment	1K-8
Starter Motor Inspection.....	1I-5	Recommended Service Material	1K-8
Starter Relay Removal and Installation.....	1I-6		
Starter Relay Inspection.....	1I-7		

Precautions

Precautions

Precautions for Engine

B815H21000001

Refer to “General Precautions in Section 00 (Page 00-1)” and “Precautions for Electrical Circuit Service in Section 00 (Page 00-2)”.

Engine General Information and Diagnosis


General Description

Injection Timing Description

B815H21101001

Injection Time (Injection Volume)

The factors to determine the injection time include the basic fuel injection time, which is calculated on the basis of the intake air pressure, engine speed and throttle opening angle, and various compensations. These compensations are determined according to the signals from various sensors that detect the engine and driving conditions.



I718H1110268-03

Compensation of Injection Time (Volume)

The following different signals are output from the respective sensors for compensation of the fuel injection time (volume).

Signal	Descriptions
ATMOSPHERIC PRESSURE SENSOR SIGNAL	When atmospheric pressure is low, the sensor sends the signal to the ECM and reduce the injection time (volume).
ENGINE COOLANT TEMPERATURE SENSOR SIGNAL	When engine coolant temperature is low, injection time (volume) is increased.
INTAKE AIR TEMPERATURE SENSOR SIGNAL	When intake air temperature is low, injection time (volume) is increased.
HEATED OXYGEN SENSOR SIGNAL	Air/fuel ratio is compensated to the theoretical ratio from density of oxygen in exhaust gasses. The compensation occurs in such a way that more fuel is supplied if detected air/fuel ratio is lean and less fuel is supplied if it is rich.
BATTERY VOLTAGE SIGNAL	ECM operates on the battery voltage and at the same time, it monitors the voltage signal for compensation of the fuel injection time (volume). A longer injection time is needed to adjust injection volume in the case of low voltage.
STARTING SIGNAL	When starting engine, additional fuel is injected during cranking engine.

Signal	Descriptions
ACCELERATION SIGNAL/ DECELERATION SIGNAL	During acceleration, the fuel injection time (volume) is increased, in accordance with the throttle opening speed and engine rpm. During deceleration, the fuel injection time (volume) is decreased.

Injection Stop Control

Signal	Descriptions
TIP-OVER SENSOR SIGNAL (FUEL SHUT-OFF)	When the motorcycle tips over, the tip-over sensor sends a signal to the ECM. Then, this signal cuts OFF current supplied to the fuel pump, fuel injectors and ignition coils.
OVER-REV. LIMITER SIGNAL	The fuel injector stops operation when engine rpm reaches rev. limit rpm.

Self-Diagnosis Function

B815H21101002

The self-diagnosis function is incorporated in the ECM. The function has two modes, "User mode" and "Dealer mode". The user can only be notified by the LCD (DISPLAY) panel and LED (FI indicator light). To check the function of the individual FI system devices, the dealer mode is provided. In this check, the special tool is necessary to read the code of the malfunction items.

User Mode

Malfunction		LCD (display) indication "A"	FI indicator light indication "B"	Indication mode
"NO"		Odometer *1	—	—
"YES"	Engine can start	Odometer (*1) and "FI" letters *2	FI indicator light turns ON.	Each 2 sec. Odometer (*1) and "FI" is indicated alternately.
	Engine can not start	"FI" letters *3	FI indicator light turns ON and blinks.	"FI" is indicated continuously.

*1

Current letter displayed any one of the odometer, tripmeter 1 or tripmeter 2.

*2

When one of the signals is not received by ECM, the fail-safe circuit works and injection is not stopped. In this case, "FI" and odometer (*1) are indicated in the LCD panel and motorcycle can run.

*3

The injection signal is stopped, when the crankshaft position sensor signal, tip-over sensor signal, ignition signal, #1, #2, #3 and #4 injector signals, fuel pump relay signal or ignition switch signal is not sent to ECM. In this case, "FI" is indicated in the LCD panel. Motorcycle does not run.

"CHEC":

The LCD panel indicates "CHEC" when no communication signal from the ECM is received for 5 seconds and more.

For Example:

The ignition switch is turned ON, and the engine stop switch is turned OFF. In this case, the speedometer does not receive any signal from the ECM, and the panel indicates "CHEC".


If CHEC is indicated, the LCD does not indicate the trouble code. It is necessary to check the wiring harness between ECM and speedometer couplers.

The possible cause of this indication is as follows:

Engine stop switch is in OFF position. Side-Stand/ignition inter-lock system is not working. Ignition fuse is burnt.

NOTE

The FI light “B” turns ON about 3 seconds after turning the ignition switch ON.



I815H1110002-03

Dealer Mode


The defective function is memorized in the computer. Use the special tool's coupler to connect to the mode select switch. The memorized malfunction code is displayed on LCD (DISPLAY) panel. Malfunction means that the ECM does not receive signal from the devices. These affected devices are indicated in the code form.

CAUTION

Before checking the malfunction code, do not disconnect the ECM coupler.
If the coupler from the ECM is disconnected, the malfunction code memory is erased and the malfunction code can not be checked.

Special tool

TOOL (A): 09930-82720 (Mode select switch)



I815H1110003-01


I815H1110004-01

Malfunction	LCD (display) indication	FI light indication	Indication mode
"NO"	C00		—
"YES"	C** code is indicated from small numeral to large one.	FI indicator light turns OFF.	For each 2 sec., code is indicated.

Schematic and Routing Diagram

FI System Wiring Diagram


B815H21102001



*15.....E-33 only
*40, *57...E-02, 19, 24 only

Terminal Alignment of ECM Coupler

B815H2110002-01




I823H1110002-01

TERMINAL NO.	CIRCUIT	TERMINAL NO.	CIRCUIT
1	STVA signal (STVA, 2A)	35	ISC valve signal (ISC, 2A)
2	STVA signal (STVA, 1A)	36	ISC valve signal (ISC, 1A)
3	—	37	Drive mode selector (DMS 1)
4	—	38	Tachometer
5	—	39	Fuel pump relay (FP relay)
6	Serial data for speedometer	40	Immobilizer communication (For E-02, 19, 24)
7	—	41	HO2 sensor heater (HO2SH)
8	TP sensor signal (TPS)	42	Starter switch
9	IAP sensor signal (IAPS)	43	Cooling fan relay
10	ECT sensor signal (ECTS)	44	PAIR control solenoid valve (PAIR)
11	Power source for sensors (VCC)	45	Primary fuel injector #4 (#41)
12	HO2 sensor signal (HO2S)	46	Primary fuel injector #3 (#31)
13	CMP sensor signal (CMPS+)	47	Primary fuel injector #2 (#21)
14	CKP sensor signal (CKPS+)	48	Primary fuel injector #1 (#11)
15	EVAP system purge control solenoid valve (EVAP) (E-33 only)	49	Ignition coil #3
16	Power source for back-up	50	Ignition coil #2
17	Power source	51	Ignition coil #1
18	STVA signal (STVA, 2B)	52	ISC valve signal (ISC, 2B)
19	STVA signal (STVA, 1B)	53	ISC valve signal (ISC, 1B)
20	STP sensor (STPS)	54	Drive mode selector (DMS 2)
21	Immobilizer indicator (For E-02, 19, 24) /Ignition switch signal (For E-03, 28, 33)	55	—
22	TO sensor signal (TOS)	56	—
23	GP switch signal (GP)	57	Immobilizer communication (For E-02, 19, 24)
24	—	58	—
25	—	59	Neutral signal
26	AP sensor signal (APS)	60	Clutch lever switch
27	IAT sensor signal (IATS)	61	Secondary fuel injector #4 (#42)
28	—	62	Secondary fuel injector #3 (#32)
29	Sensor ground (E2)	63	Secondary fuel injector #2 (#22)
30	—	64	Secondary fuel injector #1 (#12)
31	CKP sensor signal (CKPS-)	65	Mode select switch
32	Serial data for self-diagnosis	66	General power ground (E-01)
33	Power source for fuel injectors	67	Ignition system ground (E-03)
34	ECM ground	68	Ignition coil #4

Component Location


FI System Parts Location

B815H21103001



I815H1110006-03

"A": ECM	"G": Cooling fan relay	"M": Fuel pump relay (FP relay)
"B": Secondary fuel injector	"H": Cooling fan	"N": Fuel pump
"C": Primary fuel injector	"I": Engine coolant temperature sensor (ECTS)	"O": Ignition coil (IG coil)
"D": Intake air temperature sensor (IATS)	"J": Crankshaft position sensor (CKPS)	"P": Speedometer
"E": Camshaft position sensor (CMPS)	"K": Atmospheric pressure sensor (APS)	
"F": PAIR control solenoid valve (PAIR valve)	"L": Speed sensor	



I815H1110007-03

"A": ECM	"V": Tip-over sensor (TOS)
"Q": Idle speed control valve (ISC valve)	"W": Heated oxygen sensor (HO2S)
"R": Secondary throttle position sensor (STPS)	"X": Gear position switch (GP switch)
"S": Throttle position sensor (TPS)	"Y": Drive mode selector (DMS)
"T": Secondary throttle valve actuator (STVA)	"Z": EVAP system purge control valve (For E-33)
"U": Intake air pressure sensor (IAP)	

Diagnostic Information and Procedures

Engine Symptom Diagnosis

B815H21104001

Condition	Possible cause	Correction / Reference Item
Engine will not start or is hard to start (Compression too low)	Valve clearance out of adjustment.	<i>Adjust.</i>
	Worn valve guide or poor seating of valve.	<i>Repair or replace.</i>
	Mistimed valve.	<i>Adjust.</i>
	Excessively worn piston ring.	<i>Replace.</i>
	Worn-down cylinder bore.	<i>Replace.</i>
	Too slow Starter motor cranking.	<i>Refer to "Starting System Diagram in Section 1I (Page 1I-1)".</i>
	Poor seating of spark plug.	<i>Retighten.</i>
Engine will not start or is hard to start (Plug not sparking)	Fouled spark plug.	<i>Clean.</i>
	Wet spark plug.	<i>Clean and dry.</i>
	Defective ignition coil.	<i>Replace.</i>
	Defective CKP sensor.	<i>Replace.</i>
	Defective ECM.	<i>Replace.</i>
	Open-circuited wiring connection.	<i>Repair or replace.</i>
Engine will not start or is hard to start (No fuel reaching the intake manifold)	Clogged fuel filter or fuel hose.	<i>Clean or replace.</i>
	Defective fuel pump.	<i>Replace.</i>
	Defective fuel pressure regulator.	<i>Replace.</i>
	Defective fuel injector.	<i>Replace.</i>
	Defective fuel pump relay.	<i>Replace.</i>
	Defective ECM.	<i>Replace.</i>
	Open-circuited wiring connection.	<i>Check and repair.</i>
Engine will not start or is hard to start (Incorrect fuel/air mixture)	TP sensor out of adjustment.	<i>Adjust.</i>
	Defective fuel pump.	<i>Replace.</i>
	Defective fuel pressure regulator.	<i>Replace.</i>
	Defective TP sensor.	<i>Replace.</i>
	Defective CKP sensor.	<i>Replace.</i>
	Defective IAP sensor.	<i>Replace.</i>
	Defective ECM.	<i>Replace.</i>
	Defective ECT sensor.	<i>Replace.</i>
	Defective IAT sensor.	<i>Replace.</i>
	Defective AP sensor.	<i>Replace.</i>
	Clogged ISC valve air passage way.	<i>Repair or replace.</i>
Engine idles poorly	Valve clearance out of adjustment.	<i>Adjust.</i>
	Poor seating of valve.	<i>Replace or repair.</i>
	Defective valve guide.	<i>Replace.</i>
	Worn down camshaft.	<i>Replace.</i>
	Too wide spark plug gap.	<i>Adjust or replace.</i>
	Defective ignition coil/plug cap.	<i>Replace.</i>
	Defective CKP sensor.	<i>Replace.</i>
	Defective ECM.	<i>Replace.</i>
	Defective TP sensor.	<i>Replace.</i>
	Defective fuel pump.	<i>Replace.</i>
	Imbalanced throttle valve.	<i>Adjust.</i>
	Damaged or cranked vacuum hose.	<i>Replace.</i>
	Damaged or clogged ISC valve.	<i>Repair or replace.</i>
	ISC incorrect leaning.	<i>Reset learned value.</i>

1A-9 Engine General Information and Diagnosis:

Condition	Possible cause	Correction / Reference Item
Engine stalls often (Incorrect fuel/air mixture)	Defective IAP sensor or circuit.	<i>Repair or replace.</i>
	Clogged fuel filter.	<i>Clean or replace.</i>
	Defective fuel pump.	<i>Replace.</i>
	Defective fuel pressure regulator.	<i>Replace.</i>
	Defective ECT sensor.	<i>Replace.</i>
	Defective thermostat.	<i>Replace.</i>
	Defective IAT sensors.	<i>Replace.</i>
	Damaged or cracked vacuum hose.	<i>Replace.</i>
Engine stalls often (Fuel injector improperly operating)	Damaged or clogged ISC valve.	<i>Replace or repair.</i>
	Defective fuel injector.	<i>Replace.</i>
	No injection signal from ECM.	<i>Repair or replace.</i>
	Open or short circuited wiring connection.	<i>Repair or replace.</i>
Engine stalls often (Control circuit or sensor improperly operating)	Defective battery or low battery voltage.	<i>Replace or recharge.</i>
	Defective ECM.	<i>Replace.</i>
	Defective fuel pressure regulator.	<i>Replace.</i>
	Defective TP sensor.	<i>Replace.</i>
	Defective IAT sensors.	<i>Replace.</i>
	Defective CMP sensors.	<i>Replace.</i>
	Defective CKP sensor.	<i>Replace.</i>
	Defective ECT sensor.	<i>Replace.</i>
	Defective fuel pump relay.	<i>Replace.</i>
	Defective ISC valve.	<i>Replace.</i>
Engine stalls often (Engine internal parts improperly operating)	ISC inconnect learning.	<i>Reset learned value.</i>
	Fouled spark plug.	<i>Clean.</i>
	Defective CKP sensor or ECM.	<i>Replace.</i>
	Clogged fuel hose.	<i>Clean.</i>
Noisy engine (Excessive valve chatter)	Out of valve clearance adjustment.	<i>Adjust.</i>
	Too large valve clearance.	<i>Adjust.</i>
	Weakened or broken valve spring.	<i>Replace.</i>
	Worn tappet or cam surface.	<i>Replace.</i>
Noisy engine (Noise seems to come from piston)	Worn or burnt camshaft journal.	<i>Replace.</i>
	Worn down piston or cylinder.	<i>Replace.</i>
	Combustion chamber fouled with carbon.	<i>Clean.</i>
	Worn piston pin or piston pin bore.	<i>Replace.</i>
Noisy engine (Noise seems to come from cam chain)	Worn piston ring or ring groove.	<i>Replace.</i>
	Stretched cam chain.	<i>Replace.</i>
	Worn sprocket.	<i>Replace.</i>
Noisy engine (Noise seems to come from clutch)	Cam chain tension adjuster not working.	<i>Repair or replace.</i>
	Worn splines of countershaft or hub.	<i>Replace.</i>
	Worn teeth of clutch plate.	<i>Replace.</i>
	Distorted clutch plate.	<i>Replace.</i>
	Worn clutch release bearing.	<i>Replace.</i>
Noisy engine (Noise seems to come from crankshaft)	Weakened clutch damper.	<i>Replace the primary driven gear.</i>
	Rattling bearing due to wear.	<i>Replace.</i>
	Worn or burnt big-end bearing.	<i>Replace.</i>
	Worn or burnt journal bearing.	<i>Replace.</i>
Noisy engine (Noise seems to come from balancer)	Too large thrust clearance.	<i>Replace thrust bearing.</i>
	Worn or burnt journal bearing.	<i>Replace.</i>
Noisy engine (Noise seems to come from transmission)	Worn or rubbing gear.	<i>Replace.</i>
	Worn spline.	<i>Replace.</i>
	Worn or rubbing primary gear.	<i>Replace.</i>
	Worn bearing.	<i>Replace.</i>

Condition	Possible cause	Correction / Reference Item
Noisy engine (Noise seems to come from water pump)	Too much play on pump shaft bearing.	Replace.
	Worn or damaged impeller shaft.	Replace.
	Worn or damaged mechanical seal.	Replace.
	Contact between pump case and impeller.	Replace.
Engine runs poorly in high speed range (Defective engine internal/electrical parts)	Weakened valve spring.	Replace.
	Worn camshaft.	Replace.
	Valve timing out of adjustment.	Adjust.
	Too narrow spark plug gap.	Adjust.
	Ignition not advanced sufficiently due to poorly. working timing advance circuit.	Replace ECM.
	Defective ignition coil.	Replace.
	Defective CKP sensor.	Replace.
	Defective ECM.	Replace.
	Clogged air cleaner element.	Clean.
	Clogged fuel hose, resulting in inadequate fuel. supply to injector.	Clean and prime.
	Defective fuel pump.	Replace.
	Defective TP sensor.	Replace.
	Defective STP sensor or STVA.	Replace.
Engine runs poorly in high speed range (Defective air flow system)	Clogged air cleaner element.	Clean or replace.
	Defective throttle valve.	Adjust or replace.
	Defective secondary throttle valve.	Adjust or replace.
	Sucking air from throttle body joint.	Repair or replace.
	Defective ECM.	Replace.
	Imbalancing throttle valve synchronization.	Adjust.
	Defective STP sensor or STVA.	Replace.
Engine runs poorly in high speed range (Defective control circuit or sensor)	Low fuel pressure.	Repair or replace.
	Defective TP sensor.	Replace.
	Defective IAT sensors.	Replace.
	Defective CMP sensor.	Replace.
	Defective CKP sensor.	Replace.
	Defective GP sensor.	Replace.
	Defective IAP sensor.	Replace.
	Defective ECM.	Replace.
	TP sensor out of adjustment.	Adjust.
	Defective STP sensor and/or STVA.	Replace.
	Defective STVA.	Replace.
Engine lacks power (Defective engine internal/electrical parts)	Loss of valve clearance.	Adjust.
	Weakened valve spring.	Replace.
	Valve timing out of adjustment.	Adjust.
	Worn piston ring or cylinder.	Replace.
	Poor seating of valve.	Repair.
	Fouled spark plug.	Clean or replace.
	Incorrect spark plug.	Adjust or replace.
	Clogged fuel injector.	Replace.
	Defective secondary fuel injector.	Replace.
	TP sensor out of adjustment.	Adjust.
	Clogged air cleaner element.	Replace.
	Imbalancing throttle valve synchronization.	Adjust.
	Sucking air from throttle valve or vacuum hose.	Retighten or replace.
	Too much engine oil.	Drain out excess oil.
	Defective fuel pump or ECM.	Replace.
	Defective CKP sensor and ignition coil.	Replace.
	Defective STP sensor or STVA.	Replace.

1A-11 Engine General Information and Diagnosis:

Condition	Possible cause	Correction / Reference Item
Engine lacks power (Defective control circuit or sensor)	Low fuel pressure.	<i>Repair or replace.</i>
	Defective TP sensor.	<i>Replace.</i>
	Defective IAT sensor.	<i>Replace.</i>
	Defective CKP sensor.	<i>Replace.</i>
	Defective GP switch.	<i>Replace.</i>
	Defective IAP sensor.	<i>Replace.</i>
	Defective AP sensor.	<i>Replace.</i>
	TP sensor out of adjustment.	<i>Adjust.</i>
	Defective STP sensor and/or STVA.	<i>Replace.</i>
Engine overheats (Defective engine internal parts)	Heavy carbon deposit on piston crown.	<i>Clean.</i>
	Not enough oil in the engine.	<i>Add oil.</i>
	Defective oil pump or clogged oil circuit.	<i>Replace or clean.</i>
	Sucking air from intake pipe.	<i>Retighten or replace.</i>
	Use of incorrect engine oil.	<i>Change.</i>
	Defective cooling system.	<i>See radiator section.</i>
Engine overheats (Lean fuel/air mixture)	Short-circuited IAP sensor/lead wire.	<i>Repair or replace.</i>
	Short-circuited IAT sensor/lead wire.	<i>Repair or replace.</i>
	Sucking air from intake pipe joint.	<i>Repair or replace.</i>
	Defective fuel injector.	<i>Replace.</i>
	Defective ECT sensor.	<i>Replace.</i>
Engine overheats (Other factors)	Ignition timing is too advanced due to defective timing advance system (ECT sensor, GP switch, CKP sensor or ECM).	<i>Replace.</i>
	Too tight Drive chain.	<i>Adjust.</i>
	ISC inconnect learning.	<i>Reset learned value.</i>
Dirty or heavy exhaust smoke	Too much engine oil.	<i>Check with inspection window, drain out excess oil.</i>
	Worn piston ring or cylinder.	<i>Replace.</i>
	Worn valve guide.	<i>Replace.</i>
	Scored or scuffed cylinder wall.	<i>Replace.</i>
	Worn valve stem.	<i>Replace.</i>
	Defective stem seal.	<i>Replace.</i>
	Worn oil ring side rail.	<i>Replace.</i>

Self-Diagnostic Procedures

B815H21104002

Use of Mode Select Switch

NOTE

- Do not disconnect the coupler from ECM, battery cable from battery, ECM ground wire from engine or main fuse before confirming DTC (Diagnostic Trouble Code) stored in memory. Such disconnection will erase memorized information in ECM memory.
- DTC stored in ECM memory can be checked by the special tool.
- Before checking DTC, read self-diagnosis function "User mode and dealer mode" (Refer to "Self-Diagnosis Function (Page 1A-2)".) carefully to have good understanding as to what functions are available and how to use it.
- Be sure to read "Precautions for Electrical Circuit Service" (Refer to "Precautions for Electrical Circuit Service in Section 00 (Page 00-2)".) before inspection and observe what is written there.

- 1) Remove the front seat. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Connect the special tool to the mode select switch coupler at the wiring harness.

Special tool

 (A): 09930-82720 (Mode select switch)




I815H1110008-01

- 3) Start the engine or crank the engine for more than 4 seconds.
- 4) Turn the special tool's switch ON.

- 5) Check the DTC to determine the malfunction part. Refer to "DTC Table (Page 1A-20)".

Special tool

 (A): 09930-82720 (Mode select switch)



I718H1110006-04



I815H1110009-01

- 6) After repairing the trouble, turn OFF the ignition switch and turn ON again. If DTC is indicated (C00), the malfunction is cleared.

NOTE

- Even though DTC (C00) is indicated, the previous malfunction history DTC still remains stored in the ECM. Therefore, erase the history DTC memorized in the ECM using SDS.
- DTC is memorized in the ECM also when the lead wire coupler of any sensor is disconnected. Therefore, when a lead wire coupler has been disconnected at the time of diagnosis, erase the stored history DTC using SDS. Refer to "Use of SDS Diagnosis Reset Procedures (Page 1A-14)".

- 7) Turn the ignition switch OFF and disconnect the special tool from the mode select switch coupler.
- 8) Reinstall the front seat.

Use of SDS

NOTE

- Do not disconnect the coupler from ECM, battery cable from battery, ECM ground wire from the engine or main fuse before confirming DTC (Diagnostic Trouble Code) stored in memory. Such disconnection will erase the memorized information in ECM memory.
- DTC stored in ECM memory can be checked by SDS.
- Be sure to read “Precautions for Electrical Circuit Service in Section 00 (Page 00-2)” before inspection and observe what is written there.

- 1) Remove the front seat. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.

- 2) Set up the SDS tools. (Refer to the SDS operation manual for further details.)



Special tool

 (A): 09904-41010 (SDS Set)

 (B): 99565-01010-012 (CD-ROM Ver.12)




I815H1110010-01



I705H1110116-03

- 3) Click the DTC inspection button (1).



I705H1110003-01

- 4) Start the engine or crank the engine for more than 4 seconds.
 5) Check the DTC to determine the malfunction part. Refer to "DTC Table (Page 1A-20)".

NOTE

- Read the DTC (Diagnostic Trouble Code) and show data when trouble (displaying data at the time of DTC) according to instructions displayed on SDS.
- Not only SDS is used for detecting Diagnostic Trouble Codes but also for reproducing and checking on screen the failure condition as described by customers using the trigger. (Refer to "Show Data When Trouble (Displaying Data at the Time of DTC) (Page 1A-15)".)
- How to use trigger. (Refer to the SDS operation manual for further details.)

- 6) After repairing the trouble, clear to delete history code (Past DTC). Refer to "Use of SDS Diagnosis Reset Procedures (Page 1A-14)".
 7) Close the SDS tool and turn the ignition switch OFF.
 8) Disconnect the SDS tool and install the front seat.


Use of SDS Diagnosis Reset Procedures

B815H21104003

NOTE


The malfunction code is memorized in the ECM also when the lead wire coupler of any sensor is disconnected. Therefore, when a lead wire coupler has been disconnected at the time of diagnosis, erase the stored malfunction history code using SDS.

- 1) After repairing the trouble, turn OFF the ignition switch and turn ON again.
 2) Click the DTC inspection button (1).




I705H1110003-01

- 3) Check the DTC.
 4) The previous malfunction history code (Past DTC) still remains stored in the ECM. Therefore, erase the history code memorized in the ECM using SDS tool.
 5) Click "Clear" (2) to delete history code (Past DTC).



I705H1110005-01

6) Follow the displayed instructions.




I705H1110006-01



I705H1110009-01

7) Check that both "Current DTC" (3) and "Past DTC" (4) are deleted (NIL).



I705H1110008-01

8) Close the SDS tool and turn the ignition switch OFF.
9) Disconnect the SDS tool and install the front seat.

Show Data When Trouble (Displaying Data at the Time of DTC)

B815H21104004


Use of SDS

ECM stores the engine and driving conditions (in the form of data as shown in the figure) at the moment of the detection of a malfunction in its memory. This data is called "Show data when trouble". Therefore, it is possible to know engine and driving conditions (e.g., whether the engine was warm or not, where the motorcycle was running or stopped) when a malfunction was detected by checking the show data when trouble. This show data when trouble function can record the maximum of two Diagnostic Trouble Codes in the ECM. Also, ECM has a function to store each show data when trouble for two different malfunctions in the order of occurrence as the malfunction is detected. Utilizing this function, it is possible to know the order of malfunctions that have been detected. Its use is helpful when rechecking or diagnosing a trouble.

Failure #1				
P0105-H Manifold absolute pressure circuit malfunction 1				
Item	Pre-detect	Detect poi...	Post-dete...	
Engine speed	0	0	0	
Throttle position	28.9	28.9	28.9	
Manifold absolute pressure 1	135.2	144.3	145.6	
Engine coolant / oil temperature	24.0	24.0	24.0	
Gear position	N	N	N	
Secondary throttle actuator position sensor	96.1	96.1	98.4	


I705H1110010-01

1) Click "Show data when trouble" (1) to display the data.



I718H1110269-02

2) Click the drop down button (2), either "Failure #1" or "Failure #2" can be selected.



I718H1110270-01

SDS Check

Using SDS, sample the data at the time of new and periodic vehicle inspections.

After saving the sampled data in the computer, file them by model and by user.

The periodically filed data help improve the accuracy of troubleshooting since they can indicate the condition of vehicle functions that has changed with time.

For example, when a vehicle is brought in for service but the troubleshooting of a failure is not easy, comparing the current data value to past filed data value at time of normal condition can allow the specific engine failure to be determined.

Also, in the case of a customer vehicle which is not periodically brought in for service with no past data value having been saved, if the data value of a good vehicle condition have been already saved as a master (STD), comparison between the same models helps to facilitate the troubleshooting.

- 1) Remove the front seat. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Set up the SDS tool. (Refer to the SDS operation manual for further details.)

Special tool

 : 09904-41010 (SDS set)


 : 99565-01010-012 (CD-ROM Ver.12)

NOTE


- Before taking the sample of data, check and clear the Past DTC.
- A number of different data under a fixed condition as shown should be saved or filed as sample.

Sample

Data sampled from cold starting through warm-up




Data at 3 000 r/min under no load



I823H1110209-02


Data at the time of racing



I823H1110210-02


1A-19 Engine General Information and Diagnosis:

Data of intake negative pressure during idling (100 °C)



I823H1110211-01

Data of manifold absolute pressure operation at the time of starting




I823H1110212-02

Example of Trouble

Three data; value 1 (current data 1), value 2 (past data 2) and value 3 (past data 3); can be made in comparison by showing them in the graph. Read the change of value by comparing the current data to the past data that have been saved under the same condition, then you may determine how changes have occurred with the passing of time and identify what problem is currently occurring.

NOTE

With DTC not output, if the engine idling speed and ISC valve stepping position are found to be abnormal than the data saved previously, the possible cause may probably lie in the hardware side such as ISC valve air inlet hose crumple, bend, etc.



I815H1110001-02

DTC Table

B815H21104006

Code	Malfunction Part	Remarks
C00	None	No defective part
C11 (P0340) ☞ (Page 1A-28)	Camshaft position sensor (CMPS)	
C12 (P0335) ☞ (Page 1A-30)	Crankshaft position sensor (CKPS)	Pick-up coil signal, signal generator
C13 (P0105-H/L) ☞ (Page 1A-33)	Intake air pressure sensor (IAPS)	
C14 (P0120-H/L) ☞ (Page 1A-40)	Throttle position sensor (TPS)	*1
C15 (P0115-H/L) ☞ (Page 1A-47)	Engine coolant temperature sensor (ECTS)	
C21(P0110-H/L) ☞ (Page 1A-52)	Intake air temperature sensor (IATS)	
C22(P1450-H/L) ☞ (Page 1A-57)	Atmospheric pressure sensor (APS)	

1A-21 Engine General Information and Diagnosis:

Code	Malfunction Part	Remarks
C23 (P1651-H/L) ☞(Page 1A-64)	Tip-over sensor (TOS)	
C24 (P0351) ☞(Page 1A-71)	Ignition signal #1 (IG coil #1)	For #1 cylinder
C25 (P0352) ☞(Page 1A-71)	Ignition signal #2 (IG coil #2)	For #2 cylinder
C26 (P0353) ☞(Page 1A-71)	Ignition signal #3 (IG coil #3)	For #3 cylinder
C27 (P0354) ☞(Page 1A-71)	Ignition signal #4 (IG coil #4)	For #4 cylinder
C28 (P1655) ☞(Page 1A-71)	Secondary throttle valve actuator (STVA)	
C29 (P1654-H/L) ☞(Page 1A-75)	Secondary throttle position sensor (STPS)	
C31 (P0705) ☞(Page 1A-82)	Gear position signal (GP switch)	
C32 (P0201) ☞(Page 1A-84)	Primary Injector signal #1	For #1 cylinder
C33 (P0202) ☞(Page 1A-84)	Primary Injector signal #2	For #2 cylinder
C34 (P0203) ☞(Page 1A-84)	Primary Injector signal #3	For #3 cylinder
C35 (P0204) ☞(Page 1A-84)	Primary Injector signal #4	For #4 cylinder
C36 (P1764) ☞(Page 1A-88)	Secondary Injector signal #1	For #1 cylinder
C37 (P1765) ☞(Page 1A-88)	Secondary Injector signal #2	For #2 cylinder
C38 (P1766) ☞(Page 1A-88)	Secondary Injector signal #3	For #3 cylinder
C39 (P1767) ☞(Page 1A-88)	Secondary Injector signal #4	For #4 cylinder
C40 (P0505/P0506/ P0507) ☞(Page 1A-92)	Idle speed control valve (ISC valve)	
C41 (P0230-H/L, P2505) ☞(Page 1A-97) / ☞(Page 1A-100)	Fuel pump control system (FP control system), ECM/PCM power input signal	Fuel pump, fuel pump relay
C42 (P1650) ☞(Page 1A-102)	Ignition switch signal (Anti-theft)	Ignition switch for E-03, 28, 33/immobilizer for E-02, 19, 24
C44 (P0130, P0135) ☞(Page 1A-102)	Heated oxygen sensor (HO2S)	
C49 (P1656) ☞(Page 1A-108)	PAIR control solenoid valve	
C60 (P0480) ☞(Page 1A-112)	Cooling fan control system	Cooling fan relay
C62 (P0443) ☞(Page 1A-115)	EVAP system purge control solenoid valve	E-33 only

In the LCD (DISPLAY) panel, the malfunction code is indicated from small code to large code.

*1 To get the proper signal from the throttle position sensor, the sensor basic position is indicated in the LCD (DISPLAY) panel. The malfunction code is indicated in three digits. In front of the three digits, a line appears in any of the three positions, upper, middle or lower line. If the indication is upper or lower line when engine rpm is 1 150 r/min, slightly turn the throttle position sensor and bring the line to the middle.

Fail-Safe Function Table

FI system is provided with fail-safe function to allow the engine to start and the motorcycle to run in a minimum performance necessary even under malfunction condition.

Item	Fail-Safe Mode	Starting Ability	Running Ability
CMP sensor	When camshaft position signal has failed during running, the ECM determines the cylinder positions as # to be the same as before occurrence of such a failure.	"NO"	"YES"
IAP sensor	Intake air pressure value is fixed to 101 kPa (760 mmHg).	"YES"	"YES"
TP sensor	The throttle opening is fixed to full open position. Ignition timing is also fixed.	"YES"	"YES"
ECT sensor	Engine coolant temperature value is fixed to 80 °C (176 °F). Cooling fan is fixed on position.	"YES"	"YES"
IAT sensor	Intake air temperature value is fixed to 40 °C (104 °F).	"YES"	"YES"
AP sensor	Atmospheric pressure is fixed to 101 kPa (760 mmHg).	"YES"	"YES"
Ignition signal	#1 fuel-cut (primary side and secondary side)	"YES"	"YES"
	#2 fuel-cut (primary side and secondary side)	"YES"	"YES"
	#3 fuel-cut (primary side and secondary side)	"YES"	"YES"
	#4 fuel-cut (primary side and secondary side)	"YES"	"YES"
	#1, #2 & #4 cylinders can run.	"YES"	"YES"
	#1, #2 & #3 cylinders can run.	"YES"	"YES"
Primary injection signal	—	"YES"	"YES"
	—	"YES"	"YES"
	—	"YES"	"YES"
	—	"YES"	"YES"
	—	"YES"	"YES"
	—	"YES"	"YES"
Secondary injection signal	—	"YES"	"YES"
	—	"YES"	"YES"
	—	"YES"	"YES"
	—	"YES"	"YES"
	—	"YES"	"YES"
	—	"YES"	"YES"
STV actuator	Secondary throttle valve is fixed to full close position, then turns back full open position with spring. When motor disconnection or lock occurs, power from ECM is shut off.	"YES"	"YES"
STP sensor	Secondary throttle valve is fixed to full open position.	"YES"	"YES"
Gear position signal	Gear position signal is fixed to 6th gear.	"YES"	"YES"
HO2 sensor	Feedback compensation is inhibited. (Air/fuel ratio is fixed to normal.)	"YES"	"YES"
PAIR control solenoid valve	ECM stops controlling PAIR control solenoid valve.	"YES"	"YES"
ISC valve	When motor disconnection or lock occurs, power from ECM is shut off.	"YES"	"YES"
EVAP system purge control solenoid valve (E-33 only)	ECM stops controlling EVAP system purge control solenoid valve.	"YES"	"YES"

1A-23 Engine General Information and Diagnosis:

The engine can start and can run even if the signal in the table is not received from each sensor. But, the engine running condition is not complete, providing only emergency help (by fail-safe circuit). In this case, it is necessary to bring the motorcycle to the workshop for complete repair.

When two ignition signals or two injector signals are not received by ECM, the fail-safe circuit can not work and ignition or injection is stopped.

FI System Troubleshooting

B815H21104008

Customer Complaint Analysis

Record details of the problem (failure, complaint) and how it occurred as described by the customer. For this purpose, use of such an inspection form such as following will facilitate collecting information to the point required for proper analysis and diagnosis.

NOTE

This form is a standard sample. The form should be modified according to conditions and characteristic of each market.

EXAMPLE: CUSTOMER PROBLEM INSPECTION FORM

User name:	Model:	VIN:	
Date of issue:	Date Reg.:	Date of problem:	Mileage:

Malfunction indicator light condition (LED)	☐ Always ON / ☐ Sometimes ON / ☐ Always OFF / ☐ Good condition
Malfunction display/code (LCD)	User mode: ☐ No display / ☐ Malfunction display ()
	Dealer mode: ☐ No code / ☐ Malfunction code ()

PROBLEM SYMPTOMS	
☐ Difficult Starting ☐ No cranking ☐ No initial combustion ☐ No combustion ☐ Poor starting at (☐ cold / ☐ warm / ☐ always) ☐ Other	☐ Poor Driveability ☐ Hesitation on acceleration ☐ Back fire / ☐ After fire ☐ Lack of power ☐ Surging ☐ Abnormal knocking ☐ Engine rpm jumps briefly ☐ Other
☐ Poor Idling ☐ Poor fast Idle ☐ Abnormal idling speed (☐ High / ☐ Low) (r/min) ☐ Unstable ☐ Hunting (r/min to r/min) ☐ Other	☐ Engine Stall when ☐ Immediately after start ☐ Throttle valve is opened ☐ Throttle valve is closed ☐ Load is applied ☐ Other
☐ OTHERS:	

MOTORCYCLE/ENVIRONMENTAL CONDITION WHEN PROBLEM OCCURS	
Environmental condition	
Weather	☐ Fair / ☐ Cloudy / ☐ Rain / ☐ Snow / ☐ Always / ☐ Other
Temperature	☐ Hot / ☐ Warm / ☐ Cool / ☐ Cold (°C / °F) / ☐ Always
Frequency	☐ Always / ☐ Sometimes (times / day, month) / ☐ Only once ☐ Under certain condition
Road	☐ Urban / ☐ Suburb / ☐ Highway / ☐ Mountainous (☐ Uphill / ☐ Downhill) ☐ Tarmacadam / ☐ Gravel / ☐ Other
Motorcycle condition	
Engine condition	☐ Cold / ☐ Warming up phase / ☐ Warmed up / ☐ Always / ☐ Other at starting ☐ Immediately after start / ☐ Racing without load / ☐ Engine speed (r/min)
Motorcycle condition	During driving: ☐ Constant speed / ☐ Accelerating / ☐ Decelerating ☐ Right hand corner / ☐ Left hand corner ☐ At stop / ☐ Motorcycle speed when problem occurs (km/h, mile/h) ☐ Other:

Visual Inspection

Prior to diagnosis using the mode select switch or SDS, perform the following visual inspections. The reason for visual inspection is that mechanical failures (such as oil leakage) cannot be displayed on the screen with the use of mode select switch or SDS.

- Engine oil level and leakage. Refer to “Engine Oil and Filter Replacement in Section 0B (Page 0B-10)”.
- Engine coolant level and leakage. Refer to “Cooling Circuit Inspection in Section 1F (Page 1F-4)”.
- Fuel level and leakage. Refer to “Fuel Line Inspection in Section 0B (Page 0B-10)”.
- Clogged air cleaner element. Refer to “Air Cleaner Element Inspection in Section 0B (Page 0B-3)”.
- Battery condition.
- Throttle cable play. Refer to “Throttle Cable Play Inspection and Adjustment in Section 0B (Page 0B-12)”.
- Vacuum hose looseness, bend and disconnection.
- Broken fuse.
- FI indicator light operation. Refer to “Combination Meter Inspection in Section 9C (Page 9C-3)”.
- Each warning indicator light operation. Refer to “Combination Meter Inspection in Section 9C (Page 9C-3)”.
- Speedometer operation. Refer to “Speedometer Inspection in Section 9C (Page 9C-6)”.
- Exhaust gas leakage and noise. Refer to “Exhaust System Inspection in Section 1K (Page 1K-7)”.
- Each coupler disconnection.
- Clogged radiator fins. Refer to “Radiator Inspection and Cleaning in Section 1F (Page 1F-5)”.

Malfunction Code and Defective Condition Table

B815H21104009

Malfunction Code		Detected Item	Detected Failure Condition	Check For
C00		NO FAULT	—	—
C11		CMP sensor	The signal does not reach ECM for 4 sec. or more, after receiving the starter signal.	CMP sensor wiring and mechanical parts CMP sensor, intake cam pin, wiring/coupler connection
P0340				
C12		CKP sensor	The signal does not reach ECM for 4 sec. or more, after receiving the starter signal.	CKP sensor wiring and mechanical parts CKP sensor, lead wire/coupler connection
P0335				
C13		IAP sensor	The sensor should produce following voltage. 0.5 V ≤ Sensor voltage < 4.85 V In other than the above range, C13 (P0105) is indicated.	IAP sensor, lead wire/coupler connection
P0105	H		Sensor voltage is higher than specified value.	IAP sensor circuit shorted to VCC or ground circuit open
	L		Sensor voltage is lower than specified value.	IAP sensor circuit open or shorted to ground or VCC circuit open
C14		TP sensor	The sensor should produce following voltage. 0.2 V ≤ Sensor voltage < 4.8 V In other than the above range, C14 (P0120) is indicated.	TP sensor, lead wire/coupler connection
P0120	H		Sensor voltage is higher than specified value.	TP sensor circuit shorted to VCC or ground circuit open
	L		Sensor voltage is lower than specified value.	TP sensor circuit open or shorted to the ground or VCC circuit open

Malfunction Code		Detected Item	Detected Failure Condition	Check For
C15		ECT sensor	The sensor voltage should be the following. $0.15\text{ V} \leq \text{Sensor voltage} < 4.85\text{ V}$ In other than the above range, C15 (P0115) is indicated.	ECT sensor, lead wire/coupler connection
P0115	H		Sensor voltage is higher than specified value.	ECT sensor circuit open or ground circuit open
	L		Sensor voltage is lower than specified value.	ECT sensor circuit shorted to the ground
C21		IAT sensor	The sensor voltage should be the following. $0.15\text{ V} \leq \text{Sensor voltage} < 4.85\text{ V}$ In other than the above range, C21 (P0110) is indicated.	IAT sensor, lead wire/coupler connection
P0110	H		Sensor voltage is higher than specified value.	IAT sensor circuit open or ground circuit open
	L		Sensor voltage is lower than specified value.	IAT sensor circuit shorted to the ground
C22		AP sensor	The sensor voltage should be the following. $0.5\text{ V} \leq \text{Sensor voltage} < 4.85\text{ V}$ In other than the above range, C22 (P1450) is indicated.	AP sensor, lead wire/coupler connection
P1450	H		Sensor voltage is higher than specified value.	AP sensor circuit shorted to VCC or ground circuit open
	L		Sensor voltage is lower than specified value.	AP sensor circuit open or shorted to ground or VCC circuit open
C23		TO sensor	The sensor voltage should be the following for 2 sec. and more, after ignition switch is turned ON. $0.2\text{ V} \leq \text{Sensor voltage} < 4.8\text{ V}$ In other than the above value, C23 (P1651) is indicated.	TO sensor, lead wire/coupler connection
P1651	H		Sensor voltage is higher than specified value.	TO sensor circuit shorted to VCC or ground circuit open
	L		Sensor voltage is lower than specified value.	TO sensor circuit open or shorted to the ground or VCC circuit open
C24/C25 C26/C27		Ignition signal	CKP sensor (pick-up coil) signal is produced, but signal from ignition coil is interrupted 8 times or more continuously. In this case, the code C24 (P0351), C25 (P0352), C26 (P0353) or C27 (P0354) is indicated.	Ignition coil, wiring/coupler connection, power supply from the battery
P0351/P0352 P0353/P0354				
C28		STV actuator	When no actuator control signal is supplied from the ECM, communication signal does not reach ECM or operation voltage does not reach STVA motor, C28 (P1655) is indicated. STVA can not operate properly or its motor locked.	STVA motor, STVA lead wire/ coupler connection
P1655				
C29		STP sensor	The sensor should produce following voltage. $0.15\text{ V} \leq \text{Sensor voltage} < 4.85\text{ V}$ In other than the above range, C29 (P1654) is indicated.	STP sensor, lead wire/coupler connection
P1654	H		Sensor voltage is higher than specified value.	STP sensor circuit shorted to VCC or ground circuit open
	L		Sensor voltage is lower than specified value.	STP sensor circuit open or shorted to the ground or VCC circuit open

1A-27 Engine General Information and Diagnosis:

Malfunction Code		Detected Item	Detected Failure Condition	Check For
C31		Gear position signal	Gear position signal voltage should be higher than the following for 3 seconds and more. Gear position sensor voltage ≥ 0.6 V If lower than the above value, C31 (P0705) is indicated.	GP switch, wiring/coupler connection, gearshift cam, etc.
P0705				
C32/C33 C34/C35		Primary fuel injector	CKP sensor (pickup coil) signal is produced, but fuel injector signal is interrupted 4 times or more continuously. In this case, the code C32 (P0201), C33 (P0202), C34 (P0203) or C35 (P0204) is indicated.	Primary fuel injector, wiring/ coupler connection, power supply to the injector
P0201/P0202 P0203/P0204				
C36/C37 C38/C39		Secondary fuel injector	Some failure exists in the fuel injector signal in a high load, high revolution condition. In this case, the code C36 (P1764), C37 (P1765), C38 (P1766) or C39 (P1767) is indicated.	Secondary fuel injector, wiring/ coupler connection, power supply to the injector
P1764/P1765 P1766/P1767				
C40/P0505		ISC valve	The circuit voltage of motor drive is unusual.	ISC valve circuit open or shorted to the ground Power source circuit open
C40/P0506			Idle speed is lower than the desired idle speed.	Air passage clogged ISC valve is fixed ISC valve preset position is incorrect
C40/P0507			Idle speed is higher than the desired idle speed.	ISC valve hose connection ISC valve is fixed ISC valve preset position is incorrect
C41		FP relay	No voltage is applied to the fuel pump, although fuel pump relay is turned ON, or voltage is applied to fuel pump although fuel pump relay is turned OFF.	Fuel pump relay, lead wire/ coupler connection, power source to fuel pump relay and fuel injectors
P0230	H		Voltage is applied to fuel pump although fuel pump relay is turned OFF.	Fuel pump relay switch circuit shorted to power source Fuel pump relay (switch side)
	L		No voltage is applied to the fuel pump, although fuel pump relay is turned ON.	Fuel pump relay circuit open or short Fuel pump relay (coil side)
C41/P2505		ECM/PCM power input signal	No voltage is applied to the ECM.	Lead wire/coupler connection of ECM terminal to fuel fuse
C42		Ignition switch	Ignition switch signal is not input to the ECM. * When the I.D. agreement is not verified. * ECM does not receive communication signal from the immobilizer antenna.	Ignition switch, lead wire/ coupler, etc. * Immobilizer/anti-theft system
P1650				
C44/P0130		HO2 sensor	HO2 sensor output voltage is not input to ECM during engine operation and running condition. (Sensor voltage > 1.0 V) C44 (P0130) is indicated.	HO2 sensor is circuit open or shorted to the power source
C44/P0135			The Heater can not operate so that heater operation voltage is not supply to the oxygen heater circuit, C44 (P0135) is indicated.	Heated circuit open or shorted to the ground Battery voltage supply to the HO2 sensor
C49 P1656		PAIR control solenoid valve	PAIR control solenoid valve voltage is not input to ECM.	PAIR control solenoid valve, lead wire/coupler connection
C60 P0480		Cooling fan relay	Cooling fan relay signal is not input to ECM.	Cooling fan relay, lead wire/ coupler connection
C62 P0443		EVAP system purge control solenoid valve (E-33 only)	EVAP system purge control solenoid valve voltage is not input to ECM.	EVAP system purge control solenoid valve, lead wire/ coupler connection

* : Immobilizer system equipped model only. (E-02, 19, 24)


DTC “C11” (P0340) CMP Sensor Circuit Malfunction

B815H21104010

Detected Condition and Possible Cause


Detected Condition	Possible Cause
The signal does not reach ECM for 4 sec. or more, after receiving the starter signal.	<ul style="list-style-type: none">• CMP sensor circuit open or short.• CMP sensor malfunction.• ECM malfunction.

Wiring Diagram



I823H1110003-07

ECM coupler (Harness side)



I823H1110004-01




Troubleshooting

CAUTION

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent the terminal damage or terminal bend.

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to “Use of SDS Diagnosis Reset Procedures (Page 1A-14)”.

Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".</div> <div>3) Check the CMP sensor coupler (1) for loose or poor contacts. If OK, remove the CMP sensor. Refer to "CMP Sensor Removal and Installation in Section 1C (Page 1C-2)".</div> <div><div>I815H1110023-01</div></div> <div>4) Connect 3 new 1.5 V batteries in series, 1 kΩ resistor and the multi-circuit tester as shown in the figure.</div> <div><div>Special tool</div><div> 09900-25008 (Multi-circuit tester set)</div><div><u>Tester knob indication</u></div><div>Voltage (---)</div><div><div>I823H1110005-04</div></div><div>5) Under this condition, if a suitable screwdriver touching the pick-up surface of the CMP sensor is moved, the tester reading voltage changes (0.8 V and less ↔ 4.3 V and more).</div><div><div>I823H1110007-01</div></div><div>Is the voltage OK?</div></div>	<ul style="list-style-type: none">• B/Y, R or B/Br wire open or shorted to the ground.• Loose or poor contacts on the CMP sensor coupler or ECM coupler (Terminal "11", "13" or "29").• If wires and connection are OK, intermittent trouble or faulty ECM.• Recheck each terminal and wire harness for open circuit and poor connection.• Replace the ECM with a known good one, and inspect it again.	<ul style="list-style-type: none">• Inspect that metal particles or foreign material stuck on the CMP sensor and camshaft tip.• If there are no metal particles and foreign material, then replace the CMP sensor with a new one.


DTC “C12” (P0335): CKP Sensor Circuit Malfunction

B815H21104011

Detected Condition and Possible Cause


Detected Condition	Possible Cause
The signal does not reach ECM for 4 sec. or more, after receiving the starter signal.	<ul style="list-style-type: none">• Metal particles or foreign material being stuck on the CKP sensor and rotor tip.• CKP sensor circuit open or short.• CKP sensor malfunction.• ECM malfunction.

Wiring Diagram



I815H1110022-01

ECM coupler (Harness side)



I823H1110004-01


Troubleshooting



CAUTION

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent the terminal damage or terminal bend.

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to “Use of SDS Diagnosis Reset Procedures (Page 1A-14)”.

Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Lift and support the fuel tank. Refer to “Fuel Tank Removal and Installation in Section 1G (Page 1G-9)”.</div> <div>3) Check the CKP sensor coupler (1) for loose or poor contacts. If OK, then measure the CKP sensor resistance.</div> <div><p>i823H1110010-01</p></div> <div>4) Disconnect the CKP sensor coupler and measure the CKP sensor resistance.</div> <div><div>Special tool</div><div> (A): 09900-25008 (Multi-circuit tester set)</div><div><u>Tester knob indication</u></div><div>Resistance (Ω)</div><div><u>CKP sensor resistance</u></div><div>180 – 280 Ω (BI – G)</div><div><p>i823H1110011-01</p></div></div>	Go to Step 2.	Replace the CKP sensor with a new one.

Step	Action	Yes	No
1	<p>5) If OK, then check the continuity between each terminal and ground.</p> <p>Special tool  (A): 09900-25008 (Multi-circuit tester set)</p> <p>CKP sensor continuity $\infty \Omega$ (Infinity) (BI – Ground, G – Ground)</p>  <p style="text-align: right;">I823H1110012-01</p> <p><i>Are the resistance and continuity OK?</i></p>	Go to Step 2.	Replace the CKP sensor with a new one.
2	<p>1) Crank the engine several seconds with the starter motor, and measure the CKP sensor peak voltage at the coupler.</p> <p>Special tool  (A): 09900-25008 (Multi-circuit tester set)</p> <p>Tester knob indication Voltage (---)</p> <p>CKP sensor peak voltage 3.0 V and more ((+) terminal: BI – (–) terminal: G)</p>  <p style="text-align: right;">I823H1110014-02</p> <p>2) Repeat the 1) test procedures several times and measure the highest peak voltage.</p> <p><i>Is the voltage OK?</i></p>	<ul style="list-style-type: none"> • G or BI wire of the harness side open or shorted to the ground. • Loose or poor contacts on the CKP sensor coupler or ECM coupler (Terminal “14” or “31”). • If the wires and connection are OK, intermittent trouble or faulty ECM. • Recheck each terminal and wire harness for open circuit and poor connection. • Replace the ECM with a known good one, and inspect it again. Refer to “ECM Removal and Installation in Section 1C (Page 1C-2)”. 	<ul style="list-style-type: none"> • Inspect that metal particles or foreign material stuck on the CKP sensor and rotor tip. • If there are no metal particles and foreign material, then replace the CKP sensor with a new one. Refer to “CMP Sensor Removal and Installation in Section 1C (Page 1C-2)”.


DTC “C13” (P0105-H/L): IAP Sensor Circuit Malfunction

B815H21104012


Detected Condition and Possible Cause

Detected Condition		Possible Cause
C13	IAP sensor voltage is not within the following range. 0.5 V ≤ Sensor voltage < 4.85 V	<ul style="list-style-type: none">• Clogged vacuum passage between throttle body and IAP sensor.• Air being drawn from vacuum passage between throttle body and IAP sensor.• IAP sensor circuit open or shorted to the ground.• IAP sensor malfunction.• ECM malfunction.
	NOTE Note that atmospheric pressure varies depending on weather conditions as well as altitude. Take that into consideration when inspecting voltage.	
P0105	H Sensor voltage is higher than specified value.	<ul style="list-style-type: none">• IAP sensor circuit is open or shorted to VCC or ground circuit open.• IAP sensor circuit is shorted to the ground or VCC circuit open.
	L Sensor voltage is lower than specified value.	

Wiring Diagram



ECM coupler (Harness side)



Troubleshooting



CAUTION

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent the terminal damage or terminal bend.


NOTE


After repairing the trouble, clear the DTC using SDS tool. Refer to “Use of SDS Diagnosis Reset Procedures (Page 1A-14)”.

C13 (Use of mode select switch)



Step	Action	Yes	No
1	<p>1) Turn the ignition switch OFF.</p> <p>2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".</p> <p>3) Check the IAP sensor coupler (1) for loose or poor contacts. If OK, then measure the IAP sensor input voltage.</p>  <p style="text-align: right; font-size: small;">I823H1110015-01</p> <p>4) Disconnect the IAP sensor coupler.</p> <p>5) Turn the ignition switch ON.</p> <p>6) Measure the input voltage between the R wire and ground. If OK, then measure the voltage between the R wire and B/Br wire.</p> <p>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set)</p> <p>Tester knob indication Voltage (---)</p> <p>IAP sensor input voltage 4.5 – 5.5 V ((+) terminal: R – (–) terminal: Ground, (+) terminal: R – (–) terminal: B/Br)</p>  <p style="text-align: right; font-size: small;">I823H1110016-05</p> <p><i>Is the voltage OK?</i></p>	Go to Step 2.	<ul style="list-style-type: none"> Loose or poor contacts on the ECM coupler. Open or short circuit in the R or B/Br wire.



P0105-H for IAP sensor (Use of SDS)


Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Lift and support the fuel tank. Refer to “Fuel Tank Removal and Installation in Section 1G (Page 1G-9)”.</div> <div>3) Check the IAP sensor coupler (1) for loose or poor contacts. If OK, then check the IAP sensor lead wire continuity.</div> <div></div> <div>I823H1110015-01</div> <div>4) Disconnect the IAP sensor coupler.</div> <div>5) Check the continuity between the R wire and G/B wire. If the sound is not heard from the tester, the circuit condition is OK.</div> <div>Special tool  (A): 09900–25008 (Multi-circuit tester set)</div> <div><u>Tester knob indication</u> Continuity (••))</div> <div></div> <div>I823H1110017-05</div> <td>Go to Step 3.</td> <td>G/B wire shorted to VCC, or B/Br wire open.</td>	Go to Step 3.	G/B wire shorted to VCC, or B/Br wire open.

Step	Action	Yes	No
1	<p>6) Disconnect the ECM coupler. Refer to "ECM Removal and Installation in Section 1C (Page 1C-2)".</p> <p>7) Insert the needle pointed probes to the lead wire coupler.</p> <p>8) Check the continuity between the G/B wire and terminal "9".</p> <p>If OK, then check the continuity between the B/Br wire and terminal "29".</p> <p>Special tool</p> <p> (A): 09900-25008 (Multi-circuit tester set)</p> <p> (B): 09900-25009 (Needle pointed probe set)</p> <p>Tester knob indication</p> <p>Continuity test (•)))</p> <p>ECM couplers (Harness side)</p>  <p style="text-align: right;">I823H1110018-04</p> <p><i>Is the continuity OK?</i></p>	Go to Step 3.	G/B wire shorted to VCC, or B/Br wire open.

P0105-L for IAP sensor (Use of SDS)

Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".</div> <div>3) Check the IAP sensor coupler (1) for loose or poor contacts. If OK, then check the IAP sensor lead wire continuity.</div> <div></div> <div>I823H1110015-01</div> <div>4) Disconnect the IAP sensor coupler.</div> <div>5) Check the continuity between the G/B wire and ground. Also, check the continuity between the G/B wire and B/Br wire. If the sound is not heard from the tester, the circuit condition is OK.</div> <div>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set)</div> <div>Tester knob indication Continuity (••)))</div> <div></div> <div>I823H1110019-02</div>	Go to Step 2.	R and G/B wire open, G/B wire shorted to the ground.

Step	Action	Yes	No
1	<p>6) Disconnect the ECM coupler. Refer to "ECM Removal and Installation in Section 1C (Page 1C-2)".</p> <p>7) Insert the needle pointed probes to the lead wire coupler.</p> <p>8) Check the continuity between the R wire and terminal "11". Also, check the continuity between the G/B wire and terminal "9".</p> <p>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set) TOOL (B): 09900-25009 (Needle pointed probe set)</p> <p>Tester knob indication Continuity (•)))</p> <p>ECM couplers (Harness side)</p>  <p style="text-align: right;">I823H1110020-05</p> <p><i>Is the continuity OK?</i></p>	Go to Step 2.	R and G/B wire open, G/B wire shorted to the ground.
2	<p>1) Turn the ignition switch OFF.</p> <p>2) Connect the ECM coupler and IAP sensor coupler.</p> <p>3) Insert the needle pointed probes to the lead wire coupler.</p> <p>4) Run the engine at idle speed and measure the IAP sensor output voltage between the G/B wire and B/Br wire.</p> <p>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set) TOOL (B): 09900-25009 (Needle pointed probe set)</p> <p>Tester knob indication Voltage (---)</p> <p>IAP sensor output voltage Approx. 2.7 V at idle speed ((+) terminal: G/B – (–) terminal: B/Br)</p>  <p style="text-align: right;">I823H1110022-02</p> <p><i>Is the voltage OK?</i></p>	Go to Step 3.	<ul style="list-style-type: none"> • Check the vacuum hose for crack or damage. • Open or short circuit in the G/B wire. • If vacuum hose and wire are OK, replace the IAP sensor with a new one. Refer to "IAP Sensor Removal and Installation in Section 1C (Page 1C-3)".

Step	Action	Yes	No																												
3	<div>1) Turn the ignition switch OFF.</div> <div>2) Remove the IAP sensor. Refer to "IAP Sensor Removal and Installation in Section 1C (Page 1C-3)".</div> <div>3) Connect the vacuum pump gauge to the vacuum port of the IAP sensor.</div> <div>4) Arrange 3 new 1.5 V batteries in series (1) (check that total voltage is 4.5 – 5.0 V) and connect (–) terminal to the ground terminal "B" and (+) terminal to the VCC terminal "A".</div> <div>5) Check the voltage between Vout terminal "C" and ground. Also, check if voltage reduces when vacuum is applied by using vacuum pump gauge.</div> <div>Special tool  (A): 09917–47011 (Vacuum pump gauge)  (B): 09900–25008 (Multi-circuit tester set) <u>Tester knob indication</u> Voltage (---)</div> <div></div> <div>I718H1110030-02</div> <div><table><tr><th colspan="2">ALTITUDE (Reference)</th><th colspan="2">ATOMOSPHERIC PRESSURE</th><th>OUTPUT VOLTAGE</th></tr><tr><th>m</th><th>ft</th><th>kPa</th><th>mmHg</th><th>V</th></tr><tr><td>0 – 610</td><td>0 – 2 000</td><td>100 – 94</td><td>760 – 707</td><td>3.1 – 3.6</td></tr><tr><td>611 – 1 524</td><td>2 001 – 5 000</td><td>94 – 85</td><td>707 – 634</td><td>2.8 – 3.4</td></tr><tr><td>1 525 – 2 438</td><td>5 001 – 8 000</td><td>85 – 76</td><td>634 – 567</td><td>2.6 – 3.1</td></tr><tr><td>2 439 – 3 048</td><td>8 001 – 10 000</td><td>76 – 70</td><td>567 – 526</td><td>2.4 – 2.9</td></tr></table></div> <div>I823H1110023-02</div> <div>Is the voltage OK?</div> <div><ul style="list-style-type: none">• G/B, R or B/Br wire open or shorted to the ground, or poor "9", "11" or "29" connection.• If wire and connection are OK, intermittent trouble or faulty ECM.• Recheck each terminal and wire harness for open circuit and poor connection.• Replace the ECM with a known good one, and inspect it again. Refer to "ECM Removal and Installation in Section 1C (Page 1C-2)".</div> <div>If check result is not satisfactory, replace the IAP sensor with a new one. Refer to "IAP Sensor Removal and Installation in Section 1C (Page 1C-3)".</div>	ALTITUDE (Reference)		ATOMOSPHERIC PRESSURE		OUTPUT VOLTAGE	m	ft	kPa	mmHg	V	0 – 610	0 – 2 000	100 – 94	760 – 707	3.1 – 3.6	611 – 1 524	2 001 – 5 000	94 – 85	707 – 634	2.8 – 3.4	1 525 – 2 438	5 001 – 8 000	85 – 76	634 – 567	2.6 – 3.1	2 439 – 3 048	8 001 – 10 000	76 – 70	567 – 526	2.4 – 2.9
ALTITUDE (Reference)		ATOMOSPHERIC PRESSURE		OUTPUT VOLTAGE																											
m	ft	kPa	mmHg	V																											
0 – 610	0 – 2 000	100 – 94	760 – 707	3.1 – 3.6																											
611 – 1 524	2 001 – 5 000	94 – 85	707 – 634	2.8 – 3.4																											
1 525 – 2 438	5 001 – 8 000	85 – 76	634 – 567	2.6 – 3.1																											
2 439 – 3 048	8 001 – 10 000	76 – 70	567 – 526	2.4 – 2.9																											


DTC “C14” (P0120-H/L): TP Sensor Circuit Malfunction

B815H21104013

Detected Condition and Possible Cause


Detected Condition		Possible Cause
C14	Output voltage is not within the following range. Difference between actual throttle opening and opening calculated by ECM is larger than specified value. $0.2\text{ V} \leq \text{Sensor voltage} < 4.8\text{ V}$	<ul style="list-style-type: none">TP sensor maladjusted.TP sensor circuit open or short.TP sensor malfunction.ECM malfunction.
P0120	H	Sensor voltage is higher than specified value.
	L	Sensor voltage is lower than specified value.

Wiring Diagram



I823H1110024-05

ECM coupler (Harness side)



I823H1110004-01

Troubleshooting



CAUTION

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent the terminal damage or terminal bend.


NOTE


After repairing the trouble, clear the DTC using SDS tool. Refer to “Use of SDS Diagnosis Reset Procedures (Page 1A-14)”.

C14 (Use of mode select switch)



Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".</div> <div>3) Check the TP sensor coupler (1) for loose or poor contacts. If OK, then measure the TP sensor input voltage.</div> <div><p>I823H1110025-01</p></div> <div>4) Disconnect the TP sensor coupler.</div> <div>5) Turn the ignition switch ON.</div> <div>6) Measure the input voltage between the R wire and ground. If OK, then measure the input voltage between the R wire and B/Br wire.</div> <div>Special tool  (A): 09900-25008 (Multi-circuit tester set)</div> <div>Tester knob indication Voltage (---)</div> <div>TP sensor input voltage 4.5 – 5.5 V ((+) terminal: R – (–) terminal: Ground, (+) terminal: R – (–) terminal: B/Br)</div> <div><p>I823H1110026-04</p></div> <div>Is the voltage OK?</div>	Go to Step 3.	<ul style="list-style-type: none">Loose or poor contacts on the ECM coupler.Open or short circuit in the R or B/Br wire.



P0120-H (Use of SDS)


Step	Action	Yes	No
1	<p>1) Turn the ignition switch OFF.</p> <p>2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".</p> <p>3) Check the TP sensor coupler (1) for loose or poor contacts. If OK, then check the TP sensor lead wire continuity.</p>  <p style="text-align: right; font-size: small;">I823H1110025-01</p> <p>4) Disconnect the TP sensor coupler.</p> <p>5) Check the continuity between the P/B wire and R wire. If the sound is not heard from the tester, the circuit condition is OK.</p> <p>Special tool  (A): 09900-25008 (Multi-circuit tester set)</p> <p>Tester knob indication Continuity (•)))</p>  <p style="text-align: right; font-size: small;">I823H1110027-02</p> <p>6) Disconnect the ECM coupler. Refer to "ECM Removal and Installation in Section 1C (Page 1C-2)".</p>	Go to Step 3.	P/B wire shorted to VCC, or B/Br wire open.

Step	Action	Yes	No
1	<div>7) Check the continuity between the P/B wire and terminal "8". Also, check the continuity between the B/Br wire and terminal "29".</div> <div>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set) TOOL (B): 09900-25009 (Needle pointed probe set)</div> <div>Tester knob indication Continuity (•)))</div> <div>ECM coupler (Harness side)</div> <div></div> <div>Is the continuity OK?</div>	Go to Step 3.	P/B wire shorted to VCC, or B/Br wire open.

P0120-L (Use of SDS)

Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Lift and support the fuel tank. Refer to “Fuel Tank Removal and Installation in Section 1G (Page 1G-9)”.</div> <div>3) Check the TP sensor coupler (1) for loose or poor contacts. If OK, then check the TP sensor lead wire continuity.</div> <div></div> <div>I823H1110025-01</div> <div>4) Disconnect the TP sensor coupler.</div> <div>5) Check the continuity between the P/B wire and ground. Also, check the continuity between the P/B wire and B/Br wire. If the sound is not heard from the tester, the circuit condition is OK.</div> <div>Special tool  (A): 09900–25008 (Multi-circuit tester set)</div> <div>Tester knob indication Continuity test (••)))</div> <div></div> <div>I823H1110029-03</div> <td>Go to Step 2.</td> <td>R and P/B wire open, or P/B wire shorted to the ground.</td>	Go to Step 2.	R and P/B wire open, or P/B wire shorted to the ground.

Step	Action	Yes	No
1	<p>6) Disconnect the ECM coupler. Refer to “ECM Removal and Installation in Section 1C (Page 1C-2)”.</p> <p>7) Check the continuity between the P/B wire and terminal “8”. Also, check the continuity between the R wire and terminal “11”.</p> <p>Special tool  (A): 09900–25008 (Multi-circuit tester set)  (B): 09900–25009 (Needle pointed probe set)</p> <p>Tester knob indication Continuity test (•)))</p> <p>ECM coupler (Harness side)</p>  <p>I823H1110030-05</p> <p><i>Is the continuity OK?</i></p>	Go to Step 2.	R and P/B wire open, or P/B wire shorted to the ground.
2	<p>1) Connect the ECM coupler.</p> <p>2) Turn the ignition switch ON.</p> <p>3) Measure the input voltage between the R wire and ground. If OK, the measure the input voltage between the R wire and B/Br wire.</p> <p>Special tool  (A): 09900–25008 (Multi-circuit tester set)</p> <p>Tester knob indication Voltage (---)</p> <p>TP sensor input voltage 4.5 – 5.5 V (+) terminal: R – (–) terminal: Ground, (+) terminal: R – (–) terminal: B/Br)</p>  <p>I823H1110031-04</p> <p><i>Is the voltage OK?</i></p>	Go to Step 3.	Open or short circuit in the R or B/Br wire.

Step	Action	Yes	No
3	<p>1) Turn the ignition switch OFF.</p> <p>2) Connect the special tool between the TP sensor and its coupler.</p> <p>3) Turn the ignition switch ON.</p> <p>4) Measure the TP sensor output voltage between the P/B wire terminal (+) and B/Br wire terminal (–) with turning the throttle grip open and close.</p> <p>Special tool  (A): 09900–28630 (TPS test wire harness)  : 09900–25008 (Multi-circuit tester set)</p> <p>Tester knob indication Voltage (---)</p> <p>TP sensor output voltage Throttle valve is closed: Approx. 1.1 V Throttle valve is opened: Approx. 4.3 V ((+) terminal: P/B – (–) terminal: B/Br)</p>  <p style="text-align: right;">1823H1110032-05</p> <p><i>Is the voltage OK?</i></p>	<ul style="list-style-type: none"> • P/B, R or B/Br wire open or shorted to the ground, or poor “8”, “11” or “29” connection. • If wire and connection are OK, intermittent trouble or faulty ECM. • Recheck each terminal and wire harness for open circuit and poor connection. • Replace the ECM with a known good one, and inspect it again. Refer to “ECM Removal and Installation in Section 1C (Page 1C-2)”. 	<p>If check result is not satisfactory, replace TP sensor with a new one. Refer to “Throttle Body Disassembly and Assembly in Section 1D (Page 1D-12)”.</p>


DTC “C15” (P0115-H/L): ECT Sensor Circuit Malfunction

B815H21104014


Detected Condition and Possible Cause

Detected Condition			Possible Cause
C15		Output voltage is not with in the following range. 0.15 V ≤ Sensor voltage < 4.85 V	<ul style="list-style-type: none">ECT sensor circuit open or short.ECT sensor malfunction.ECM malfunction.ECT sensor circuit is open or ground circuit open.
P0115	H	Sensor voltage is higher than specified value.	
	L	Sensor voltage is lower than specified value.	

Wiring Diagram



ECM coupler (Harness side)



Troubleshooting


⚠ CAUTION

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent the terminal damage or terminal bend.



NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to “Use of SDS Diagnosis Reset Procedures (Page 1A-14)”.


C15 (Use of mode select switch)



Step	Action	Yes	No
1	<p>1) Turn the ignition switch OFF.</p> <p>2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".</p> <p>3) Check the ECT sensor coupler (1) for loose or poor contacts. If OK, then measure the ECT sensor input voltage.</p>  <p style="text-align: right;">I823H1110034-01</p> <p>4) Disconnect the ECT coupler and turn the ignition switch ON.</p> <p>5) Measure the input voltage between the B/BI wire and ground. If OK, then measure the input voltage between the B/BI wire and B/Br wire.</p> <p>Special tool  (A): 09900-25008 (Multi-circuit tester set)</p> <p>Tester knob indication Voltage (---)</p> <p>ECT sensor input voltage 4.5 – 5.5 V (+) terminal: B/BI – (–) terminal: Ground, (+) terminal: B/BI – (–) terminal: B/Br)</p>  <p style="text-align: right;">I718H1110048-03</p> <p><i>Is the voltage OK?</i></p>	Go to Step 2.	<ul style="list-style-type: none"> Loose or poor contacts on the ECM coupler. Open or short circuit in the B/BI or B/Br wire.

P0115-H (Use of SDS)

Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".</div> <div>3) Check the ECT sensor coupler (1) for loose or poor contacts. If OK, then check the ECT sensor lead wire continuity.</div> <div></div> <div>4) Disconnect the ECT sensor coupler.</div> <div>5) Disconnect the ECM coupler. Refer to "ECM Removal and Installation in Section 1C (Page 1C-2)".</div> <div>6) Insert the needle pointed probes to the lead wire coupler.</div> <div>7) Check the continuity between the B/BI wire and terminal "10". Also, check the continuity between the B/Br wire and terminal "29".</div> <div>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set) TOOL (B): 09900-25009 (Needle pointed probe set)</div> <div>Tester knob indication Continuity test (•)))</div> <div>ECM couplers (Harness side) </div> <div><div>Is the continuity and voltage OK?</div><div>I823H1110034-01</div><div>I823H1110036-05</div></div>	Go to Step 2.	B/BI or B/Br wire open.

P0115-L (Use of SDS)

Step	Action	Yes	No
1	<p>1) Turn the ignition switch OFF.</p> <p>2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".</p> <p>3) Check the ECT sensor coupler (1) for loose or poor contacts. If OK, then check the ECT sensor lead wire continuity.</p>  <p style="text-align: right; font-size: small;">I823H1110034-01</p> <p>4) Disconnect the ECT sensor coupler.</p> <p>5) Check the continuity between the B/BI wire and ground. If the sound is not heard from the tester, the circuit condition is OK.</p> <p>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set)</p> <p>Tester knob indication Continuity test (•)))</p>  <p style="text-align: right; font-size: small;">I718H1110054-03</p> <p>6) Connect the ECT sensor coupler.</p> <p>7) Insert the needle pointed probes to the lead wire coupler.</p> <p>8) Turn the ignition switch ON.</p>	Go to Step 2.	<ul style="list-style-type: none"> • B/BI wire shorted to the ground. • If wire is OK, go to Step 2.

Step	Action	Yes	No
1	<p>9) Measure the output voltage between the B/BI wire and ground.</p> <p>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set) TOOL (B): 09900-25009 (Needle pointed probe set)</p> <p>Tester knob indication Voltage (V)</p> <p>ECT sensor output voltage 0.15 – 4.85 V ((+) terminal: B/BI – (–) terminal: Ground)</p>  <p style="text-align: right;">I823H1110035-01</p> <p><i>Are the continuity and voltage OK?</i></p>	Go to Step 2.	<ul style="list-style-type: none"> • B/BI wire shorted to the ground. • If wire is OK, go to Step 2.
2	<p>1) Turn the ignition switch OFF. 2) Disconnect the ECT sensor coupler. 3) Measure the ECT sensor resistance.</p> <p>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set)</p> <p>Tester knob indication Resistance (Ω)</p> <p>ECT sensor resistance Approx. 2.45 kΩ at 20 °C (68 °F) (Terminal – Terminal)</p>  <p style="text-align: right;">I823H1110037-01</p> <p>NOTE Refer to “ECT Sensor Inspection in Section 1C (Page 1C-5)” for details.</p> <p><i>Is the resistance OK?</i></p>	<ul style="list-style-type: none"> • B/BI or B/Br wire open or shorted to the ground, or poor “10” or “29” connection. • If wire and connection are OK, intermittent trouble or faulty ECM. • Recheck each terminal and wire harness for open circuit and poor connection. • Replace the ECM with a known good one, and inspect it again. Refer to “ECM Removal and Installation in Section 1C (Page 1C-2)”. 	Replace the ECT sensor with a new one. Refer to “ECT Sensor Removal and Installation in Section 1C (Page 1C-5)”.


DTC “C21” (P0110-H/L): IAT Sensor Circuit Malfunction

B815H21104015


Detected Condition and Possible Cause

Detected Condition			Possible Cause
C21		Output voltage is not with in the following range. $0.15\text{ V} \leq \text{Sensor voltage} < 4.85\text{ V}$	<ul style="list-style-type: none">IAT sensor circuit open or short.IAT sensor malfunction.ECM malfunction.IAT sensor circuit open or ground circuit open.
P0110	H	Sensor voltage is higher than specified value.	
	L	Sensor voltage is lower than specified value.	

Wiring Diagram



ECM coupler (Harness side)



Troubleshooting



⚠ CAUTION

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent the terminal damage or terminal bend.



NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to “Use of SDS Diagnosis Reset Procedures (Page 1A-14)”.



C21 (Use of mode select switch)



Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".</div> <div>3) Check the IAT sensor coupler (1) for loose or poor contacts. If OK, then measure the IAT sensor input voltage.</div> <div></div> <div>I823H1110039-01</div> <div>4) Disconnect the IAT sensor coupler and turn the ignition switch ON.</div> <div>5) Measure the input voltage between the Dg wire terminal and ground. If OK, then measure the input voltage between the Dg wire terminal and B/Br wire terminal.</div> <div>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set)</div> <div>Tester knob indication Voltage (---)</div> <div>IAT sensor input voltage 4.5 – 5.5 V ((+) terminal: Dg – (–) terminal: Ground, (+) terminal: Dg – (–) terminal: B/Br)</div> <div></div> <div>I823H1110040-03</div> <div>Is the voltage OK?</div>	Go to Step 2.	<ul style="list-style-type: none">Loose or poor contacts on the ECM coupler.Open or short circuit in the Dg or B/Br wire.

P0110-H (Use of SDS)

Step	Action	Yes	No
1	<p>1) Turn the ignition switch OFF.</p> <p>2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".</p> <p>3) Check the IAT sensor coupler (1) for loose or poor contacts. If OK, then check the IAT sensor lead wire continuity.</p>  <p style="text-align: right;">I823H1110039-01</p> <p>4) Disconnect the IAT sensor coupler.</p> <p>5) Disconnect the ECM coupler. Refer to "ECM Removal and Installation in Section 1C (Page 1C-2)".</p> <p>6) Insert the needle pointed probes to the lead wire coupler.</p> <p>7) Check the continuity between the Dg wire and terminal "27". Also, check the continuity between the B/Br wire and terminal "29".</p> <p>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set) TOOL (B): 09900-25009 (Needle pointed probe set)</p> <p>Tester knob indication Continuity test (•)))</p> <p>ECM couplers (Harness side)</p>  <p style="text-align: right;">I815H1110030-02</p> <p><i>Is the continuity OK?</i></p>	Connect the ECM coupler and go to Step 2.	Dg or B/Br wire open.

P0110-L (Use of SDS)

Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".</div> <div>3) Check the IAT sensor coupler (1) for loose or poor contacts. If OK, then check the IAT sensor lead wire continuity.</div> <div></div> <div>I823H1110039-01</div> <div>4) Disconnect the IAT sensor coupler.</div> <div>5) Check the continuity between the Dg wire and ground. If the sound is not heard from the tester, the circuit condition is OK.</div> <div>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set) Tester knob indication Continuity test (•)))</div> <div></div> <div>I823H1110042-03</div> <div>6) Connect the IAT sensor coupler.</div> <div>7) Turn the ignition switch ON.</div> <div>8) Insert the needle pointed probes to the lead wire coupler.</div>	Go to Step 2.	<ul style="list-style-type: none">• Dg wire shorted to the ground.• If wire is OK, go to Step 2.

Step	Action	Yes	No
1	<p>9) Measure the output voltage between the Dg wire and ground.</p> <p>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set) TOOL (B): 09900-25009 (Needle pointed probe set)</p> <p>Tester knob indication Voltage (---)</p> <p>IAT sensor output voltage 0.15 – 4.85 V ((+) terminal: Dg – (-) terminal: Ground)</p>  <p style="text-align: right; font-size: small;">I823H1110043-02</p> <p><i>Are the continuity and voltage OK?</i></p>	Go to Step 2.	<ul style="list-style-type: none"> • Dg wire shorted to the ground. • If wire is OK, go to Step 2.
2	<p>1) Turn the ignition switch OFF. 2) Disconnect the IAT sensor coupler. 3) Measure the IAT sensor resistance.</p> <p>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set)</p> <p>Tester knob indication Resistance (Ω)</p> <p>IAT sensor resistance Approx. 2.58 kΩ at 20 °C (68 °F) (Terminal – Terminal)</p>  <p style="text-align: right; font-size: small;">I815H1110031-01</p> <p>NOTE IAT sensor resistance measurement method is the same way as that of the ECT sensor. Refer to “ECT Sensor Inspection in Section 1C (Page 1C-5)”.</p> <p><i>Is the resistance OK?</i></p>	<ul style="list-style-type: none"> • Dg or B/Br wire open or shorted to the ground, or poor “27” or “29” connection. • If wire and connection are OK, intermittent trouble or faulty ECM. • Recheck each terminal and wire harness for open circuit and poor connection. • Replace the ECM with a known good one, and inspect it again. Refer to “ECM Removal and Installation in Section 1C (Page 1C-2)”. 	Replace the IAT sensor with a new one. Refer to “IAP Sensor Removal and Installation in Section 1C (Page 1C-3)”.


DTC “C22” (P01450-H/L): AP Sensor Circuit Malfunction

B815H21104016


Detected Condition and Possible Cause

Detected Condition		Possible Cause
C22	AP sensor voltage is not within the following range. 0.5 V ≤ Sensor voltage < 4.85 V	<ul style="list-style-type: none">• Clogged vacuum passage with dust.• AP sensor circuit open or shorted to the ground.• AP sensor malfunction.• ECM malfunction.
	NOTE Note that atmospheric pressure varies depending on weather conditions as well as altitude. Take that into consideration when inspecting voltage.	
P1450	H Sensor voltage is higher than specified value.	<ul style="list-style-type: none">• AP sensor circuit is open or shorted to VCC or ground circuit open.• AP sensor circuit is shorted to the ground or VCC circuit open.
	L Sensor voltage is lower than specified value.	

Wiring Diagram



ECM coupler (Harness side)



Troubleshooting



CAUTION

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent the terminal damage or terminal bend.



NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to “Use of SDS Diagnosis Reset Procedures (Page 1A-14)”.

C22 (Use of mode select switch)



Step	Action	Yes	No
1	<p>1) Turn the ignition switch OFF.</p> <p>2) Remove the front seat. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".</p> <p>3) Check the AP sensor coupler (1) for loose or poor contacts. If OK, then measure the AP sensor input voltage.</p>  <p style="text-align: right; font-size: small;">I823H1110046-01</p> <p>4) Disconnect the AP sensor coupler.</p> <p>5) Turn the ignition switch ON.</p> <p>6) Measure the input voltage between the R wire and ground. If OK, then measure the voltage between the R wire and B/Br wire.</p> <p>Special tool  (A): 09900-25008 (Multi-circuit tester set)</p> <p><u>Tester knob indication</u> Voltage (---)</p> <p><u>AP sensor input voltage</u> 4.5 – 5.5 V ((+) terminal: R – (–) terminal: Ground, (+) terminal: R – (–) terminal: B/Br)</p>  <p style="text-align: right; font-size: small;">I823H1110016-05</p> <p><i>Is the voltage OK?</i></p>	Go to Step 2.	<ul style="list-style-type: none"> • Loose or poor contacts on the ECM coupler. • Open or short circuit in the R or B/Br wire.



P1450-H (Use of SDS)


Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Remove the front seat. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".</div> <div>3) Check the AP sensor coupler (1) for loose or poor contacts. If OK, then check the AP sensor lead wire continuity.</div> <div></div> <div>I823H1110046-01</div> <div>4) Disconnect the AP sensor coupler.</div> <div>5) Check the continuity between the R wire and G/Y wire. If the sound is not heard from the tester, the circuit condition is OK.</div> <div>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set)</div> <div>Tester knob indication Continuity (••)))</div> <div></div> <div>I823H1110017-05</div>	Go to Step 2.	G/Y wire shorted to VCC, or B/Br wire open.

Step	Action	Yes	No
1	<div>6) Disconnect the ECM coupler. Refer to “ECM Removal and Installation in Section 1C (Page 1C-2)”.</div> <div>7) Insert the needle pointed probes to the lead wire coupler.</div> <div>8) Check the continuity between the G/Y wire and terminal “26”.</div> <div>If OK, then check the continuity between the B/Br wire and terminal “29”.</div> <div>Special tool</div> <div> (A): 09900-25008 (Multi-circuit tester set)</div> <div> (B): 09900-25009 (Needle pointed probe set)</div> <div>Tester knob indication</div> <div>Continuity test (•)))</div> <div>ECM coupler (Harness side)</div> <div><p>“26” (Black) “29” (Gray)</p><p>I823H1110047-04</p></div> <div>Is the continuity OK?</div>	Go to Step 2.	G/Y wire shorted to VCC, or B/Br wire open.

P01450-L (Use of SDS)

Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Remove the front seat. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".</div> <div>3) Check the AP sensor coupler (1) for loose or poor contacts. If OK, then check the AP sensor lead wire continuity.</div> <div><p>I823H1110046-01</p></div> <div>4) Disconnect the AP sensor coupler.</div> <div>5) Check the continuity between the G/Y wire and ground. Also, check the continuity between the G/Y wire and B/Br wire. If the sound is not heard from the tester, the circuit condition is OK.</div> <div>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set)</div> <div>Tester knob indication Continuity (••)))</div> <div><p>I823H1110019-02</p></div>	Go to Step 2.	R and G/Y wire open, G/Y wire shorted to the ground.

Step	Action	Yes	No
1	<p>6) Disconnect the ECM coupler. Refer to "ECM Removal and Installation in Section 1C (Page 1C-2)".</p> <p>7) Insert the needle pointed probes to the lead wire coupler.</p> <p>8) Check the continuity between the R wire and terminal "11". Also, check the continuity between the G/Y wire and terminal "26".</p> <p>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set) TOOL (B): 09900-25009 (Needle pointed probe set)</p> <p>Tester knob indication Continuity (•)))</p> <p>ECM coupler (Harness side)</p>  <p>I823H1110048-05</p> <p><i>Is the continuity OK?</i></p>	Go to Step 2.	R and G/Y wire open, G/Y wire shorted to the ground.
2	<p>1) Turn the ignition switch OFF.</p> <p>2) Connect the ECM coupler and AP sensor coupler.</p> <p>3) Insert the needle pointed probes to the lead wire coupler.</p> <p>4) Run the engine at idle speed and measure the AP sensor output voltage between the G/Y wire and B/Br wire.</p> <p>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set) TOOL (B): 09900-25009 (Needle pointed probe set)</p> <p>Tester knob indication Voltage (---)</p> <p>AP sensor output voltage Approx. 3.6 V at 100 kPa (760 mmHg) ((+) terminal: G/Y – (–) terminal: B/Br)</p>  <p>I823H1110049-04</p> <p><i>Is the voltage OK?</i></p>	Go to Step 3.	<ul style="list-style-type: none"> • Check the vacuum port for crack or damage. • Open or short circuit in the G/Y wire. • If vacuum hose and wire are OK, replace the AP sensor with a new one. Refer to "IAP Sensor Removal and Installation in Section 1C (Page 1C-3)".

Step	Action	Yes	No																												
3	<div>1) Turn the ignition switch OFF.</div> <div>2) Remove the AP sensor. Refer to "IAP Sensor Removal and Installation in Section 1C (Page 1C-3)".</div> <div>3) Connect the vacuum pump gauge to the vacuum port of the AP sensor.</div> <div>4) Arrange 3 new 1.5 V batteries in series (1) (check that total voltage is 4.5 – 5.0 V) and connect (–) terminal to the ground terminal "B" and (+) terminal to the VCC terminal "A".</div> <div>5) Check the voltage between Vout terminal "C" and ground. Also, check if voltage reduces when vacuum is applied up to 53 kPa (400 mmHg) by using vacuum pump gauge.</div> <div>Special tool  (A): 09917–47011 (Vacuum pump gauge)  (B): 09900–25008 (Multi-circuit tester set)</div> <div>Tester knob indication Voltage (---)</div> <div></div> <div>I718H1110030-02</div> <div><table><tr><th colspan="2">ALTITUDE (Reference)</th><th colspan="2">ATOMOSPHERIC PRESSURE</th><th>OUTPUT VOLTAGE</th></tr><tr><th>m</th><th>ft</th><th>kPa</th><th>mmHg</th><th>V</th></tr><tr><td>0 – 610</td><td>0 – 2 000</td><td>100 – 94</td><td>760 – 707</td><td>3.1 – 3.6</td></tr><tr><td>611 – 1 524</td><td>2 001 – 5 000</td><td>94 – 85</td><td>707 – 634</td><td>2.8 – 3.4</td></tr><tr><td>1 525 – 2 438</td><td>5 001 – 8 000</td><td>85 – 76</td><td>634 – 567</td><td>2.6 – 3.1</td></tr><tr><td>2 439 – 3 048</td><td>8 001 – 10 000</td><td>76 – 70</td><td>567 – 526</td><td>2.4 – 2.9</td></tr></table></div> <div>I823H1110023-02</div> <div>Is the voltage OK?</div> <div><ul style="list-style-type: none">• G/Y, R or B/Br wire open or shorted to the ground, or poor "26", "11" or "29" connection.• If wire and connection are OK, intermittent trouble or faulty ECM.• Recheck each terminal and wire harness for open circuit and poor connection.• Replace the ECM with a known good one, and inspect it again. Refer to "ECM Removal and Installation in Section 1C (Page 1C-2)".</div> <div>If check result is not satisfactory, replace the AP sensor with a new one. Refer to "IAP Sensor Removal and Installation in Section 1C (Page 1C-3)".</div>	ALTITUDE (Reference)		ATOMOSPHERIC PRESSURE		OUTPUT VOLTAGE	m	ft	kPa	mmHg	V	0 – 610	0 – 2 000	100 – 94	760 – 707	3.1 – 3.6	611 – 1 524	2 001 – 5 000	94 – 85	707 – 634	2.8 – 3.4	1 525 – 2 438	5 001 – 8 000	85 – 76	634 – 567	2.6 – 3.1	2 439 – 3 048	8 001 – 10 000	76 – 70	567 – 526	2.4 – 2.9
ALTITUDE (Reference)		ATOMOSPHERIC PRESSURE		OUTPUT VOLTAGE																											
m	ft	kPa	mmHg	V																											
0 – 610	0 – 2 000	100 – 94	760 – 707	3.1 – 3.6																											
611 – 1 524	2 001 – 5 000	94 – 85	707 – 634	2.8 – 3.4																											
1 525 – 2 438	5 001 – 8 000	85 – 76	634 – 567	2.6 – 3.1																											
2 439 – 3 048	8 001 – 10 000	76 – 70	567 – 526	2.4 – 2.9																											


DTC “C23” (P1651-H/L): TO Sensor Circuit Malfunction

B815H21104017

Detected Condition and Possible Cause


Detected Condition			Possible Cause
C23		The sensor voltage should be the following for 2 sec. and more, after ignition switch is turned ON. $0.2\text{ V} \leq \text{Sensor voltage} < 4.8\text{ V}$	<ul style="list-style-type: none">• TO sensor circuit open or short.• TO sensor malfunction.• ECM malfunction.
P1651	H	Sensor voltage is higher than specified value.	<ul style="list-style-type: none">• TO sensor circuit is open or ground circuit open.• TO sensor circuit is open or shorted to the ground or VCC circuit open.
	L	Sensor voltage is lower than specified value.	

Wiring Diagram



I823H1110104-02

ECM coupler (Harness side)



I823H1110004-01

Troubleshooting



⚠ CAUTION

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent the terminal damage or terminal bend.



NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to “Use of SDS Diagnosis Reset Procedures (Page 1A-14)”.

C23 (Use of mode select switch)



Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".</div> <div>3) Check the TO sensor coupler (1) for loose or poor contacts. If OK, then measure the TO sensor resistance.</div> <div></div> <div>4) Remove the TO sensor. Refer to "TO Sensor Removal and Installation in Section 1C (Page 1C-7)".</div> <div>5) Measure the resistance between terminal "A" and terminal "C".</div> <div>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set)</div> <div>Tester knob indication Resistance (Ω)</div> <div>TO sensor resistance 16.5 – 22.3 kΩ (Terminal "A" – Terminal "C")</div> <div></div> <div><i>Is the resistance OK?</i></div>	Go to Step 2.	Replace the TO sensor with a new one. Refer to "TO Sensor Removal and Installation in Section 1C (Page 1C-7)".

P1651-H (Use of SDS)



Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Lift and support the fuel tank. Refer to “Fuel Tank Removal and Installation in Section 1G (Page 1G-9)”.</div> <div>3) Check the TO sensor coupler (1) for loose or poor contacts. If OK, then check the TO sensor lead wire continuity.</div> <div></div> <div>4) Disconnect the TO sensor coupler.</div> <div>5) Check the continuity between the R wire and B wire. If the sound is not heard from the tester, the circuit condition is OK.</div> <div>Special tool  (A): 09900–25008 (Multi-circuit tester set)</div> <div>Tester knob indication Continuity test (•)))</div> <div></div> <div>Go to Step 2.</div> <div>B wire shorted to VCC, or B/Br wire open.</div>		

Step	Action	Yes	No
1	<div>6) Disconnect the ECM coupler. Refer to “ECM Removal and Installation in Section 1C (Page 1C-2)”.</div> <div>7) Insert the needle pointed probes to the lead wire coupler.</div> <div>8) Check the continuity between the B wire and terminal “22”. Also, check the continuity between B/Br wire and terminal “29”.</div> <div>Special tool TOOL (A): 09900–25008 (Multi-circuit tester set) TOOL (B): 09900–25009 (Needle pointed probe set)</div> <div>Tester knob indication Continuity test (•)))</div> <div>ECM coupler (Harness side)</div> <div><p>Diagram illustrating the continuity test setup. The ECM coupler (Harness side) is connected to the multi-circuit tester (TOOL A) and the needle pointed probe set (TOOL B). The tester is connected to terminal 22 (Black) and terminal 29 (Gray). The probe set is connected to the B wire and the B/Br wire. The tester display shows a continuity symbol (•)).</p><p>I823H1110052-04</p></div> <div>Is the continuity OK?</div>	Go to Step 2.	B wire shorted to VCC, or B/Br wire open.

P1651-L (Use of SDS)

Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Lift and support the fuel tank. Refer to “Fuel Tank Removal and Installation in Section 1G (Page 1G-9)”.</div> <div>3) Check the TO sensor coupler (1) for loose or poor contacts. If OK, then check the TO sensor lead wire continuity.</div> <div></div> <div>4) Disconnect the TO sensor coupler.</div> <div>5) Check the continuity between the B wire and ground. Also, check the continuity between the B wire and B/Br wire. If the sound is not heard from the tester, the circuit condition is OK.</div> <div>Special tool  (A): 09900–25008 (Multi-circuit tester set)</div> <div>Tester knob indication Continuity test (•)))</div> <div></div>	Go to Step 2.	R or B wire open, or B wire shorted to the ground.

Step	Action	Yes	No
1	<div>6) Disconnect the ECM coupler. Refer to “ECM Removal and Installation in Section 1C (Page 1C-2)”.</div> <div>7) Insert the needle pointed probes to the lead wire coupler.</div> <div>8) Check the continuity between the R wire and terminal “11”. Also, then check the continuity between B wire and terminal “22”.</div> <div>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set) TOOL (B): 09900-25009 (Needle pointed probe set)</div> <div>Tester knob indication Continuity test (●)))</div> <div>ECM coupler (Harness side)</div> <div><p>The diagram illustrates the setup for a continuity test. At the top, an ECM coupler (Harness side) is shown. A multi-circuit tester (TOOL A) is connected to the coupler. A needle pointed probe set (TOOL B) is used to check continuity between the R wire and terminal "11" (Black) and between the B wire and terminal "22" (Gray). The tester (TOOL A) has a display showing "●)))" indicating continuity.</p><p>I823H1110054-04</p></div> <div>Is the continuity OK?</div>	Go to Step 2.	R or B wire open, or B wire shorted to the ground.

Step	Action	Yes	No
2	<p>1) Connect the ECM coupler and TO sensor coupler.</p> <p>2) Remove the TO sensor. Refer to "TO Sensor Removal and Installation in Section 1C (Page 1C-7)".</p> <p>3) Insert the needle pointed probes to the lead wire coupler.</p> <p>4) Turn the ignition switch ON.</p> <p>5) Measure the voltage at the wire side coupler between B wire and B/Br wire.</p> <p>Special tool  (A): 09900-25008 (Multi-circuit tester set)  (B): 09900-25009 (Needle pointed probe set)</p> <p>Tester knob indication Voltage (---)</p> <p>TO sensor voltage (Normal) 0.4 – 1.4 V ((+) terminal: B – (-) terminal: B/Br)</p>  <p style="text-align: right; font-size: small;">I823H1110055-01</p> <p>6) Measure the voltage when it is leaned 65° and more to left and right, from the horizontal level.</p> <p>TO sensor voltage (Leaning) 3.7 – 4.4 V ((+) terminal: B – (-) terminal: B/Br)</p>  <p style="text-align: right; font-size: small;">I823H1110056-04</p> <p><i>Is the voltage OK?</i></p>	<ul style="list-style-type: none"> • R, B or B/Br wire open or shorted to the ground, or poor "11", "22" or "29" connection. • If wire and connection are OK, intermittent trouble or faulty ECM. • Recheck each terminal and wire harness for open circuit and poor connection. • Replace the ECM with a known good one, and inspect it again. Refer to "ECM Removal and Installation in Section 1C (Page 1C-2)". 	<ul style="list-style-type: none"> • Loosen or poor contacts on the ECM coupler. • Open or short circuit. • Replace the TO sensor with a new one. Refer to "TO Sensor Removal and Installation in Section 1C (Page 1C-7)".

DTC “C24” (P0351), “C25” (P0352), “C26” (P0353) or “C27” (P0354): Ignition System Malfunction B815H21104018


NOTE
Refer to “No Spark or Poor Spark in Section 1H (Page 1H-5)” for details.

DTC “C28” (P1655): Secondary Throttle Valve Actuator (STVA) Malfunction B815H21104019

Detected Condition and Possible Cause


Detected Condition	Possible Cause
The operation voltage does not reach the STVA. ECM does not receive communication signal from the STVA. STVA can not operate properly or its motor locked.	<ul style="list-style-type: none">• STVA malfunction.• STVA circuit open or short.• STVA motor malfunction.

Wiring Diagram



I815H1110012-01

ECM coupler (Harness side)



I823H1110004-01



Troubleshooting



⚠ CAUTION

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent the terminal damage or terminal bend.

NOTE


After repairing the trouble, clear the DTC using SDS tool. Refer to "Use of SDS Diagnosis Reset Procedures (Page 1A-14)".

Step	Action	Yes	No
1	<p>1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".</p> <p>2) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation in Section 1D (Page 1D-6)".</p> <p>3) Check the STVA lead wire coupler (1) for loose or poor contacts.</p>  <p style="text-align: right;">I823H1110061-02</p> <p>4) Start the engine to check the STV operation. (STVA operating order: Open → Close)</p>  <p style="text-align: right;">I705H1110063-01</p> <p><i>Is the operation OK?</i></p>	Go to Step 2.	<ul style="list-style-type: none"> • Loose or poor contacts on the coupler. • Open or short circuit in the B/Lg, P/W, G or W/B wire. • If wire and connection are OK, go to Step 2.

Step	Action	Yes	No
2	<div>1) Turn the ignition switch OFF.</div> <div>2) Disconnect the STVA lead wire coupler.</div> <div>3) Check the continuity between each terminal and ground.</div> <div>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set)</div> <div>Tester knob indication Resistance (Ω)</div> <div>STVA continuity $\infty \Omega$ (Infinity) (Terminal – Ground)</div> <div></div> <div>I823H1110059-02</div> <div>4) If OK, then measure the STVA resistance (between the B wire “A” and P wire “B”) and (between the G wire “C” and W/BI wire “D”).</div> <div>STVA resistance Approx. 6.5 Ω (Terminal “A” – Terminal “B”, Terminal “C” – Terminal “D”)</div> <div></div> <div>I823H1110060-04</div> <div>Is the resistance OK?</div> <div><ul style="list-style-type: none">• B/Lg, P/W, G and W/ B wire open or shorted to the ground, or poor “19”, “2”, “18” and “1” connection.• If wire and connection are OK, intermittent trouble or faulty ECM.• Recheck each terminal and wire harness for open circuit and poor connection.• Replace the ECM with a known good one, and inspect it again. Refer to “ECM Removal and Installation in Section 1C (Page 1C-2)”.</div> <div><ul style="list-style-type: none">• Loose or poor contacts on the ECM coupler.• Replace the throttle body assembly with a new one. Refer to “Throttle Body Disassembly and Assembly in Section 1D (Page 1D-12)”.</div>		

Active Control Inspection

- 1) Set up the SDS tool. (Refer to the SDS operation manual for further details.)
- 2) Turn the ignition switch ON.
- 3) Click "Secondary throttle operating control" (1).




I815H1110013-01


- 4) Click each button (2).

At this time, if an operation sound is heard from the STVA, the function is normal.

Item	Value	Unit
☐ Engine speed	0	rpm
☐ Throttle position	27.9	°
☐ Secondary throttle full opened	Except full opn	
☐ Secondary throttle full closed	Full closed	
☐ Secondary throttle actuator position sensor	98.4	%
☐ Manifold absolute pressure 1	101.6	kPa



Item	Value	Unit
☐ Engine speed	0	rpm
☐ Throttle position	27.9	°
☐ Secondary throttle full opened	Full opened	
☐ Secondary throttle full closed	Except full cls	
☐ Secondary throttle actuator position sensor	98.4	%
☐ Manifold absolute pressure 1	101.6	kPa



I823H1110201-02


DTC “C29” (P1654-H/L): Secondary Throttle Position Sensor (STPS) Circuit Malfunction

B815H21104020


Detected Condition and Possible Cause

Detected Condition			Possible Cause
C29		Output voltage is not within the following range. Difference between actual throttle opening and opening calculated by ECM is larger than specified value. $0.15\text{ V} \leq \text{Sensor voltage} < 4.85\text{ V}$	<ul style="list-style-type: none">• STP sensor maladjusted.• STP sensor circuit open or short.• STP sensor malfunction.• ECM malfunction.
P1654	H	Sensor voltage is higher than specified value.	• STP sensor circuit shorted to VCC or ground circuit open.
	L	Sensor voltage is lower than specified value.	• STP sensor circuit open or shorted to the ground or VCC circuit open.

Wiring Diagram



ECM coupler (Harness side)



Troubleshooting



⚠ CAUTION

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent the terminal damage or terminal bend.



NOTE


After repairing the trouble, clear the DTC using SDS tool. Refer to “Use of SDS Diagnosis Reset Procedures (Page 1A-14)”.

C29 (Use of mode select switch)



Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".</div> <div>3) Check the STP sensor coupler (1) for loose or poor contacts. If OK, then measure the STP sensor input voltage.</div> <div></div> <div>I823H1110061-02</div> <div>4) Disconnect the STP sensor coupler.</div> <div>5) Turn the ignition switch ON.</div> <div>6) Measure the input voltage between the R wire and ground. Also, measure the voltage between the R wire and B/Br wire.</div> <div>Special tool  (A): 09900-25008 (Multi-circuit tester set)</div> <div>Tester knob indication Voltage (---)</div> <div>STP sensor input voltage 4.5 – 5.5 V (+) terminal: R – (-) terminal: Ground, (+) terminal: R – (-) terminal: B/Br)</div> <div></div> <div>I823H1110062-02</div> <div>Is the voltage OK?</div>	Go to Step 3.	<ul style="list-style-type: none">Loose or poor contacts on the ECM coupler.Open or short circuit in the R wire or B/Br wire.



P1654-H (Use of SDS)


Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Lift and support the fuel tank. Refer to “Fuel Tank Removal and Installation in Section 1G (Page 1G-9)”.</div> <div>3) Check the STP sensor coupler (1) for loose or poor contacts. If OK, then check the STP sensor lead wire continuity.</div> <div></div> <div>I823H1110063-02</div> <div>4) Disconnect the STP sensor coupler.</div> <div>5) Check the continuity between the Y/W wire and R wire. If the sound is not heard from the tester, the circuit condition is OK.</div> <div>Special tool  (A): 09900-25008 (Multi-circuit tester set)</div> <div><u>Tester knob indication</u> Continuity (•)))</div> <div></div> <div>I823H1110064-03</div> <td>Go to Step 3.</td> <td>Y/W wire shorted to VCC, or B/Br wire open.</td>	Go to Step 3.	Y/W wire shorted to VCC, or B/Br wire open.

Step	Action	Yes	No
1	<div>6) Disconnect the ECM coupler. Refer to “ECM Removal and Installation in Section 1C (Page 1C-2)”.</div> <div>7) Check the continuity between the Y/W wire and terminal “20”. Also, check the continuity between the B/Br wire and terminal “29”.</div> <div>Special tool  (A): 09900-25008 (Multi-circuit tester set)  (B): 09900-25009 (Needle pointed probe set)</div> <div>Tester knob indication Continuity test (•))))</div> <div>ECM couplers (Harness side)</div> <div><p>1823H1110065-05</p></div> <div>Is the continuity OK?</div>	Go to Step 3.	Y/W wire shorted to VCC, or B/Br wire open.

P1654-L (Use of SDS)

Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".</div> <div>3) Check the STP sensor coupler (1) for loose or poor contacts. If OK, then check the STP sensor lead wire continuity.</div> <div><p>I823H1110066-02</p></div> <div>4) Disconnect the STP sensor coupler.</div> <div>5) Check the continuity between the Y/W wire and ground. Also, check the continuity between the Y/W wire and B/Br wire. If the sound is not heard from the tester, the circuit condition is OK.</div> <div>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set) Tester knob indication Continuity test (•)))</div> <div><p>I823H1110067-03</p></div> <div>6) Disconnect the ECM coupler. Refer to "ECM Removal and Installation in Section 1C (Page 1C-2)".</div>	Go to Step 2.	R or Y/W wire open, or Y/W wire shorted to the ground.

Step	Action	Yes	No
1	<p>7) Check the continuity between the Y/W wire and terminal "20". Also, check the continuity between the R wire and terminal "11".</p> <p>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set) TOOL (B): 09900-25009 (Needle pointed probe set)</p> <p>Tester knob indication Continuity test (•)))</p> <p>ECM couplers (Harness side)</p>  <p>Is the continuity OK?</p>	Go to Step 2.	R or Y/W wire open, or Y/W wire shorted to the ground.
2	<p>1) Connect the ECM coupler.</p> <p>2) Turn the ignition switch ON.</p> <p>3) Measure the input voltage between the R wire and ground. Also, measure the input voltage between the R wire and B/Br wire.</p> <p>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set)</p> <p>Tester knob indication Voltage (---)</p> <p>STP sensor input voltage 4.5 – 5.5 V ((+) terminal: R – (–) terminal: Ground, (+) terminal: R – (–) terminal: B/Br)</p>  <p>Is the voltage OK?</p>	Go to Step 3.	Open or short circuit in the R or B/Br wire.

Step	Action	Yes	No
3	<div>1) Turn the ignition switch OFF.</div> <div>2) Connect the ECM coupler and STP sensor coupler.</div> <div>3) Disconnect the STVA lead wire coupler. Refer to “DTC “C28” (P1655): Secondary Throttle Valve Actuator (STVA) Malfunction (Page 1A-71)”.</div> <div>4) Insert the needle point probes to the lead wire coupler.</div> <div>5) Turn the ignition switch ON.</div> <div>6) Measure the STP sensor output voltage at the coupler (between the Y wire (+) and B wire (–)) by turning the secondary throttle valve (close and open) with your finger.</div> <div>Special tool  (A): 09900–25008 (Multi-circuit tester set)  (B): 09900–25009 (Needle pointed probe set)</div> <div>Tester knob indication Voltage (---)</div> <div>STP sensor output voltage Secondary throttle valve is closed: Approx. 0.5 V Secondary throttle valve is opened: Approx. 3.9 V (+) terminal: Y – (–) terminal: B</div> <div><div>I823H1110070-01</div></div> <div><div></div><div>I705H1110071-01</div></div> <div>Is the voltage OK?</div> <div><ul style="list-style-type: none">• R, Y/W or B/Br wire open or shorted to the ground, or poor “11”, “20” or “29” connection.• If wire and connection are OK, intermittent trouble or faulty ECM.• Recheck each terminal and wire harness for open circuit and poor connection.• Replace the ECM with a known good one, and inspect it again. Refer to “ECM Removal and Installation in Section 1C (Page 1C-2)”.</div> <div>If check result is not satisfactory, replace the STP sensor with a new one. Refer to “STP Sensor Removal and Installation in Section 1C (Page 1C-8)”.</div>		


DTC “C31” (P0705): GP Switch Circuit Malfunction

B815H21104021


Detected Condition and Possible Cause

Detected Condition	Possible Cause
No Gear Position switch voltage GP switch voltage is not within the following range. GP switch voltage ≥ 0.6 V	<ul style="list-style-type: none">GP switch circuit open or short.GP switch malfunction.ECM malfunction.

Wiring Diagram



ECM coupler (Harness side)





Troubleshooting

CAUTION

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent the terminal damage or terminal bend.

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to “Use of SDS Diagnosis Reset Procedures (Page 1A-14)”.

Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".</div> <div>3) Check the GP switch coupler (1) for loose or poor contacts. If OK, then measure the GP switch voltage.</div> <div> I823H1110072-01</div> <div>4) Support the motorcycle with a jack.</div> <div>5) Fold the side-stand to up position.</div> <div>6) Make sure the engine stop switch is in the "RUN" position.</div> <div>7) Insert the needle pointed probe to the lead wire coupler.</div> <div>8) Turn the ignition switch ON.</div> <div>9) Measure the voltage between the R and B wire, when shifting the gearshift lever from 1st to Top.</div> <div>Special tool  (A): 09900-25008 (Multi-circuit tester set)  (B): 09900-25009 (Needle pointed probe set)</div> <div><u>Tester knob indication</u> Voltage (---)</div> <div><u>GP switch voltage</u> 0.6 V and more ((+) terminal: R – (-) terminal: B)</div> <div> I823H1110073-02</div> <div>Is the voltage OK?</div> <div><ul style="list-style-type: none">• P wire open or shorted to the ground.• If wire and connection are OK, intermittent trouble or faulty ECM.• Recheck each terminal and wire harness for open circuit and poor connection.• Replace the ECM with a known good one, and inspect it again. Refer to "ECM Removal and Installation in Section 1C (Page 1C-2)".</div> <div><ul style="list-style-type: none">• R or B wire open, or R wire shorted to the ground.• Loose or poor contacts on the ECM coupler.• If wire and connection are OK, replace the GP switch with a new one. Refer to "Gear Position (GP) Switch Removal and Installation in Section 5B (Page 5B-11)".</div>		


DTC “C32” (P0201), “C33” (P0202), “C34” (P0203) or “C35” (P0204): Primary Fuel Injector Circuit Malfunction

B815H21104022

Detected Condition and Possible Cause


Detected Condition	Possible Cause
CKP signal is produced but fuel injector signal is interrupted by 4 times or more continuity.	<ul style="list-style-type: none">• Injector circuit open or short.• Injector malfunction.• ECM malfunction.

Wiring Diagram



I823H1110074-02

ECM coupler (Harness side)



I823H1110004-01


Troubleshooting


CAUTION


When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent the terminal damage or terminal bend.

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to “Use of SDS Diagnosis Reset Procedures (Page 1A-14)”.

Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Lift and support the fuel tank. Refer to “Fuel Tank Removal and Installation in Section 1G (Page 1G-9)”.</div> <div>3) Check the primary fuel injector coupler for loose or poor contacts. If OK, then measure the injector resistance.</div> <div><div>I823H1110075-01</div></div> <div>4) Disconnect the injector coupler and measure the resistance between terminals.</div> <div><div>Special tool</div><div>TOOL (A): 09900-25008 (Multi-circuit tester set)</div><div><u>Tester knob indication</u></div><div>Resistance (Ω)</div><div><u>Injector resistance</u></div><div>11 – 13 Ω at 20 °C (68 °F)</div><div>(Terminal – Terminal)</div><div><div>I823H1110077-03</div></div></div>	Go to Step 2.	Replace the injector with a new one. Refer to “Throttle Body Disassembly and Assembly in Section 1D (Page 1D-12)”.

Step	Action	Yes	No
1	<div>5) If OK, then check the continuity between each terminal and ground.</div> <div>Special tool  (A): 09900-25008 (Multi-circuit tester set)</div> <div>Injector continuity $\infty \Omega$ (Infinity)</div> <div></div> <div>1823H1110076-03</div> <div>Are the resistance and continuity OK?</div>	Go to Step 2.	Replace the injector with a new one. Refer to “Throttle Body Disassembly and Assembly in Section 1D (Page 1D-12)”.

Step	Action	Yes	No
2	<div>1) Turn the ignition switch ON.</div> <div>2) Measure the injector voltage between the Y/R wire and ground.</div> <div>NOTE</div> <div>Injector voltage can be detected only for 3 seconds after ignition switch is turned ON.</div> <div>Special tool</div> <div>TOOL (A): 09900-25008 (Multi-circuit tester set)</div> <div>Tester knob indication</div> <div>Voltage (---)</div> <div>Injector voltage</div> <div>Battery voltage</div> <div>((+) terminal: Y/R – (–) terminal: Ground)</div> <div></div> <div><small>I823H1110078-02</small></div> <div>Is the voltage OK?</div>	<ul style="list-style-type: none">• Gr/W wire open or shorted to the ground, or poor “48” connection (#1 cylinder side).• Gr/B wire open or shorted to the ground, or poor “47” connection (#2 cylinder side).• Gr/Y wire open or shorted to the ground, or poor “46” connection (#3 cylinder side).• Gr/R wire open or shorted to the ground, or poor “45” connection (#4 cylinder side).• If wire and connection are OK, intermittent trouble or faulty ECM.• Recheck each terminal and wire harness for open circuit and poor connection.• Replace the ECM with a known good one, and inspect it again. Refer to “ECM Removal and Installation in Section 1C (Page 1C-2)”.	Open circuit in the Y/R wire.


DTC “C36” (P1764), “C37” (P1765), “C38” (P1766) or “C39” (P1767): Secondary Fuel Injector Circuit Malfunction

B815H21104023

Detected Condition and Possible Cause


Detected Condition	Possible Cause
Some failure exists in the fuel injector signal in a high load, high revolution condition.	<ul style="list-style-type: none">• Injector circuit open or short.• Injector malfunction.• ECM malfunction.

Wiring Diagram



I823H1110079-03

ECM coupler (Harness side)



I823H1110004-01



Troubleshooting


CAUTION


When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent the terminal damage or terminal bend.

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to “Use of SDS Diagnosis Reset Procedures (Page 1A-14)”.

Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".</div> <div>3) Check the secondary fuel injector coupler for loose or poor contacts. If OK, then measure the injector resistance.</div> <div></div> <div>I823H1110081-01</div> <div>4) Disconnect the injector coupler and measure the resistance between terminals.</div> <div>Special tool  (A): 09900-25008 (Multi-circuit tester set)</div> <div>Tester knob indication Resistance (Ω)</div> <div>Injector resistance 11 – 13 Ω at 20 °C (68 °F) (Terminal – Terminal)</div> <div></div> <div>I823H1110080-01</div>	Go to Step 2.	Replace the injector with a new one. Refer to "Throttle Body Disassembly and Assembly in Section 1D (Page 1D-12)".

Step	Action	Yes	No
1	<div>5) If OK, then check the continuity between each terminal and ground.</div> <div>Special tool  (A): 09900-25008 (Multi-circuit tester set)</div> <div>Injector continuity $\infty \Omega$ (Infinity)</div> <div></div> <div>1823H1110082-04</div> <div>Are the resistance and continuity OK?</div>	Go to Step 2.	Replace the injector with a new one. Refer to "Throttle Body Disassembly and Assembly in Section 1D (Page 1D-12)".


Step	Action	Yes	No
2	<div>1) Turn the ignition switch ON.</div> <div>2) Measure the injector voltage between the Y/R wire and ground.</div> <div>NOTE</div> <div>Injector voltage can be detected only for 3 seconds after ignition switch is turned ON.</div> <div>Special tool</div> <div>TOOL (A): 09900-25008 (Multi-circuit tester set)</div> <div>Tester knob indication</div> <div>Voltage (---)</div> <div>Injector voltage</div> <div>Battery voltage</div> <div>((+) terminal: Y/R – (-) terminal: Ground)</div> <div></div> <div><small>I823H1110083-02</small></div> <div>Is the voltage OK?</div>	<ul style="list-style-type: none">• Lg wire open or shorted to the ground, or poor “64” connection (#1 cylinder side).• Lg/W wire open or shorted to the ground, or poor “63” connection (#2 cylinder side).• Lg/G wire open or shorted to the ground, or poor “62” connection (#3 cylinder side).• Lg/Bl wire open or shorted to the ground, or poor “61” connection (#4 cylinder side).• If wire and connection are OK, intermittent trouble or faulty ECM.• Recheck each terminal and wire harness for open circuit and poor connection.• Replace the ECM with a known good one, and inspect it again. Refer to “ECM Removal and Installation in Section 1C (Page 1C-2)”.	Open circuit in the Y/R wire.

DTC “C40” (P0505 / P0506 / P0507): ISC Valve Circuit Malfunction


B815H21104024

Detected Condition and Possible Cause

Detected Condition		Possible Cause
C40/P0505	The circuit voltage of motor drive is unusual.	<ul style="list-style-type: none"> ISC valve circuit open or shorted to the ground. Air passage clogged. ISC valve is fixed. ISC valve preset position is incorrect. Disconnect ISC valve hose. ISC valve is fixed. ISC valve preset position is incorrect.
C40/P0506	Idle speed is lower than the desired idle speed.	
C40/P0507	Idle speed is high than the desired idle speed.	

Wiring Diagram

I815H1110014-01

ECM coupler (Harness side)



I823H1110004-01



Troubleshooting**⚠ CAUTION**

- Be careful not to disconnect the ISC valve coupler at least 5 seconds after ignition switch is turned to OFF.
If the ECM coupler is disconnected within 5 seconds after ignition switch is turned to OFF, there is a possibility of an usual valve being written in ECM and causing an error of ISC valve operation.
- When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent the terminal damage or terminal bend.

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to “Use of SDS Diagnosis Reset Procedures (Page 1A-14)”.


Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation in Section 1D (Page 1D-6)".</div> <div>3) Check the ISC valve coupler (1) for loose or poor contacts. If OK, then check the ISC valve lead wire continuity.</div> <div></div> <div>I823H1110102-01</div> <div>4) Disconnect the ISC valve coupler and ECM coupler. Refer to "ECM Removal and Installation in Section 1C (Page 1C-2)".</div> <div>5) Check the continuity between terminal "A" and terminal "36", terminal "B" and terminal "53", terminal "C" and terminal "35", terminal "D" and terminal "52".</div> <div>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set) TOOL (B): 09900-25009 (Needle pointed probe set)</div> <div>Tester knob indication Continuity test (•)))</div> <div>ECM couplers (Harness side)</div> <div></div> <div>I823H1110085-05</div> <div>Is the continuity OK?</div>	Go to Step 2.	Bl, Y, G or Br wire open.

Step	Action	Yes	No
2	<p>1) Check the continuity between each ISC valve terminal and ground.</p> <p>Special tool  (A): 09900-25008 (Multi-circuit tester set)</p> <p>Tester knob indication Resistance (Ω)</p> <p>ISC valve continuity $\infty \Omega$ (Infinity) (Terminal – Ground)</p>  <p style="text-align: right;">I823H1110086-01</p> <p>2) If OK, then measure the resistance (between the BI wire terminal “A” and Y wire terminal “B”) and (between the G wire terminal “C” and Br wire terminal “D”).</p> <p>ISC valve resistance Approx. 80 Ω at 20 °C (68 °F) (Terminal: “A” – Terminal: “B”, Terminal: “C” – Terminal: “D”)</p>  <p style="text-align: right;">I823H1110087-03</p> <p><i>Is the resistance OK?</i></p>	<p>If wire is OK, intermittent trouble or faulty ECM.</p>	<p>Replace the ISC valve with a new one. Refer to “Throttle Body Disassembly and Assembly in Section 1D (Page 1D-12)”.</p>

ACTIVE CONTROL INSPECTION (ISC RPM CONTROL)

Check 1

- 1) Set up the SDS tool. (Refer to the SDS operation manual for further details.)
- 2) Check that the engine is running.
- 3) Click the "Active control".
- 4) Click the "ISC rpm control" (1).



I815H1110015-01

- 5) Check that the "Spec" (2) is idle speed $1\,150 \pm 100$ rpm.
- 6) Check that the "Desired idle speed" (3) is within the specified idle rpm.




I823H1110192-02

Item		Value	Unit
☐ Engine speed	3	1178	rpm
☐ Desired idle speed		1155	rpm
☐ ISC valve position		58	step
☐ Throttle position		28.4	°

I823H1110193-03

Check 2

- 1) Click the button (4) and decrease the "Spec" (2) to 1 050 rpm slowly.
- 2) Check that the "Desired idle speed" (3) is nearly equal to the "Spec" (2). At the same time, check that the number of steps (5) in the ISC valve position decreases.
- 3) Click the button (6) and increase the "Spec" (2) slowly.
- 4) Check that the "Desired idle speed" (3) is nearly equal to the "Spec" (2). Also, check that the number of steps (5) in the ISC valve position increases.




I823H1110194-03

Item		Value	Unit
☐ Engine speed	3	1059	rpm
☐ Desired idle speed		1054	rpm
☐ ISC valve position	5	48	step
☐ Throttle position		28.4	°

I823H1110196-03

Check 3

- 1) Click the button (6) and increase the “Spec” (2) to 1 500 rpm slowly.
- 2) Check that the “Desired idle speed” (3) is nearly equal to the “Spec” (2). Also, check that the number of steps (5) in the ISC valve position increases.



I823H1110197-03

Item		Value	Unit
☐ Engine speed	3	1504	rpm
☐ Desired idle speed		1506	rpm
☐ ISC valve position	5	78	step
☐ Throttle position		28.4	°


I823H1110195-03

Check 4

- 1) Click the button (6) and increase the “Spec” (2) to 1 900 rpm.
- 2) Check that the “Desired idle speed” (3) is approx. 1 900 rpm.
- 3) Check that the “Engine speed” (7) is close to 1 900 rpm.

NOTE

Be careful not to increase the “Spec” to 2 000 rpm, or the “Engine speed” may reach the upper limit.



I823H1110198-02

Item		Value	Unit
☐ Engine speed	7	1900	rpm
☐ Desired idle speed		1907	rpm
☐ ISC valve position		104	step
☐ Throttle position	3	28.4	°

I823H1110199-02

If the ISC valve does not function properly, inspect the ISC valve or replace the ISC valve. Refer to “DTC “C40” (P0505 / P0506 / P0507): ISC Valve Circuit Malfunction (Page 1A-92)” or “Throttle Body Disassembly and Assembly in Section 1D (Page 1D-12)”.


DTC “C41” (P0230-H/L): FP Relay Circuit Malfunction

B815H21104025


Detected Condition and Possible Cause

Detected Condition			Possible Cause
C41		No voltage is applied to fuel pump.	<ul style="list-style-type: none">Fuel pump relay circuit open or short.Fuel pump relay malfunction.Fuel pump relay switch circuit is shorted to power source.Faulty pump relay (switch side).Fuel pump relay coil circuit open or short.Faulty pump relay (coil side).
P0230	H	Voltage is applied to fuel pump although fuel pump relay is turned OFF.	
	L	No voltage is applied to fuel pump although fuel pump relay is turned ON.	

Wiring Diagram



ECM coupler (Harness side)



Troubleshooting


⚠ CAUTION

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent the terminal damage or terminal bend.


NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to “Use of SDS Diagnosis Reset Procedures (Page 1A-14)”.

C41 (Use of mode select switch)

Step	Action	Yes	No
1	<p>1) Turn the ignition switch OFF.</p> <p>2) Remove the frame cover. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".</p> <p>3) Check the FP relay coupler (1) for loose or poor contacts. If OK, then check the FP relay. Refer to "Fuel Pump Relay Inspection in Section 1G (Page 1G-7)".</p>  <p style="text-align: right;">I815H1110011-01</p> <p><i>Is the FP relay OK?</i></p>	<ul style="list-style-type: none"> ECM power input signal malfunction. Refer to "DTC "C41" (P2505): ECM Power Input Signal Malfunction (Page 1A-100)". Y/B or O/W wire open or short or poor "39" connection. Y/R or R/BI wire open, shorted or poor "33" connection. If wire and connection are OK, intermittent trouble or faulty ECM. Recheck each terminal and wire harness for open circuit and poor connection. Replace the ECM with a known good one, and inspect it again. Refer to "ECM Removal and Installation in Section 1C (Page 1C-2)". 	Replace the FP relay with a new one.

P0230-H (Use of SDS)

Step	Action	Yes	No
1	<p>1) Turn the ignition switch OFF.</p> <p>2) Remove the frame cover. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".</p> <p>3) Check the FP relay coupler (1) for loose or poor contacts. If OK, then check the FP relay. Refer to "Fuel Pump Relay Inspection in Section 1G (Page 1G-7)".</p>  <p style="text-align: right;">I815H1110011-01</p> <p><i>Is the FP relay OK?</i></p>	<ul style="list-style-type: none"> Y/B wire shorted to power source. Y/B wire shorted to the ground. If wire and connection are OK, intermittent trouble or faulty ECM. Recheck each terminal and wire harness for open circuit and poor connection. Replace the ECM with a known good one, and inspect it again. Refer to "ECM Removal and Installation in Section 1C (Page 1C-2)". 	Replace the FP relay with a new one.

P0230-L (Use of SDS)



Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Remove the frame cover. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".</div> <div>3) Check the FP relay coupler (1) for loose or poor contacts. If OK, then check the FP relay. Refer to "Fuel Pump Relay Inspection in Section 1G (Page 1G-7)".</div> <div></div> <div><small>I815H11110011-01</small></div> <div>Is the FP relay OK?</div>	<ul style="list-style-type: none">• Y/B wire open or poor "39" connection.• O/W wire open or shorted to the ground.• R/BI or Y/R wire open or shorted to the ground, or poor "33" connection.• If wire and connection are OK, intermittent trouble of faulty ECM.• Recheck each terminal and wire harness for open circuit and poor connection.• Replace the ECM with a known good one, and inspect it again. Refer to "ECM Removal and Installation in Section 1C (Page 1C-2)".	Replace the FP relay with a new one.

DTC “C41” (P2505): ECM Power Input Signal Malfunction

B815H21104026

Detected Condition and Possible Cause


	Detected Condition	Possible Cause
C41/P2505	No voltage is applied to the ECM.	<ul style="list-style-type: none"> Lead wire/coupler connection of ECM terminal to fuel fuse. Fuel fuse.

Wiring Diagram**ECM coupler (Harness side)****Troubleshooting****⚠ CAUTION**

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent the terminal damage or terminal bend.

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to “Use of SDS Diagnosis Reset Procedures (Page 1A-14)”.

Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Remove the front seat. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".</div> <div>3) Check the ECM coupler for loose or poor contacts. If OK, then measure the ECM input voltage.</div> <div></div> <div>I823H1110090-01</div> <div>4) Disconnect the ECM coupler.</div> <div>5) Insert the needle pointed probe to ECM coupler.</div> <div>6) Measure the voltage between terminal "16" and ground.</div> <div>Special tool  (A): 09900-25008 (Multi-circuit tester set)  (B): 09900-25009 (Needle pointed probe set)</div> <div>Tester knob indication Voltage (---)</div> <div>ECM input voltage Battery voltage ((+) terminal: "16" – (-) terminal: Ground)</div> <div>ECM couplers (Harness side)</div> <div></div> <div>I718H1110250-01</div> <div>Is the voltage OK?</div> <div><ul style="list-style-type: none">Fuel pump relay circuit malfunction. Refer to "DTC "C41" (P0230-H/L): FP Relay Circuit Malfunction (Page 1A-97)".R/BI wire open or short or poor "16" connection.Power source of speedometer shorted to the grand or open.If wire and connection are OK, intermittent trouble or faulty ECM.Recheck each terminal and wire harness for open circuit and poor connection.Replace the ECM with a known good one, and inspect it again. Refer to "ECM Removal and Installation in Section 1C (Page 1C-2)".</div> <div>Open or short circuit in the R/BI wire.</div>		

DTC “C42” (P1650): IG Switch Circuit Malfunction

B815H21104027

Detected Condition and Possible Cause

Detected Condition	Possible Cause
Ignition switch signal is not input to the ECM.	<ul style="list-style-type: none"> Ignition system circuit open or short. ECM malfunction.
When the ID agreement is not verified. ECM does not receive communication signal from the immobilizer antenna. (For E-02, 19, 24)	<ul style="list-style-type: none"> Immobilizer system malfunction. (For E-02, 19, 24)

Troubleshooting**NOTE**



- Refer to “Ignition Switch Inspection in Section 9C (Page 9C-8)” for details.
- After repairing the trouble, clear the DTC using SDS tool. Refer to “Use of SDS Diagnosis Reset Procedures (Page 1A-14)”.

DTC “C44” (P0130/P0135): HO2 Sensor (HO2S) Circuit Malfunction

B815H21104028

Detected Condition and Possible Cause

Detected Condition	Possible Cause
C44/P0130 HO2 sensor output voltage is not input to ECM during engine operation and running condition. Sensor voltage > 1.0 V	<ul style="list-style-type: none"> HO2 sensor circuit is open or shorted to the power source.
C44/P0135 The heater can not operate so that heater operation voltage is not supplied to the oxygen heater circuit.	<ul style="list-style-type: none"> Heated circuit is open or shorted to the ground. Battery voltage is not supply to the HO2 sensor.

Wiring Diagram**ECM coupler (Harness side)**



Troubleshooting (When Indicating C44/P0130:)


⚠ CAUTION



When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent the terminal damage or terminal bend.

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to “Use of SDS Diagnosis Reset Procedures (Page 1A-14)”.

Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Remove the right side cowling. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.</div> <div>3) Check the HO2 sensor coupler (1) for loose or poor contacts. If OK, then check the HO2 sensor lead wire continuity.</div> <div> I823H1110092-01</div> <div>4) Disconnect the HO2 sensor coupler.</div> <div>5) Check the continuity between the W/G wire and O/W wire. If the sound is not heard from the tester, the circuit condition is OK.</div> <div>Special tool  (A): 09900-25008 (Multi-circuit tester set)</div> <div>Tester knob indication Continuity test (●)))</div> <div> I815H1110025-01</div> <div>6) Disconnect the ECM coupler. Refer to “ECM Removal and Installation in Section 1C (Page 1C-2)”.</div>	Go to Step 2.	W/G wire shorted to the power source, or W/G or B/Br wire open.



Step	Action	Yes	No
1	<div>7) Check the continuity between the W/G wire terminal “A” and terminal “12”. Also, check the continuity between the B/Br wire terminal “B” and terminal “29”.</div> <div>Special tool  (A): 09900-25008 (Multi-circuit tester set)  (B): 09900-25009 (Needle pointed probe set)</div> <div>Tester knob indication Continuity (•)))</div> <div>ECM couplers (Harness side)</div> <div></div> <div><small>I823H1110093-02</small></div> <div>Is the continuity OK?</div>	Go to Step 2.	W/G wire shorted to the power source, or W/G or B/Br wire open.


Step	Action	Yes	No
2	<p>1) Connect the ECM coupler and HO2 sensor coupler.</p> <p>2) Warm up the engine enough.</p> <p>3) Insert the needle pointed probes to the lead wire coupler.</p> <p>4) Measure the HO2 sensor output voltage between the W/G wire and B/Br wire, in idling condition.</p> <p>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set) TOOL (B): 09900-25009 (Needle pointed probe set)</p> <p>Tester knob indication Voltage (---)</p> <p>HO2 sensor output voltage at idle speed 0.3 V and less ((+) terminal: W/G – (–) terminal: B/Br)</p>  <p style="text-align: right;">I815H1110026-01</p> <p>5) If OK, then pinch the PAIR hose (1) with a proper hose clamp.</p>  <p style="text-align: right;">I815H1110027-01</p> <p>6) Measure the HO2 sensor output voltage while holding the engine speed at 3 000 r/min.</p> <p>HO2 sensor output voltage at 3 000 r/min 0.6 V and more ((+) terminal: W/G – (–) terminal: B/Br)</p> <p><i>Is the voltage OK?</i></p>	<ul style="list-style-type: none"> W/G or B/Br wire open or shorted to the power source, or poor “12” or “29” connection. If wire and connection are OK, intermittent trouble or faulty ECM. Recheck each terminal and wire harness for open circuit and poor connection. Replace the ECM with a known good one, and inspection it again. Refer to “ECM Removal and Installation in Section 1C (Page 1C-2)”. 	<p>Replace the HO2 sensor with a new one. Refer to “Heated Oxygen Sensor (HO2S) Removal and Installation in Section 1B (Page 1B-9)”.</p>

Troubleshooting (When Indicating C44/P0135:)

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to “Use of SDS Diagnosis Reset Procedures (Page 1A-14)”.

Step	Action	Yes	No
1	<p>1) Turn the ignition switch OFF.</p> <p>2) Remove the right side cowling. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.</p> <p>3) Check the HO2 sensor coupler (1) for loose or poor contacts. If OK, then measure the HO2 sensor resistance.</p>  <p style="text-align: right; font-size: small;">I823H1110092-01</p> <p>4) Disconnect the HO2 sensor coupler and measure the resistance between terminals.</p> <p>⚠ CAUTION</p> <ul style="list-style-type: none"> • Temperature of the sensor affects resistance value largely. • Make sure that the sensor heater is in atmospheric temperature. <p>Special tool  (A): 09900-25008 (Multi-circuit tester set)</p> <p>Tester knob indication Resistance (Ω)</p> <p>HO2 sensor heater resistance Approx. 8 Ω at 23 °C (73 °F) (W – W)</p>  <p style="text-align: right; font-size: small;">I815H1110028-02</p> <p>Is the resistance OK?</p>	Go to Step 2.	Replace the HO2 sensor with a new one. Refer to “HO2 Sensor Removal and Installation in Section 1C (Page 1C-10)”.


Step	Action	Yes	No
2	<div>1) Connect the HO2 sensor coupler.</div> <div>2) Insert the needle pointed probes to the lead wire coupler.</div> <div>3) Turn the ignition switch ON and measure the heater voltage between the W/B wire and ground.</div> <div>If the tester voltage indicates the battery voltage, it is good condition.</div> <div>NOTE</div> <div>Battery voltage can be detected only before starting the engine.</div> <div>Special tool</div> <div> (A): 09900-25008 (Multi-circuit tester set)</div> <div> (B): 09900-25009 (Needle pointed probe set)</div> <div>Tester knob indication</div> <div>Voltage (---)</div> <div>Heater voltage</div> <div>Battery voltage</div> <div>(+) terminal: W/B – (-) terminal: Ground)</div> <div></div> <div>I815H1110029-01</div> <div>Is the voltage OK?</div>	<ul style="list-style-type: none">• O/W or W/B wire open or shorted to the ground, or poor “41” connection.• Recheck each terminal and wire harness for open circuit and poor connection.• If wire and connection are OK, intermittent trouble or faulty ECM.• Replace the ECM with a known good one, and inspect it again. Refer to “ECM Removal and Installation in Section 1C (Page 1C-2)”.	<ul style="list-style-type: none">• Open or short circuit in the W/B wire or O/ W wire.• Loose or poor contacts on the ECM coupler or HO2 sensor coupler.

DTC “C49” (P1656): PAIR Control Solenoid Valve Circuit Malfunction


B815H21104029

Detected Condition and Possible Cause

Detected Condition	Possible Cause
PAIR control solenoid valve voltage is not input to ECM.	<ul style="list-style-type: none"> PAIR control solenoid valve circuit open or short. PAIR control solenoid valve malfunction. ECM malfunction.

Wiring Diagram

I815H1110017-02

ECM coupler (Harness side)



I823H1110004-01


Troubleshooting**⚠ CAUTION**

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent the terminal damage or terminal bend.

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to “Use of SDS Diagnosis Reset Procedures (Page 1A-14)”.

Step	Action	Yes	No
1	<div>1) Turn the ignition switch OFF.</div> <div>2) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation in Section 1D (Page 1D-6)".</div> <div>3) Check the PAIR control solenoid valve coupler (1) for loose or poor contacts. If OK, then measure the PAIR control solenoid valve resistance.</div> <div></div> <div>I823H1110096-01</div> <div>4) Disconnect the PAIR control solenoid valve coupler.</div> <div>5) Measure the resistance between terminals.</div> <div>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set)</div> <div>Tester knob indication Resistance (Ω)</div> <div>PAIR control solenoid valve resistance 20 – 24 Ω at 20 – 30 °C (68 – 86 °F) (Terminal – Terminal)</div> <div></div> <div>I823H1110097-01</div> <div>Is the resistance OK?</div>	Go to Step 2.	Replace the PAIR control solenoid with a new one. Refer to "PAIR Control Solenoid Valve Removal and Installation in Section 1B (Page 1B-10)".

Step	Action	Yes	No
2	<p>1) Turn the ignition switch ON.</p> <p>2) Measure the voltage between the O/W wire and ground.</p> <p>Special tool TOOL (A): 09900-25008 (Multi-circuit tester set)</p> <p>Tester knob indication Voltage (---)</p> <p>PAIR control solenoid valve voltage Battery voltage ((+) terminal: O/W – (–) terminal: Ground)</p>  <p>1823H1110098-01</p> <p><i>Is the voltage OK?</i></p>	<ul style="list-style-type: none"> • Gr wire open or shorted to the ground, or poor “44” connection failure. • If wire and connection are OK, intermittent trouble or faulty ECM. • Recheck each terminal and wire harness for open circuit and poor connection. • Replace the ECM with a known good one, and inspect it again. Refer to “ECM Removal and Installation in Section 1C (Page 1C-2)”. 	Open or short circuit in the O/W wire.

Active Control Inspection


- 1) Set up the SDS tool. (Refer to SDS operation manual for further details.)
- 2) Turn the ignition switch ON.
- 3) Click “PAIR Sol operating control” (1).



I815H1110018-01

- 4) Click each button (2). At this time, if an operating sound is heard from the PAIR control solenoid valve, the function is normal.

☐ Throttle position	27.9	*
☐ PAIR control solenoid valve	On	
☐ Secondary throttle actuator position sensor	98.4	%



I815H1110019-01


DTC “C60” (P0480): Cooling Fan Relay Circuit Malfunction

B815H21104030

Detected Condition and Possible Cause


Detected Condition	Possible Cause
Cooling fan relay signal is not input to ECM.	<ul style="list-style-type: none"> Cooling fan relay circuit open or short. ECM malfunction.

Wiring Diagram



I823H1110099-05

ECM coupler (Harness side)



I823H1110004-01


Troubleshooting

⚠ CAUTION

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent the terminal damage or terminal bend.


NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to “Use of SDS Diagnosis Reset Procedures (Page 1A-14)”.

Step	Action	Yes	No
1	<div><div>1) Turn the ignition switch OFF.</div><div>2) Remove the left upper panel. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.</div><div>3) Check the cooling fan relay (1) coupler for loose or poor contacts.</div><div>If OK, then inspection the cooling fan relay. Refer to “Cooling Fan Inspection in Section 1F (Page 1F-8)”.</div></div> <div></div> <div>I823H1110100-01</div> <div>Is the cooling fan relay OK?</div>	<ul style="list-style-type: none">• O/W and O/R wire open or shorted to the ground, or poor “43” connection.• If wire and connection are OK, intermittent trouble or faulty ECM.• Recheck each terminal and wire harness for open circuit and poor connection.• Replace the ECM with a known good one, and inspect it again. Refer to “ECM Removal and Installation in Section 1C (Page 1C-2)”.	Replace the cooling fan relay with a new one.

Active Control Inspection

- 1) Set up the SDS tool. (Refer to SDS operation manual for further details.)
- 2) Start the engine and run it in idling condition.
- 3) Click "Cooling fan relay control" (1).




I815H1110020-01

- 4) Click the "Operate" (2).

At this time, if an operation sound is heard from the cooling fan relay and cooling fan motors are operated, the function is normal.

☐ Secondary throttle actuator position sensor	31.0	%
☐ Cooling fan relay	On	
☐ Manifold absolute pressure 1	75.0	kPa
☐ PAIR control solenoid valve	Off	



I823H1110205-03

- 5) Click the "Stop" (3) to check the operation properly.

☐ Secondary throttle actuator position sensor	31.0	%
☐ Cooling fan relay	Off	
☐ Manifold absolute pressure 1	75.0	kPa
☐ PAIR control solenoid valve	Off	



I823H1110206-03


DTC “C62” (P0443): EVAP System Purge Control Solenoid Valve Circuit Malfunction (E-33 only)

B815H21104031

Detected Condition and Possible Cause


Detected Condition	Possible Cause
EVAP system purge control valve voltage is not input to ECM.	<ul style="list-style-type: none">• EVAP system purge control valve circuit open or short.• EVAP system purge control valve malfunction.• ECM malfunction.

Wiring Diagram



I815H1110016-02

ECM coupler (Harness side)



I823H1110004-01


Troubleshooting


⚠ CAUTION

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent the terminal damage or terminal bend.

NOTE


After repairing the trouble, clear the DTC using SDS tool. Refer to “Use of SDS Diagnosis Reset Procedures (Page 1A-14)”.

Step	Action	Yes	No
1	<p>1) Turn the ignition switch OFF.</p> <p>2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".</p> <p>3) Check the EVAP system purge control valve coupler (1) for loose or poor contacts. If OK, then measure the EVAP system purge control valve resistance.</p>  <p style="text-align: right; font-size: small;">I823H1110103-01</p> <p>4) Disconnect the EVAP system purge control valve coupler.</p> <p>5) Measure the resistance between terminals.</p> <p>Special tool <u>TOOL (A): 09900-25008 (Multi-circuit tester set)</u></p> <p><u>Tester knob indication</u> Resistance (Ω)</p> <p><u>EVAP system purge control valve resistance</u> Approx. 32 Ω at 20 °C (68 °F) (Terminal – Terminal)</p>  <p style="text-align: right; font-size: small;">I823H1110105-01</p> <p><i>Is the resistance OK?</i></p>	Go to Step 2.	<p>Replace the EVAP system purge control with a new one. Refer to "Evaporative Emission Control System Removal and Installation (Only for E-33) in Section 1B (Page 1B-14)".</p>

Step	Action	Yes	No
2	<div>1) Turn the ignition switch ON.</div> <div>2) Measure the voltage between the O/W wire and ground.</div> <div>Special tool</div> <div>TOOL (A): 09900-25008 (Multi-circuit tester set)</div> <div>Tester knob indication</div> <div>Voltage (---)</div> <div>EVAP system purge control valve voltage</div> <div>Battery voltage</div> <div>((+) terminal: O/W – (–) terminal: Ground)</div> <div></div> <div>I718H2110003-01</div> <div>Is the voltage OK?</div>	<ul style="list-style-type: none">• Dbr wire open or shorted to the ground, or poor “15” connection failure.• If wire and connection are OK, intermittent trouble or faulty ECM.• Recheck each terminal and wire harness for open circuit and poor connection.• Replace the ECM with a known good one, and inspect it again. Refer to “ECM Removal and Installation in Section 1C (Page 1C-2)”.	Open or short circuit in the O/W wire.

Active Control Inspection

- 1) Set up the SDS tool. (Refer to SDS operation manual for further details.)
- 2) Turn the ignition switch ON.
- 3) Click “EVAP purge valve operating control” (1).



- 4) Click each button (2). At this time, if an operating sound is heard from the EVAP system purge control valve, the function is normal.

☐ Engine speed	0 rpm
☐ Engine coolant / oil temperature	25.8 °C
☐ EVAP purge valve	On
☐ Manifold absolute pressure 1	100.3 kPa
☐ Intake air temperature	25.8 °C



1823H1110219-01

Specifications

Service Data

B815H21107001

Injector + Fuel Pump + Fuel Pressure Regulator

Item	Specification	Note
Injector resistance	11 – 13 Ω at 20 °C (68 °F)	

FI Sensors

Item	Standard/Specification		Note
CKP sensor resistance	180 – 280 Ω		
CKP sensor peak voltage	3.0 V and more		When cranking
IAP sensor input voltage	4.5 – 5.5 V		
IAP sensor output voltage	Approx. 2.7 V at idle speed		
TP sensor input voltage	4.5 – 5.5 V		
TP sensor output voltage	Closed	Approx. 1.1 V	
	Opened	Approx. 4.3 V	
ECT sensor input voltage	4.5 – 5.5 V		
ECT sensor output voltage	0.15 – 4.85 V		
ECT sensor resistance	Approx. 2.45 k Ω at 20 °C (68 °F)		
IAT sensor input voltage	4.5 – 5.5 V		
IAT sensor output voltage	0.15 – 4.85 V		
IAT sensor resistance	Approx. 2.58 k Ω at 20 °C (68 °F)		
AP sensor input voltage	4.5 – 5.5 V		
AP sensor output voltage	Approx. 3.6 V at 100 kPa (760 mmHg)		
TO sensor resistance	16.5 – 22.3 k Ω		
TO sensor voltage	Normal	0.4 – 1.4 V	
	Leaning	3.7 – 4.4 V	When leaning 65°
GP switch voltage	0.6 V and more		From 1st to Top
Injector voltage	Battery voltage		
Ignition coil primary peak voltage	80 V and more		When cranking
HO2 sensor output voltage	0.3 V and less at idle speed		
	0.6 V and more at 3 000 r/min		
HO2 sensor heater resistance	Approx. 8 Ω at 23 °C (73 °F)		
PAIR control solenoid valve resistance	20 – 24 Ω at 20 – 30 °C (68 – 86 °F)		
STP sensor input voltage	4.5 – 5.5 V		
STP sensor output voltage	Closed	Approx. 0.5 V	
	Opened	Approx. 3.9 V	
STVA resistance	Approx. 6.5 Ω		
EVAP system purge control solenoid valve resistance	Approx. 32 Ω at 20 °C (68 °F)		E-33 only
ISC valve resistance	Approx. 80 Ω at 20 °C (68 °F)		


Special Tools and Equipment

Special Tool

B815H21108001

09900-25008

Multi-circuit tester set




(Page 1A-29) /
 (Page 1A-31) /
 (Page 1A-32) /
 (Page 1A-110) /
 (Page 1A-116) /
 (Page 1A-117) /
 (Page 1A-32) /
 (Page 1A-34) /
 (Page 1A-35) /
 (Page 1A-36) /
 (Page 1A-37) /
 (Page 1A-38) /
 (Page 1A-38) /
 (Page 1A-39) /
 (Page 1A-41) /
 (Page 1A-42) /
 (Page 1A-43) /
 (Page 1A-44) /
 (Page 1A-45) /
 (Page 1A-45) /
 (Page 1A-46) /
 (Page 1A-48) /
 (Page 1A-49) /
 (Page 1A-50) /
 (Page 1A-51) /
 (Page 1A-51) /
 (Page 1A-53) /
 (Page 1A-54) /
 (Page 1A-55) /
 (Page 1A-56) /
 (Page 1A-56) /
 (Page 1A-58) /
 (Page 1A-59) /
 (Page 1A-60) /
 (Page 1A-61) /
 (Page 1A-62) /
 (Page 1A-62) /
 (Page 1A-63) /
 (Page 1A-65) /
 (Page 1A-66) /
 (Page 1A-67) /
 (Page 1A-68) /
 (Page 1A-69) /
 (Page 1A-70) /
 (Page 1A-73) /
 (Page 1A-76) /
 (Page 1A-77) /
 (Page 1A-78) /
 (Page 1A-79)

(Page 1A-80) /
 (Page 1A-80) /
 (Page 1A-81) /
 (Page 1A-83) /
 (Page 1A-85) /
 (Page 1A-86) /
 (Page 1A-87) /
 (Page 1A-89) /
 (Page 1A-90) /
 (Page 1A-91) /
 (Page 1A-93) /
 (Page 1A-94) /
 (Page 1A-101) /
 (Page 1A-103) /
 (Page 1A-104) /
 (Page 1A-105) /
 (Page 1A-106) /
 (Page 1A-107) /
 (Page 1A-109)






09900-25009

Needle pointed probe set



(Page 1A-36) /
 (Page 1A-38) /
 (Page 1A-38) /
 (Page 1A-43) /
 (Page 1A-45) /
 (Page 1A-49) /
 (Page 1A-51) /
 (Page 1A-54) /
 (Page 1A-56) /
 (Page 1A-60) /
 (Page 1A-62) /
 (Page 1A-62) /
 (Page 1A-67) /
 (Page 1A-69) /
 (Page 1A-70) /
 (Page 1A-78) /
 (Page 1A-80) /
 (Page 1A-81) /
 (Page 1A-83) /
 (Page 1A-93) /
 (Page 1A-101) /
 (Page 1A-104) /
 (Page 1A-105) /
 (Page 1A-107)

<p>09900-28630 TPS test wire harness ☞ (Page 1A-46)</p>	<p>09904-41010 SDS set ☞ (Page 1A-13) / ☞ (Page 1A-17)</p>
<p>09917-47011 Vacuum pump gauge ☞ (Page 1A-39) / ☞ (Page 1A-63)</p>	<p>09930-82720 Mode select switch ☞ (Page 1A-3) / ☞ (Page 1A-12) / ☞ (Page 1A-12)</p>
<p>99565-01010-012 CD-ROM Ver.12 ☞ (Page 1A-13) / ☞ (Page 1A-17)</p>	



Emission Control Devices

Precautions

Precautions for Emission Control Devices

B815H21200001


Refer to "General Precautions in Section 00 (Page 00-1)".

General Description

Fuel Injection System Description

B815H21201001

GSX1300R motorcycles are equipped with a fuel injection system for emission level control. This fuel injection system is precision designed, manufactured and adjusted to comply with the applicable emission limits. With varying engine conditions, all of the fuel injection volumes are precisely controlled by the programmed injection maps in the ECM to reduce CO, NOX and HC. Adjusting, interfering with, improper replacement, or resetting of any of the fuel injection components may adversely affect injection performance and cause the motorcycle to exceed the exhaust emission level limits.




I815H1120001-01

1. Fuel tank	5. Fuel delivery pipe	9. Secondary fuel injector
2. Fuel pump	6. Fuel pressure regulator	"A": Before-pressurized fuel
3. Fuel mesh filter (For low pressure)	7. Fuel filter (For high pressure)	"B": Pressurized fuel
4. Fuel feed hose	8. Primary fuel injector	"C": Relieved fuel

Crankcase Emission Control System Description

B815H21201002

The engine is equipped with a PCV system to prevent discharging crankcase emissions into the atmosphere. Blow-by gas in the engine is constantly drawn into the crankcase, which is returned to the combustion chamber through the PCV (breather) hose, air cleaner and throttle body.




I815H1120002-01

1. Air cleaner box	3. PCV (breather) hose	"B": Fuel/Air mixture	"D": Exhaust gas
2. PCV (breather) reed valve	"A": Fresh air	"C": Blow-by gas	

Exhaust Emission Control System Description

B815H21201003


The exhaust emission control system is composed of the PAIR system, HO2 sensor, three-way catalyst system and ISC system. The fresh air is drawn into the exhaust port through the PAIR control solenoid valve and PAIR reed valve. The PAIR control solenoid valve is operated by the ECM, which is controlled according to the signals from TPS, ECTS, IATS, IAPS and CKPS. The ISC valve adjusts the bypass air volume of the throttle body to control engine idling speed with various sensor signals by varying engine running conditions and the idling control contributes to reduce exhaust emission level.



I815H1120003-01


1. PAIR control solenoid valve	4. Primary fuel injector	7. ECM	"A": Fresh air
2. PAIR reed valve	5. Secondary fuel injector	8. Three-way catalyst	"B": Exhaust gas
3. Air cleaner box	6. ISC valve	9. HO2 sensor	

PAIR System Diagram



1. PAIR control solenoid valve	2. PAIR reed valve	"A": Fresh air	"B": Exhaust gas
--------------------------------	--------------------	----------------	------------------

Pair System Hose Routing Diagram



I815H1120005-03

1. PAIR control solenoid valve	3. Marking (Yellow)	"B": Top side	"b": 0°
2. PAIR reed valve	"A": To the air cleaner box	"a": 45°	 (a) : 11 N·m (1.1 kgf-m, 8.0 lb-ft)

Noise Emission Control System Description

B815H21201004

TAMPERING WITH THE NOISE CONTROL SYSTEM PROHIBITED: Local law or federal law prohibits the following acts or the causing thereof:


- The removal or rendering inoperative by any person, other than for purposes of maintenance, repair or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use, or
- The use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

Among Those Acts Presumed to Constitute Tampering are the Acts Listed Below:

- Removing or puncturing the muffler, baffles, header pipes, screen type spark arrester (if equipped) or any other component which conducts exhaust gases.
- Removing or puncturing the air cleaner case, air cleaner cover, baffles or any other component which conducts intake air.
- Replacing the exhaust system or muffler with a system or muffler not marked with the same model specific code as the code listed on the Motorcycle Noise Emission Control Information label.

Evaporative Emission Control System Diagram (Only for E-33)

B815H21201005




I815H1120006-01

1. Fuel tank	6. Fuel tank pressure control valve	11. IAP sensor
2. Fuel pump	7. EVAP canister	“A”: Fuel
3. Fuel feed hose	8. Purge hose	“B”: HC vapor
4. Surge hose	9. EVAP purge control valve	“C”: Fresh air
5. Fuel shut-off valve	10. Throttle body	“D”: Vacuum

Schematic and Routing Diagram

EVAP Canister Hose Routing Diagram (Only for E-33)

B815H21202001



I815H1120007-01

1. Fuel shut-off valve	8. Clamp : The ends of the clamp should face upward.
2. TPC valve	9. Clamp : The ends of the clamp should face backward.
3. EVAP canister	10. White paint : White paint marking on the surge hose should face backward.
4. Surge hose	11. White paint : White paint marking on the surge hose should face upward.
5. Pruge hose	"A": Pass the surge hose over the battery (-) cable.
6. EVAP pruge system control solenoid valve	"B": Pass the purge hose under the battery (-) cable.
7. Clamp : The ends of the clamp should face outside.	

Repair Instructions

Heated Oxygen Sensor (HO2S) Removal and Installation

B815H21206001

Removal


⚠ WARNING

Do not remove the HO2 sensor while it is hot.

⚠ CAUTION

- Be careful not to expose the HO2 sensor to excessive shock.
- Do not use an impact wrench when removing or installing the HO2 sensor.
- Be careful not to twist or damage the sensor lead wires.

- 1) Remove the right side cowling. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Disconnect the HO2 sensor coupler (1).
- 3) Remove the HO2 sensor (2).



I815H1120008-01

Installation

Install the HO2 sensor in the reverse order of removal. Pay attention to the following points:


⚠ CAUTION

Do not apply oil or other materials to the sensor air hole.

- Tighten the HO2 sensor (1) to the specified torque.

Tightening torque

HO2 sensor (a): 25 N·m (2.5 kgf·m, 18.0 lb·ft)



I815H1120009-01

Heated Oxygen Sensor (HO2S) Inspection

B815H21206002


Refer to "DTC "C44" (P0130/P0135): HO2 Sensor (HO2S) Circuit Malfunction in Section 1A (Page 1A-102)".

PAIR Reed Valve Removal and Installation

B815H21206003


Removal

- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".
- 2) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation in Section 1D (Page 1D-6)".
- 3) Disconnect the PAIR hoses (1) and remove the PAIR reed valve covers (2).



I815H1120010-01

- 4) Remove the PAIR reed valves (3).



I815H1120011-02

Installation


Install the PAIR reed valve in the reverse order of removal. Pay attention to the following points:

- Apply thread lock to the bolts and tighten them to the specified torque.

1322 : Thread lock cement 99000-32110
(THREAD LOCK CEMENT SUPER 1322 or equivalent)

Tightening torque

PAIR reed valve cover bolt (a): 11 N·m (1.1 kgf-m, 8.0 lb-ft)




I815H1120012-01

PAIR Control Solenoid Valve Removal and Installation

B815H21206004

Removal

- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".
- 2) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation in Section 1D (Page 1D-6)".
- 3) Disconnect the PAIR control solenoid valve coupler (1) and PAIR hoses (2).
- 4) Remove the PAIR control solenoid valve (3).



I815H1120013-01

Installation

Install the PAIR control solenoid valve in the reverse order of removal. Pay attention to the following point:


- Connect the PAIR control solenoid valve coupler and PAIR hoses securely. Refer to "Exhaust Emission Control System Description (Page 1B-3)".

PAIR System Inspection

B815H21206005

PAIR Hose

- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".
- 2) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation in Section 1D (Page 1D-6)".
- 3) Inspect the PAIR hoses (1) for wear or damage. If it is worn or damaged, replace the PAIR hose with a new one. Refer to "Exhaust Emission Control System Description (Page 1B-3)".



I815H1120015-01

- 4) Reinstall the removed parts.

PAIR Reed Valve

NOTE

PAIR control solenoid valve can be checked without removing it from the motorcycle. Refer to "DTC "C49" (P1656): PAIR Control Solenoid Valve Circuit Malfunction in Section 1A (Page 1A-108)".

- 1) Remove the PAIR reed valves. Refer to "PAIR Reed Valve Removal and Installation (Page 1B-9)".
- 2) Inspect the reed valves for the carbon deposit. If the carbon deposit is found in the reed valve, replace the PAIR reed valve with a new one.




I823H1120013-01

- 3) Reinstall the PAIR reed valves. Refer to "PAIR Reed Valve Removal and Installation (Page 1B-9)".


PAIR Control Solenoid Valve

- 1) Remove the PAIR control solenoid valve. Refer to "PAIR Control Solenoid Valve Removal and Installation (Page 1B-10)".
- 2) Check that air flows through the air inlet port to the air outlet port. If air does not flow out, replace the PAIR control solenoid valve with a new one.



I823H1120014-01

- 3) Connect the 12 V battery to the PAIR control solenoid valve terminals and check the air flow. If air does not flow out, the solenoid valve is in normal condition.



I823H1120015-01

- 4) Check the resistance between the terminals of the PAIR control solenoid valve.

Special tool


TOOL : 09900-25008 (Multi-circuit tester set)

Tester knob indication

Resistance (Ω)

PAIR control solenoid valve resistance

20 – 24 Ω at 20 – 30 °C (68 – 86 °F)



I823H1120016-01

- 5) Reinstall the PAIR control solenoid valve. Refer to "PAIR Control Solenoid Valve Removal and Installation (Page 1B-10)".

Crankcase Breather (PCV) Hose Inspection

B815H21206006

Inspect the crankcase breather (PCV) hose in the following procedures:

- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".
- 2) Inspect the PCV hose (1) for wear and damage. If it is worn or damaged, replace the PCV hose with a new one.
- 3) Check that the PCV hose (1) is securely connected.



I815H1120014-01


- 4) Install the removed parts.

Crankcase Breather (PCV) Hose / Reed Valve / Cover Removal and Installation

B815H21206007

Removal

- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".
- 2) Disconnect the PCV hose (1).
- 3) Remove the PCV reed valve cover (2).




I815H1120016-01

- 4) Remove the PCV reed valve (3).



I815H1120017-01

- 5) Remove the PCV cover (4).



I815H1120018-04

1B-13 Emission Control Devices:

Installation

Installation is in the reverse order of removal.


Pay attention to the following points:

- Apply bond to the mating surface of the PCV cover.

1207B : Sealant 99000-31140 (SUZUKI BOND No.1207B or equivalent)

NOTE

- Make surfaces free from moisture, oil, dust and other foreign materials.
- Spread the sealant on surfaced thinly to form an even layer, and assembly the crankcases within a few minutes.



I823H1120021-02

- Fit the engine ground lead wire (1) and tighten the bolts.



I815H1120019-03

- Install the PCV reed valve.
- Connect the PCV hose securely.

Crankcase Breather (PCV) Cover Inspection

B815H21206008

Inspect the crankcase breather (PCV) cover in the following procedures:

- 1) Remove the PCV cover. Refer to "Crankcase Breather (PCV) Hose / Reed Valve / Cover Removal and Installation (Page 1B-12)".
- 2) Inspect the PCV cover in the carbon deposit. If the carbon deposit is found in the PCV cover, remove the carbon.



I823H1120024-01

- 3) Reinstall the PCV cover. Refer to "Crankcase Breather (PCV) Hose / Reed Valve / Cover Removal and Installation (Page 1B-12)".

Crankcase Breather (PCV) Inspection

- 1) Remove the PCV reed valve. Refer to "Crankcase Breather (PCV) Hose / Reed Valve / Cover Removal and Installation (Page 1B-12)".
- 2) Inspect the PCV reed valve for the carbon deposit. If the carbon deposit is found in the reed valve, replace the PCV reed valve with a new one.



I823H1120025-01

- 3) Reinstall the PCV reed valve. Refer to "Crankcase Breather (PCV) Hose / Reed Valve / Cover Removal and Installation (Page 1B-12)".

Evaporative Emission Control System Removal and Installation (Only for E-33)

B815H21206009

Hose

Removal


- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".
- 2) Remove the frame cover. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 3) Remove the EVAP hoses as shown in the EVAP canister hose routing diagram. Refer to "EVAP Canister Hose Routing Diagram (Only for E-33) (Page 1B-8)".

Installation

- 1) Install the EVAP hoses as shown in the EVAP canister hose routing diagram. Refer to "EVAP Canister Hose Routing Diagram (Only for E-33) (Page 1B-8)".
- 2) Reinstall the removed parts.

EVAP Canister Removal

- 1) Remove the frame cover. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Disconnect the surge hose (1) and purge hose (2).
- 3) Remove the EVAP canister (3) from the bracket.




I815H1120020-02

Installation

Install the EVAP canister in the reverse order of removal.

EVAP System Purge Control Solenoid Valve Removal

- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".
- 2) Disconnect the coupler (1) and purge hoses (2).
- 3) Remove the EVAP system purge control solenoid valve (3).




I815H1120021-02

Installation

- 1) Install the EVAP system purge control solenoid valve as shown in the EVAP canister hose routing diagram. Refer to "EVAP Canister Hose Routing Diagram (Only for E-33) (Page 1B-8)".
- 2) Reinstall the removed parts.

Tank Pressure Control Valve Removal

- 1) Remove the frame cover. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Disconnect the surge hoses (1).
- 3) Remove the tank pressure control valve (2).



I815H1120022-02


Installation

- 1) Install the tank pressure control valve as shown in the EVAP canister hose routing diagram. Refer to "EVAP Canister Hose Routing Diagram (Only for E-33) (Page 1B-8)".
- 2) Reinstall the removed parts.

Fuel Shut-off Valve

Removal

- 1) Remove the fuel tank. Refer to “Fuel Tank Removal and Installation in Section 1G (Page 1G-9)”.
- 2) Disconnect the surge hose (1).
- 3) Remove the fuel shut-off valve (2).



I815H1120024-01

Installation

- 1) Install the fuel shut-off valve as shown in the EVAP canister hose routing diagram. Refer to “EVAP Canister Hose Routing Diagram (Only for E-33) (Page 1B-8)”.
- 2) Reinstall the removed parts.

Evaporative Emission Control System Inspection (For E-33 only)

B815H21206010

Refer to “Evaporative Emission Control System Removal and Installation (Only for E-33) (Page 1B-14)”.

Hose


Inspect the hoses for wear or damage. If it is worn or damaged, replace the hose with a new one.

NOTE

Make sure that the hoses are securely connected.

EVAP Canister

Inspect the EVAP canister body for damage to the body. If any defect is found, replace the EVAP canister with a new one.



I815H1120023-01

EVAP System Purge Control Solenoid Valve

NOTE


EVAP system purge control solenoid valve can be checked without removing it from the motorcycle. Refer to “DTC “C62” (P0443): EVAP System Purge Control Solenoid Valve Circuit Malfunction (E-33 only) in Section 1A (Page 1A-115)”.

- 1) Check that no air flows through both of the air inlet and outlet ports. If air flows out, replace the EVAP system purge control solenoid valve with a new one.



I718H2120003-03

- 2) Connect the 12 V battery to the terminals of the EVAP system purge control solenoid valve and check the air flow. If air flows out, the solenoid valve is in normal condition.



I718H2120004-01

- 3) Check the resistance between the terminals of the EVAP system purge control solenoid valve. If the resistance is not within the standard range, replace the EVAP system purge control solenoid valve with a new one.

Special tool


TOOL (A): 09900-25008 (Multi-circuit tester set)

Tester knob indication

Resistance (Ω)

EVAP system purge control solenoid valve resistance

Approx. 32Ω at 20°C (68°F)




I718H2120005-02

Tank Pressure Control Valve


Inspect the tank pressure control valve body for damage. Inspect the tank pressure control valve operation in the following procedures:

- 1) When air pressure is applied lightly to the tank pressure control valve from the side "A", air should flow out through the valve smoothly.



I815H1120025-01

- 2) When air pressure is applied lightly to the tank pressure control valve from the side "B", air should flow out through the valve difficulty.



I815H1120026-01

- 3) If the tank pressure control valve operates otherwise, it must be replaced.

⚠ WARNING

Gasoline and gasoline vapor is toxic. A small amount of fuel remains in the tank pressure control valve when checking it. Do not swallow the fuel when blowing the tank pressure control valve.


NOTE

When connecting the tank pressure control valve to the hose, the side "B" should face toward the fuel shut-off valve side, and the side "A" should face toward the canister side.

Fuel Shut-Off Valve

Inspect the fuel shut-off valve body for damage. Inspect the fuel shut-off valve operation in the following procedures:

- 1) When air is blown into the fuel shut-off valve with its side "A" positioned upward, the air can pass through to the canister side.




I823H1120037-01

1B-17 Emission Control Devices:

- 2) When air is blown into the fuel shut-off valve with its side "A" positioned sideways, the air cannot pass through to the canister side. If the fuel shut-off valve operates otherwise, it must be replaced.

⚠ WARNING

Gasoline and gasoline vapor is toxic. A small amount of fuel remains in the fuel shut-off valve when checking it. Do not swallow the fuel when blowing the fuel shut-off valve.



I823H1120038-02

Specifications

Service Data

B815H21207001

FI sensors

Item	Specification	Note
HO2 sensor heater resistance	Approx. 8 Ω at 23 °C (73 °F)	
HO2 sensor output voltage	0.3 V and less at idle speed	
	0.6 V and more at 3 000 r/min	
PAIR control solenoid valve resistance	20 – 24 Ω at 20 – 30 °C (68 – 86 °F)	
EVAP system purge control solenoid valve resistance	Approx. 32 Ω at 20 °C (68 °F)	E-33 only

Tightening Torque Specifications

B815H21207002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
HO2 sensor	25	2.5	18.0	☞ (Page 1B-9)
PAIR reed valve cover bolt	11	1.1	8.0	☞ (Page 1B-10)

NOTE

The specified tightening torque is also described in the following.
"Exhaust Emission Control System Description (Page 1B-3)"

Reference:

For the tightening torque of fastener not specified in this section, refer to "Tightening Torque List in Section 0C (Page 0C-9)".

Special Tools and Equipment


Recommended Service Material

B815H21208001

Material	SUZUKI recommended product or Specification		Note
Sealant	SUZUKI BOND No.1207B or equivalent	P/No.: 99000-31140	☞ (Page 1B-13)
Thread lock cement	THREAD LOCK CEMENT SUPER 1322 or equivalent	P/No.: 99000-32110	☞ (Page 1B-10)

Special Tool

B815H21208002

09900-25008 Multi-circuit tester set ☞ (Page 1B-12) / ☞ (Page 1B-16)		
---	---	--

Engine Electrical Devices

Precautions

Precautions for Engine Electrical Device

B815H21300001

Refer to "General Precautions in Section 00 (Page 00-1)" and "Precautions for Electrical Circuit Service in Section 00 (Page 00-2)".

Component Location

Engine Electrical Components Location

B815H21303001

Refer to "Electrical Components Location in Section 0A (Page 0A-8)".

Diagnostic Information and Procedures

Engine Symptom Diagnosis

B815H21304001

Refer to "Engine Symptom Diagnosis in Section 1A (Page 1A-8)".


Repair Instructions

ECM Removal and Installation

B815H21306001

Removal

- 1) Remove the front seat. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Disconnect the couplers and remove the ECM (1).



I815H1130001-01

Installation

Install the ECM in the reverse order of removal.

CMP Sensor Inspection

B815H21306002


Refer to "DTC "C11" (P0340) CMP Sensor Circuit Malfunction in Section 1A (Page 1A-28)".

CMP Sensor Removal and Installation

B815H21306003

Removal

- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation in Section 1D (Page 1D-6)".
- 2) Disconnect the coupler (1) and remove the CMP sensor (2).



I815H1130002-01

Installation

Install the CMP sensor in the reverse order of removal. Pay attention to the following points:

⚠ CAUTION

When installing the CMP sensor, make sure to clean the sensor surface.

- Tighten the CMP sensor bolt (1) to the specified torque.

Tightening torque

CMP sensor bolt (a): 10 N·m (1.0 kgf-m, 7.0 lb-ft)



I815H1130003-01

CKP Sensor Inspection

B815H21306004


Refer to "CKP Sensor Inspection in Section 1H (Page 1H-10)".

CKP Sensor Removal and Installation

B815H21306005

Removal

- 1) Remove the left side cowling. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Remove the generator cover. Refer to "Generator Removal and Installation in Section 1J (Page 1J-6)".
- 3) Remove the CKP sensor (1) along with generator stator (2).



I815H1130004-01

1C-3 Engine Electrical Devices:

Installation

Install the CKP sensor in the reverse order of removal. Refer to "Generator Removal and Installation in Section 1J (Page 1J-6)".

IAP Sensor Inspection

B815H21306006


Refer to "DTC "C13" (P0105-H/L): IAP Sensor Circuit Malfunction in Section 1A (Page 1A-33)".

IAP Sensor Removal and Installation

B815H21306007

Removal

- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".
- 2) Disconnect the coupler (1) and vacuum hose (2).
- 3) Remove the IAP sensor (3) from the air cleaner box.



I815H1130005-01

Installation

Install the IAP sensor in the reverse order of removal.

TP Sensor Inspection

B815H21306008

Refer to "DTC "C14" (P0120-H/L): TP Sensor Circuit Malfunction in Section 1A (Page 1A-40)".

TP Sensor Removal and Installation

B815H21306009

Refer to "Throttle Body Disassembly and Assembly in Section 1D (Page 1D-12)".

Removal


- 1) Remove the throttle body. Refer to "Throttle Body Removal and Installation in Section 1D (Page 1D-10)".
- 2) Remove the TP sensor (1) with the special tool.

Special tool

 : 09930-11950 (Torx wrench)

NOTE

Prior to disassembly, mark the TP sensor's original position with a paint or scribe for accurate reinstallation.



I815H1130006-01

Installation

Install the TP sensor in the reverse order of removal. Pay attention to the following points:

- With the throttle valves fully closed, install the TP sensor (1) and tighten the TP sensor mounting screw to the specified torque.

NOTE

- Apply thin coat of engine oil to the O-ring.
- Align the throttle shaft end "A" with the groove "B" of the TP sensor.
- Apply grease to the throttle shaft end "A" if necessary.


 **Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)**

Special tool

 **09930-11950 (Torx wrench)**

Tightening torque


TP sensor mounting screw: 3.5 N·m (0.35 kgf-m, 2.5 lb-ft)



I815H1130007-02

NOTE

- Make sure the throttle valves smoothly open and close.
- For TP sensor setting procedure, refer to "TP Sensor Adjustment (Page 1C-4)".



I815H1130008-01

TP Sensor Adjustment

B815H21306010


Inspect the TP sensor setting position and adjust it if necessary in the following procedures:

- 1) Connect the special tool (Mode select switch) to the dealer mode coupler. Refer to "Self-Diagnostic Procedures in Section 1A (Page 1A-12)".

Special tool

 **09930-82720 (Mode select switch)**

- 2) Warm up the engine and keep it running in idling speed.
- 3) Turn the mode select switch ON.
- 4) Check the position of the bar in the left of C code displayed on the LCD panel.




I823H1130022-01

"A": Incorrect position "B": Correct position

- 5) If the TP sensor adjustment is necessary, lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".
- 6) Loosen the TP sensor mounting screw using the special tool and turn the TP sensor to bring the bar to the correct position.

Special tool

 **09930-11950 (Torx wrench)**



I815H1130009-02

- 7) Tighten the TP sensor mounting screw to the specified torque.

Tightening torque

TP sensor mounting screw: 3.5 N·m (0.35 kgf-m, 2.5 lb-ft)

- 8) Turn off the engine and place back the fuel tank.

ECT Sensor Removal and Installation


B815H21306011

Removal

- 1) Lift and support the fuel tank. Refer to “Fuel Tank Removal and Installation in Section 1G (Page 1G-9)”.
- 2) Drain engine coolant. Refer to “Cooling System Inspection in Section 0B (Page 0B-13)”.
- 3) Disconnect the coupler and remove the ECT sensor (1).

⚠ CAUTION

Take special care when handling the ECT sensor. It may cause damage if it gets an excessive impact.



I815H1130010-01

Installation

Install the ECT sensor in the reverse order of removal. Pay attention to the following points:

- Tighten the ECT sensor (1) to the specified torque.

⚠ CAUTION

Use new gasket washer to prevent engine coolant leakage.

Tightening torque

ECT sensor (a): 18 N·m (1.8 kgf·m, 13.0 lb·ft)



I815H1130011-01

- Pour engine coolant. Refer to “Cooling System Inspection in Section 0B (Page 0B-13)”.

ECT Sensor Inspection

B815H21306012

Refer to “DTC “C15” (P0115-H/L): ECT Sensor Circuit Malfunction in Section 1A (Page 1A-47)”.

Inspect the ECT sensor in the following procedures:

- 1) Remove the ECT sensor. Refer to “ECT Sensor Removal and Installation (Page 1C-5)”.
- 2) Connect the ECT sensor (1) to the circuit tester and place it in the oil (2) contained in a pan, which is placed on a stove.
- 3) Heat the oil to raise its temperature slowly and read the column thermometer (3) and ohmmeter. If the ECT sensor ohmic value does not change in the proportion indicated, replace it with a new one.

⚠ CAUTION

- Take special care when handling the ECT sensor. It may cause damage if it gets an excessive sharp impact.
- Do not contact the ECT sensor and column thermometer with a pan.

Special tool


TOOL (A): 09900-25008 (Multi-circuit tester set)

Tester knob indication

Resistance (Ω)

ECT sensor specification

Temperature	Standard resistance
20 °C (68 °F)	Approx. 2.45 kΩ
50 °C (122 °F)	Approx. 0.811 kΩ
80 °C (176 °F)	Approx. 0.318 kΩ
110 °C (230 °F)	Approx. 0.142 kΩ



I718H1130014-01


- 4) Install the ECT sensor. Refer to “ECT Sensor Removal and Installation (Page 1C-5)”.

IAT Sensor Removal and Installation

B815H21306013

Removal

- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation in Section 1D (Page 1D-6)".
- 2) Remove the IAT sensor (1) from the air cleaner box.



I815H1130012-01


Installation

Install the IAT sensor in the reverse order of removal. Pay attention to the following point:

- Tighten the CMP sensor screw (1) to the specified torque.

Tightening torque

IAT sensor mounting screw (a): 5.5 N·m (0.55 kgf-m, 4.0 lb-ft)



I815H1130013-01

IAT Sensor Inspection

B815H21306014

Refer to "DTC "C21" (P0110-H/L): IAT Sensor Circuit Malfunction in Section 1A (Page 1A-52)". Inspect the IAT sensor.

NOTE

IAT sensor resistance measurement method is the same way as that of the ECT sensor. Refer to "ECT Sensor Inspection (Page 1C-5)".

⚠ CAUTION

- The IAT sensor operative temperature range is $-30 - 120^{\circ}\text{C}$ ($-22 - 248^{\circ}\text{F}$).
- Do not heat the oil up to 120°C (248°F) or more for this inspection.

IAT sensor specification

Temperature	Standard resistance
20 °C (68 °F)	Approx. 2.58 kΩ
80 °C (176 °F)	Approx. 0.28 kΩ
120 °C (248 °F)	Approx. 0.09 kΩ

AP Sensor Inspection

B815H21306015


Refer to "DTC "C22" (P01450-H/L): AP Sensor Circuit Malfunction in Section 1A (Page 1A-57)".

AP Sensor Removal and Installation

B815H21306016

Removal

- 1) Remove the front seat. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Disconnect the coupler and remove the AP sensor (1).



I815H1130014-01

Installation

Install the AP sensor in the reverse order of removal.

TO Sensor Inspection

B815H21306017

Refer to "DTC "C23" (P1651-H/L): TO Sensor Circuit Malfunction in Section 1A (Page 1A-64)".

TO Sensor Removal and Installation

B815H21306018

Removal

- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".
- 2) Disconnect the coupler and remove the TO sensor (1).



I815H1130015-01

Installation

Install the TO sensor in the reverse order of removal. Pay attention to the following point:

- When installing the TO sensor, bring the "UPPER" letters upward.



I815H1130016-01

STP Sensor Inspection

B815H21306019


Refer to "DTC "C29" (P1654-H/L): Secondary Throttle Position Sensor (STPS) Circuit Malfunction in Section 1A (Page 1A-75)".

STP Sensor Adjustment

B815H21306020

Adjust the STP sensor in the following procedures:

- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation in Section 1D (Page 1D-6)".
- 2) Disconnect the STVA lead wire coupler (1).
- 3) Insert the needle pointed probes to the STP sensor coupler (2) (between Y and B wires).



I815H1130017-01

- 4) Turn the ignition switch ON.

- 5) Close the secondary throttle valve by finger and measure the STP sensor output voltage.

Special tool


-  (A): 09900-25008 (Multi-circuit tester set)
 (B): 09900-25009 (Needle pointed probe set)

Tester knob indication


Voltage (---)

STP sensor output voltage

ST valve is fully closed: Approx. 0.5 V ((+): Y – (–): B)



I718H1130017-01



I823H1110070-01

- 6) Loosen the STP sensor mounting screw using the special tool and adjust the STP sensor (2) until the output voltage comes within the specified value.

Special tool

-  : 09930-11950 (Torx wrench)

- 7) Tighten the STP sensor mounting screw to the specified torque.

Tightening torque

STP sensor mounting screw: 3.5 N·m (0.35 kgf·m, 2.5 lb·ft)



I815H1130019-02

- 8) Reinstall the removed parts.

STP Sensor Removal and Installation

B815H21306021

Removal


- 1) Remove the throttle body. Refer to "Throttle Body Removal and Installation in Section 1D (Page 1D-10)".
- 2) Remove the STP sensor (1) with the special tool.

Special tool

-  : 09930-11950 (Torx wrench)

NOTE

Prior to disassembly, mark the STP sensor's original position with a paint or scribe for accurate reinstallation.



I815H1130018-02

Installation

Install the STP sensor in the reverse order of removal. Pay attention to the following point:

- With the secondary throttle valves fully opened, install the STP sensor (1) and tighten the STP sensor mounting screw to the specified torque.

NOTE

- Apply thin coat of engine oil to the O-ring.
- Align the secondary throttle shaft end "A" with the groove "B" of the STP sensor.
- Apply grease to the secondary throttle shaft end "A" if necessary.


FAH: Grease 99000–25010 (SUZUKI SUPER GREASE A or equivalent)

Special tool

TOOL: 09930–11950 (Torx wrench)

Tightening torque


STP sensor mounting screw: 3.5 N·m (0.35 kgf·m, 2.5 lb·ft)



I815H1130020-02

NOTE

- Make sure the secondary throttle valves smoothly open and close.
- If the STP sensor adjustment is necessary, refer to “STP Sensor Inspection (Page 1C-7)” for STP sensor setting procedure.



I815H1130021-01

STV Actuator Inspection

B815H21306022

Refer to “DTC “C28” (P1655): Secondary Throttle Valve Actuator (STVA) Malfunction in Section 1A (Page 1A-71)”.

STV Actuator Removal and Installation

B815H21306023

Refer to “Throttle Body Disassembly and Assembly in Section 1D (Page 1D-12)”.

CAUTION

Never remove the STVA from the throttle body.

ISC Valve Inspection

B815H21306024

Refer to “DTC “C40” (P0505 / P0506 / P0507): ISC Valve Circuit Malfunction in Section 1A (Page 1A-92)”.

ISC Valve Removal and Installation

B815H21306025

Refer to “Throttle Body Disassembly and Assembly in Section 1D (Page 1D-12)”.

CAUTION


- Be careful not to disconnect the ISC valve coupler at least 5 seconds after ignition switch is turned to OFF. If the ECM coupler or ISC valve coupler is disconnected within 5 seconds after ignition switch is turned to OFF, there is a possibility of an unusual valve position being written in ECM and causing an error of ISC valve operation.
- When the throttle body assembly is replaced with a new one, the ISC valve must be set present position. Refer to “ISC Valve Preset and Opening Initialization (Page 1C-9)”.

ISC Valve Preset and Opening Initialization

B815H21306026


When removing or replacing the ISC valve, set the ISC valve to the following procedures:

- 1) Turn the ignition switch ON.
- 2) Set up the SDS tool. (Refer to the SDS operation manual for further details.)
- 3) Click the “Active control”.
- 4) Click the “ISC learned value reset” (1).




I718H1130018-01

- 5) Click the "Reset" button to clear the ISC leaned value.



NOTE

The leaned value of the ISC valve is set at Preset position.



- 6) Close the SDS tool and turn the ignition switch OFF.

NOTE

The ISC valve opening initialization is automatically started after the ignition switch is turned OFF position.

HO2 Sensor Inspection

B815H21306027

Refer to "DTC "C44" (P0130/P0135): HO2 Sensor (HO2S) Circuit Malfunction in Section 1A (Page 1A-102)".

HO2 Sensor Removal and Installation

B815H21306028

Refer to "Heated Oxygen Sensor (HO2S) Removal and Installation in Section 1B (Page 1B-9)".

GP Switch Inspection

B815H21306029

Refer to "Side-stand / Ignition Interlock System Parts Inspection in Section 1I (Page 1I-8)".

GP Switch Removal and Installation

B815H21306030

Refer to "Gear Position (GP) Switch Removal and Installation in Section 5B (Page 5B-11)".

Specifications

Service Data

B815H21307001

FI Sensors

Item	Standard/Specification		Note
CKP sensor resistance	180 – 280 Ω		
CKP sensor peak voltage	3.0 V and more		When cranking
IAP sensor input voltage	4.5 – 5.5 V		
IAP sensor output voltage	Approx. 2.7 V at idle speed		
TP sensor input voltage	4.5 – 5.5 V		
TP sensor output voltage	Closed	Approx. 1.1 V	
	Opened	Approx. 4.3 V	
ECT sensor input voltage	4.5 – 5.5 V		
ECT sensor output voltage	0.15 – 4.85 V		
ECT sensor resistance	Approx. 2.45 k Ω at 20 °C (68 °F)		
IAT sensor input voltage	4.5 – 5.5 V		
IAT sensor output voltage	0.15 – 4.85 V		
IAT sensor resistance	Approx. 2.58 k Ω at 20 °C (68 °F)		
AP sensor input voltage	4.5 – 5.5 V		
AP sensor output voltage	Approx. 3.6 V at 100 kPa (760 mmHg)		
TO sensor resistance	16.5 – 22.3 k Ω		
TO sensor voltage	Normal	0.4 – 1.4 V	
	Leaning	3.7 – 4.4 V	When leaning 65°
GP switch voltage	0.6 V and more		From 1st to Top
Injector voltage	Battery voltage		
Ignition coil primary peak voltage	80 V and more		When cranking
HO2 sensor output voltage	0.3 V and less at idle speed		
	0.6 V and more at 3 000 r/min		
HO2 sensor heater resistance	Approx. 8 Ω at 23 °C (73 °F)		
PAIR control solenoid valve resistance	20 – 24 Ω at 20 – 30 °C (68 – 86 °F)		
STP sensor input voltage	4.5 – 5.5 V		
STP sensor output voltage	Closed	Approx. 0.5 V	
	Opened	Approx. 3.9 V	
STV actuator resistance	Approx. 6.5 Ω		
EVAP system purge control solenoid valve resistance	Approx. 32 k Ω at 20 °C (68 °F)		E-33 only
ISC valve resistance	Approx. 80 Ω at 25 °C (77 °F)		

Tightening Torque Specifications

B815H21307002

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
CMP sensor bolt	10	1.0	7.0	☞ (Page 1C-2)
TP sensor mounting screw	3.5	0.35	2.5	☞ (Page 1C-4) / ☞ (Page 1C-4)
ECT sensor	18	1.8	13.0	☞ (Page 1C-5)
IAT sensor mounting screw	5.5	0.55	4.0	☞ (Page 1C-6)
STP sensor mounting screw	3.5	0.35	2.5	☞ (Page 1C-8) / ☞ (Page 1C-9)

Reference:

For the tightening torque of fastener not specified in this section, refer to "Tightening Torque List in Section 0C (Page 0C-9)".

Special Tools and Equipment




Recommended Service Material

B815H21308001

Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI SUPER GREASE A or equivalent	P/No.: 99000-25010	☞ (Page 1C-4) / ☞ (Page 1C-9)

Special Tool

B815H21308002



09900-25008 Multi-circuit tester set ☞ (Page 1C-5) / ☞ (Page 1C-8) 	09900-25009 Needle pointed probe set ☞ (Page 1C-8) 
09930-11950 Torx wrench ☞ (Page 1C-3) / ☞ (Page 1C-4) / ☞ (Page 1C-4) / ☞ (Page 1C-8) / ☞ (Page 1C-8) / ☞ (Page 1C-9) 	09930-82720 Mode select switch ☞ (Page 1C-4) 

Engine Mechanical

Schematic and Routing Diagram

Camshaft and Sprocket Assembly Diagram


B815H21402001



I823H1140001-01

Throttle Cable Routing Diagram

B815H21402002



I815H1140001-01

1. Throttle cable No. 1	5. Front brake hose
2. Throttle cable No. 2	 "A": Pass through the throttle cables No. 1 and No. 2 between the air cleaner box and guide the of screw.
3. Throttle cable guide	 "B": Pass through the throttle cable No. 1 over the throttle cable No. 2.
4. Throttle cable guide	"a": 0 mm (0 in)

Diagnostic Information and Procedures

Engine Mechanical Symptom Diagnosis

B815H21404001

Refer to “Engine Symptom Diagnosis in Section 1A (Page 1A-8)”.

Compression Pressure Check

B815H21404002


The compression pressure reading of a cylinder is a good indicator of its internal condition. The decision to overhaul the cylinder is often based on the results of a compression test. Periodic maintenance records kept at your dealership should include compression readings for each maintenance service.

NOTE

- Before checking the engine for compression pressure, make sure that the cylinder head nuts are tightened to the specified torque values and the valves are properly adjusted.
 - Make sure that the battery is in fully-charged condition.
- 1) Warm up the engine.
 - 2) Lift and support the fuel tank. Refer to “Fuel Tank Removal and Installation in Section 1G (Page 1G-9)”.
 - 3) Remove the air cleaner box. Refer to “Air Cleaner Box Removal and Installation (Page 1D-6)”.
 - 4) Remove all the spark plugs. Refer to “Ignition Coil / Plug Cap and Spark Plug Removal and Installation in Section 1H (Page 1H-6)”.
 - 5) Install the compression gauge and adaptor in the spark plug hole. Make sure that the connection is tight.

Special tool

- TOOL (A): 09915-64512 (Compression gauge)
- TOOL (B): 09915-63311 (Compression gauge attachment)



I815H1140002-01

- 6) Keep the throttle grip in the fully-opened position.



I815H1140003-03

- 7) Press the starter button and crank the engine for a few seconds. Record the maximum gauge reading as the cylinder compression.
- 8) Repeat this procedure with the other cylinders.

Compression pressure specification

Standard	Limit	Difference
1 400 – 1 800 kPa (14 – 18 kgf/cm ² , 199 – 256 psi)	1 000 kPa (10 kgf/cm ² , 142 psi)	200 kPa (2 kgf/cm ² , 28 psi)

Low compression pressure can indicate any of the following conditions:

- Excessively worn cylinder walls
- Worn piston or piston rings
- Piston rings stuck in grooves
- Poor valve seating
- Ruptured or otherwise defective cylinder head gasket

Overhaul the engine in the following cases:

- Compression pressure in one of the cylinders is 1 000 kPa (10 kgf/cm², 142 psi) and less.
 - The difference in compression pressure between any two cylinders is 200 kPa (2 kgf/cm², 28 psi) and more.
 - All compression pressure readings are below 1 400 kPa (14 kgf/cm², 199 psi) even when they measure 1 000 kPa (10 kgf/cm², 142 psi) and more.
- 9) After checking the compression pressure, reinstall the removed parts.

Repair Instructions

Engine Components Removable with the Engine in Place

B815H21406001

Engine components which can be removed while the engine is installed on the frame are as follows. For the installing and removing procedures, refer to respective paragraphs describing each component.

Center of Engine

Item	Removal	Inspection	Installation
Air cleaner element	Refer to "Air Cleaner Element Removal and Installation (Page 1D-6)".	Refer to "Air Cleaner Element Inspection in Section 0B (Page 0B-3)".	Refer to "Air Cleaner Element Removal and Installation (Page 1D-6)".
Exhaust pipes/Muffler	Refer to "Exhaust Pipe / Muffler Removal and Installation in Section 1K (Page 1K-3)".	Refer to "Exhaust System Inspection in Section 1K (Page 1K-7)".	Refer to "Exhaust Pipe / Muffler Removal and Installation in Section 1K (Page 1K-3)".
Oil filter	Refer to "Engine Oil and Filter Replacement in Section 0B (Page 0B-10)".	—	Refer to "Engine Oil and Filter Replacement in Section 0B (Page 0B-10)".
Oil cooler	Refer to "Oil Cooler / Oil Cooler Hose Removal and Installation in Section 1E (Page 1E-8)".	—	Refer to "Oil Cooler / Oil Cooler Hose Removal and Installation in Section 1E (Page 1E-8)".
Oil pan	Refer to "Oil Pan / Oil Strainer / Oil Pressure Regulator Removal and Installation in Section 1E (Page 1E-6)".	—	Refer to "Oil Pan / Oil Strainer / Oil Pressure Regulator Removal and Installation in Section 1E (Page 1E-6)".
Throttle body	Refer to "Throttle Body Removal and Installation (Page 1D-10)".	Refer to "Throttle Body Inspection and Cleaning (Page 1D-16)".	Refer to "Throttle Body Removal and Installation (Page 1D-10)".
Cam chain tension adjuster	Refer to "Engine Top Side Disassembly (Page 1D-27)".	Refer to "Cam Chain Tension Adjuster Inspection (Page 1D-45)".	Refer to "Engine Top Side Assembly (Page 1D-31)".
Cylinder head cover	Refer to "Engine Top Side Disassembly (Page 1D-27)".	—	Refer to "Engine Top Side Assembly (Page 1D-31)".
Camshafts	Refer to "Engine Top Side Disassembly (Page 1D-27)".	Refer to "Camshaft Inspection (Page 1D-42)".	Refer to "Engine Top Side Assembly (Page 1D-31)".
Starter motor	Refer to "Starter Motor Removal and Installation in Section 1I (Page 1I-4)".	Refer to "Starter Motor Inspection in Section 1I (Page 1I-5)".	Refer to "Starter Motor Removal and Installation in Section 1I (Page 1I-4)".
Crank balancer	Refer to "Engine Bottom Side Disassembly (Page 1D-63)".	Refer to "Crank Balancer Inspection (Page 1D-89)".	Refer to "Engine Bottom Side Assembly (Page 1D-71)".

1D-5 Engine Mechanical:**Engine Right Side**

Item	Removal	Inspection	Installation
Clutch cover	Refer to "Clutch Removal in Section 5C (Page 5C-14)".	—	Refer to "Clutch Installation in Section 5C (Page 5C-17)".
Clutch plates	Refer to "Clutch Removal in Section 5C (Page 5C-14)".	Refer to "Clutch Parts Inspection in Section 5C (Page 5C-21)".	Refer to "Clutch Installation in Section 5C (Page 5C-17)".
Clutch sleeve hub	Refer to "Clutch Removal in Section 5C (Page 5C-14)".	—	Refer to "Clutch Installation in Section 5C (Page 5C-17)".
Primary driven gear	Refer to "Clutch Removal in Section 5C (Page 5C-14)".	Refer to "Clutch Parts Inspection in Section 5C (Page 5C-21)".	Refer to "Clutch Installation in Section 5C (Page 5C-17)".
Oil pump drive gear	Refer to "Oil Pump Removal and Installation in Section 1E (Page 1E-12)".	—	Refer to "Oil Pump Removal and Installation in Section 1E (Page 1E-12)".
Oil pump	Refer to "Oil Pump Removal and Installation in Section 1E (Page 1E-12)".	Refer to "Oil Pump Inspection in Section 1E (Page 1E-13)".	Refer to "Oil Pump Removal and Installation in Section 1E (Page 1E-12)".
Oil pressure switch	Refer to "Oil Pressure Switch Removal and Installation in Section 1E (Page 1E-9)".	Refer to "Oil Pressure Indicator Inspection in Section 9C (Page 9C-7)".	Refer to "Oil Pressure Switch Removal and Installation in Section 1E (Page 1E-9)".
Gear position switch	Refer to "Gear Position (GP) Switch Removal and Installation in Section 5B (Page 5B-11)".	Refer to "Gear Position (GP) Switch Inspection in Section 5B (Page 5B-11)".	Refer to "Gear Position (GP) Switch Removal and Installation in Section 5B (Page 5B-11)".
Starter torque limiter	Refer to "Starter Torque Limiter / Starter Clutch Removal and Installation in Section 1I (Page 1I-10)".	—	Refer to "Starter Torque Limiter / Starter Clutch Removal and Installation in Section 1I (Page 1I-10)".
Starter clutch	Refer to "Starter Torque Limiter / Starter Clutch Removal and Installation in Section 1I (Page 1I-10)".	Refer to "Starter Clutch Inspection in Section 1I (Page 1I-12)".	Refer to "Starter Torque Limiter / Starter Clutch Removal and Installation in Section 1I (Page 1I-10)".

Engine Left Side


Item	Removal	Inspection	Installation
Generator	Refer to "Generator Removal and Installation in Section 1J (Page 1J-6)".	Refer to "Generator Inspection in Section 1J (Page 1J-5)".	Refer to "Generator Removal and Installation in Section 1J (Page 1J-6)".
Engine sprocket	Refer to "Engine Sprocket Removal and Installation in Section 3A (Page 3A-2)".	Refer to "Drive Chain Related Parts Inspection in Section 3A (Page 3A-5)".	Refer to "Engine Sprocket Removal and Installation in Section 3A (Page 3A-2)".
Driven chain	Refer to "Drive Chain Replacement in Section 3A (Page 3A-7)".	Refer to "Drive Chain Inspection and Adjustment in Section 0B (Page 0B-15)".	Refer to "Drive Chain Replacement in Section 3A (Page 3A-7)".
CKP sensor	Refer to "Generator Removal and Installation in Section 1J (Page 1J-6)".	Refer to "CKP Sensor Inspection in Section 1H (Page 1H-10)".	Refer to "Generator Removal and Installation in Section 1J (Page 1J-6)".
Water pump	Refer to "Water Pump Removal and Installation in Section 1F (Page 1F-12)".	Refer to "Water Pump Related Parts Inspection in Section 1F (Page 1F-16)".	Refer to "Water Pump Removal and Installation in Section 1F (Page 1F-12)".
Speed sensor	Refer to "Speed Sensor Removal and Installation in Section 9C (Page 9C-6)".	Refer to "Speed Sensor Inspection in Section 9C (Page 9C-7)".	Refer to "Speed Sensor Removal and Installation in Section 9C (Page 9C-6)".

Air Cleaner Element Removal and Installation

B815H21406002


Removal

- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".
- 2) Remove the air cleaner box cover (1).



I815H1140004-01

- 3) Remove the air cleaner element (2).



I815H1140005-01

Installation


Install the air cleaner element in the reverse order of removal.

Air Cleaner Box Removal and Installation

B815H21406003


Removal

- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".
- 2) Remove the IAP sensor (1) from the air cleaner box.




I815H1140008-01

- 3) Disconnect the ISC valve hose (2) and PCV hose (3).




I815H1140009-01

- 4) Remove the bolt.




I815H1140010-01

- 5) Loosen the clamp screw (LH).
- 6) Disconnect the IAT sensor coupler (4).



I815H1140011-02

- 7) Loosen the clamp screw (RH).
- 8) Disconnect the PAIR hose (5).
- 9) Remove the air cleaner box.



I815H1140012-02

Installation

Install the air cleaner box in the reverse order of removal. Pay attention to the following point:

- Route the hoses properly. Refer to “Throttle Body Construction (Page 1D-9)”.

Air Cleaner Element Inspection and Cleaning

B815H21406004

Refer to “Air Cleaner Element Inspection in Section 0B (Page 0B-3)”.

Throttle Cable Removal and Installation

B815H21406005

Removal

- 1) Remove the air cleaner box. Refer to “Air Cleaner Box Removal and Installation (Page 1D-6)”.
- 2) Remove the right handlebar switch box. Refer to “Handlebar Removal and Installation in Section 6B (Page 6B-3)”.
- 3) Remove the throttle cables as shown in the cable routing diagram. Refer to “Throttle Cable Routing Diagram (Page 1D-2)”.

Installation

Install the throttle cables in the reverse order of removal. Pay attention to the following points:

- Install the throttle cables as shown in the cable routing diagram. Refer to “Throttle Cable Routing Diagram (Page 1D-2)”.
- Check the throttle cable play and proper operation. Refer to “Throttle Cable Play Inspection and Adjustment in Section 0B (Page 0B-12)”.

Throttle Cable Inspection

B815H21406006

Check that the throttle grip moves smoothly from full open to full close. If it does not move smoothly, lubricate the throttle cables.


Throttle Cable Play Inspection and Adjustment

B815H21406007

Refer to “Throttle Cable Play Inspection and Adjustment in Section 0B (Page 0B-12)”.

Throttle Body Components

B815H21406008




I815H1140013-03

1. TP sensor	8. Secondary fuel injector	15. Fuel delivery pipe
2. STP sensor	9. Primary fuel injector	16. Fuel delivery pipe T-joint
3. O-ring	10. Cushion seal	17. EVAP system purge control solenoid valve
4. O-ring	11. O-ring	[A]: For E-33 only
5. Air screw	12. Fuel pipe	(a) : 3.5 Nm (0.35 kgf-m, 2.5 lb-ft)
6. ISC valve hose	13. O-ring	(b) : Apply engine oil.
7. Vacuum hose	14. O-ring	(c) : Do not reuse.

Throttle Body Construction

B815H21406009



I815H1140014-05

1. Fuel feed hose	5. EVAP purge control solenoid valve (E-33 only)	"a": Approx. 45°
2. ISC valve hose	"A": To the IAP sensor	⌚(a) : 1.5 N·m (0.15 kgf-m, 1.0 lb-ft)
3. PCV hose	"B": To the EVAP purge control solenoid valve (E-33 only)	
4. IAT sensor	"C": To the canister (E-33 only)	

Throttle Body Removal and Installation


B815H21406010

Removal

- 1) Remove the side cowlings. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation (Page 1D-6)".
- 3) Disconnect the throttle cables from their drum.

⚠ CAUTION

After disconnecting the throttle cables, do not snap the throttle valves from full open to full close. It may cause damage to the throttle valves and throttle body.




I815H1140015-01

- 4) Place a rag under the fuel feed hose (1) and disconnect the fuel feed hose from the fuel pump.


⚠ WARNING

For California models, drain fuel from the fuel tank before disconnect the fuel feed hose to prevent fuel leakage.




I815H1140016-01

- 5) Disconnect the TP sensor lead wire coupler (2), STP sensor lead wire coupler (3) and STVA lead wire coupler (4).
- 6) Remove the clamp (5).




I815H1140017-01

- 7) Disconnect secondary fuel injector lead wire couplers (6) and primary fuel injector lead wire couplers (7).



I815H1140018-01


- 8) Disconnect the ISC valve lead wire coupler (8).



I815H1140019-01


1D-11 Engine Mechanical:

- 9) Disconnect the vacuum hose (9) from the IAP sensor.
- 10) Disconnect the purge hose (10) from the EVAP system purge control solenoid valve. (E-33 only)




I815H1140020-02

- 11) Loosen the throttle body clamp screws at the intake pipe side.
- 12) Remove the throttle body assembly.



I815H1140021-01


- Installation**
- Installs in the reverse order of removal. Pay attention to the following points:
- Connect the primary injector couplers (1) and secondary infector couplers (2) to the respective fuel injectors. Make sure that each coupler is installed in the correct position. The color on each lead wire refers to the appropriate fuel injector.



I815H1140022-01

	Primary injector	Secondary injector
#1	Y/R and Gr/W	Y/R and Lg
#2	Y/R and Gr/B	Y/R and Lg/W
#3	Y/R and Gr/Y	Y/R and Lg/G
#4	Y/R and Gr/R	Y/R and Lg/Bl

- Connect the throttle pulling cable (3) and throttle returning cable (4) to the throttle cable drum.



I823H1140524-01

- Loosen each throttle cable lock-nut.
- Turn in each throttle cable adjuster fully and locate each outer cable so that the clearance “a” is 0 mm (0 in).
- Tighten each lock-nut.
- Adjust the throttle cable play. Refer to “Throttle Cable Play Inspection and Adjustment in Section 0B (Page 0B-12)”.

Throttle Body Disassembly and Assembly

B815H21406011


Refer to "Throttle Body Removal and Installation (Page 1D-10)".

Disassembly

⚠ CAUTION

Identify the position of each removed part. Organize the parts in their respective groups so that they can be reinstalled in their original positions.

- 1) Disconnect the fuel feed hose (1), vacuum hoses (2) and ISC valve hose (3).
- 2) Disconnect the purge hose (4). (For E-33)




I815H1140023-01

- 3) Remove the fuel delivery pipe assembly (5).


⚠ CAUTION

Be careful not to twist the fuel delivery pipe T-joint when removing the fuel delivery pipes, or joint part "A" of the fuel delivery pipe get damage.



I815H1140024-04

- 4) Remove the primary fuel injectors (6) and secondary fuel injectors (7) from the fuel delivery pipe.




I815H1140025-01

- 5) Remove the fuel pipe (8) from the primary fuel injector.




I815H1140109-01

- 6) Remove the T-joint (9) from the fuel delivery pipes.



I815H1140026-01

- 7) Remove the ISC valve hoses (10) and ISC valve (11).



I815H1140027-01

1D-13 Engine Mechanical:


- 8) Remove the TP sensor (12) and STP sensor (13) with the special tool.

Special tool

 : 09930-11950 (Torx wrench)

NOTE


Prior to disassembly, mark the each sensor's original position with a paint or scribe for accurate reinstallation.



I815H1140028-02

⚠ CAUTION


Never remove the STVA (14) from the throttle body.



I815H1140029-01

⚠ CAUTION


Never remove the throttle valves (15) and secondary throttle valves (16).




I815H1140030-01

⚠ CAUTION

These adjusting screws (17), (18) and (19) are factory-adjusted at the time of delivery and do not turn or remove them.



I815H1140031-01



I815H1140032-01

⚠ CAUTION

Do not separate the throttle body.



I815H1140033-01

Assembly

Reassemble the throttle body in the reverse order of disassembly. Pay attention to the following points:

- With the secondary throttle valves fully opened, install the STP sensor (1) and tighten the STP sensor mounting screw to the specified torque.

NOTE

- Apply thin coat of engine oil to the O-ring.
- Align the secondary throttle shaft end "A" with the groove "B" of the STP sensor.
- Apply grease to the secondary throttle shaft end "A" if necessary.


 : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)

Special tool

 : 09930-11950 (Torx wrench)

Tightening torque

STP sensor mounting screw: 3.5 N·m (0.35 kgf-m, 2.5 lb-ft)



I815H1140034-01

NOTE

- Make sure the secondary throttle valves smoothly open and close.
- If the STP sensor adjustment is necessary, refer to "STP Sensor Adjustment in Section 1C (Page 1C-7)" for STP sensor setting procedure.




I815H1140035-01

- Apply a thin coat of engine oil to the O-ring and install the ISC valve to the throttle body.

Tightening torque

ISC valve mounting screw (a): 2 N·m (0.2 kgf-m, 1.5 lb-ft)



I823H1140593-01

- With the throttle valves fully closed, install the TP sensor (2) and tighten the TP sensor mounting screw to the specified torque.

CAUTION

- Apply thin coat of engine oil to the O-ring.
- Align the throttle shaft end "C" with the groove "D" of the TP sensor.
- Apply grease to the throttle shaft end "C" if necessary.


 : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)

Special tool

 : 09930-11950 (Torx wrench)

Tightening torque

TP sensor mounting screw: 3.5 N·m (0.35 kgf-m, 2.5 lb-ft)



I815H1140036-01

NOTE

- Make sure the throttle valves smoothly open and close.
- For TP sensor setting procedure, refer to "TP Sensor Adjustment in Section 1C (Page 1C-4)".




I815H1140037-01


- Apply thin coat of engine oil to the new O-rings (3) and cushion seals (4).

CAUTION

Replace the O-rings and cushion seals with new ones.



I823H1140026-01




I815H1140038-01

- Assemble the fuel delivery pipes as shown in the figure.

CAUTION

Be careful not to twist the fuel delivery pipe T-joint when installing the fuel delivery pipes, or joint part "E" of the fuel delivery pipe may get damage.



I815H1140039-01

- Install each fuel injector by pushing it straight to the fuel delivery pipe and throttle body.

CAUTION

Never turn the injector while pushing it.




I815H1140040-02

- Install the fuel delivery pipe assembly to the throttle body.
- Tighten the fuel delivery pipe mounting screws (5) to the specified torque.

Tightening torque

Fuel delivery pipe mounting screw (b): 3.5 N·m (0.35 kgf-m, 2.5 lb-ft)



I815H1140041-01

Throttle Body Inspection and Cleaning

B815H21406012

Refer to "Throttle Body Disassembly and Assembly (Page 1D-12)".

Cleaning

⚠ WARNING

Some carburetor cleaning chemicals, especially dip-type soaking solutions, are very corrosive and must be handled carefully. Always follow the chemical manufacturer's instructions on proper use, handling and storage.

- Clean passageways with a spray-type carburetor cleaner and blow dry with compressed air.

⚠ CAUTION

Never clean the throttle body main bore. Do not use wire to clean passageways. Wire can damage passageways. If the components cannot be cleaned with a spray cleaner it may be necessary to use a dip-type cleaning solution and allow them to soak. Always follow the chemical manufacturer's instructions for proper use and cleaning of the throttle body components. Do not apply carburetor cleaning chemicals to the rubber and plastic materials.

Inspection

Check following items for any defects or clogging. Replace the damaged part if necessary.

- O-rings
- Throttle valves
- Secondary throttle valves
- Vacuum hoses
- ISC valve hoses
- Fuel delivery pipes
- Cushion seals
- Fuel injectors

ISC Valve Visual Inspection

B815H21406013

Visually inspect the ISC valve if necessary.

- Inspect the ISC valve for any carbon deposition defects. Clean or replace the ISC valve if necessary.



I823H1140594-01


Throttle Valve Synchronization

B815H21406014

Use of SDS Tool


Check and adjust the throttle valve synchronization among four cylinders.

- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".
- 2) Disconnect the respective vacuum hoses (1) from each vacuum nipple on the throttle body.



I815H1140042-02


- 3) Disconnect the IAP sensor coupler (2).



I815H1140043-02

1D-17 Engine Mechanical:

- 4) Connect the respective vacuum tester hoses to each vacuum nipple.




I815H1140044-02

- 5) Set up the SDS tool. (Refer to the SDS operation manual for further details.)
- 6) Start the engine.
- 7) Click “Date monitor”.
- 8) Warm up the engine (Engine coolant temp. more than 70 °C (158 °F)).

☐ Cooling fan relay	Off	
☐ Secondary throttle actuator position sensor	102	%
☐ Engine coolant / oil temperature	87.3	°C
☐ Engine speed	1171	rpm
☐ PAIR control solenoid valve	Off	
☐ Intake air temperature	22.1	°C

I718H1140382-01

- 9) Click “Active control”.
- 10) Click “ISC air volume control” (3).



I815H1140045-01

- 11) Click “ON” button (4) to fix the ISC air volume of four cylinders.

NOTE

When making this synchronization, be sure that the water temperature is within 70 – 100 °C (158 – 212 °F).

Item	Value	Unit	
☐ Engine speed	"A" → 1147	rpm	
☐ Desired idle speed	1155	rpm	
☐ ISC valve position	"B" → 57	step	
☐ Manifold absolute pressure 1	146.7	kPa	
☐ Engine coolant / oil temperature	94.2	°C	←
☐ Throttle position	28.4	°	
☐ Secondary throttle actuator position sensor	2.0	%	
☐ PAIR control solenoid valve	Off		

ISC air volume control

Spec

Off

On

I823H1140589-02

"A": Engine speed: Approx 1 150 rpm "B": ISC valve position: Approx. 57 step

- 12) Check for the synchronization of vacuum from #1 to #4 cylinders.




I815H1140046-01

- 13) Equalize the vacuum of the cylinders by turning each air screw (5) and keep it running at idling speed.

NOTE

Always set the engine rpm at idle rpm.



I815H1140047-01

- 14) If the adjustment is not yet correct, remove each air screw and clean them with a spray-type carburetor cleaner and blow dry with a compressed air. Also, clean the air screw passageways.

NOTE

- **Slowly turn the air screw clockwise and count the number of turns until the screw is lightly seated.**
- **Make a note of how many turns were made so the screw can be reset correctly after cleaning.**


- 15) Repeat the procedures from 6) to 13).
- 16) Close the SDS tool and turn the ignition switch OFF.
- 17) Disconnect the vacuum tester and reinstall the removed parts.
- 18) After completing the throttle valve synchronization, clear the DTC and reset the ISC learned value using SDS tool. Refer to "ISC Valve Preset and Opening Initialization in Section 1C (Page 1C-9)".

ISC Valve Reset

B815H21406015



When removing or replacing the throttle body assembly, reset the ISC valve learned value in the following procedures:

- 1) Turn the ignition switch ON position.
- 2) Set up the SDS tools. (Refer to the SDS operation manual for further details.)
- 3) Click "Active control".
- 4) Click "ISC learned value reset" (1).



I815H1140048-01


- 5) Click "Reset" button (2) to clear the ISC learned value.



I823H1140530-05

NOTE

The learned value of the ISC valve is set at RESET position.



I823H1140531-03

- 6) Close the SDS tool.
- 7) Turn the ignition switch OFF position.

NOTE

The ISC valve opening initialization is automatically started after the ignition switch is turned OFF.

TP Reset

B815H21406016

When replacing the throttle body assembly or TP sensor with a new one or reinstalling the TP sensor, reset the TP learned value in the following procedures:

- 1) Turn the ignition switch OFF position.
- 2) Connect the special tool to the dealer mode coupler and turn its switch ON position. Refer to "Self-Diagnostic Procedures in Section 1A (Page 1A-12)".
- 3) Turn the ignition switch ON position (and wait more than 2 seconds) to clear the TP learned value.

CAUTION

Do not open the throttle when clearing the TP learned value.

- 4) Turn the ignition switch OFF position.
- 5) Turn the special tool OFF position and remove it from the dealer mode coupler.

Engine Assembly Removal

B815H21406017


Before taking the engine out of the frame, wash the engine using a steam cleaner. Engine removal is sequentially explained in the following steps:

- 1) Remove the side cowlings. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Disconnect the battery (-) lead wire.




I815H1140065-01

- 3) Drain engine oil. Refer to "Engine Oil and Filter Replacement in Section 0B (Page 0B-10)".
- 4) Drain engine coolant. Refer to "Engine Oil and Filter Replacement in Section 0B (Page 0B-10)".
- 5) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".
- 6) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation (Page 1D-6)".
- 7) Remove the throttle body assembly. Refer to "Throttle Body Removal and Installation (Page 1D-10)".
- 8) Remove the horn (1) with its bracket.




I815H1140066-01

- 9) Remove the oil hoses (2) and (3).




I815H1140067-01




I815H1140068-01

- 10) Disconnect the water/air bleed hose (4) and cylinder head outlet hose (5).



I815H1140069-01

- 11) Disconnect the left and right cooling fan lead wire couplers.




I815H1140070-01

- 12) Remove the radiator with oil cooler by removing their mounting bolts.

⚠ CAUTION

Be careful not to bend the radiator and oil cooler fins.




I815H1140071-01




I815H1140072-01

- 13) Remove the radiator heat shield (6).



I815H1140073-01


- 14) Remove the radiator bracket (7) and oil cooler bracket (8).



I815H1140074-02


1D-21 Engine Mechanical:

- 15) Disconnect the HO2 sensor lead wire coupler (9) and oil pressure switch lead wire (10).




I815H1140075-01

- 16) Loosen the muffler connecting bolts.



I815H1140076-01

- 17) Remove the mufflers.




I815H1140077-01

- 18) Remove the exhaust pipe mounting bolt.




I815H1140078-01

- 19) Remove the exhaust pipe assembly.



I815H1140079-01

- 20) Remove the exhaust pipe gaskets (11).




I815H1140080-01

- 21) Disconnect the starter motor lead wire (12) and engine ground lead wire (13).




I815H1140081-01

- 22) Disconnect the ECT sensor lead wire coupler (14) .




I815H1140082-01

- 23) Disconnect the CKP sensor lead wire coupler (15), generator lead wire coupler (16) and GP switch lead wire coupler (17).



I815H1140083-01

- 24) Disconnect the side-stand switch lead wire coupler (18).




I815H1140084-02

- 25) Disconnect the CMP sensor lead wire coupler (19), ignition coil/plug cap lead wire couplers (20) and PAIR hoses (21).

⚠ CAUTION

Do not remove the ignition coil/plug cap before disconnecting its coupler.




I815H1140085-01

- 26) Remove the ignition coil/plug caps (22).


⚠ CAUTION

- Do not pry up the ignition coil/plug cap with a screwdriver or a bar to avoid its damage.
- Be careful not to drop the ignition coil/plug cap to prevent its short or open circuit.




I815H1140086-01

- 27) Remove the engine sprocket cover.



I815H1140087-02


- 28) Remove the clutch push rod (23), sprocket cover protector (24) and dowel pins.



I815H1140088-01

1D-23 Engine Mechanical:

- 29) Jack up the motorcycle and fix it for safety.
- 30) Remove the side-stand (25) with its bracket.
- 31) Remove the engine sprocket (26). Refer to "Engine Sprocket Removal and Installation in Section 3A (Page 3A-2)".



I815H1140089-01

- 32) Support the engine using an engine jack.




I815H1140090-02

- 33) Remove the engine mounting bolts (27) and (28).



I815H1140091-02

- 34) Loosen the engine mounting pinch bolt (29).
- 35) Remove the engine mounting bolts (30) and (31).



I815H1140092-01


- 36) Loosen the engine mounting thrust adjuster lock-nut (32) with the special tool.
- 37) Loosen the engine mounting thrust adjuster (33) fully.

Special tool


Tool (A): 09940-14990 (Engine mounting thrust adjuster socket wrench)



I815H1140093-01




I815H1140094-01



I815H1140104-01

- 38) Remove the engine mounting nuts (34) and (35).



I815H1140105-01


- 39) Loosen the engine mounting thrust adjuster lock-nuts (36) and (37) with the special tool.
- 40) Loosen the engine mounting thrust adjusters (38) and (39) fully.

Special tool


TOOL (A): 09940-14990 (Engine mounting thrust adjuster socket wrench)

NOTE


Do not remove the engine mounting bolts at this stage.




I815H1140095-01



I815H1140096-01



I815H1140107-01



I815H1140108-01

- 41) Remove the engine mounting bolts and gradually lower the front side of the engine. Then, take off the driven chain from the driveshaft.
- 42) Remove the engine assembly.

Engine Assembly Installation

B815H21406018

Install the engine in the reverse order of engine removal. Pay attention to the following points:

- Gradually raise the rear side of the engine assembly, and then put the drive chain on the driveshaft.

CAUTION

Be careful not to catch the wiring harness between the frame and the engine.



I815H1140097-01

- Install all engine mounting bolts and spacers, then tighten them temporarily.

1D-25 Engine Mechanical:


- Tighten the engine mounting thrust adjusters (1) to the specified torque with the special tool.

Tightening torque


Engine mounting thrust adjuster (a): 10 N·m (1.0 kgf-m, 7.0 lb-ft)



I815H1140098-01



I815H1140099-01



I815H1140100-01


- Tighten the engine mounting thrust adjuster lock-nuts (2) to the specified torque with the special tool.

Tightening torque


Engine mounting thrust adjuster lock-nut (b): 45 N·m (4.5 kgf-m, 32.5 lb-ft)

Special tool


 (A): 09940-14990 (Engine mounting thrust adjuster socket wrench)



I815H1140101-01



I815H1140102-03




I815H1140103-01

- Tighten all engine mounting bolts and nuts to the specified torque.

NOTE

The engine mounting nuts are self-locking. Once the nuts have been removed, they are no longer of any use.

- Tighten the engine mounting pinch bolt to the specified torque.



- Install the engine sprocket. Refer to “Engine Sprocket Removal and Installation in Section 3A (Page 3A-2)”.
- Install the exhaust pipe assembly and muffler. Refer to “Exhaust Pipe / Muffler Removal and Installation in Section 1K (Page 1K-3)”.
- Install the radiator. Refer to “Radiator / Cooling Fan Motor Removal and Installation in Section 1F (Page 1F-6)”.
- Install the throttle body. Refer to “Throttle Body Removal and Installation (Page 1D-10)”.
- Install the air cleaner box. Refer to “Air Cleaner Box Removal and Installation (Page 1D-6)”.
- After remounting the engine, route the wiring harness, cable and hoses properly. Refer to “Wiring Harness Routing Diagram in Section 9A (Page 9A-5)”, “Throttle Cable Routing Diagram (Page 1D-2)” and “Water Hose Routing Diagram in Section 1F (Page 1F-3)”.
- Pour engine coolant and engine oil. Refer to “Cooling System Inspection in Section 0B (Page 0B-13)” and “Engine Oil and Filter Replacement in Section 0B (Page 0B-10)”.
- Pour engine oil. Refer to “Engine Oil and Filter Replacement in Section 0B (Page 0B-10)”.
- After finishing the engine installation, check the following items.
 - Throttle cable play
Refer to “Throttle Cable Play Inspection and Adjustment in Section 0B (Page 0B-12)”.
 - Throttle valve synchronization
Refer to “Throttle Valve Synchronization (Page 1D-16)”.
 - Drive chain slack
Refer to “Drive Chain Inspection and Adjustment in Section 0B (Page 0B-15)”.
 - Engine oil and coolant leakage
Refer to “Cooling Circuit Inspection in Section 1F (Page 1F-4)”.

Engine Top Side Disassembly

B815H21406019

It is unnecessary to remove the engine assembly from the frame when servicing the cylinder head cover and camshafts.

NOTE

Before servicing the engine top side components (until camshafts removal) with the engine in place, remove the following parts:

- Air cleaner box
- Throttle body


Except for these “Engine Top Side Components” can not be serviced with the engine installed in the frame. Refer to “Engine Assembly Removal (Page 1D-19)” and “Engine Assembly Installation (Page 1D-24)”.

⚠ CAUTION

Identify the position of each removed part. Organize the parts in their respective groups (e.g., intake, exhaust) so that they can be reinstalled in their original positions.

Cylinder Head Cover


Remove the cylinder head cover (1) and its gaskets.



I823H1140030-01


Camshafts

- 1) Remove the spark plugs. Refer to “Ignition Coil / Plug Cap and Spark Plug Removal and Installation in Section 1H (Page 1H-6)”.
- 2) Remove the valve timing inspection cap (1) and starter clutch cover cap (2).




I823H1140031-01


- 3) Turn the crankshaft to bring the line "A" on the starter clutch to the slit "B" of the valve timing inspection hole and also to bring the cams to the position as shown in the figure.



I823H1140032-02




I823H1140033-02




I823H1140034-01

- 4) Remove the cam chain tension adjuster (3).




I823H1140035-01

- 5) Remove the gasket (4).



I823H1140036-01

- 6) Remove the oil pipe (5) and cam chain guide No. 2 (6).




I823H1140037-02

- 7) Remove the intake camshaft journal holder (7) and exhaust camshaft journal holder (8).

⚠ CAUTION


Be sure to loosen the camshaft journal holder bolts evenly by shifting the wrench in the descending order of numbers.



I823H1140038-01

1D-29 Engine Mechanical:

- 8) Remove the dowel pins.
- 9) Remove the intake camshaft (9) and exhaust camshaft (10).



I823H1140039-01

Cylinder Head

NOTE


The cylinder head can not be serviced with the engine installed in the frame.

- 1) Remove the water hose (1).




I823H1140040-01

- 2) Remove the oil hoses (2) and (3).



I823H1140041-01




I823H1140042-01

- 3) Remove the cylinder head side bolt (4) and its gasket (5).


⚠ CAUTION

When removing the cylinder head side bolt (4), pull the cam chain upward, or the chain will be caught between the cylinder head and the side bolt (4).



I823H1140043-01

- 4) Remove the cylinder head bolts (M6) (6).
- 5) Remove the cylinder head bolt (M6) (7).
- 6) Loosen the cylinder nuts (8).




I823H1140044-01

- 7) Remove the cylinder head bolts and washers.

NOTE


When loosening the cylinder head bolts, loosen each bolt little by little diagonally.

- 8) Remove the cylinder head.



I823H1140045-01

- 9) Remove the dowel pins and cylinder head gasket (9).



I823H1140046-02

Cam Chain Guide No. 1

NOTE

The cam chain guide can not be serviced with the engine installed in the frame.

- Remove the cam chain guide No. 1 (1).




I823H1140047-01

Cylinder

NOTE


The cylinder can not be serviced with the engine installed in the frame.

- 1) Remove the water hose (1).



I823H1140048-01


- 2) Remove the cylinder nuts (2).
- 3) Remove the cylinder.



I823H1140049-01

1D-31 Engine Mechanical:

- 4) Remove the dowel pins and cylinder base gasket (3).



I823H1140050-03

Piston

NOTE

The piston can not be serviced with the engine installed in the frame.

- 1) Place a clean rag over the cylinder base so as not to drop the piston pin circlips into the crankcase.
- 2) Remove each piston pin circlip (1).




I823H1140051-02

- 3) Draw out each piston pin (2) and remove the piston (3).

NOTE

Scribe the cylinder number on the piston head.



I823H1140052-01

Engine Top Side Assembly

B815H21406020

Assemble the engine top side in the reverse order of disassembly. Pay attention to the following points:

Piston


- When installing the pistons, apply molybdenum oil solution onto each piston pin.

M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)

- Install the pistons and piston pins.

NOTE

- Be sure to install the pistons in the cylinders from which they were removed in disassembly, refer to the cylinder numbers, #1 through #4, scribed on the piston.
- When installing the pistons, the indent "A" on the piston head must be faced to exhaust side.



I823H1140053-01


- Place a clean rag over the cylinder base so as not to drop the piston pin circlips (1) into the crankcase.
- Install the piston pin circlips (1).

⚠ CAUTION

Use new piston pin circlips (1) to prevent circlip failure which will occur when it is bent.

NOTE


End gap of the circlip "B" should not be aligned with the cutaway in the piston pin bore.



I815H1140050-01


CAUTION

When turning the crankshaft, pull the cam chain upward, or the chain will be caught between the crankcase and the cam drive sprocket.



I823H1140055-01

- Position the gaps of the three rings and side rails as shown in the figure. Before inserting piston into the cylinder, check that the gaps are so located.



I823H1140573-02

"C": 1st ring and upper side rail
"D": Spacer
"E": 2nd ring and lower side rail


Cylinder

- Fit the dowel pins and a new gasket (1) to the crankcase.

CAUTION

Use a new gasket to prevent oil leakage.

- Apply engine oil to the sliding surface of the pistons.



I823H1140056-01

- Install special tools to the No. 2 and No. 3 pistons.


Special tool

TOOL (A): 09916-74521 (Holder body)

TOOL (B): 09916-74550 (Band (Piston diam.: 73 – 85 mm))

NOTE

Do not overtighten the bands, or the piston installation into the cylinders will be difficult.



I823H1140057-01

1D-33 Engine Mechanical:

- Insert the No. 2 and No. 3 pistons into the cylinder.

NOTE

Some light resistance must be overcome to lower the cylinder.

- After inserting the No. 2 and No. 3 pistons in place, insert the No. 1 and No. 4 pistons in the same manner of the No. 2 and No. 3 pistons.

NOTE


When installing the cylinder block, keep the cam chain taut. The cam chain must not be caught between cam drive sprocket and crankcase when turning the crankshaft.

- Tighten the cylinder nuts (M6) temporarily.



I823H1140058-01

- Install the water hose (2).




I823H1140059-01

Cylinder Head


- Pull the cam chain out of the cylinder and install the cam chain guide No. 1 (1).

⚠ CAUTION

- There is the guide holder "A" for the bottom end of the cam chain guide No. 1 (1) cast in the crankcase.
- Be sure that the cam chain guide No. 1 (1) is installed properly.



I823H1140060-01




I823H1140061-01

- Fit the dowel pins and a new cylinder head gasket (2) to the cylinder.

⚠ CAUTION

Use a new gasket to prevent gas leakage.




I823H1140062-01

- Place the cylinder head on the cylinder.

NOTE

- When installing the cylinder head, keep the cam chain taut.
- Apply engine oil to the washers and thread portion of the bolts before installing the cylinder head bolts.




I823H1140063-01

- Tighten the cylinder head bolts (M10) to the specified two-step torque with a torque wrench sequentially and diagonally.

Tightening torque

Cylinder head bolt (M10) (Initial): 25 N·m (2.5 kgf-m, 18.0 lb-ft)

Cylinder head bolt (M10) (Final): 52 N·m (5.2 kgf-m, 37.5 lb-ft)




I823H1140064-01

- After firmly tightening the cylinder head bolts (M10), install the cylinder head bolts (M6) (3).
- Tighten the cylinder head bolts (3) and the cylinder nuts (4) to the specified torque.

Tightening torque

Cylinder head bolt (M6) (a): 10 N·m (1.0 kgf-m, 7.0 lb-ft)

Cylinder nut (M6) (b): 10 N·m (1.0 kgf-m, 7.0 lb-ft)



I823H1140065-03


- Install the gasket (5) and cylinder head side bolt (6). Tighten the bolt to the specified torque.

Tightening torque

Cylinder head side bolt (c): 14 N·m (1.4 kgf-m, 10.0 lb-ft)

NOTE

- The metal side "B" of the gasket (5) should face outside.
- Install the cylinder head side bolt between the cam chain.



I815H1140051-01

- Install the oil hose (7).

⚠ CAUTION


Use new gasket washers to prevent oil leakage.

1D-35 Engine Mechanical:

- With the oil hose union contacted to the stopper "C", tighten the bolts to the specified torque.


Tightening torque

Oil hose union bolt (d): 18 N·m (1.8 kgf-m, 13.0 lb-ft)



I815H1140052-01

- Install the oil hose (8) and water hose (9).




I815H1140053-02

Camshaft

- The cam shafts are identified by the embossed letters.
IN: Intake camshaft
EX: Exhaust camshaft
- Before placing the camshafts on the cylinder head, apply molybdenum oil solution to their journals.

M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)




I823H1140069-02


- Turn the crankshaft clockwise and align the line "A" on the starter clutch with the index mark "B" of the valve timing inspection hole while keeping the cam chain pulled upward.

⚠ CAUTION

- Pull the cam chain upward, or the chain will be caught between crankcase and cam drive sprocket.
- To adjust the camshaft timing correctly, be sure to align the line "A" with the index mark "B" and hold this position when installing the camshafts.



I823H1140070-01



I823H1140072-01

- Pull the cam chain lightly.
- Turn the exhaust camshaft so that the arrow is aligned with the gasket surface of the cylinder head. (The exhaust camshaft sprocket has an arrow marked "1" "C".)
- Engage the cam chain with the exhaust camshaft sprocket.

NOTE

- Before installing the camshaft, check that the tappets are installed correctly.
 - Align the C-ring (1) of the exhaust camshaft bearing with the groove "D".
-
- Bind the cam chain and the sprocket with a proper clamp (2) to prevent the cam chain disengagement while installing the camshaft journal holders.
 - The other arrow marked "2" "E" should now be pointing straight up. Starting from the roller pin that is directly above the arrow marked "2" "E", count out 15 roller pins (from the exhaust camshaft side going towards the intake camshaft side).
 - Engage the 15th roller pin "F" on the cam chain with the arrow marked "3" on the intake sprocket.


NOTE

- Before installing the camshaft, check that the tappets are installed correctly.
- Align the C-ring (3) of the intake camshaft bearing with the groove "G".


- Bind the cam chain and the sprocket with a proper clamp (4) to prevent the cam chain disengagement while installing the camshaft journal holders.

NOTE


The cam chain should now be on all three sprockets. Be careful not to move the crankshaft until the camshaft journal holders and cam chain tension adjuster are secured.




I823H1140073-01




I823H1140074-01



I823H1140075-03




I823H1140076-02



I823H1140077-02

- Install the dowel pins.
- Install the camshaft journal holders.



I823H1140078-01

- Have the camshaft journal holders evenly by tightening the camshaft journal holder bolts lightly, in the ascending order of numbers.

NOTE

- Damage to head or camshaft journal holder thrust surfaces may result if the camshaft journal holders are not drawn down evenly.
- Each camshaft journal holder is identified with a cast-on letters "IN" and "EX".
- The ascending order of numbers are indicated on the camshaft journal holders.

- Tighten the camshaft journal holder bolts in ascending order of numbers to the specified torque.


Tightening torque

Camshaft journal holder bolt: 10 N·m (1.0 kgf-m, 7.0 lb-ft)

⚠ CAUTION

The camshaft journal holder bolts are made of a special material and much superior in strength, compared with other types of high strength bolts.

Take special care not to use other types of bolts instead of these special bolts.



I823H1140079-03


- Install the oil pipe (4) and tighten oil pipe bolts to the specified torque.

NOTE


- Install the washer (5) between each bolt and oil pipe.
- The exhaust side oil pipe bolt (6) is longer than the intake side one (7).

Tightening torque

Oil pipe bolt (Camshaft housing): 10 N·m (1.0 kgf-m, 7.0 lb-ft)



I823H1140080-01




I823H1140081-01

- Install the cam chain guide No. 2 (8).

Tightening torque

Cam chain guide No. 2 bolt: 10 N·m (1.0 kgf-m, 7.0 lb-ft)


- Remove the clamps.



I823H1140082-01

Cam Chain Tension Adjuster

- Holding the cam chain tension adjuster as shown in the figure, compress the plunger by turning the adjuster body until the outer circlip "A" reaches the groove "B".
- Hook the outer circlip "A" into the groove "B", then turn the plunger head clockwise more than 90° to make a little play at the inner thread mechanism.




I823H1140355-01

- Fit a new gasket (1).

⚠ CAUTION

Use a new gasket to prevent oil leakage.




I823H1140084-01

- Install the cam chain tension adjuster (2).

Tightening torque

Cam chain tension adjuster mounting bolt (a): 10 N·m (1.0 kgf-m, 7.0 lb-ft)

- Remove the cam chain tension adjuster service cap (3).



I823H1140085-03


- Unhook the outer circlip "A" from its groove by pushing in the stepped part (4) of the plunger head with a (-) screwdriver.
- Rotate the crankshaft (some turns), and recheck the valve timing.

⚠ CAUTION


Make sure that the adjuster works properly by checking no slack at point "B".

Tightening torque



Cam chain tension adjuster service cap: 23 N·m (2.3 kgf-m, 16.5 lb-ft)



I823H1140358-05



I823H1140086-04



I823H1140577-02


NOTE

The cam chain tension adjuster can be serviced with the engine installed in the frame.

- After installing the cam chain tension adjuster, turn the crankshaft approx. 180° counterclockwise to make the plunger come out from the adjuster against the cam chain, via chain tensioner.

NOTE


When slight pushing force is applied to the plunger head, the plunger is automatically out from the adjuster body.



I823H1140574-02

⚠ CAUTION

Make sure that the adjuster works properly by checking no slack at point "B".




I823H1140575-03

- Tighten the valve timing inspection cap (5) and starter clutch cover cap (6) to the specified torque.

Tightening torque

Valve timing inspection cap (b): 23 N·m (2.3 kgf-m, 16.5 lb-ft)


Starter clutch cover cap (c): 10 N·m (1.0 kgf-m, 7.0 lb-ft)



I815H1140054-01

Cylinder Head Cover

- Check and adjust the valve clearance. Refer to "Valve Clearance Inspection and Adjustment in Section 0B (Page 0B-4)".
- Pour engine oil in each oil pocket in the cylinder head.




I823H1140088-01

- Install the dowel pins and new gaskets to the cylinder head cover.
- Apply bond to the cam end caps of the gasket as shown in the figure.

1207B : Sealant 99000-31140 (SUZUKI BOND No.1207B or equivalent)

⚠ CAUTION

Use new gaskets to prevent oil leakage.




I823H1140089-04

- Place the cylinder head cover on the cylinder head.
- Fit new gaskets to each head cover bolt.

⚠ CAUTION

Use new gaskets to prevent oil leakage.

- Apply engine oil to both sides of the gaskets.




I823H1140090-01

- Tighten the head cover bolts (1) to the specified torque.

Tightening torque

Head cover bolt (a): 14 N·m (1.4 kgf-m, 10.0 lb-ft)



I823H1140091-02

- Install the spark plugs. Refer to "Ignition Coil / Plug Cap and Spark Plug Removal and Installation in Section 1H (Page 1H-6)".
- Install the following parts:
 - Air cleaner box
(Refer to "Air Cleaner Box Removal and Installation (Page 1D-6)".)
 - Throttle body
(Refer to "Throttle Body Removal and Installation (Page 1D-10)".)

Camshaft Inspection

B815H21406021

Refer to "Engine Top Side Disassembly (Page 1D-27)".
Refer to "Engine Top Side Assembly (Page 1D-31)".

Camshaft Identification

The exhaust camshaft has the embossed letters "EX" and the intake camshaft has the embossed letters "IN".



I823H1140092-01

Cam Wear

Check the camshaft for wear or damage.

Measure the cam height "a" with a micrometer.

Replace a camshaft if the cams are worn to the service limit.


Special tool

TOOL : 09900-20202 (Micrometer (1/100 mm, 25 – 50 mm))

Cam height "a"

Service limit (IN.): 36.68 mm (1.444 in)

Service limit (EX.): 36.28 mm (1.428 in)



I649G1140199-02

Camshaft Runout

Measure the runout using the dial gauge. Replace the camshaft if the runout exceeds the limit.

Special tool


TOOL (A): 09900-20607 (Dial gauge (1/100 mm, 10 mm))

TOOL (B): 09900-20701 (Magnetic stand)

TOOL (C): 09900-21304 (V-block (100 mm))

Camshaft runout (IN. & EX.)

Service limit: 0.10 mm (0.004 in)



I823H1140093-01

Camshaft Journal Wear


Inspect the camshaft journal wear in the following procedures:

- 1) Remove the water bypass union. Refer to "Cylinder Head Disassembly and Assembly (Page 1D-47)".
- 2) Determine whether or not each journal is worn down to the limit by measuring the oil clearance with the camshaft installed in place.
- 3) Use the plastigauge to read the clearance at the widest portion, which is specified as follows.

Special tool

TOOL (A): 09900-22301 (Plastigauge (0.025 – 0.076 mm))

TOOL (B): 09900-22302 (Plastigauge (0.051 – 0.152 mm))



I815H1140128-01

- 4) Install each camshaft journal holder to its original position. Refer to "Engine Top Side Assembly (Page 1D-31)".


- 5) Tighten the camshaft journal holder bolts in ascending order of numbers to the specified torque. Refer to "Engine Top Side Assembly (Page 1D-31)".

NOTE

Do not rotate the camshafts with the plastigauge in place.

Tightening torque


Camshaft journal holder bolt: 10 N·m (1.0 kgf-m, 7.0 lb-ft)



I823H1140095-03

- 6) Remove the camshaft journal holders and measure the width of the compressed plastigauge using the envelope scale.
- 7) This measurement should be taken at the widest part of the compressed plastigauge.

Camshaft journal oil clearance (IN. & EX.)
Service limit: 0.150 mm (0.0059 in)



I823H1140096-03

- 8) If the camshaft journal oil clearance exceeds the limit, measure the inside diameter of the camshaft journal holder and the outside diameter of the camshaft journal. Replace the camshaft or the cylinder head depending upon which one exceeds the specification.

Special tool

TOOL (C): 09900-20602 (Dial gauge (1/1000 mm, 1 mm))

TOOL (D): 09900-22403 (Small bore gauge (18 – 35 mm))


TOOL (E): 09900-20205 (Micrometer (0 – 25 mm))

Camshaft journal holder I.D. (IN. & EX.)


Standard: 24.012 – 24.025 mm (0.9454 – 0.9459 in)

Camshaft journal O.D. (IN. & EX.)

Standard: 23.959 – 23.980 mm (0.9433 – 0.9441 in)



I823H1140097-01



I649G1140204-03

Camshaft Sprocket / Bearing Inspection

B815H21406022

Inspect the camshaft sprockets/bearings in the following procedures:

- 1) Remove the intake and exhaust camshafts. Refer to "Engine Top Side Disassembly (Page 1D-27)".
- 2) Inspect the teeth of each camshaft sprocket for wear or damage.

If they are worn or damaged, replace the sprocket/camshaft assembly and cam chain as a set.



I823H1140098-01

- 3) Inspect the bearings for abnormal play, noise and smooth rotation. If it is unusual, replace the sprocket/camshaft assembly with a new one.

⚠ CAUTION

Do not attempt to disassemble the cam sprocket or right side bearing. They are unserviceable.



I823H1140099-01


- 4) Install the camshafts. Refer to "Engine Top Side Assembly (Page 1D-31)".

Cam Chain Tension Adjuster Inspection

B815H21406023

The cam chain tension adjuster is maintained at the proper tension by an automatically adjusted.

- 1) Remove the cam chain tension adjuster. Refer to "Engine Top Side Disassembly (Page 1D-27)".
- 2) Holding the cam chain tension adjuster as shown in the figure, compress the plunger by turning the adjuster body until the outer circlip "A" reaches the groove "B".
- 3) Hook the outer circlip "A" into the groove "B", then turn the plunger head clockwise more than 90° to make a little play at the inner thread mechanism.




I823H1140355-01

NOTE

If it is difficult to compress the plunger because of internal engine oil, disassemble the adjuster by releasing the inner circlip "C" and spill out the oil.

⚠ CAUTION

Do not turn the adjuster body until the outer circlip "A" passes over the groove "B". If the inner circlip "C" hooks into the groove "B", plunger may not be automatically out from the adjuster body even pushing force is applied on the head. In such case, it needs to be disassembled.




I823H1140365-01



I823H1140366-01

- 4) Check that the plunger is automatically out when tapping its head "D". If it does not work smoothly, replace the cam chain tension adjuster with a new one.



I823H1140367-01


- 5) Install the cam chain tension adjuster. Refer to "Engine Top Side Assembly (Page 1D-31)".

Cam Chain Guide Removal and Installation

B815H21406024


Removal

- 1) Remove the cylinder head cover. Refer to "Engine Top Side Disassembly (Page 1D-27)".
- 2) Remove the cam chain guide No. 2 (1).



I823H1140104-01

- 3) Remove the cylinder head. Refer to "Engine Top Side Disassembly (Page 1D-27)" and "Engine Bottom Side Disassembly (Page 1D-63)".
- 4) Remove the cam chain guide No. 1 (2).



I823H1140105-01

Installation

Install the cam chain guides in the reverse order of removal.

Cam Chain Guide Inspection

B815H21406025

Inspect the cam chain guide in the following procedures:

- 1) Remove the cam chain guides. Refer to "Cam Chain Guide Removal and Installation (Page 1D-46)".
- 2) Check the contacting surface of the cam chain guides. If it is worn or damaged, replace it with a new one.



I823H1140106-01


- 3) Install the cam chain guides. Refer to "Cam Chain Guide Removal and Installation (Page 1D-46)".

Cam Chain Tensioner Inspection

B815H21406026

Inspect the cam chain tensioner in the following procedures:

- 1) Remove the cylinder. Refer to "Engine Top Side Disassembly (Page 1D-27)".
- 2) Remove the starter clutch. Refer to "Starter Torque Limiter / Starter Clutch Removal and Installation in Section 1I (Page 1I-10)".
- 3) Remove the cam chain tensioner (1).



I823H1140107-02

- 4) Check the contacting surface of the cam chain tensioner. If it is worn or damaged, replace it with a new one.



I823H1140108-01

- 5) Install the cam chain tensioner.
- 6) Reinstall the starter clutch. Refer to "Starter Torque Limiter / Starter Clutch Removal and Installation in Section 1I (Page 1I-10)".
- 7) Install the cylinder. Refer to "Engine Top Side Disassembly (Page 1D-27)".

Cylinder Head Disassembly and Assembly

B815H21406027


Refer to "Engine Top Side Disassembly (Page 1D-27)".
Refer to "Engine Top Side Assembly (Page 1D-31)".

⚠ CAUTION

Identify the position of each removed part.
Organize the parts in their respective groups (i.e., intake, exhaust, No. 1 or No. 2) so that they can be installed in their original locations.

Disassembly

- 1) Remove the tappet (1) and shim (2) by fingers or magnetic hand.



I823H1140109-01

- 2) Insert the special tool (A) between the valve spring and cylinder head.
- 3) Using the special tools, compress the valve spring and remove the two cotter halves (3) from the valve stem.

⚠ CAUTION

Be careful not to damage the tappet sliding surface with the special tool.


Special tool

TOOL (A): 09919-28620 (Sleeve protector)

TOOL (B): 09916-14522 (Valve spring compressor attachment)

TOOL (C): 09916-14510 (Valve spring compressor)

TOOL : 09916-84511 (Tweezers)




I823H1140111-01




I823H1140110-01

- 4) Remove the valve spring retainer (4) and valve spring (5).
- 5) Pull out the valve (6) from the combustion chamber side.




I823H1140112-01

- 6) Remove the oil seal (7) and spring seat (8).
- 7) Remove the other valves in the same manner as described previously.




I823H1140113-01

- 8) Remove the ECT sensor (9).




I823H1140114-01

- 9) Remove the thermostat cover (10).
- 10) Remove the thermostat (11).




I823H1140115-01

- 11) Remove the intake pipes (12).




I823H1140116-01

- 12) Remove the water bypass union (13).



I823H1140117-01

- 13) Remove the oil gallery plug (14).
- 14) Remove the cylinder head plug (15).



I823H1140118-02

Assembly

Assembly is in the reverse order of disassembly. Pay attention to the following points:

- Tighten the cam chain tension adjuster service cap (1) and oil gallery plug (2) to the specified torque.


CAUTION

Replace the gaskets with new ones.

Tightening torque

Cam chain tension adjuster service cap (a): 23 N·m (2.3 kgf-m, 16.5 lb-ft)

Oil gallery plug (Cylinder head) (b): 10 N·m (1.0 kgf-m, 7.0 lb-ft)




I823H1140119-02

- Apply bond to the thread part of the water bypass union (3) and tighten it to the specified torque.

 : Sealant 99000-31140 (SUZUKI BOND No.1207B or equivalent)


Tightening torque

Water bypass union (c): 14 N·m (1.4 kgf-m, 10.0 lb-ft)




I823H1140296-02

- After aligning the boss "A" on the cylinder head with the slit on the intake pipe, install the intake pipes.



I823H1140120-01

- Set the clamp screws as shown in the figure.



I823H1140121-03

"B": Upper	"C": Lower	"D": Left	"E": Right	"a": 45°
------------	------------	-----------	------------	----------

- Install the thermostat.


NOTE

The air bleeder hole "F" of the thermostat faces upside.

- Tighten the thermostat cover bolts (4) to the specified torque.

Tightening torque

Thermostat cover bolt (d): 10 N·m (1.0 kgf-m, 7.0 lb-ft)



I823H1140122-04


- Tighten the ECT sensor (5) to the specified torque.

Tightening torque

Engine coolant temperature sensor (e): 18 N·m (1.8 kgf-m, 13.0 lb-ft)

CAUTION

- Take special care when handling the temperature sensor. It may cause damage if it gets a sharp impact.
- Replace a gasket with a new one.




I823H1140123-03

1D-51 Engine Mechanical:

- Install the valve spring seat.
- Apply engine oil to the oil seal (6), and press-fit it into the position.

⚠ CAUTION

Do not reuse the removed oil seal.




I823H1140124-04

- Insert the valve, with its stem coated with molybdenum oil solution all around and along the full stem length without any break.

⚠ CAUTION


When inserting the valve, take care not to damage the lip of the oil seal.

M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)



I705H1140165-01

- Install the valve spring with the small-pitch portion "G" facing cylinder head.



I823H1140304-02

"G": Small-pitch portion	"I": Upward
H": Large-pitch portion	"J": Paint

- Put on the valve spring retainer (7), and using the special tools, press down the spring, fit the cotter halves to the stem end, and release the lifter to allow the cotter halves to wedge in between retainer and stem.

⚠ CAUTION


- Be sure to restore each spring and valve to their original positions.
- Be careful not to damage the valve and valve stem when handling them.
- Be careful not to damage the tappet sliding surface with the special tool.

Special tool

- TOOL (A): 09916-14510 (Valve spring compressor)**
- TOOL (B): 09916-14522 (Valve spring compressor attachment)**
- TOOL (C): 09919-28620 (Sleeve protector)**
- TOOL : 09916-84511 (Tweezers)**




I823H1140125-01



I823H1140126-04

- Be sure that the rounded lip "K" of the cotter fits snugly into the groove "L" in the stem end.



I823H1140127-04

8. Valve spring retainer

9. Cotter

- Install the other valves and springs in the same manner as described previously.
- Install the tappet shims and the tappets to their original positions.

NOTE

- Apply engine oil to the stem end, shim and tappet before fitting them.
- When seating the tappet shim, be sure the figure printed surface faces the tappet.



I823H1140128-01

Cylinder Head Related Parts Inspection

B815H21406028

Refer to "Cylinder Head Disassembly and Assembly (Page 1D-47)".

Cylinder Head Distortion


- Decarbonize the combustion chambers.
- Check the gasket surface of the cylinder head for distortion. Use a straightedge and thickness gauge. Take clearance readings at several places. If readings exceed the service limit, replace the cylinder head.

Special tool

TOOL : 09900-20803 (Thickness gauge)

Cylinder head distortion

Service limit: 0.20 mm (0.008 in)



I823H1140129-01

Valve Stem Runout

Support the valve using V-blocks, as shown in the figure, and check its runout using the dial gauge. If the runout exceeds the service limit, replace the valve.

Special tool


TOOL (A): 09900-20607 (Dial gauge (1/100 mm, 10 mm))

TOOL (B): 09900-20701 (Magnetic stand)

TOOL (C): 09900-21304 (V-block (100 mm))

Valve stem runout (IN. & EX.)

Service limit: 0.05 mm (0.002 in)



I649G1140231-03

Valve Head Radial Runout

Place the dial gauge at a right angle to the valve head face and measure the valve head radial runout. If it measures more than the service limit, replace the valve.

Special tool


 (A): 09900-20607 (Dial gauge (1/100 mm, 10 mm))

 (B): 09900-20701 (Magnetic stand)

 (C): 09900-21304 (V-block (100 mm))

Valve head radial runout (IN. & EX.)

Service limit: 0.03 mm (0.001 in)



I649G1140232-03

Valve Stem and Valve Face Wear Condition

- Visually inspect each valve stem and valve face for wear and pitting. If it is worn or damaged, replace the valve with a new one.



I823H1140130-01

Valve Stem Deflection

Lift the valve about 10 mm (0.39 in) from the valve seat. Measure the valve stem deflection in two directions, "X" and "Y", perpendicular to each other. Position the dial gauge as shown. If the deflection exceeds the service limit, then determine whether the valve or the guide should be replaced with a new one.


Special tool

 (A): 09900-20607 (Dial gauge (1/100 mm, 10 mm))

 (B): 09900-20701 (Magnetic stand)

Valve stem deflection (IN. & EX.)

Service limit: 0.25 mm (0.010 in)



I823H1140131-01

Valve Stem Wear

Measure the valve stem O.D. using the micrometer. If it is out of specification, replace the valve with a new one. If the valve stem O.D. is within specification but the valve stem deflection is not, replace the valve guide. After replacing the valve or valve guide, recheck the deflection.

Special tool

TOOL (A): 09900-20205 (Micrometer (0 – 25 mm))


Valve stem O.D.

Standard (IN.): 4.975 – 4.990 mm (0.1959 – 0.1965 in)

Standard (EX.): 4.955 – 4.970 mm (0.1951 – 0.1957 in)

NOTE

If valve guides have to be removed for replacement after inspecting related parts, carry out the steps shown in valve guide replacement. Refer to “Valve Guide Replacement (Page 1D-56)”.



I718H1140122-01

Valve Spring

The force of the coil spring keeps the valve seat tight. A weakened spring results in reduced engine power output and often accounts for the chattering noise coming from the valve mechanism.

Check the valve springs for proper strength by measuring their free length and also by the force required to compress them. If the spring length is less than the service limit or if the force required to compress the spring does not fall within the specified range, replace the valve spring.

Special tool


TOOL (A): 09900-20102 (Vernier calipers (1/20 mm, 200 mm))

Valve spring free length (IN. & EX.)


Service limit: 42.3 mm (1.67 in)

Valve spring tension (IN. & EX.)

Standard: Approx. 137 N (14.0 kgf, 30.8 lbs)/36.6 mm (1.44 in)



I649G1140237-03



I649G1140238-03

Tension “a”	Length “b”
Approx. 137 N (14.0 kgf, 30.8 lbs)	36.6 mm (1.44 in)

Valve Seat Width

- 1) Visually check for valve seat width on each valve face. If the valve face has worn abnormally, replace the valve.
- 2) Coat the valve seat with a red lead (Prussian Blue) and set the valve in place.


⚠ CAUTION

Do not use lapping compound.

- 3) Rotate the valve with light pressure.

Special tool

TOOL (A): 09916-10911 (Valve lapper set)




I823H1140132-01

- 4) Check that the transferred red lead (blue) on the valve face is uniform all around and in center of the valve face.

If the seat width “a” measured exceeds the standard value, or seat width is not uniform reface the seat using the seat cutter. Refer to “Valve Seat Repair (Page 1D-57)”.

Valve seat width “a” (IN. & EX.)

Standard: 0.9 – 1.1 mm (0.035 – 0.043 in)




I649G1140246-02

Valve Seat Sealing Condition

- 1) Clean and assemble the cylinder head and valve components.
- 2) Fill the intake and exhaust ports with gasoline to check for leaks. If any leaks occur, inspect the valve seat and face for burrs or other things that could prevent the valve from sealing. Refer to “Valve Seat Repair (Page 1D-57)”.

⚠ WARNING

Always use extreme caution when handling gasoline.



I823H1140133-01

NOTE

After servicing the valve seats, be sure to check the valve clearance after the cylinder head has been reinstalled. Refer to “Valve Clearance Inspection and Adjustment in Section 0B (Page 0B-4)”.

Valve Guide Replacement

B815H21406029


- 1) Remove the cylinder head. Refer to "Engine Top Side Disassembly (Page 1D-27)".
- 2) Remove the valves. Refer to "Cylinder Head Disassembly and Assembly (Page 1D-47)".
- 3) Using the valve guide remover, drive the valve guide out toward the intake or exhaust camshaft side.

Special tool

 (A): 09916-44310 (Valve guide remover/installer)

NOTE

- Discard the removed valve guide sub-assemblies.
- Only oversized valve guides are available as replacement parts. (Part No. 11115-15H70)



I823H1140134-01

- 4) Refinish the valve guide holes in the cylinder head using the reamer and handle.


⚠ CAUTION

When refinishing or removing the reamer from the valve guide hole, always turn it clockwise.

Special tool

 (B): 09916-34580 (Valve guide reamer (10.8 mm))

 (C): 09916-34542 (Reamer handle)



I823H1140135-01

- 5) Cool down the new valve guides in a freezer for about one hour and heat the cylinder head to 100 – 150 °C (212 – 302 °F) with a hot plate.

⚠ CAUTION

Do not use a burner to heat the valve guide hole to prevent cylinder head distortion.

- 6) Apply engine oil to each valve guide and valve guide hole.
- 7) Drive the guide into the guide hole using the valve guide installer.


⚠ CAUTION

Failure to oil the valve guide hole before driving the new guide into place may result in a damaged guide or head.

Special tool


 (A): 09916-44310 (Valve guide remover/installer)

 (D): 09916-53350 (Attachment)



I718H1140127-01

1. Cylinder head	"a": 18.0 mm (0.71 in)
------------------	------------------------



I823H1140136-01


- 8) After installing the valve guides, refinish their guiding bores using the reamer. Be sure to clean and oil the guides after reaming.

NOTE

- Be sure to cool down the cylinder head to ambient air temperature.
- Insert the reamer from the combustion chamber and always turn the reamer handle clockwise.

Special tool

-  (C): 09916-34542 (Reamer handle)
 (E): 09916-34570 (Valve guide reamer (5.0 mm))




I823H1140137-01

- 9) Reassemble the cylinder head. Refer to “Cylinder Head Disassembly and Assembly (Page 1D-47)”.
- 10) Install the cylinder head assembly. Refer to “Engine Top Side Assembly (Page 1D-31)”.

Valve Seat Repair

B815H21406030

The valve seats (1) for both the intake and exhaust valves are machined to three different angles. The seat contact surface is cut at 45°.



I823H1140138-01

	Intake	Exhaust
Seat angle	30°/45°/60°	15°/45°/60°
Seat width	0.9 – 1.1 mm (0.035 – 0.043 in)	←
Valve diameter	33 mm (1.30 in)	27.5 mm (1.08 in)
Valve guide I.D.	5.000 – 5.012 mm (0.1969 – 0.1973 in)	←

⚠ CAUTION

- The valve seat contact area must be inspected after each cut.
- Do not use lapping compound after the final cut is made. The finished valve seat should have a velvety smooth finish but not a highly polished or shiny finish. This will provide a soft surface for the final seating of the valve which will occur during the first few seconds of engine operation.
- The titanium valves are coated with an oxidized membrane treatment to resist wear but the membrane tend to removed if lapped after valve seat servicing.

NOTE

After servicing the valve seats, be sure to check the valve clearance after the cylinder head has been reinstalled. Refer to “Valve Clearance Inspection and Adjustment in Section 0B (Page 0B-4)”.

Cylinder Disassembly and Assembly


B815H21406031

Refer to "Engine Top Side Disassembly (Page 1D-27)".

Refer to "Engine Top Side Assembly (Page 1D-31)".


Disassembly

- 1) Remove the water inlet connector (1).



I823H1140139-01

- 2) Remove the water jacket plugs (2).



I823H1140140-01

Assembly

Assembly is in the reverse order of disassembly. Pay attention to the following points:

- Apply engine coolant to O-rings of water jacket plugs.


⚠ CAUTION

Replace the O-rings with new ones.

- Tighten the water jacket plugs (1) to the specified torque.

Tightening torque

Water jacket plug (a): 11 N·m (1.1 kgf-m, 8.0 lb-ft)




I823H1140141-02

- Apply engine coolant to O-ring of water inlet connector.

⚠ CAUTION

Replace the O-ring with a new one.




I823H1140142-01

- Tighten the water inlet connector bolts (2) to the specified torque.

Tightening torque

Water inlet connector bolt (b): 10 N·m (1.0 kgf-m, 7.0 lb-ft)



I823H1140143-03

Cylinder Inspection

B815H21406032

Refer to "Engine Top Side Disassembly (Page 1D-27)".
Refer to "Engine Top Side Assembly (Page 1D-31)".

Cylinder Distortion


Check the gasket surface of the cylinder for distortion.
Use a straightedge and thickness gauge. Take clearance readings at several places. If any reading exceeds the service limit, replace the cylinder.

Special tool

 : 09900-20803 (Thickness gauge)

Cylinder distortion

Service limit: 0.20 mm (0.008 in)



I823H1140144-01

Cylinder Bore


Measure the cylinder bore diameter at six places. If any one of the measurements exceed the limit, overhaul the cylinder and replace the piston with an oversize piston. The remaining cylinders must also be rebored accordingly; otherwise, the imbalance might cause excessive vibration.

Special tool


 (A): 09900-20530 (Cylinder gauge set)

Cylinder bore

Standard: 81.000 – 81.015 mm (3.1890 – 3.1896 in)



I823H1140145-02



I823H1140146-02

Piston-to-cylinder Clearance

Refer to "Piston and Piston Ring Inspection (Page 1D-61)".

Piston Ring Removal and Installation


B815H21406033

Removal

- 1) Draw out the piston pin and remove the piston. Refer to "Engine Top Side Disassembly (Page 1D-27)".
- 2) Carefully spread the ring opening with your thumbs and then push up the opposite side of the 1st ring to remove it.

NOTE

Do not expand the piston ring excessively since it is apt to be broken down.



I823H1140303-01


- 3) Remove the 2nd ring and oil ring in the same manner.

Installation

NOTE

- When installing the piston ring, be careful not to damage the piston.
- Do not expand the piston ring excessively since it is apt to be broken down.


- 1) Install the piston rings in the order of the oil ring, second ring and top ring.
 - a) The first member to go into the oil ring groove is the spacer (1).
After placing the spacer, fit the two side rails (2).



I718H1140143-02

⚠ CAUTION

When installing the spacer, be careful not to allow its two ends to overlap in the groove.




I705H1140170-02

"A": INCORRECT	"B": CORRECT
----------------	--------------

- b) Install the 2nd ring (3) and 1st ring (4) to piston.

NOTE


1st ring (4) and 2nd ring (3) differ in shape.



I823H1140147-01


NOTE

Face the side with the stamped mark upward when assembling.



I823H1140148-03

- 2) Position the gaps of the three rings and side rails as shown. Before inserting piston into the cylinder, check that the gaps are so located.



I823H1140573-02

"C": 1st ring and upper side rail
"D": Spacer
"E": 2nd ring and lower side rail

- 3) Install each piston and piston pin. Refer to "Engine Top Side Assembly (Page 1D-31)".

Piston and Piston Ring Inspection

B815H21406034

Refer to "Piston Ring Removal and Installation (Page 1D-60)".

Piston Diameter


Measure the piston diameter using the micrometer at 15 mm (0.6 in) "a" from the skirt end. If the piston diameter is less than the service limit, replace the piston.

Special tool


TOOL (A): 09900-20204 (Micrometer (75 – 100 mm))

Piston diameter

Service limit: 80.880 mm (3.1842 in)



I823H1140149-01



I649G1140262-03

Piston-to-cylinder Clearance

Subtract the piston diameter from the cylinder bore diameter. If the piston-to-cylinder clearance exceeds the service limit, replace both the cylinder and the piston.

Piston-to-cylinder clearance

Service limit: 0.120 mm (0.0047 in)

Piston Ring-to-groove Clearance

Measure the side clearances of the 1st and 2nd piston rings using the thickness gauge. If any of the clearances exceed the limit, replace both the piston and piston rings.

Special tool

TOOL (A): 09900-20803 (Thickness gauge)

TOOL (B): 09900-20205 (Micrometer (0 – 25 mm))

Piston ring-to-groove clearance

Service limit (1st): 0.180 mm (0.0071 in)

Service limit (2nd): 0.150 mm (0.0059 in)


Piston ring groove width

"a": Standard (1st): 0.83 – 0.85 mm (0.0327 – 0.0335 in)


"b": Standard (1st): 1.30 – 1.32 mm (0.0512 – 0.0520 in)

Standard (2nd): 1.01 – 1.03 mm (0.0398 – 0.0406 in)


Standard (Oil): 2.01 – 2.03 mm (0.0791 – 0.0799 in)



I649G1140263-03




I823H1140580-02

Piston ring thickness**Standard (1st): 0.76 – 0.81 mm (0.0299 – 0.0319 in)****Standard (1st): 1.08 – 1.10 mm (0.0425 – 0.0433 in)****Standard (2nd): 0.97 – 0.99 mm (0.0382 – 0.0390 in)**


I649G1140264-03

Piston Ring Free End Gap and Piston Ring End Gap

Measure the piston ring free end gap using vernier calipers. Next, fit the piston ring squarely into the cylinder and measure the piston ring end gap using the thickness gauge. If any of the measurements exceed the service limit, replace the piston ring with a new one.

Special tool**TOOL (A): 09900-20102 (Vernier calipers (1/20 mm, 200 mm))****Piston ring free end gap****Service limit (1st): 5.2 mm (0.20 in)****Service limit (2nd): 7.2 mm (0.28 in)****Special tool****TOOL (B): 09900-20803 (Thickness gauge)****Piston ring end gap****Service limit (1st): 0.50 mm (0.020 in)****Service limit (2nd): 0.50 mm (0.020 in)**


I649G1140265-03



I823H1140151-01


Piston Pin and Pin Bore

Measure the piston pin bore inside diameter using the small bore gauge. If either is out of specification or the difference between these measurements surpass limits, replace the piston.

Special tool**TOOL (A): 09900-20602 (Dial gauge (1/1000 mm, 1 mm))****TOOL (B): 09900-22403 (Small bore gauge (18 – 35 mm))****Piston pin bore****Service limit: 18.030 mm (0.7098 in)**

I649G1140267-03

Measure the piston pin outside diameter at three positions using the micrometer. If any of the measurements are out of specification, replace the piston pin.

Special tool**TOOL (C): 09900-20205 (Micrometer (0 – 25 mm))****Piston pin O.D.****Service limit: 17.980 mm (0.7079 in)**

I649G1140268-03

Engine Bottom Side Disassembly

B815H21406035


NOTE

The crankcase must be separated to service the crankshaft and conrod.

- 1) Remove the engine assembly from the frame. Refer to "Engine Assembly Removal (Page 1D-19)".
- 2) Remove the engine top side. Refer to "Engine Top Side Disassembly (Page 1D-27)".

Crankcase Breather (PCV) Hose


Disconnect the crankcase breather (PCV) hose (1).



I815H1140055-01


Crankcase Breather (PCV) Hose Cover

- 1) Remove the reed valve cover (1).




I823H1140153-01

- 2) Remove the reed valve (2).



I823H1140154-01


- 3) Remove the crankcase breather (PCV) cover (3).



I823H1140155-01

Starter Motor

Remove the starter motor (1).




I823H1140156-01

Starter Torque Limiter

Remove the starter torque limiter (1) and starter idle gear (2). Refer to "Starter Torque Limiter / Starter Clutch Removal and Installation in Section 1I (Page 1I-10)".

NOTE


Do not remove the starter clutch for clutch disassembly.



I815H1140056-01

Clutch

Remove the clutch component parts (1). Refer to "Clutch Removal in Section 5C (Page 5C-14)".




I823H1140158-04

Oil Pump

- 1) Remove the snap ring (1).
- 2) Remove the oil pump driven gear (2).


NOTE

Take care not to drop the snap ring (1), pin (3) or washer (4) into the crankcase.




I823H1140159-01

- 3) Remove the pin (3) and washer (4).



I823H1140160-01


- 4) Remove the oil pump (5).



I823H1140161-01

Gear Position Switch


- 1) Remove the gear position switch lead wire clamps.
- 2) Remove the gear position switch (1).



I823H1140162-01

Starter Clutch


Remove the starter clutch (1). Refer to “Starter Torque Limiter / Starter Clutch Removal and Installation in Section 1I (Page 1I-10)”.



I823H1140163-01

Cam Chain


Remove the cam chain (1) and cam chain drive sprocket (2).



I823H1140164-02

Cam Chain Tensioner


Remove the cam chain tensioner (1).



I823H1140165-01

Generator


Remove the generator component parts (1). Refer to “Generator Removal and Installation in Section 1J (Page 1J-6)”.



I823H1140166-01

Water Pump


Remove the water pump (1).



I823H1140167-01


Gearshift System

1) Remove the gearshift cover (1).




I823H1140168-01

2) Remove the gasket (2) and dowel pins.



I823H1140169-01


3) Remove the gearshift shaft assembly (3) with the washers (4).



I823H1140170-01


4) Remove the gearshift cam plate bolt (5).

5) Remove the gearshift cam plate (6).



I823H1140171-01

6) Remove the gearshift cam stopper (7) and gearshift arm stopper (8).




I815H1140057-01

Oil Filter

Remove the oil filter (1) using the special tool.

Special tool


TOOL (A): 09915-40610 (Oil filter wrench)



I823H1140173-02

Oil Pipe


- 1) Remove the oil pipe (1).
- 2) Remove the cushion (2).



I823H1140175-01

Oil Pressure Switch


Remove the oil pressure switch (1).



I815H1140059-01


Oil Pan

- 1) Remove the oil pan (1).



I823H1140176-02


- 2) Remove the gasket (2).



I823H1140177-01

Oil Pressure Regulator

Remove the oil pressure regulator (1).



I823H1140178-01


Oil Strainer

- 1) Remove the oil strainer (1).



I815H1140120-01


- 2) Remove the O-ring (2).



I823H1140180-01

Breather Pipe


Remove the breather pipe (1).



I823H1140181-01


Crank Balancer

- 1) Remove the oil separator (1).




I823H1140182-01

- 2) Remove the balancer shaft arm (2).




I823H1140183-02

- 3) Remove the balancer shaft (3).



I823H1140184-01

- 4) Remove the crank balancer assembly (4) with the washers (5).




I823H1140185-01

Crankcase


- 1) Remove the crankcase bolts.

NOTE

Loosen the crankcase bolts diagonally and the smaller sizes first.



I823H1140186-02




I815H1140060-01

- 2) Remove the crankshaft journal bolts.

NOTE


Loosen the crankshaft journal bolts in the descending order of the numbers on the crankcase.



I823H1140290-02

1D-69 Engine Mechanical:

- 3) Make sure that all of the bolts are removed. Then, tap the sides of the lower crankcase using a plastic hammer to separate the upper and lower crankcase halves and then lift the lower crankcase off of the upper crankcase.
- 4) Remove the dowel pins.




I823H1140188-01

Crankshaft / Conrod

- 1) Remove the crankshaft assembly (1) from the upper crankcase.
- 2) Remove the thrust bearings (2).

NOTE

Remove the conrod if necessary. Refer to "Conrod Removal and Installation (Page 1D-89)".



I823H1140189-01

Transmission


Remove the transmission component. Refer to "Transmission Removal in Section 5B (Page 5B-3)".



I823H1140190-01


Oil Jet

- 1) Remove the piston cooling oil jets (1) from the upper crankcase.




I823H1140191-01

- 2) Remove the oil jet (2) (for transmission oil spray) from the upper crankcase.




I823H1140192-01

- 3) Remove the oil jet (3) (for generator) from the upper crankcase.




I823H1140193-01

- 4) Remove the oil jet (4) (for transmission) from the lower crankcase.



I823H1140194-01

- 5) Remove the oil gallery jet (5) from the lower crankcase.



I823H1140195-01

Crankshaft Journal Bearing


Remove the crankshaft journal bearings, upper and lower.

⚠ CAUTION


- When removing the crankshaft journal bearings, be careful not to scratch the crankcase and the crankshaft journal bearings.
- Do not touch the bearing surfaces with your hands. Grasp the bearings by their edges.

NOTE

- Do not remove the crankshaft journal bearings unless absolutely necessary.
- Make a note of where the crankshaft journal bearings are removed from so that they can be reinstalled in their original positions.




I823H1140196-01




I823H1140197-01

Oil Gallery Plug


- 1) Remove the oil gallery plug (M6) (1), (M14) (2), (M14) (3) and (M6) (4) from the upper crankcase.



I823H1140198-01




I823H1140199-01




I823H1140200-01

- 2) Remove the oil gallery plugs (M6) (5), (M8) (6), (M10) (7), (M6) (8) and (M16) (9) from the lower crankcase.



I823H1140201-01



I823H1140202-01

Bearing

Remove the bearings if necessary. Refer to "Gearshift Shaft Oil Seal / Bearing Removal and Installation in Section 5B (Page 5B-17)".

Engine Bottom Side Assembly

B815H21406036

Assemble the engine bottom side in the reverse order of disassembly. Pay attention to the following points:

NOTE

Apply engine oil to each running and sliding part before reassembling.

Oil Seal / Bearing

- Install the oil bearings. Refer to "Gearshift Shaft Oil Seal / Bearing Removal and Installation in Section 5B (Page 5B-17)".

Oil Gallery Plug

- Tighten each plug to the specified torque.

⚠ CAUTION

Replace the gaskets with new ones.


Tightening torque

Oil gallery plug (M6) and (M8) (a): 10 N·m (1.0 kgf-m, 7.0 lb-ft)


Oil gallery plug (M10) (b): 18 N·m (1.8 kgf-m, 13.0 lb-ft)

Oil gallery plug (M14) (c): 23 N·m (2.3 kgf-m, 16.5 lb-ft)

Oil gallery plug (M16) (d): 35 N·m (3.5 kgf-m, 25.5 lb-ft)




I823H1140203-01




I823H1140204-01



I823H1140205-01



I823H1140206-01



I823H1140207-01

Crankshaft Journal Bearing


- When fitting the crankshaft journal bearings to the upper and lower crankcases, be sure to fix the stopper part "A" first and press the other end.

⚠ CAUTION

Do not touch the bearing surfaces with your hands. Grasp by the edge of the bearing shell.

NOTE

Inspect and select the crankshaft journal bearing if necessary. Refer to "Crankshaft Journal Bearing Inspection and Selection (Page 1D-94)".



I823H1140208-02

Oil Jet


- Fit the new O-rings (1) to each piston cooling oil jet and apply engine oil to them.

CAUTION

Use the new O-rings to prevent oil pressure leakage.

NOTE

Be sure to face the oil hole "A" of each piston cooling oil jet to the top when installing them.



I823H1140209-01

- Install each piston cooling oil jet.

NOTE

Apply a small quantity of thread lock to the bolts and tighten them to the specified torque.

 1322 : Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER 1322 or equivalent)


Tightening torque

Piston cooling oil jet bolt (a): 10 N·m (1.0 kgf-m, 7.0 lb-ft)



I823H1140210-04

- Install the oil jets (for transmission (2) and oil spray (3)).




I823H1140211-01

- Install the oil jets (for generator (4)) onto the upper crankcase and tighten it to the specified torque.

Tightening torque

Oil jet (For generator) (b): 5 N·m (0.5 kgf-m, 3.5 lb-ft)



I823H1140212-02

Transmission


- Install the transmission. Refer to "Transmission Installation in Section 5B (Page 5B-4)".



I823H1140305-01

Crankshaft

- Before installing the crankshaft assembly, apply engine oil to each crankshaft journal bearing.
- Install the crankshaft assembly to the upper crankcase.




I823H1140213-01

- Insert the right and left-thrust bearings with the oil grooves "A" facing towards the crankshaft web.

NOTE


- Right-thrust bearing has green painting.
- Inspect and select the crankshaft thrust clearance if necessary. Refer to "Crankshaft Thrust Clearance Inspection and Selection (Page 1D-96)".



I823H1140214-02

Crankcase

- Install the dowel pins to the upper crankcase.




I823H1140215-01

- Apply bond to the mating surface of the lower crankcase as follows.

NOTE

- Make surfaces free from moisture, oil, dust and other foreign materials.
- Spread the sealant on surfaces thinly to form an even layer, and assemble the crankcases within a few minutes.
- Take extreme care not to apply sealant to any oil hole, oil groove and bearing.
- Apply sealant to distorted surfaces as it forms a comparatively thick film.
- Apply sealant to both mating surface of crankcases at hatched parts.

1207B : Sealant 99000-31140 (SUZUKI BOND No.1207B or equivalent)




"A": Apply bond to both surfaces of the upper and lower cases.	: Apply bond.
--	---------------

- Match the upper and lower crankcases.

NOTE

Align the gearshift forks with each gearshift groove.



I823H1140216-01

- Tighten the crankshaft journal bolts (M9) in ascending order of numbers assigned to these bolts. Tighten each bolt a little at a time to equalize the pressure in the following two steps.


CAUTION

Fit the new copper washers to the bolts ("7", "8", "9" and "10") to prevent oil leakage.

Tightening torque

Crankshaft journal bolt (M9) (Initial): 18 N·m (1.8 kgf-m, 13.0 lb-ft)

Crankshaft journal bolt (M9) (Final): 32 N·m (3.2 kgf-m, 23.0 lb-ft)



I823H1140309-02

- Tighten the other crankcase bolts a little at a time to equalize the pressure.

CAUTION


Fit the new copper washers to the bolts "B".

Tightening torque


Crankcase bolt (M6): 11 N·m (1.1 kgf-m, 8.0 lb-ft)

Crankcase bolt (M8): 26 N·m (2.6 kgf-m, 19.0 lb-ft)

Crankcase bolt (M10): 50 N·m (5.0 kgf-m, 36.0 lb-ft)



I823H1140218-03




I823H1140219-04


- After the crankshaft journal bolts and crankcase bolts have been tightened, check that the crankshaft rotates smoothly.

1D-77 Engine Mechanical:

- Also check that the driveshaft and countershaft rotate smoothly.



I815H1140126-01



I815H1140127-01


Crank Balancer

- Temporarily install the cam chain drive sprocket, starter clutch and starter clutch cover. Refer to "Starter Torque Limiter / Starter Clutch Removal and Installation in Section 1I (Page 1I-10)".

NOTE


Before installing the starter clutch cover, install the dowel pins.

- Turn the crankshaft to bring the line "A" on starter clutch to the slit "B" of the valve timing inspection hole.



I823H1140220-01


- Hold the crankshaft and install the crank balancer assembly.



I823H1140221-01

NOTE

Align the engraved line "C" on the crank balancer, punch mark "D" on the balancer gear and triangle mark "E" on the crankcase in line.



I823H1140222-01


- Apply molybdenum oil solution to the balancer shaft.

M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)

⚠ CAUTION

Replace the O-ring (1) with a new one.

- Install the balancer shaft.



I823H1140223-02

- Install the balancer shaft arm.

NOTE

Apply a small quantity of thread lock to the balancer shaft arm bolt and tighten it to the specified torque.

①③②② : Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER 1322 or equivalent)

Tightening torque

Balancer shaft arm bolt (a): 10 N·m (1.0 kgf-m, 7.0 lb-ft)



I823H1140310-01


- Slowly turn the balancer shaft (2) clockwise until it stops (position "F") with a (–) screwdriver.
- From this position, turn the balancer shaft (2) counterclockwise by 1.5 – 2 graduations "G" and tighten the bolt (3).
From "F" to "G": 1.5 – 2 graduations

Tightening torque


Balancer shaft mounting bolt (b): 10 N·m (1.0 kgf-m, 7.0 lb-ft)

NOTE

If the balancer gear is noisy after starting the engine, turn in or out the balancer shaft within 1 graduation from standard setting to reduce the gear noise.



I815H1140110-01



I823H1140226-01

- Install the balancer cover.


NOTE

Apply a small quantity of thread lock to the balancer cover bolt and tighten it to the specified torque.

 : Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER 1322 or equivalent)

Tightening torque

Balancer cover bolt (c): 10 N·m (1.0 kgf-m, 7.0 lb-ft)



I815H1140061-01

- Remove the starter clutch cover, starter clutch and cam chain drive sprocket.

Breather Pipe

- Install the breather pipe to the crankcase.

NOTE

Apply a small quantity of thread lock to the breather pipe bolt and tighten it to the specified torque.

 : Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER 1322 or equivalent)

Tightening torque

Breather pipe bolt (a): 10 N·m (1.0 kgf-m, 7.0 lb-ft)



I823H1140228-02

Oil Strainer

- Install a new O-ring.

NOTE

Apply grease to the O-ring.

 : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)

CAUTION

Use the new O-ring to prevent oil leakage.



I823H1140229-01

- Install the oil strainer.

NOTE

Apply a small quantity of thread lock to the strainer bolts and tighten it to the specified torque.

 : Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER 1322 or equivalent)

Tightening torque

Oil strainer bolt (a): 10 N·m (1.0 kgf-m, 7.0 lb-ft)



I815H1140111-02


Oil Pressure Regulator

- Apply grease to the new O-ring and press in the oil pressure regulator to the crankcase.

 **Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)**

 CAUTION

Use the new O-ring to prevent oil leakage.




I815H1140121-01

Oil Pan

- Install a new gasket (1).

 CAUTION

Use the new gasket to prevent oil leakage.



I815H1140122-01


- Install the oil pan and tighten the bolts diagonally.

NOTE

Fit the new gasket washer to the oil pan bolt (2).

Tightening torque

Oil pan bolt (a): 10 N·m (1.0 kgf-m, 7.0 lb-ft)



I815H1140123-01

Oil Pressure Switch

- Apply bond to the thread part of oil pressure switch and tighten oil pressure switch to the specified torque.


NOTE

Be careful not to apply bond to the hole of thread end.

 **Sealant 99000-31140 (SUZUKI BOND No.1207B or equivalent)**

Tightening torque

Oil pressure switch: 14 N·m (1.4 kgf-m, 10.0 lb-ft)



I718H1140233-01


Oil Pipe

- Install the new O-ring to the oil pipe and apply grease to it.

⚠ CAUTION

Use a new O-ring to prevent oil leakage.

⚠ : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)




I823H1140234-01

- Install the new gasket washers (1).


⚠ CAUTION

Use the new washers to prevent oil leakage.



I823H1140235-02

- Install the cushion (2).



I815H1140062-01

- Tighten the oil pipe bolts (3) and oil pipe union bolt (4) to the specified torque.

NOTE


- Apply a small quantity of thread lock to the oil pipe bolts (3).
- Apply engine oil to the oil pipe union bolt (4).

1322 : Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER 1322 or equivalent)

Tightening torque

Oil pipe bolt (M6) (a): 10 N·m (1.0 kgf-m, 7.0 lb-ft)

Oil pipe union bolt (M14) (b): 24 N·m (2.4 kgf-m, 17.5 lb-ft)




I815H1140063-02

Oil Filter

- Install the oil filter with the special tool. Refer to "Engine Oil and Filter Replacement in Section 0B (Page 0B-10)".

Special tool

TOOL (A): 09915-40610 (Oil filter wrench)



I823H1140238-01

Gearshift System

- Install the gearshift cam stopper (1), bolt (2), washer (3) and return spring (4).
- Apply a small quantity of thread lock to the gearshift cam stopper bolt (2) and tighten it to the specified torque.


 **1303** : Thread lock cement 99000-32030 (THREAD LOCK CEMENT SUPER 1303 or equivalent)

NOTE


Hook the return spring end "A" to the stopper (1).

Tightening torque

Gearshift cam stopper bolt (a): 10 N·m (1.0 kgf-m, 7.0 lb-ft)



I823H1140239-02




I815H1140064-02

- Check the gearshift cam stopper moves smoothly.
- Locate the gearshift cam in the neutral position.

- Install the gearshift cam stopper plate (5).

NOTE

Align the gearshift cam pin "B" with the gearshift cam stopper plate hole "C".




I815H1140112-01

- Apply a small quantity of thread lock to the gearshift cam stopper plate bolt (6) and tighten it to the specified torque.

 **1322** : Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER 1322 or equivalent)

Tightening torque

Gearshift cam stopper plate bolt (b): 13 N·m (1.3 kgf-m, 9.5 lb-ft)




I815H1140129-01

- Install the gearshift shaft assembly (7) and washers (8) as shown in the figure.

NOTE

Pinch the gearshift arm stopper with return spring ends.



I815H1140114-01

1D-83 Engine Mechanical:


- Install a new gasket (9) and the dowel pins.

CAUTION

Use a new gasket to prevent oil leakage.

- Apply grease to the lip of the gearshift cover oil seal.

 : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)




I815H1140115-01

- Tighten the gearshift cover bolts (10) to the specified torque.

Tightening torque

Gearshift cover bolt (c): 10 N·m (1.0 kgf-m, 7.0 lb-ft)



I815H1140116-01


Water Pump

- Apply grease to new O-ring (1).

CAUTION

Use the new O-ring to prevent oil leakage.

 : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)




I823H1140246-04

- Tighten the water pump mounting bolts (2) to the specified torque.

Tightening torque


Water pump mounting bolt (a): 10 N·m (1.0 kgf-m, 7.0 lb-ft)



I823H1140247-02

Generator

- Install the generator component parts (1). Refer to "Generator Removal and Installation in Section 1J (Page 1J-6)".




I815H1140125-01

Cam Chain Tensioner


- Install the cam chain tensioner (1).
- Apply thread lock to the cam chain tensioner bolt (2).

Tightening torque

Cam chain tensioner bolt (a): 23 N·m (2.3 kgf-m, 16.5 lb-ft)



I823H1140249-02



I823H1140581-03


(a)	: 23 Nm (2.3 kgf-m, 16.5 lb-ft)
1322	: Apply thread lock.

Cam Chain

- Install the cam chain drive sprocket (1) to the crankshaft.


NOTE

Align the wide spline tooth of cam chain drive sprocket and that of crankshaft.



I823H1140250-02


- Install the cam chain (2) onto the cam chain drive sprocket.



I823H1140251-01

Starter Clutch

- Install the starter clutch (1). Refer to "Starter Torque Limiter / Starter Clutch Removal and Installation in Section 1I (Page 1I-10)".




I823H1140252-01

Gear Position Switch

NOTE

Align the gear position switch pin "A" with the gearshift cam hole "B".




I823H1140253-01

- Install the gear position switch.
- Install the gear position switch lead wire clamps.
- Apply a bond lightly to the groove of gear position switch lead wire grommet.

1207B : Sealant 99000-31140 (SUZUKI BOND No.1207B or equivalent)

NOTE

- The flat surface of the clamp faces the lead wire.
- After contacting the clamp to the stopper "C" of the crankcase, tighten the clamp bolt.
- Be sure to install the grommet (1) to the crankcase.




I815H1140124-01

Tightening torque

GP switch mounting bolt (a): 6.5 N·m (0.65 kgf-m, 4.7 lb-ft)

GP switch lead wire clamp bolt (b): 6.5 N·m (0.65 kgf-m, 4.7 lb-ft)



I823H1140255-02

Oil Pump

- Install the new O-ring to the oil pump and apply grease to it.


⚠ CAUTION

Use the new O-ring to prevent oil leakage.

⚠ : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)

NOTE

Set the oil pump shaft end "A" to the water pump shaft.




I823H1140256-01

- Install the oil pump and tighten the bolts to the specified torque.

Tightening torque

Oil pump mounting bolt (a): 10 N·m (1.0 kgf-m, 7.0 lb-ft)




I823H1140257-02

- Install the washer (1) and pin (2).

NOTE

Be careful not to drop the washer or pin into the crankcase.




I823H1140258-01

- Install the oil pump driven gear (3).
- Install the snap ring (4).

Special tool


Tool : 09900-06107 (Snap ring pliers)



I823H1140259-01

Clutch


- Remove the clutch component parts (1). Refer to "Clutch Removal in Section 5C (Page 5C-14)".



I823H1140260-01

Starter Torque Limiter


- Install the starter idle gear and starter torque limiter. Refer to "Starter Torque Limiter / Starter Clutch Removal and Installation in Section 1I (Page 1I-10)".



I823H1140261-01

Starter Motor

- Install the starter motor (1). Refer to "Starter Motor Removal and Installation in Section 1I (Page 1I-4)".



I815H1140117-01


Crankcase Breather (PCV) Cover

- Apply bond to the mating surface of the breather cover.

NOTE

- Make surfaces free from moisture, oil, dust and other foreign materials.
- Spread the sealant on surfaces thinly to form an even layer, and assemble the breather cover within a few minutes.
- Apply to distorted surfaces as it forms a comparatively thick film.

1207B : Sealant 99000-31140 (SUZUKI BOND No.1207B or equivalent)




I823H1140308-01

1. Crankcase breather (PCV) cover
1207B : Apply bond.

- Install the crankcase breather (PCV) cover (2).


Tightening torque

PCV cover bolt (a): 10 N·m (1.0 kgf-m, 7.0 lb-ft)



I815H1140118-01

- Install the reed valve (3).




I823H1140264-02

- Install the reed valve cover (4).

Tightening torque

PCV reed valve cover bolt (b): 10 N·m (1.0 kgf-m, 7.0 lb-ft)




I815H1140119-01

Engine Top Side

- Assemble the engine top side. Refer to "Engine Top Side Disassembly (Page 1D-27)".

Crankcase Breather (PCV) Hose

- Install the crankcase breather (PCV) hose (1).



I823H1140266-01

Crank Balancer Disassembly and Assembly

B815H21406037

Refer to "Engine Bottom Side Disassembly (Page 1D-63)".

Refer to "Engine Bottom Side Assembly (Page 1D-71)".

NOTE

It is unnecessary to remove the engine assembly from the frame when removing the crank balancer. Refer to "Oil Pan / Oil Strainer / Oil Pressure Regulator Removal and Installation in Section 1E (Page 1E-6)".

Disassembly

- 1) Remove the washers (1), bearings (2) and spacer (3) from the crank balancer.



I823H1140267-02

- 2) Remove the balancer gear (4) along with the dampers (5) from the crank balancer.
- 3) Remove the dampers (5) from the balancer gear (4).



I823H1140268-02

Assembly

Assemble the crank balancer in the reverse order of disassembly. Pay attention to the following points:

- Apply molybdenum oil solution to the dampers.

M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)




I823H1140269-03


- Install the dampers to the balancer gear as shown in the figure.
- Install the crank balancer to the balancer gear.

NOTE

- Align the parts "A" of the crank balancer with between the dampers.
- Align the engraved line "B" on the crank balancer with the punched mark "C" on the balancer gear.



I823H1140270-01




I823H1140271-01

1D-89 Engine Mechanical:

- Apply molybdenum oil solution to the bearings, spacers and washers.

M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)



I823H1140272-04

Crank Balancer Inspection

B815H21406038

Refer to "Crank Balancer Disassembly and Assembly (Page 1D-88)".

Damper

Inspect the damper for wear and damage, replace it if any defects are found.



I823H1140273-01

Bearing and Washer

Inspect the bearings and the washers for wear or damage. Replace the bearing or the washer if there is anything unusual.



I823H1140274-02

Balancer Shaft

Inspect the balancer shaft for wear or damage. Replace the balancer shaft if there is anything unusual.



I823H1140275-01

Conrod Removal and Installation

B815H21406039

Removal

- 1) Remove the crankshaft assembly from the crankcase. Refer to "Engine Bottom Side Disassembly (Page 1D-63)".
- 2) Loosen the conrod cap bolts using a 10 mm, 12 point socket wrench, then tap the conrod cap bolts lightly with plastic hammer to remove the conrod cap.
- 3) Remove the conrods and mark them to identify their respective cylinders.



I823H1140276-02


- 4) Remove the bearings (1).

NOTE

- Do not remove the bearings (1) unless absolutely necessary.
- Make a note of where the bearings are removed from so that they can be reinstalled in their original positions.

CAUTION

When removing the bearings, be careful not to scratch the conrods and the bearings.




I718H1140269-01

Installation

- 1) When installing the conrod bearings, be sure to fix the stopper part "A" first, and then press the other side.

NOTE

Inspect and select the conrod crank pin bearing if necessary. Refer to "Conrod Crank Pin Bearing Inspection and Selection (Page 1D-92)".




I823H1140578-01

- 2) Apply molybdenum oil solution to the crank pin and bearing surface.

CAUTION


Be sure to clean the conrod big end.

M/O: Molybdenum oil (Molybdenum oil solution)



I718H1140273-01

- 3) When fitting the conrod cap, make sure that I.D. code "B" on each conrod faces intake side.



I823H1140277-01


- 4) Apply engine oil to the conrod cap bolts.
5) Tighten the conrod cap bolt by using a 10 mm, 12 point socket wrench in the following two steps.

Tightening torque

Conrod cap bolt: 21 N·m (2.1 kgf·m, 15.0 lb·ft) then turn in 1/4 (90°) turn



I823H1140278-01



I823H1140279-01

"a": 90°

- 6) Check that the conrod moves smoothly.
7) Install the crankshaft assembly to the crankcase. Refer to "Engine Bottom Side Assembly (Page 1D-71)".

Conrod and Crankshaft Inspection

B815H21406040

Refer to "Conrod Removal and Installation (Page 1D-89)".

Conrod Small End I.D.

Measure the conrod small end inside diameter using the small bore gauge.

If the conrod small end inside diameter exceeds the service limit, replace the conrod.


Special tool

TOOL (A): 09900-20602 (Dial gauge (1/1000 mm, 1 mm))

TOOL (B): 09900-22403 (Small bore gauge (18 – 35 mm))

Conrod small end I.D.

Service limit: 18.040 mm (0.7102 in)



I823H1140280-01

Conrod Big End Side Clearance


- 1) Check the conrod big end side clearance using the thickness gauge.

Special tool

TOOL (A): 09900-20803 (Thickness gauge)

Conrod big end side clearance

Service limit: 0.3 mm (0.012 in)



I823H1140281-01

- 2) If the clearance exceeds the limit, remove the conrod and measure the conrod big end width and crank pin width. Refer to "Conrod Removal and Installation (Page 1D-89)". If any of the measurements are out of specification, replace the conrod or crankshaft.

Special tool

TOOL (B): 09900-20205 (Micrometer (0 – 25 mm))


TOOL (C): 09900-20605 (Dial calipers (1/100 mm, 10 – 34 mm))

Conrod big end width

Standard: 20.95 – 21.00 mm (0.825 – 0.827 in)

Crank pin width

Standard: 21.10 – 21.15 mm (0.831 – 0.833 in)



I823H1140282-01

Crankshaft Runout

Support the crankshaft using V-blocks as shown, with the two end journals resting on the blocks. Set up the dial gauge as shown, and rotate the crankshaft slowly to read the runout. Replace the crankshaft if the runout exceeds the service limit.

Special tool


TOOL (A): 09900-20607 (Dial gauge (1/100 mm, 10 mm))

TOOL (B): 09900-20701 (Magnetic stand)

TOOL (C): 09900-21304 (V-block (100 mm))

Crankshaft runout

Service limit: 0.05 mm (0.002 in)



I823H1140283-02


Conrod Crank Pin Bearing Inspection and Selection

B815H21406041

Refer to "Conrod Removal and Installation (Page 1D-89)".

Inspection

- 1) Inspect the bearing surfaces for any signs of fusion, pitting, burn or flaws. If any, replace them with a specified set of bearings.




I718H1140285-01

- 2) Place the plastigauge axially along the crank pin, avoiding the oil hole, as shown in the figure.

Special tool

TOOL (A): 09900-22301 (Plastigauge (0.025 – 0.076 mm))



I718H1140286-01


- 3) Tighten the conrod cap bolts to the specified torque, in two stages.

NOTE

- When installing the conrod cap to the crank pin, make sure that I.D code "A" on the conrod faces towards the intake side.
- Never rotate the crankshaft or conrod when a piece of plastigauge is installed.

Tightening torque

Conrod cap bolt: 21 N·m (2.1 kgf-m, 15.0 lb-ft)
then turn in 1/4 (90°) turn



I823H1140284-01


- 4) Remove the conrod caps and measure the width of the compressed plastigauge using the envelope scale. This measurement should be taken at the widest part of the compressed plastigauge. If the oil clearance exceeds the service limit, select the specified bearings from the bearing selection table.

Conrod big end oil clearance

Standard: 0.032 – 0.056 mm (0.0013 – 0.0022 in)

Conrod big end oil clearance


Service limit: 0.080 mm (0.0031 in)



I718H1140289-01

Selection

- 1) Check the corresponding conrod I.D. code numbers ([1] or [2]) "A".




I718H1140290-01

Conrod I.D. specification

Code "A"	I.D. specification
1	41.000 – 41.008 mm (1.6142 – 1.6145 in)
2	41.008 – 41.016 mm (1.6145 – 1.6148 in)

- 2) Check the corresponding crank pin O.D. code numbers ([1], [2] or [3]) “B”.



I823H1140285-02


- 3) Measure the conrod crank pin O.D. with the special tool. If any of the measurements are out of specification, replace the crankshaft.

Crank pin O.D. specification

Code “B”	O.D. specification
1	37.992 – 38.000 mm (1.4957 – 1.4961 in)
2	37.984 – 37.992 mm (1.4954 – 1.4957 in)
3	37.976 – 37.984 mm (1.4951 – 1.4954 in)

Special tool

TOOL (A): 09900–20202 (Micrometer (1/100 mm, 25 – 50 mm))



I823H1140286-01

- 4) Select the specified bearings from the bearing selection table.

⚠ CAUTION

The bearings should be replaced as a set.


Bearing selection table

		Crank pin O.D. "B"			
		Code	1	2	3
Conrod I.D. "A"	1	Green	Black	Brown	
	2	Black	Brown	Yellow	

I718H1140293-01

Bearing thickness specification

Color “C” (Part No.)	Thickness
Green (12164-46E01-0A0)	1.480 – 1.484 mm (0.0583 – 0.0584 in)
Black (12164-46E01-0B0)	1.484 – 1.488 mm (0.0584 – 0.0586 in)
Brown (12164-46E01-0C0)	1.488 – 1.492 mm (0.0586 – 0.0587 in)
Yellow (12164-46E01-0D0)	1.492 – 1.496 mm (0.0587 – 0.0589 in)



I823H1140595-01

“C”: Color code

Crankshaft Journal Bearing Inspection and Selection


B815H21406042

Refer to "Engine Bottom Side Disassembly (Page 1D-63)".


Refer to "Engine Bottom Side Assembly (Page 1D-71)".

Inspection

- 1) Inspect each upper and lower crankcase bearing for any damage.



I823H1140287-01



I823H1140288-01


- 2) Set the crankshaft onto the upper crank case.
- 3) Install the plastigauge onto each crankshaft journal as shown in the figure.

Special tool

Tool (A): 09900-22301 (Plastigauge (0.025 – 0.076 mm))

NOTE

Do not place the plastigauge on the oil hole.



I823H1140289-01

- 4) Mate the lower crankcase with the upper crankcase.
- 5) Tighten the crankshaft journal bolts (M9) in ascending order of numbers assigned to these bolts. Tighten each bolt a little at a time to equalize the pressure in the following two steps.


NOTE

Do not rotate the crankshaft when a piece of plastigauge is installed.

Tightening torque

Crankshaft journal bolt (M9) (Initial): 18 N·m (1.8 kgf-m, 13.0 lb-ft)

Crankshaft journal bolt (M9) (Final): 32 N·m (3.2 kgf-m, 23.0 lb-ft)



I823H1140290-02


- 6) Remove the lower crankcase and measure the width of compressed plastigauge using the envelope scale. This measurement should be taken at the widest part of the compressed plastigauge. If the oil clearance exceeds the service limit, select the specified bearings from the bearing selection table.

Crankshaft journal oil clearance

Standard: 0.010 – 0.028 mm (0.0004 – 0.0011 in)

Crankshaft journal oil clearance


Service limit: 0.080 mm (0.0031 in)



I823H1140291-02

Selection

- 1) Check the corresponding crankcase journal I.D. codes “A” ([A] or [B]), which are stamped on the rear of the upper crankcase.




I823H1140292-02

Crankcase journal I.D. specification

Code “A”	I.D. specification
A	43.000 – 43.006 mm (1.6929 – 1.6931 in)
B	43.006 – 43.012 mm (1.6931 – 1.6934 in)
C	43.012 – 43.018 mm (1.6934 – 1.6936 in)

- 2) Check the corresponding crankshaft journal O.D. codes “B” ([A], [B] or [C]), which are stamped on the crankshaft.



I823H1140293-01


- 3) Measure the crankshaft O.D. with the special tool. If any of the measurements are out of specification, replace the crankshaft.

Crankshaft journal O.D. specification

Code “B”	O.D. specification
A	39.994 – 40.000 mm (1.5746 – 1.5748 in)
B	39.988 – 39.994 mm (1.5743 – 1.5746 in)
C	39.982 – 39.988 mm (1.5741 – 1.5743 in)

Special tool

TOOL (A): 09900–20202 (Micrometer (1/100 mm, 25 – 50 mm))



I823H1140294-01

- 4) Select the specified bearings from the bearing selection table.


Bearing selection table

		Crankshaft O.D. "B"			
		Code	A	B	C
Crankcase I.D. "A"	A	Green	Black	Brown	
	B	Black	Brown	Yellow	
	C	Brown	Yellow	Blue	

I823H1140299-01

Bearing thickness specification

Color "C" (Part No.)	Thickness
Green (12229-15H00-0A0)	1.492 – 1.495 mm (0.0587 – 0.0589 in)
Black (12229-15H00-0B0)	1.495 – 1.498 mm (0.0589 – 0.0590 in)
Brown (12229-15H00-0C0)	1.498 – 1.501 mm (0.0590 – 0.0591 in)
Yellow (12229-15H00-0D0)	1.501 – 1.504 mm (0.0591 – 0.0592 in)
Blue (12229-15H00-0E0)	1.504 – 1.507 mm (0.0592 – 0.0593 in)



I718H1140303-01

"C": Color code

Crankshaft Thrust Clearance Inspection and Selection

B815H21406043

Refer to "Engine Bottom Side Disassembly (Page 1D-63)".

Refer to "Engine Bottom Side Assembly (Page 1D-71)".

Inspection

- 1) With the crankshaft's right-side and left-side thrust bearings inserted into the upper crankcase.
- 2) Measure the thrust clearance "a" between the left-side thrust bearing and crankshaft using the thickness gauge. If the thrust clearance exceeds the standard range, adjust the thrust clearance.

NOTE


Pull the crankshaft to the left (generator side) so that there is no clearance on the right-side thrust bearing.

Special tool

TOOL (A): 09900-20803 (Thickness gauge)


Crankshaft thrust clearance "a"

Standard: 0.055 – 0.110 mm (0.0022 – 0.0043 in)



I823H1140295-02

1. Right-side thrust bearing	"A": Front side
2. Left-side thrust bearing	



I823H1140297-02

Selection


- 1) Remove the right-side thrust bearing and measure its thickness using the micrometer. If the thickness of the right-side thrust bearing is below standard, replace it with a new bearing and measure the thrust clearance again, as described in 1) and 2).

Special tool

Tool (A): 09900-20205 (Micrometer (0 – 25 mm))

Right-side thrust bearing thickness

Standard: 2.425 – 2.450 mm (0.0955 – 0.0965 in)




I649G1140343-02

- 2) If the right-side thrust bearing is within the standard range, reinsert the right-side thrust bearing and remove the left-side thrust bearing.
- 3) With the left-side thrust bearing removed, measure the clearance “a” using the thickness gauge as shown.

Special tool

Tool (B): 09900-20803 (Thickness gauge)



I823H1140298-02


- 4) Select a left-side thrust bearing from the selection table.

NOTE

Right-side thrust bearing has the same specification as the GREEN (12228-24F00-0D0) of left-side thrust bearing.

Left-side thrust bearing selection table

Clearance before inserting the left-side thrust bearing	Color “A” (Part No.)	Thrust bearing thickness	Thrust clearance
2.560 – 2.585 mm (0.1008 – 0.1018 in)	White (12228-24F00-0F0)	2.475 – 2.500 mm (0.0974 – 0.0984 in)	0.060 – 0.110 mm (0.0024 – 0.0043 in)
2.535 – 2.560 mm (0.0998 – 0.1008 in)	Yellow (12228-24F00-0E0)	2.450 – 2.475 mm (0.0965 – 0.0974 in)	
2.510 – 2.535 mm (0.0988 – 0.0998 in)	Green (12228-24F00-0D0)	2.425 – 2.450 mm (0.0955 – 0.0965 in)	
2.485 – 2.510 mm (0.0978 – 0.0988 in)	Blue (12228-24F00-0C0)	2.400 – 2.425 mm (0.0945 – 0.0955 in)	
2.460 – 2.485 mm (0.0969 – 0.0978 in)	Black (12228-24F00-0B0)	2.375 – 2.400 mm (0.0935 – 0.0945 in)	
2.430 – 2.460mm (0.0957 – 0.0969 in)	Red (12228-24F00-0A0)	2.350 – 2.375 mm (0.0925 – 0.0935 in)	0.055 – 0.110 mm (0.0022 – 0.0043 in)



I649G1140345-02

“A”: Color code

- 5) After selecting a left-side thrust bearing, install it and then measure the thrust clearance again.

Specifications

Service Data

B815H21407001

Valve + Guide

Unit: mm (in)

Item	Standard		Limit
Valve diam.	IN.	33 (1.30)	—
	EX.	27.5 (1.08)	—
Valve clearance (when cold)	IN.	0.08 – 0.18 (0.003 – 0.007)	—
	EX.	0.18 – 0.28 (0.007 – 0.011)	—
Valve guide to valve stem clearance	IN.	0.010 – 0.037 (0.0004 – 0.0015)	—
	EX.	0.030 – 0.057 (0.0012 – 0.0022)	—
Valve guide I.D.	IN. & EX.	5.000 – 5.012 (0.1969 – 0.1973)	—
Valve stem O.D.	IN.	4.975 – 4.990 (0.1959 – 0.1965)	—
	EX.	4.955 – 4.970 (0.1951 – 0.1957)	—
Valve stem deflection	IN. & EX.	—	0.25 (0.010)
Valve stem runout	IN. & EX.	—	0.05 (0.002)
Valve seat width	IN. & EX.	0.9 – 1.1 (0.035 – 0.043)	—
Valve head radial runout	IN. & EX.	—	0.03 (0.001)
Valve spring free length	IN. & EX.	—	42.3 (1.67)
Valve spring tension	IN. & EX.	Approx. 137 N (14.0 kgf, 30.8 lbs) at length 36.6 mm (1.44 in)	—

Camshaft + Cylinder Head

Unit: mm (in)

Item	Standard		Limit
Cam height	IN.	36.98 – 37.02 (1.456 – 1.457)	36.68 (1.444)
	EX.	36.58 – 36.62 (1.440 – 1.442)	36.28 (1.428)
Camshaft journal oil clearance	IN. & EX.	0.032 – 0.066 (0.0013 – 0.0026)	0.150 (0.0059)
Camshaft journal holder I.D.	IN. & EX.	24.012 – 24.025 (0.9454 – 0.9459)	—
Camshaft journal O.D.	IN. & EX.	23.959 – 23.980 (0.9433 – 0.9441)	—
Camshaft runout	—		0.10 (0.004)
Cam chain pin (at arrow “3”)	15th pin		—
Cylinder head distortion	—		0.20 (0.008)

1D-99 Engine Mechanical:**Cylinder + Piston + Piston Ring**

Unit: mm (in)

Item	Standard			Limit
Compression pressure	1 400 – 1 800 kPa (14 – 18 kgf/cm ² , 199 – 256 psi)			1 000 kPa (10 kgf/cm ² , 142 psi)
Compression pressure difference	—			200 kPa (2 kgf/cm ² , 28 psi)
Piston-to-cylinder clearance	0.035 – 0.045 (0.0014 – 0.0018)			0.120 (0.0047)
Cylinder bore	81.000 – 81.015 (3.1890 – 3.1896)			No nicks or Scratches
Piston diam.	80.960 – 80.975 (3.1874 – 3.1880) Measure 15 mm (0.6 in) from the skirt end.			80.880 (3.1842)
Cylinder distortion	—			0.20 (0.008)
Piston ring free end gap	1st	—	Approx. 6.5 (0.26)	5.2 (0.20)
	2nd	2T	Approx. 9.0 (0.35)	7.2 (0.28)
Piston ring end gap	1st	—	0.06 – 0.18 (0.002 – 0.007)	0.50 (0.020)
	2nd	2T		
Piston ring-to-groove clearance	1st	—		0.180 (0.0071)
	2nd	—		0.150 (0.0059)
Piston ring groove width	1st	0.83 – 0.85 (0.0327 – 0.0335)		—
		1.30 – 1.32 (0.0512 – 0.0520)		
	2nd	1.01 – 1.03 (0.0398 – 0.0406)		—
	Oil	2.01 – 2.03 (0.0791 – 0.0799)		—
Piston ring thickness	1st	0.76 – 0.81 (0.0299 – 0.0319)		—
		1.08 – 1.10 (0.0425 – 0.0433)		
	2nd	0.97 – 0.99 (0.0382 – 0.0390)		—
Piston pin bore	18.002 – 18.008 (0.7087 – 0.7090)			18.030 (0.7098)
Piston pin O.D.	17.996 – 18.000 (0.7085 – 0.7087)			17.980 (0.7079)

Conrod + Crankshaft

Unit: mm (in)

Item	Standard		Limit
Conrod small end I.D.	18.010 – 18.018 (0.7091 – 0.7094)		18.040 (0.7102)
Conrod big end side clearance	0.10 – 0.20 (0.004 – 0.008)		0.3 (0.012)
Conrod big end width	20.95 – 21.00 (0.825 – 0.827)		—
Crank pin width	21.10 – 21.15 (0.831 – 0.833)		—
Conrod big end oil clearance	0.032 – 0.056 (0.0013 – 0.0022)		0.080 (0.0031)
Crank pin O.D.	37.976 – 38.000 (1.4951 – 1.4960)		—
Crankshaft journal oil clearance	0.010 – 0.028 (0.0004 – 0.0011)		0.080 (0.0031)
Crankshaft journal O.D.	39.982 – 40.000 (1.5741 – 1.5748)		—
Crankshaft thrust bearing thickness	Right side	2.425 – 2.450 (0.0955 – 0.0965)	—
	Left side	2.350 – 2.500 (0.0925 – 0.0984)	—
Crankshaft thrust clearance	0.055 – 0.110 (0.0022 – 0.0043)		—
Crankshaft runout	—		0.05 (0.002)

Throttle Body

Item	Specification
Bore size	44 mm (1.73 in)
I.D. No.	15H1 (For E-33), 15H0 (For the others)
Idle r/min	1 150 ± 100 r/min
Throttle cable play	2.0 – 4.0 mm (0.08 – 0.16 in)

Tightening Torque Specifications

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
STP sensor mounting screw	3.5	0.35	2.5	☞ (Page 1D-14)
ISC valve mounting screw	2	0.2	1.5	☞ (Page 1D-14)
TP sensor mounting screw	3.5	0.35	2.5	☞ (Page 1D-14)
Fuel delivery pipe mounting screw	3.5	0.35	2.5	☞ (Page 1D-15)
Engine mounting thrust adjuster	10	1.0	7.0	☞ (Page 1D-25)
Engine mounting thrust adjuster lock-nut	45	4.5	32.5	☞ (Page 1D-25)
Cylinder head bolt (M10) (Initial)	25	2.5	18.0	☞ (Page 1D-34)
Cylinder head bolt (M10) (Final)	52	5.2	37.5	☞ (Page 1D-34)
Cylinder head bolt (M6)	10	1.0	7.0	☞ (Page 1D-34)
Cylinder nut (M6)	10	1.0	7.0	☞ (Page 1D-34)
Cylinder head side bolt	14	1.4	10.0	☞ (Page 1D-34)
Oil hose union bolt	18	1.8	13.0	☞ (Page 1D-35)
Camshaft journal holder bolt	10	1.0	7.0	☞ (Page 1D-37) / ☞ (Page 1D-43)
Oil pipe bolt (Camshaft housing)	10	1.0	7.0	☞ (Page 1D-38)
Cam chain guide No. 2 bolt	10	1.0	7.0	☞ (Page 1D-38)
Cam chain tension adjuster mounting bolt	10	1.0	7.0	☞ (Page 1D-39)
Cam chain tension adjuster service cap	23	2.3	16.5	☞ (Page 1D-39) / ☞ (Page 1D-49)
Valve timing inspection cap	23	2.3	16.5	☞ (Page 1D-41)
Starter clutch cover cap	10	1.0	7.0	☞ (Page 1D-41)
Head cover bolt	14	1.4	10.0	☞ (Page 1D-42)
Oil gallery plug (Cylinder head)	10	1.0	7.0	☞ (Page 1D-49)
Water bypass union	14	1.4	10.0	☞ (Page 1D-49)
Thermostat cover bolt	10	1.0	7.0	☞ (Page 1D-50)
Engine coolant temperature sensor	18	1.8	13.0	☞ (Page 1D-50)
Water jacket plug	11	1.1	8.0	☞ (Page 1D-58)
Water inlet connector bolt	10	1.0	7.0	☞ (Page 1D-58)
Oil gallery plug (M6) and (M8)	10	1.0	7.0	☞ (Page 1D-72)
Oil gallery plug (M10)	18	1.8	13.0	☞ (Page 1D-72)
Oil gallery plug (M14)	23	2.3	16.5	☞ (Page 1D-72)
Oil gallery plug (M16)	35	3.5	25.5	☞ (Page 1D-72)
Piston cooling oil jet bolt	10	1.0	7.0	☞ (Page 1D-73)
Oil jet (For generator)	5	0.5	3.5	☞ (Page 1D-73)
Crankshaft journal bolt (M9) (Initial)	18	1.8	13.0	☞ (Page 1D-76) / ☞ (Page 1D-94)
Crankshaft journal bolt (M9) (Final)	32	3.2	23.0	☞ (Page 1D-76) / ☞ (Page 1D-94)
Crankcase bolt (M6)	11	1.1	8.0	☞ (Page 1D-76)
Crankcase bolt (M8)	26	2.6	19.0	☞ (Page 1D-76)
Crankcase bolt (M10)	50	5.0	36.0	☞ (Page 1D-76)
Balancer shaft arm bolt	10	1.0	7.0	☞ (Page 1D-78)
Balancer shaft mounting bolt	10	1.0	7.0	☞ (Page 1D-78)
Balancer cover bolt	10	1.0	7.0	☞ (Page 1D-79)
Breather pipe bolt	10	1.0	7.0	☞ (Page 1D-79)
Oil strainer bolt	10	1.0	7.0	☞ (Page 1D-79)
Oil pan bolt	10	1.0	7.0	☞ (Page 1D-80)
Oil pressure switch	14	1.4	10.0	☞ (Page 1D-80)
Oil pipe bolt (M6)	10	1.0	7.0	☞ (Page 1D-81)
Oil pipe union bolt (M14)	24	2.4	17.5	☞ (Page 1D-81)
Gearshift cam stopper bolt	10	1.0	7.0	☞ (Page 1D-82)
Gearshift cam stopper plate bolt	13	1.3	9.5	☞ (Page 1D-82)
Gearshift cover bolt	10	1.0	7.0	☞ (Page 1D-83)
Water pump mounting bolt	10	1.0	7.0	☞ (Page 1D-83)
Cam chain tensioner bolt	23	2.3	16.5	☞ (Page 1D-84)
GP switch mounting bolt	6.5	0.65	4.7	☞ (Page 1D-85)

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
GP switch lead wire clamp bolt	6.5	0.65	4.7	☞ (Page 1D-85)
Oil pump mounting bolt	10	1.0	7.0	☞ (Page 1D-85)
PCV cover bolt	10	1.0	7.0	☞ (Page 1D-87)
PCV reed valve cover bolt	10	1.0	7.0	☞ (Page 1D-87)
Conrod cap bolt	21 N·m (2.1 kgf·m, 15.0 lb·ft) then turn in 1/4 (90°) turn			☞ (Page 1D-90) / ☞ (Page 1D-92)

NOTE

The specified tightening torque is also described in the following.

“Throttle Body Components (Page 1D-8)”

“Throttle Body Construction (Page 1D-9)”

“Engine Assembly Installation (Page 1D-24)”

“Engine Bottom Side Assembly (Page 1D-71)”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Tightening Torque List in Section 0C (Page 0C-9)”.

Special Tools and Equipment

Recommended Service Material

B815H21408001

Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI SUPER GREASE A or equivalent	P/No.: 99000–25010	☞ (Page 1D-14) / ☞ (Page 1D-14) / ☞ (Page 1D-79) / ☞ (Page 1D-80) / ☞ (Page 1D-81) / ☞ (Page 1D-83) / ☞ (Page 1D-83) / ☞ (Page 1D-85)
Molybdenum oil	MOLYBDENUM OIL SOLUTION	—	☞ (Page 1D-31) / ☞ (Page 1D-35) / ☞ (Page 1D-51) / ☞ (Page 1D-77) / ☞ (Page 1D-88) / ☞ (Page 1D-89) / ☞ (Page 1D-90)
Sealant	SUZUKI BOND No.1207B or equivalent	P/No.: 99000–31140	☞ (Page 1D-41) / ☞ (Page 1D-49) / ☞ (Page 1D-74) / ☞ (Page 1D-80) / ☞ (Page 1D-85) / ☞ (Page 1D-87)
Thread lock cement	THREAD LOCK CEMENT SUPER 1303 or equivalent	P/No.: 99000–32030	☞ (Page 1D-82)
	THREAD LOCK CEMENT SUPER 1322 or equivalent	P/No.: 99000–32110	☞ (Page 1D-73) / ☞ (Page 1D-78) / ☞ (Page 1D-79) / ☞ (Page 1D-79) / ☞ (Page 1D-79) / ☞ (Page 1D-81) / ☞ (Page 1D-82)

NOTE













Required service material is also described in the following.

“Throttle Body Components (Page 1D-8)”















“Engine Bottom Side Assembly (Page 1D-71)”





Special Tool

B815H21408002

09900-06107 Snap ring pliers ☞ (Page 1D-86)		09900-20102 Vernier calipers (1/20 mm, 200 mm) ☞ (Page 1D-54) / ☞ (Page 1D-62)	
09900-20202 Micrometer (1/100 mm, 25 – 50 mm) ☞ (Page 1D-42) / ☞ (Page 1D-93) / ☞ (Page 1D-95)		09900-20204 Micrometer (75 – 100 mm) ☞ (Page 1D-61)	
09900-20205 Micrometer (0 – 25 mm) ☞ (Page 1D-44) / ☞ (Page 1D-54) / ☞ (Page 1D-61) / ☞ (Page 1D-62) / ☞ (Page 1D-91) / ☞ (Page 1D-97)		09900-20530 Cylinder gauge set ☞ (Page 1D-59)	
09900-20602 Dial gauge (1/1000 mm, 1 mm) ☞ (Page 1D-44) / ☞ (Page 1D-62) / ☞ (Page 1D-91)		09900-20605 Dial calipers (1/100 mm, 10 – 34 mm) ☞ (Page 1D-91)	
09900-20607 Dial gauge (1/100 mm, 10 mm) ☞ (Page 1D-42) / ☞ (Page 1D-52) / ☞ (Page 1D-53) / ☞ (Page 1D-53) / ☞ (Page 1D-91)		09900-20701 Magnetic stand ☞ (Page 1D-42) / ☞ (Page 1D-52) / ☞ (Page 1D-53) / ☞ (Page 1D-53) / ☞ (Page 1D-91)	
09900-20803 Thickness gauge ☞ (Page 1D-52) / ☞ (Page 1D-59) / ☞ (Page 1D-61) / ☞ (Page 1D-62) / ☞ (Page 1D-91) / ☞ (Page 1D-96) / ☞ (Page 1D-97)		09900-21304 V-block (100 mm) ☞ (Page 1D-42) / ☞ (Page 1D-52) / ☞ (Page 1D-53) / ☞ (Page 1D-91)	

1D-103 Engine Mechanical:

09900–22301 Plastigauge (0.025 – 0.076 mm) ☞ (Page 1D-43) / ☞ (Page 1D-92) / ☞ (Page 1D-94)		09900–22302 Plastigauge (0.051 – 0.152 mm) ☞ (Page 1D-43)	
09900–22403 Small bore gauge (18 – 35 mm) ☞ (Page 1D-44) / ☞ (Page 1D-62) / ☞ (Page 1D-91)		09915–40610 Oil filter wrench ☞ (Page 1D-66) / ☞ (Page 1D-81)	
09915–63311 Compression gauge attachment ☞ (Page 1D-3)		09915–64512 Compression gauge ☞ (Page 1D-3)	
09916–10911 Valve lapper set ☞ (Page 1D-55)		09916–14510 Valve spring compressor ☞ (Page 1D-47) / ☞ (Page 1D-51)	
09916–14522 Valve spring compressor attachment ☞ (Page 1D-47) / ☞ (Page 1D-51)		09916–34542 Reamer handle ☞ (Page 1D-56) / ☞ (Page 1D-57)	
09916–34570 Valve guide reamer (5.0 mm) ☞ (Page 1D-57)		09916–34580 Valve guide reamer (10.8 mm) ☞ (Page 1D-56)	
09916–44310 Valve guide remover/ installer ☞ (Page 1D-56) / ☞ (Page 1D-56)		09916–53350 Attachment ☞ (Page 1D-56)	
09916–74521 Holder body ☞ (Page 1D-32)		09916–74550 Band (Piston diam.: 73 – 85 mm) ☞ (Page 1D-32)	

<p>09916–84511 Valve adjuster driver ☞ (Page 1D-47) / ☞ (Page 1D-51)</p>	 <p>09919–28620 Sleeve protector ☞ (Page 1D-47) / ☞ (Page 1D-51)</p> 
<p>09930–11950 Torx wrench ☞ (Page 1D-13) / ☞ (Page 1D-14) / ☞ (Page 1D-14)</p> 	<p>09940–14990 Engine mounting thrust adjuster socket wrench ☞ (Page 1D-23) / ☞ (Page 1D-24) / ☞ (Page 1D-25)</p> 

Engine Lubrication System

Precautions

Precautions for Engine Oil


B815H21500001

Refer to “Fuel and Oil Recommendation in Section 0A (Page 0A-4)”.

Schematic and Routing Diagram


Engine Lubrication System Chart Diagram

B815H21502001




Engine Lubrication Circuit Diagram

B815H21502002



1. Main gallery

I823H1150042-01



1

1. Main gallery

Diagnostic Information and Procedures

Engine Lubrication Symptom Diagnosis

B815H21504001

Condition	Possible cause	Correction / Reference Item
Engine overheats	Insufficient amount of engine oil.	Check level and add.
	Defective oil pump.	Replace.
	Clogged oil circuit.	Clean.
	Clogged oil cooler.	Clean or replace.
	Incorrect engine oil.	Change.
Exhaust smoke is dirty or thick	Excessive amount of engine oil.	Check level and drain.
Engine lacks power	Excessive amount of engine oil.	Check level and drain.

Oil Pressure Check

B815H21504002


Check the engine oil pressure periodically. This will give a good indication of the condition of the moving parts.

NOTE

Before checking the oil pressure, check the following.

- Oil level (Refer to “Engine Oil and Filter Replacement in Section 0B (Page 0B-10)”.)
- Oil leaks (If leak is found, repair it.)
- Oil quality (If oil is discolored or deteriorated, replace it.)

- 1) Remove the right side cowl. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.
- 2) Start the engine and check if the oil pressure indicator light is turned on. If the light stays on, check the oil pressure indicator light circuit. If the circuit is OK, check the oil pressure in the following manner.
- 3) Remove the main oil gallery plug (1).




I815H1150001-01

- 4) Install the oil pressure gauge and attachment to the main oil gallery.

Special tool

- TOOL (A):** 09915-74521 (Oil pressure gauge hose)
TOOL (B): 09915-74540 (Oil pressure gauge attachment)
TOOL (C): 09915-77331 (Meter (for high pressure))



I815H1150002-01

- 5) Warm up the engine as follows:
 Summer: 10 min. at 2 000 r/min
 Winter: 20 min. at 2 000 r/min
- 6) After warming up, increase the engine speed to 3 000 r/min (Observe the tachometer), and read the oil pressure gauge.
 If the oil pressure is lower or higher than the specification, the following causes may be considered.

Oil pressure specification

200 – 500 kPa (2.0 – 5.0 kgf/cm², 28.4 – 71.1 psi)
 at 3 000 r/min, Oil temp. at 60 °C (140 °F)

High oil pressure	Low oil pressure
<ul style="list-style-type: none"> • Engine oil viscosity is too high • Clogged oil passage • Combination of the above items 	<ul style="list-style-type: none"> • Clogged oil filter • Oil leakage from the oil passage • Damaged O-ring • Defective oil pump • Combination of the above items


- 7) Stop the engine and remove the oil pressure gauge and attachment.
- 8) Reinstall the main oil gallery plug (1) and tighten it to the specified torque.

⚠ CAUTION

Use a new gasket to oil leakage.

Tightening torque

Main oil gallery plug (M16) (a): 35 N·m (3.5 kgf-m, 25.5 lb-ft)



I815H1150003-01

- 9) Check the engine oil level. Refer to “Engine Oil and Filter Replacement in Section 0B (Page 0B-10)”.
- 10) Install the removed parts.

Repair Instructions

Engine Oil and Filter Replacement

B815H21506001

Refer to “Engine Oil and Filter Replacement in Section 0B (Page 0B-10)”.

Engine Oil Level Inspection

B815H21506002


Refer to “Engine Oil and Filter Replacement in Section 0B (Page 0B-10)”.

Oil Pan / Oil Strainer / Oil Pressure Regulator Removal and Installation

B815H21506003


Removal

- 1) Drain engine oil. Refer to “Engine Oil and Filter Replacement in Section 0B (Page 0B-10)”.
- 2) Remove the side cowlings. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.
- 3) Remove the exhaust pipe assembly. Refer to “Exhaust Pipe / Muffler Removal and Installation in Section 1K (Page 1K-3)”.
- 4) Remove the left oil cooler hose bolts (1).
- 5) Remove the oil pan (2) and gasket. Refer to “Engine Bottom Side Disassembly in Section 1D (Page 1D-63)”.




I815H1150004-02

- 6) Remove the oil pressure regulator (3), breather pipe (4) and oil strainer (5).



I815H1150005-01

- 7) Remove the O-ring (6).



I815H1150006-01

1E-7 Engine Lubrication System:

Installation

Installation is in the reverse order of removal. Pay attention to the following points:

- Apply grease to the O-rings.

CAUTION

Use the new O-rings to prevent oil leakage.

 : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)



I823H1150009-02




I815H1150007-01

- Tighten the oil pan bolts diagonally.

CAUTION

- Use the new oil pan gasket to prevent oil leakage.
- Fit the new gasket washer to the oil pan bolt (1) to prevent oil leakage.



I815H1150008-01

- Connect the left oil cooler hose to the oil pan. Refer to "Oil Cooler / Oil Cooler Hose Removal and Installation (Page 1E-8)".
- Pour engine oil. Refer to "Engine Oil and Filter Replacement in Section 0B (Page 0B-10)".
- Install removed parts.

Oil Pressure Regulator / Oil Strainer Inspection

B815H21506004

Refer to "Oil Pan / Oil Strainer / Oil Pressure Regulator Removal and Installation (Page 1E-6)".

Oil pressure regulator

Inspect the operation of the oil pressure regulator by pushing on the piston with a proper bar.

If the piston does not operate, replace the oil pressure regulator with a new one.



I718H1150033-01

Oil Strainer

Clean the oil strainer if necessary.

Inspect the oil strainer body for damage. If necessary, replace it with a new one.



I823H1150012-01


Oil Cooler / Oil Cooler Hose Inspection and Cleaning

B815H21506005

Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.

Oil Cooler Hose Inspection


Inspect the oil cooler hoses for any damage and oil leakage. If any defects are found, replace the oil cooler hose with new ones.



I815H1150009-01

Oil Cooler Inspection

Inspect the oil cooler for oil leakage. If any defects are found, replace the oil cooler with a new one. If the fins are bent or dented, repair them by carefully straightening them with the blade of a small screwdriver.




I815H1150010-01

Oil Cooler Cleaning

Blow out any foreign matter that is stuck in the oil cooler fins using compressed air.

⚠ CAUTION

- Make sure not to bend the fins when using compressed air.
- If compressed air is applied from the front side, dirt will be forced into the pores of oil cooler.




I815H1150011-01

Oil Cooler / Oil Cooler Hose Removal and Installation


B815H21506006

Removal

- 1) Remove the side cowlings. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.
- 2) Drain engine oil. Refer to “Engine Oil and Filter Replacement in Section 0B (Page 0B-10)”.
- 3) Remove the oil hoses (1) and (2).




I815H1150012-01



I815H1150013-01

1E-9 Engine Lubrication System:

- 4) Remove the oil cooler guard (3).
- 5) Remove the oil cooler (4).



I815H1150014-01


Installation

Install the oil cooler and oil cooler hoses in the reverse order of removal. Pay attention to the following points:


- Apply engine oil to the O-rings.

CAUTION

Replace the O-rings with new ones to prevent oil leakage.



I823H1150030-01



I815H1150015-01

- Tighten the oil cooler hose bolts to the specified torque.

Tightening torque

Oil cooler hose bolt: 10 N·m (1.0 kgf-m, 7.0 lb-ft)

- Pour engine oil. Refer to "Engine Oil and Filter Replacement in Section 0B (Page 0B-10)".
- Install the removed parts.


Oil Pressure Switch Removal and Installation

B815H21506007

Refer to "Electrical Components Location in Section 0A (Page 0A-8)".

Removal

- 1) Turn the ignition switch OFF.
- 2) Remove the right side cowling. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 3) Drain engine oil. Refer to "Engine Oil and Filter Replacement in Section 0B (Page 0B-10)".
- 4) Disconnect the oil pressure switch lead wire (1).
- 5) Remove the oil pressure switch (2).



I815H1150016-01



Installation

- 1) Install the oil pressure switch (1), apply a bond lightly to its thread and tighten it to the specified torque.

■1207B : Sealant 99000-31140 (SUZUKI Bond 1207B or equivalent)

Tightening torque

Oil pressure switch (a): 14 N·m (1.4 kgf-m, 10.0 lb-ft)




I815H1150017-01

- 2) Connect the oil pressure switch lead wire securely. Refer to "Wiring Harness Routing Diagram in Section 9A (Page 9A-5)".

Tightening torque

Oil pressure switch lead wire bolt (b): 1.5 N·m (0.15 kgf-m, 1.1 lb-ft)



I815H1150018-01

- 3) Pour engine oil. Refer to "Engine Oil and Filter Replacement in Section 0B (Page 0B-10)".
- 4) Install the removed parts.

Oil Pressure Switch Inspection

B815H21506008

Refer to "Oil Pressure Indicator Inspection in Section 9C (Page 9C-7)".


Oil Jet / Oil Gallery Jet Removal and Installation

B815H21506009

Oil Jet (For Pistons)

Removal

- 1) Remove the engine assembly. Refer to "Engine Assembly Removal in Section 1D (Page 1D-19)".
- 2) Remove the Cylinder. Refer to "Engine Top Side Disassembly in Section 1D (Page 1D-27)".
- 3) Remove the piston cooling oil jets (1).



I815H1150019-01


Installation

Installation is in the reverse order of removal. Pay attention to the following points:

- Fit the new O-ring (1) to each piston cooling oil jet and apply engine oil to them.

⚠ CAUTION

Use the new O-rings to prevent oil pressure leakage.




I823H1150033-01

- Apply a small quantity of thread lock to the bolts and tighten them to the specified torque.

1322 : Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER 1322 or equivalent)

Tightening torque

Piston cooling oil jet bolt (a): 10 N·m (1.0 kgf-m, 7.0 lb-ft)




I815H1150020-01

1E-11 Engine Lubrication System:

Oil Jet (For Transmission)


Removal

- 1) Remove the engine assembly. Refer to "Engine Assembly Removal in Section 1D (Page 1D-19)".
- 2) Separate the crankcases, upper and lower. Refer to "Engine Bottom Side Disassembly in Section 1D (Page 1D-63)".
- 3) Remove the oil jet (1) (for transmission oil spray) from the upper crankcase.



I815H1150021-01

- 4) Remove the oil jet (2) (for transmission) from the lower crankcase.



I815H1150022-01


Installation

Installation is in the reverse order of removal.

Oil Jet (For Generator)

Removal

- 1) Remove the generator cover. Refer to "Generator Removal and Installation in Section 1J (Page 1J-6)".
- 2) Remove the oil jet (1) (for generator).



I815H1150023-01


Installation

Installation is in the reverse order of removal. Pay attention to the following point:

- Tighten the oil jet (for generator) to the specified torque.

Tightening torque

Oil jet (For generator) (a): 5 N·m (0.5 kgf-m, 3.5 lb-ft)




I815H1150024-01

Oil Gallery Jet

Removal

- 1) Remove the oil filter. Refer to "Engine Oil and Filter Replacement in Section 0B (Page 0B-10)".
- 2) Remove the oil gallery jet (1) from the lower crankcase.



I815H1150025-01

Installation

Installation is in the reverse order of removal. Pay attention to the following point:

- Replace the oil filter with a new one. Refer to "Engine Oil and Filter Replacement in Section 0B (Page 0B-10)".


Oil Jet / Oil Gallery Jet Inspection

B815H21506010

Refer to “Oil Jet / Oil Gallery Jet Removal and Installation (Page 1E-10)”.

Oil Jet

Make sure that the oil jets are not clogged. If they are clogged, clean their oil passage using a wire of the proper size and compressed air.



I823H1150040-01

1.	Piston cooling jet
2.	Oil jet (For transmission oil spray)
3.	Oil jet (For transmission)
4.	Oil jet (For generator)

Oil Gallery Jet

Inspect the oil gallery jet for clogging. Clean the oil gallery if necessary.



I823H1150041-01

Oil Pump Removal and Installation

B815H21506011

NOTE


Be careful not to drop any parts into the crankcase.

Removal

- 1) Remove the right side cowling. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.
- 2) Drain engine oil. Refer to “Engine Oil and Filter Replacement in Section 0B (Page 0B-10)”.
- 3) Remove the clutch assembly. Refer to “Clutch Removal in Section 5C (Page 5C-14)”.
- 4) Remove the snap ring (1) and oil pump driven gear (2).


Special tool

TOOL : 09900-06107 (Snap ring pliers)



I815H1150026-02

- 5) Remove the pin (3) and washer (4).
- 6) Remove the oil pump (5).



I815H1150027-01

1E-13 Engine Lubrication System:

Installation

Installation is in reverse order of removal. Pay attention to the following points:

- Apply grease to the O-ring.

CAUTION


Use a new O-ring to prevent oil leakage.

 : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)

- Install the oil pump.

NOTE

Set the oil pump shaft end "A" to the water pump shaft.



I815H1150028-01

- Tighten the oil pump mounting bolts (1) to the specified torque.


Tightening torque

Oil pump mounting bolt (a): 10 N·m (1.0 kgf-m, 7.0 lb-ft)

- Install the washer (2) and pin (3).

NOTE

Be careful not to drop any parts into the crankcase.



I815H1150029-01


- Install the oil pump driven gear (4) and snap ring (5).

CAUTION

Never reuse a snap ring.

Special tool

 : 09900-06107 (Snap ring pliers)



I815H1150030-02

- Install the clutch assembly. Refer to "Clutch Installation in Section 5C (Page 5C-17)".

Oil Pump Inspection

B815H21506012

Inspect the oil pump in the following procedures:

- 1) Remove the oil pump. Refer to "Oil Pump Removal and Installation (Page 1E-12)".
- 2) Rotate the oil pump by hand and check that it moves smoothly. If it does not move smoothly, replace the oil pump assembly.

CAUTION

Do not attempt to disassemble the oil pump. The oil pump is available only as an assembly.



I823H1150022-02

- 3) Install the oil pump. Refer to "Oil Pump Removal and Installation (Page 1E-12)".

Specifications

Service Data

B815H21507001

Oil Pump

Item	Standard	Limit
Oil pressure (at 60 °C, 140 °F)	200 – 500 kPa (2.0 – 5.0 kgf/cm ² , 28.4 – 71.1 psi) at 3 000 r/min	—

Oil

Item	Specification	Note
Engine oil type	SAE 10W-40, API SF/SG or SH/SJ with JASO MA	
Engine oil capacity	Change	3 100 ml (3.3/2.7 US/lmp qt)
	Filter change	3 300 ml (3.5/2.9 US/lmp qt)
	Overhaul	4 000 ml (4.2/3.5 US/lmp qt)

Tightening Torque Specifications

B815H21507002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Main oil gallery plug (M16)	35	3.5	25.5	☞ (Page 1E-6)
Oil cooler hose bolt	10	1.0	7.0	☞ (Page 1E-9)
Oil pressure switch	14	1.4	10.0	☞ (Page 1E-9)
Oil pressure switch lead wire bolt	1.5	0.15	1.1	☞ (Page 1E-10)
Piston cooling oil jet bolt	10	1.0	7.0	☞ (Page 1E-10)
Oil jet (For generator)	5	0.5	3.5	☞ (Page 1E-11)
Oil pump mounting bolt	10	1.0	7.0	☞ (Page 1E-13)

Reference:

For the tightening torque of fastener not specified in this section, refer to “Tightening Torque List in Section 0C (Page 0C-9)”.

Special Tools and Equipment





Recommended Service Material

B815H21508001

Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI SUPER GREASE A or equivalent	P/No.: 99000-25010	☞ (Page 1E-7) / ☞ (Page 1E-13)
Sealant	SUZUKI Bond 1207B or equivalent	P/No.: 99000-31140	☞ (Page 1E-9)
Thread lock cement	THREAD LOCK CEMENT SUPER 1322 or equivalent	P/No.: 99000-32110	☞ (Page 1E-10)

Special Tool

B815H21508002

09900-06107 Snap ring pliers ☞ (Page 1E-12) / ☞ (Page 1E-13)		09915-74521 Oil pressure gauge hose ☞ (Page 1E-5)	
09915-74540 Oil pressure gauge attachment ☞ (Page 1E-5)		09915-77331 Meter (for high pressure) ☞ (Page 1E-5)	

Engine Cooling System

Precautions

Precautions for Engine Cooling System

B815H21600001

⚠ WARNING

- You can be injured by boiling fluid or steam if you open the radiator cap when the engine is hot. After the engine cools, wrap a thick cloth around cap and carefully remove the cap by turning it a quarter turn to allow pressure to escape and then turn the cap all the way off.
- The engine must be cool before servicing the cooling system.
- Coolant is harmful:
 - If it comes in contact with skin or eyes, flush with water.
 - If swallowed accidentally, induce vomiting and call physician immediately.
 - Keep it away from children.

Precautions for Engine Coolant

B815H21600002

Refer to "Engine Coolant Recommendation in Section 0A (Page 0A-5)".

General Description

Engine Coolant Description

B815H21601001

⚠ CAUTION


- Use a high quality ethylene glycol base anti-freeze, mixed with distilled water. Do not mix an alcohol base anti-freeze and different brands of anti-freeze.
- Do not put in more than 60% anti-freeze or less than 50%. (Refer to Fig. 1 and 2.)

At the time of manufacture, the cooling system is filled with a 50:50 mixture of distilled water and ethylene glycol anti-freeze. This 50:50 mixture will provide the optimum corrosion protection and excellent heat protection, and will protect the cooling system from freezing at temperatures above -31°C (-24°F). If the vehicle is to be exposed to temperatures below -31°C (-24°F), this mixing ratio should be increased up to 55% or 60% according to the figure.

Anti-freeze Proportioning Chart


Anti-freeze density	Freezing point
50%	-31°C (-24°F)
55%	-40°C (-40°F)
60%	-55°C (-67°F)

Fig.1: Engine coolant density-freezing point curve



I310G1160001-01

Fig.2: Engine coolant density-boiling point curve




I310G1160002-01

Schematic and Routing Diagram

Cooling Circuit Diagram


B815H21602001



I823H1160001-01

Water Hose Routing Diagram

B815H21602002



I815H1160030-07

1. Air bleeder hole	"J": Green marking
▣ "A": Clamp ends should face backward.	▣ "K": Engine coolant reservoir cushion rubber : Clean the adhesive surface before adhering the cushion rubber.
▣ "B": Clamp ends should face forward.	"a": 90°
▣ "C": Clamp ends should face downward.	"b": Keep a clearance.
▣ "D": Clamp screw head should face outside.	"c": Approx. 20 mm (0.8 in)
▣ "E": Clamp screw head should face backward.	"d": Approx. 10 mm (0.4 in)
"F": Yellow marking	⚙ (a) : 6 N·m (0.6 kgf-m, 4.5 lb-ft)
"G": White marking	⚙ (b) : 10 N·m (1.0 kgf-m, 7.0 lb-ft)
▣ "H": Color paint marking position : Aling the marking "H" with rib "I" of pipe.	⚙ (c) : 1.5 N·m (0.15 kgf-m, 1.0 lb-ft)
"I": Rib of pipe	

Diagnostic Information and Procedures

Engine Cooling Symptom Diagnosis

B815H21604001

Condition	Possible cause	Correction / Reference Item
Engine overheats	Not enough engine coolant.	Add engine coolant.
	Radiator core clogged with dirt or scale.	Clean.
	Faulty cooling fan.	Repair or replace.
	Defective cooling fan relay, or open-or-short circuited.	Repair or replace.
	Clogged water passage.	Clean.
	Air trapped in the cooling circuit.	Bleed air.
	Defective water pump.	Replace.
	Use of incorrect engine coolant.	Replace.
	Defective thermostat.	Replace.
	Defective ECT sensor.	Replace.
	Defective ECM.	Replace.
	Damaged ISC valve.	Replace.
	ISC bad learning.	Reset learned value.
Engine over cools	Defective cooling fan relay, or open-or-short circuited.	Repair or replace.
	Extremely cold weather.	Put on radiator cover.
	Defective thermostat.	Replace.
	Defective ECT sensor.	Replace.
	Defective ECM.	Replace.

Repair Instructions

Cooling Circuit Inspection

B815H21606001

⚠ WARNING


- Do not open the radiator cap when the engine is hot, as you may be injured by escaping hot liquid or vapor.
- When removing the radiator cap tester, put a rag on the filler to prevent the engine coolant from spraying out.

Inspect the cooling circuit in the following procedures:


- 1) Remove the right side cowling. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Remove the radiator cap (1) and connect the radiator tester (2) to the filler.
- 3) Pressurize the cooling system with 110 kPa (1.1 kgf/cm, 15.6 psi) of pressure, and then check if it holds the pressure for 10 seconds.

⚠ CAUTION

Do not exceed the radiator cap release pressure, or the radiator cap and subsequently the radiator, can be damaged.



I815H1160001-01



I815H1160002-01


- 4) After finishing the cooling circuit inspection, reinstall the removed parts.

Radiator Cap Inspection

B815H21606002

Inspect the radiator cap in the following procedures:

- 1) Remove the radiator cap. Refer to "Cooling Circuit Inspection (Page 1F-4)".
- 2) Attach the radiator cap (1) to the radiator tester (2) as shown.



I718H1160033-01

- 3) Slowly apply pressure to the radiator cap. If the radiator cap does not hold the pressure for at least 10 seconds, replace it with a new one.

Radiator cap release pressure

93 – 123 kPa (0.93 – 1.23 kgf/cm², 13.2 – 17.5 psi)

- 4) After finishing the radiator cap inspection, reinstall the removed parts.

Radiator Inspection and Cleaning

B815H21606003

Radiator Hose

Refer to "Cooling System Inspection in Section 0B (Page 0B-13)".

Radiator

Inspect the radiator for water leaks. If any defects are found, replace the radiator with a new one. If the fins are bent or dented, repair them by carefully straightening them with the blade of a small screwdriver.

NOTE

If necessary, remove the side cowlings. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".



I815H1160003-01


Radiator Cleaning

Blow out any foreign matter that is stuck in the radiator fins using compressed air.

⚠ CAUTION


- **Make sure not to bend the fins when using compressed air.**
- **If compressed air is applied from the front side, dirt will be forced into the pores of radiator.**

- 1) Remove the side cowlings. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Disconnect the horn lead wire coupler(1).
- 3) Remove the horn (2).




I815H1160004-01

- 4) Disconnect the cooling fan motor lead wire couplers (3).



I815H1160005-02

- 5) Remove the radiator mounting bolts (4).



I815H1160006-03

1F-6 Engine Cooling System:

- 6) Move the radiator forward.
- 7) Always apply compressed air from the engine side.



I815H1160007-01


- 8) Reinstall the removed parts.

Radiator / Cooling Fan Motor Removal and Installation

B815H21606004


Removal

- 1) Remove the side cowlings. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Drain engine coolant. Refer to "Cooling System Inspection in Section 0B (Page 0B-13)".
- 3) Disconnect the reservoir tank hose (1).
- 4) Remove the radiator reservoir tank (2).




I815H1160008-01

- 5) Disconnect the radiator inlet hose (3), water air bleed hose (4) and cooling fan motor lead wire coupler (right) (5).




I815H1160009-01

- 6) Disconnect the cooling fan motor lead wire coupler (left) (6) and radiator outlet hose (7).




I815H1160010-01

- 7) Remove the radiator assembly (8) by removing the bolts.



I815H1160011-02

- 8) Remove the cooling fan motors (9) from the radiator.




I815H1160012-01

Installation

Install the radiator in the reverse order of removal. Pay attention to the following points:

- Connect the radiator hoses securely. Refer to "Water Hose Routing Diagram (Page 1F-3)".
- Pour engine coolant. Refer to "Cooling System Inspection in Section 0B (Page 0B-13)".
- Bleed air from the cooling circuit. Refer to "Cooling System Inspection in Section 0B (Page 0B-13)".
- Fill the reservoir tank to the upper level "A". Refer to "Cooling System Inspection in Section 0B (Page 0B-13)".



I815H1160013-01


Water Hose Inspection

B815H21606005

Inspect the water hoses in the following procedures:

- 1) Remove the side cowlings. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Check the water hoses for crack, damage or engine coolant leakage. If any defect is found, replace the radiator hose with a new one.


- 3) Any leakage from the connecting section should be corrected by proper tightening. Refer to "Water Hose Routing Diagram (Page 1F-3)".



I815H1160014-01



I815H1160015-01



I815H1160016-01

- 4) After finishing the water hose inspection, reinstall the removed parts.

Water Hose Removal and Installation

B815H21606006

Removal

- 1) Remove the side cowlings. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.
- 2) Drain engine coolant. Refer to “Cooling System Inspection in Section 0B (Page 0B-13)”.
- 3) Lift and support the fuel tank. Refer to “Fuel Tank Removal and Installation in Section 1G (Page 1G-9)”.
- 4) Remove the water hose as shown in the water hose routing diagram. Refer to “Water Hose Routing Diagram (Page 1F-3)”.

Installation

- 1) Install the water hose as shown in the water hose routing diagram. Refer to “Water Hose Routing Diagram (Page 1F-3)”.
- 2) Pour engine coolant and bleed air from the cooling circuit. Refer to “Cooling System Inspection in Section 0B (Page 0B-13)”.
- 3) Reinstall the fuel tank. Refer to “Fuel Tank Removal and Installation in Section 1G (Page 1G-9)”.
- 4) Install the side cowlings. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.

Radiator Reservoir Tank Removal and Installation


B815H21606007

Refer to “Radiator / Cooling Fan Motor Removal and Installation (Page 1F-6)”.

Radiator Reservoir Tank Inspection

B815H21606008

Inspect the radiator reservoir tank cooling leaks. If any defects are found, replace the radiator reservoir tank with a new one.



I815H1160017-01

Cooling Fan Inspection


B815H21606009

Cooling fan operating temperature
Standard

(ON → OFF): Approx. 100 °C (212 °F)
(OFF → ON): Approx. 105 °C (221 °F)

Inspect the cooling fan in the following procedures:

- 1) Disconnect the cooling fan motor couplers (1).




I815H1160018-01

- 2) Test the cooling fan motor for load current with an ammeter connected as shown in the figure. If the fan motor does not turn, replace the cooling fan assembly with a new one. Refer to “Radiator / Cooling Fan Motor Removal and Installation (Page 1F-6)”.

NOTE

- When making this test, it is not necessary to remove the cooling fan.
- The voltmeter is for making sure that the battery applies 12 V to the motor. With the fan motor with electric motor fan running at full speed, the ammeter should be indicating not more than 5 A.



I718H1160048-01

2. Fan motor	3. Ammeter	4. Battery
--------------	------------	------------


- 3) Connect the cooling fan motor couplers.

Cooling Fan Relay Inspection

B815H21606010

Inspect the fan relay in the following procedures:

- 1) Remove the upper panel. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Remove the cooling fan relay (1).



I815H1160019-01


- 3) First check the insulation between "A" and "B" terminals with tester. Then apply 12 volts to "C" and "D" terminals, (+) to "C" and (-) to "D", and check the continuity between "A" and "B". If there is no continuity, replace it with a new one.

Special tool

TOOL : 09900-25008 (Multi-circuit tester set)

Tester knob indication set

Continuity test (•)))



I718H1160006-03

- 4) Reinstall the removed parts.

ECT Sensor Removal and Installation

B815H21606011

Refer to "ECT Sensor Removal and Installation in Section 1C (Page 1C-5)".

ECT Sensor Inspection

B815H21606012


Refer to "ECT Sensor Inspection in Section 1C (Page 1C-5)".

Thermostat Cover / Thermostat Removal and Installation

B815H21606013


Removal

- 1) Drain a small amount of engine coolant. Refer to "Cooling System Inspection in Section 0B (Page 0B-13)".
- 2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".
- 3) Disconnect the water air bleed hose (1) and cylinder head outlet hose (2).




I815H1160020-01

- 4) After removing of the thermostat cover bolts (3), remove the thermostat cover (4).



I815H1160021-01

- 5) Remove the thermostat (5).



I815H1160022-01

1F-10 Engine Cooling System:


Installation

Install the thermostat in the reverse order of removal. Pay attention to the following points:

- Install the thermostat.

NOTE

The air bleeder hole "A" of the thermostat faces upside.




I823H1160025-01

- Tighten the thermostat cover bolts (1) to the specified torque.

Tightening torque

Thermostat cover bolt (a): 10 N·m (1.0 kgf-m, 7.0 lb-ft)



I815H1160023-01

- Connect the water hoses securely. Refer to "Water Hose Routing Diagram (Page 1F-3)".
- Pour engine coolant and bleed air from the cooling circuit. Refer to "Cooling System Inspection in Section 0B (Page 0B-13)".

Thermostat Inspection

B815H21606014

Inspect the thermostat in the following procedures:

- 1) Remove the thermostat. Refer to "Thermostat Cover / Thermostat Removal and Installation (Page 1F-9)".
- 2) Inspect the thermostat pellet for signs of cracking.




I823H1160027-01

- 3) Test the thermostat at the bench for control action.

⚠ CAUTION

- Do not contact the thermostat (1) and column thermometer (2) with a pan.
- As the thermostat operating response to water temperature change is gradual, do not raise water temperature too quickly.
- The thermostat with its valve open even slightly under normal temperature must be replaced.

- 4) Immerse the thermostat (1) in the water contained in a beaker and note that the immersed thermostat is in suspension.
- 5) Heat the water by placing the beaker on a stove and observe the rising temperature on a thermometer (2).



I705H1160030-03

"A": String

"B": Water

- 6) Read the thermometer just when opening the thermostat. If this reading, which is the temperature level at which the thermostat valve begins to open, is out of the standard value, replace the thermostat with a new one.

Thermostat valve opening temperature


Standard: Approx. 82 °C (180 °F)

- 7) Keep on heating the water to raise its temperature.

- 8) Just when the water temperature reaches specified value, the thermostat valve should have been lifted by at least 8 mm (0.31 in). A thermostat failing to satisfy either of the two requirements (start-to-open temperature and valve lift) must be replaced.

Thermostat valve lift "a"

Standard: Over 8 mm (0.31 in) and at 95 °C (203 °F)




I705H1160031-04

- 9) Install the thermostat. Refer to "Thermostat Cover / Thermostat Removal and Installation (Page 1F-9)".

Water Pump Components

B815H21606015




I815H1160031-02

1. Water pump case	(a): 8 N·m (0.8 kgf·m, 6.0 lb-ft)	Torque wrench: Apply molybdenum oil solution.
2. O-ring	(b): 6 N·m (0.6 kgf·m, 4.5 lb-ft)	1322: Apply thread lock.
3. Impeller	(c): 10 N·m (1.0 kgf·m, 7.0 lb-ft)	X: Do not reuse.
4. Mechanical seal	AH: Apply grease.	
5. Oil seal	LLC: Apply engine coolant.	

Water Pump Construction

B815H21606016



I823H1160028-03

1. Impeller	5. O-ring	: Apply thread lock.
2. Mechanical seal	: 8 N·m (0.8 kgf·m, 6.0 lb·ft)	: Apply molybdenum oil solution.
3. Oil seal	: Apply grease.	: Do not reuse.
4. O-ring	: Apply engine coolant.	

Water Pump Removal and Installation

B815H21606017


Removal

NOTE

Before draining engine oil and engine coolant, inspect engine oil and coolant leakage between the water pump and crankcase. If engine oil is leaking, visually inspect the oil seal and O-ring. If engine coolant is leaking, visually inspect the mechanical seal and seal washer. Refer to “Water Pump Related Parts Inspection (Page 1F-16)”.


- 1) Drain engine oil and coolant. Refer to “Engine Oil and Filter Replacement in Section 0B (Page 0B-10)” and “Cooling System Inspection in Section 0B (Page 0B-13)”.
- 2) Remove the engine sprocket covers, outer and inner. Refer to “Engine Sprocket Removal and Installation in Section 3A (Page 3A-2)”.

- 3) Disconnect the water bypass hose (1), water pump inlet hose (2) and cylinder inlet hose (3).



I815H1160024-01

- 4) Remove the water pump (4).



I815H1160025-01

Installation

Install the water pump in the reverse order of removal. Pay attention to the following points:


- Apply grease to the O-ring.

⚠ CAUTION

Replace the O-ring with the a new one.

⚙ : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)

- Install the water pump assembly with the slot on the pump shaft end "A" securely engaged with the flat "B" on the oil pump shaft.




I815H1160026-01

- Tighten the water pump mounting bolts (1) to the specified torque.

Tightening torque

Water pump mounting bolt (a): 10 N·m (1.0 kgf-m, 7.0 lb-ft)



I815H1160027-01

- Connect the water hoses securely. Refer to "Water Hose Routing Diagram (Page 1F-3)".
- Pour engine oil and coolant. Refer to "Engine Oil and Filter Replacement in Section 0B (Page 0B-10)" and "Cooling System Inspection in Section 0B (Page 0B-13)".
- Bleed air from the cooling circuit. Refer to "Cooling System Inspection in Section 0B (Page 0B-13)".


Water Pump Disassembly and Assembly

B815H21606018

Refer to "Water Pump Removal and Installation (Page 1F-12)".


Disassembly

- 1) Remove the water pump case (1).




I815H1160028-01

- 2) Remove the impeller securing bolt by holding the impeller (2) with a water pump pliers.



I823H1160034-01


- 3) Remove the mechanical seal ring (3) and rubber seal (4) from the impeller.



I823H1160035-01

1F-14 Engine Cooling System:

- 4) Remove the impeller shaft (5) and washer (6) from the water pump body.



I823H1160036-01


- 5) Remove the mechanical seal with the special tool.

NOTE

If there is no abnormal condition, the mechanical seal removal is not necessary.

Special tool

 (A): 09921-20240 (Bearing remover set)




I823H1160037-02

- 6) Remove the oil seal.

NOTE

If there is no abnormal condition, the oil seal removal is not necessary.



I823H1160038-02

Assembly

- 1) Install the oil seal with the special tool.

CAUTION


The removed oil seal must be replaced with a new one.

NOTE

The stamped mark on the oil seal should face mechanical seal side.

Special tool


 (A): 09913-70210 (Bearing installer set)



I823H1160039-01

- 2) Apply a small quantity of the grease to the oil seal lip.

 : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)



I823H1160040-01


- 3) Install a new mechanical seal using a suitable size socket wrench.

⚠ CAUTION

The removed mechanical seal must be replaced with a new one.

NOTE

On new mechanical seals, the sealer "A" has been applied.



I823H1160041-01




I823H1160042-01

- 4) Apply molybdenum solution to the impeller shaft (1) and washer (2).

M/O: Moly paste 99000-25140 (SUZUKI MOLY PASTE or equivalent)

- 5) Install the impeller shaft (1) and washer (2) to the water pump body.




I823H1160043-03

- 6) Install the rubber seal (3) into the impeller (4).
7) After wiping off the oily or greasy matter from the mechanical seal ring (5), install it into the impeller.

NOTE

The paint marked side "B" of mechanical seal ring faces the rubber seal.




I823H1160044-02

- 8) Install the washer (6) and seal washer (7) onto the impeller securing bolt.

NOTE

The metal side "C" of seal washer and the curved side "D" of washer face the impeller securing bolt head.




I823H1160045-03

- 9) Install the impeller and tighten the impeller securing bolt (8) to the specified torque.

Tightening torque

Impeller securing bolt (a): 8 N·m (0.8 kgf-m, 6.0 lb-ft)



I823H1160046-01

1F-16 Engine Cooling System:

10) Install new O-rings (9) and (10).


CAUTION

Use new O-rings to prevent engine coolant or oil leakage.

NOTE

- Apply engine coolant to the O-ring (9).
- Apply grease to the O-ring (10).

 : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)




I815H1160032-01

11) Fit the water pump case and tighten the water pump case screws (11) to the specified torque.

Tightening torque

Water pump case screw (b): 6 N·m (0.6 kgf-m, 4.5 lb-ft)



I815H1160029-01


Water Pump Related Parts Inspection

B815H21606019

Refer to "Water Pump Disassembly and Assembly (Page 1F-13)".

Mechanical Seal


Visually inspect the mechanical seal for damage, with particular attention given to the sealing face. Replace the mechanical seal that shows indications of leakage.



I823H1160049-01

Oil Seal


Visually inspect the oil seal for damage, with particular attention given to the lip. Replace the oil seal that shows indications of leakage.



I823H1160050-01

Seal Washer

Visually inspect the seal washer for damage, with particular attention given to the sealing face. Replace the seal washer that shows indications of leakage.



I823H1160051-01

Impeller / Shaft

Visually inspect the impeller and its shaft for damage.
Replace the impeller or shaft if necessary.



I823H1160052-01

Impeller Shaft Journal

Visually inspect the journal for damage or scratch.
Replace the water pump body if necessary.



I823H1160053-01

Specifications

Service Data

B815H21607001

Thermostat + Radiator + Fan + Coolant

Item	Specification		Note
Thermostat valve opening temperature	Approx. 82 °C (180 °F)		—
Thermostat valve lift	Over 8 mm (0.31 in) and at 95 °C (203 °F)		—
ECT sensor resistance	20 °C (68 °F)	Approx. 2.45 kΩ	—
	50 °C (122 °F)	Approx. 0.811 kΩ	—
	80 °C (176 °F)	Approx. 0.318 kΩ	—
	110 °C (230 °F)	Approx. 0.142 kΩ	—
Radiator cap valve opening pressure	93 – 123 kPa (0.93 – 1.23 kgf/cm ² , 13.2 – 17.5 psi)		—
Cooling fan operating temperature	OFF → ON	Approx. 105 °C (221 °F)	—
	ON → OFF	Approx. 100 °C (212 °F)	—
Engine coolant type	Use an anti-freeze/coolant compatible with aluminum radiator, mixed with distilled water only, at the ratio of 50:50.		—
Engine coolant including reserve	Reserve tank side	Approx. 250 ml (0.3/0.2 US/Imp qt)	—
	Engine side	Approx. 2 700 ml (2.9/2.4 US/Imp qt)	—

Tightening Torque Specifications

B815H21607002

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
Thermostat cover bolt	10	1.0	7.0	☞ (Page 1F-10)
Water pump mounting bolt	10	1.0	7.0	☞ (Page 1F-13)
Impeller securing bolt	8	0.8	6.0	☞ (Page 1F-15)
Water pump case screw	6	0.6	4.5	☞ (Page 1F-16)

NOTE

The specified tightening torque is also described in the following.

“Water Hose Routing Diagram (Page 1F-3)”

“Water Pump Components (Page 1F-11)”

“Water Pump Construction (Page 1F-12)”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Tightening Torque List in Section 0C (Page 0C-9)”.

Special Tools and Equipment

Recommended Service Material

B815H21608001

Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI SUPER GREASE A or equivalent	P/No.: 99000-25010	☞ (Page 1F-13) / ☞ (Page 1F-14) / ☞ (Page 1F-16)
Moly paste	SUZUKI MOLY PASTE or equivalent	P/No.: 99000-25140	☞ (Page 1F-15)

NOTE




Required service material is also described in the following.

“Water Pump Components (Page 1F-11)”

“Water Pump Construction (Page 1F-12)”

Special Tool

B815H21608002

09900-25008 Multi-circuit tester set ☞ (Page 1F-9) 	09913-70210 Bearing installer set ☞ (Page 1F-14) 
09921-20240 Bearing remover set ☞ (Page 1F-14) 	

Fuel System

Precautions

Precautions for Fuel System

B815H21700001

⚠ WARNING

- Keep away from fire or spark.
 - During disassembling, use care to minimize spillage of gasoline.
 - Spilled gasoline should be wiped off immediately.
 - Work in a well-ventilated area.
 - For California models, drain fuel from the fuel tank before disconnecting the fuel feed hose to prevent fuel leakage.
-

⚠ CAUTION

- To prevent the fuel system (fuel tank, fuel hose, etc.) from contamination with foreign particles, blind all openings.
 - After removing the throttle body, tape the cylinder intake section to prevent foreign particles from entering.
-

General Description


Fuel Injection System Description

B815H21701001

Fuel System

The fuel delivery system consists of the fuel tank (1), fuel pump (2), fuel filters (3) and (4), fuel feed hose (5), fuel delivery pipes (6) including fuel injectors (7) and (8), fuel pressure regulator (9). There is no fuel return hose. The fuel in the fuel tank is pumped up by the fuel pump and pressurized fuel flows into the injectors installed in the fuel delivery pipe. Fuel pressure is regulated by the fuel pressure regulator. As the fuel pressure applied to the fuel injectors (the fuel pressure in the fuel delivery pipe) is always kept at absolute fuel pressure of 300 kPa (3.0 kgf/cm², 43 psi), the fuel is injected into the throttle body in conic dispersion when the injector opens according to the injection signal from the ECM.

The fuel relieved by the fuel pressure regulator flows back to the fuel tank.




1. Fuel tank	7. Primary fuel infector
2. Fuel pump	8. Secondary fuel infector
3. Fuel mesh filter (For low pressure)	9. Fuel pressure regulator
4. Fuel filter (For high pressure)	"A": Before-pressurized fuel
5. Fuel feed hose	"B": Pressurized fuel
6. Fuel delivery pipes	"C": Relieved fuel

I815H1170002-02

Schematic and Routing Diagram

Fuel Tank Drain Hose and Breather Hose Routing Diagram

B815H21702001



I815H1170001-03

1. Fuel tank drain hose	▲ "A": Pass the breather hose and drain hose to right side of the rear shock absorber.
2. Fuel tank breather hose	▲ "B": Pass the breather hose and drain hose into the hole of the swingarm.
3. Hose guide	▲ "C": Pass the breather hose and drain hose to outside of the rear cushion rod.
4. Heat shield	"D": To the fuel tank
"a": 100 mm (4.0 in)	[A]: E-33 only
"b": 90 mm (3.5 in)	

Diagnostic Information and Procedures

Fuel System Diagnosis

B815H21704001

Condition	Possible cause	Correction / Reference Item
Engine will not start or is hard to start (No fuel reaching the intake manifold)	Clogged fuel filter or fuel hose.	<i>Clean or replace.</i>
	Defective fuel pump.	<i>Replace.</i>
	Defective fuel pressure regulator.	<i>Replace.</i>
	Defective fuel injector.	<i>Replace.</i>
	Defective fuel pump relay.	<i>Replace.</i>
	Defective ECM.	<i>Replace.</i>
	Open-circuited wiring connection.	<i>Check and repair.</i>
Engine will not start or is hard to start (Incorrect fuel/air mixture)	TP sensor out of adjustment.	<i>Adjust.</i>
	Defective fuel pump.	<i>Replace.</i>
	Defective fuel pressure regulator.	<i>Replace.</i>
	Defective TP sensor.	<i>Replace.</i>
	Defective CKP sensor.	<i>Replace.</i>
	Defective IAP sensor.	<i>Replace.</i>
	Defective ECM.	<i>Replace.</i>
	Defective ECT sensor.	<i>Replace.</i>
	Defective IAT sensors.	<i>Replace.</i>
	Defective AP sensors.	<i>Replace.</i>
	Clogged ISC valve air passage way.	<i>Repair or replace.</i>
Engine stalls often (Incorrect fuel/air mixture)	Defective IAP sensor or circuit.	<i>Repair or replace.</i>
	Clogged fuel filter.	<i>Clean or replace.</i>
	Defective fuel pump.	<i>Replace.</i>
	Defective fuel pressure regulator.	<i>Replace.</i>
	Defective ECT sensor.	<i>Replace.</i>
	Defective thermostat.	<i>Replace.</i>
	Defective IAT sensor.	<i>Replace.</i>
	Damaged or cracked vacuum hose.	<i>Replace.</i>
Engine stalls often (Fuel injector improperly operating)	Damaged or cracked ISC valve.	<i>Repair or replace.</i>
	Defective fuel injector.	<i>Replace.</i>
	No injection signal from ECM.	<i>Repair or replace.</i>
	Open or short circuited wiring connection.	<i>Repair or replace.</i>
Engine runs poorly in high speed range (Defective control circuit or sensor)	Defective battery or low battery voltage.	<i>Replace or recharge.</i>
	Low fuel pressure.	<i>Repair or replace.</i>
	Defective TP sensor.	<i>Replace.</i>
	Defective IAT sensor.	<i>Replace.</i>
	Defective CMP sensor.	<i>Replace.</i>
	Defective CKP sensor.	<i>Replace.</i>
	Defective GP switch.	<i>Replace.</i>
	Defective IAP sensor.	<i>Replace.</i>
	Defective ECM.	<i>Replace.</i>
	TP sensor out of adjustment.	<i>Replace.</i>
	Defective STP sensor and/or STVA.	<i>Replace.</i>

Repair Instructions

Fuel Pressure Inspection

B815H21706001

⚠ WARNING

- Keep away from fire or spark.
- Spilled gasoline should be wiped off immediately.
- Work in a well-ventilated area.

Inspect the fuel pressure in the following procedures:

- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation (Page 1G-9)".
- 2) Place a rag under the fuel feed hose (1) and remove the fuel feed hose.



I815H1170003-01

- 3) Install the special tools between the fuel pump and fuel delivery pipe.


Special tool

TOOL (A): 09940-40211 (Fuel pressure gauge adapter)

TOOL (B): 09940-40220 (Fuel pressure gauge hose attachment)

TOOL (C): 09915-77331 (Meter (for high pressure))

TOOL (D): 09915-74521 (Oil pressure gauge hose)



I815H1170004-01

- 4) Turn the ignition ON and check for fuel pressure.

Fuel pressure

Approx. 300 kPa (3.0 kgf/cm², 43 psi)

If the fuel pressure is lower than the specification, check for the followings:

- Fuel hose leakage
- Clogged fuel filter
- Pressure regulator
- Fuel pump

If the fuel pressure is higher than the specification, check for the followings:

- Fuel pump
- Pressure regulator

- 5) Remove the special tools.

⚠ WARNING

Before removing the special tools, turn the ignition switch OFF and release the fuel pressure slowly.

- 6) Reinstall the fuel tank. Refer to "Fuel Tank Removal and Installation (Page 1G-9)".

NOTE

Connect the fuel feed hose to the fuel pump until it locks securely (a click is heard).

Fuel Pump Inspection

B815H21706002

Turn the ignition switch ON and check that the fuel pump operates for a few seconds.

If the fuel pump motor does not make operating sound, inspect the fuel pump circuit connections or inspect the fuel pump relay and TO sensor. Refer to "Fuel Pump Relay Inspection (Page 1G-7)" and "DTC "C23" (P1651-H/L): TO Sensor Circuit Malfunction in Section 1A (Page 1A-64)".

If the fuel pump relay, TO sensor and fuel pump circuit connections are OK, the fuel pump may be faulty, replace the fuel pump with a new one. Refer to "Fuel Pump Disassembly and Assembly (Page 1G-12)".

Fuel Discharge Amount Inspection

B815H21706003

▲ WARNING

- **Keep away from fire or spark.**
- **Spilled gasoline should be wiped off immediately.**
- **Work in a well-ventilated area.**


Inspect the fuel discharge amount in the following procedures:

- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation (Page 1G-9)".
- 2) Place a rag under the fuel feed hose (1) and disconnect fuel feed hose from the fuel pump.



I815H1170005-01

- 3) Connect a proper fuel hose (2) to the fuel pump.
- 4) Place the measuring cylinder and insert the fuel hose end into the measuring cylinder.
- 5) Disconnect the fuel pump lead wire coupler (3).



I815H1170006-01

- 6) Connect a proper lead wire into the fuel pump lead wire coupler (fuel pump side) and apply 12 V to the fuel pump (between (+) Y/R wire and (-) B/W wire) for 10 seconds and measure the amount of fuel discharged.


If the discharge amount is out of the specification, the probable cause may be failure of the fuel pump or clogged fuel filter.

NOTE

The battery must be in fully charged condition.

Fuel discharge amount

220 ml (7.4/7.7 US/Imp oz) and more/10 seconds



I815H1170007-01

- 7) After finishing the fuel discharge inspection, reinstall the fuel tank. Refer to "Fuel Tank Removal and Installation (Page 1G-9)".

NOTE

Connect the fuel feed hose to the fuel pump until it locks securely (a click is heard).


Fuel Pump Relay Inspection

B815H21706004

Refer to "Electrical Components Location in Section 0A (Page 0A-8)".

Inspect the fuel pump relay in the following procedures:

- 1) Remove the frame cover. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Remove the fuel pump relay (1).



I815H1170008-01


- 3) First, check for insulation with the tester between terminals "A" and "B". Next, check for continuity between "A" and "B" with 12 V voltage applied, positive (+) to terminal "C" and negative (–) to terminal "D". If continuity does not exist, replace the relay with a new one.

Special tool

 : 09900–25008 (Multi-circuit tester set)

Tester knob indication

Continuity test (•)))



I718H1170013-01

Fuel Hose Inspection

B815H21706005

Refer to "Fuel Line Inspection in Section 0B (Page 0B-10)".


Fuel Level Gauge Inspection

B815H21706006

Refer to "Fuel Level Gauge Inspection in Section 9C (Page 9C-6)".

Fuel Tank Construction

B815H21706007




 1. Fuel tank cushion : Apply adhesive agent.	"a": 5 mm (0.20 in)
 2. Dent mark : Align the fuel tank cushion with the dent mark (2).	"b": 2 mm (0.08 in)
 3. Arrow mark : Face the arrow forward.	"c": 4 mm (0.16 in)

I815H1170009-02

Fuel Tank Heat Shield Construction

B815H21706008



I815H1170010-01

1. Fuel tank heat shield No. 1	4. Clamp : The end of the clamp should face backward.
2. Fuel tank heat shield No. 2	5. Adhesive tape : Clean the adhesive surface before adhering the adhesive tape.
3. Clamp : The end of the clamp should face forward.	

Fuel Tank Removal and Installation

B815H21706009


Removal

⚠ WARNING

- Keep away from fire or spark.
- Spilled gasoline should be wiped off immediately.
- Work in a well-ventilated area.

- 1) Remove the seats. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".

- 2) Take out the fuel tank prop stay (1).



I815H1170011-01

1G-10 Fuel System:

- 3) Remove the bolts.



I815H1170012-01

- 4) Lift and support the fuel tank with the prop stay.




I815H1170013-01

- 5) Disconnect the fuel pump lead wire coupler (2).
6) Place a rag under the fuel feed hose (3) and disconnect the fuel feed hose from the fuel tank.


⚠ CAUTION

When removing the fuel tank, do not leave the fuel feed hose on the fuel pump side.




I815H1170015-01

- 7) Disconnect the fuel tank drain hose (4).
8) Disconnect the surge hose (5). (For E-33)
9) Disconnect the fuel tank breather hose. (Except for E-33)




I815H1170014-01

- 10) Remove the fuel tank by removing its bracket bolts.



I815H1170016-01

- 11) Remove the fuel shut-off valve (6) and surge hose (7) from the fuel tank. (For E-33)



I815H1170025-01

Installation


Install the fuel tank in the reverse order of removal.

NOTE

Connect the fuel feed hose to the fuel pump until it locks securely (a click is heard).

Fuel Pump Components

B815H21706010



1. Fuel level gauge	6. Fuel pump holder	: 10 N·m (1.0 kgf·m, 7.0 lb·ft)
2. Fuel filter cartridge	7. Fuel mesh filter	: Apply grease.
3. Bushing	8. O-ring	: Apply engine oil.
4. Fuel pump	9. Fuel pump plate	: Do not reuse.
5. Fuel pump cushion	10. O-ring (Fuel tank side)	

I815H1170017-03

Fuel Pump Disassembly and Assembly

B815H21706011

Disassembly

- 1) Remove the fuel tank. Refer to "Fuel Tank Removal and Installation (Page 1G-9)".
- 2) Remove the fuel pump assembly (1) by removing its mounting bolts diagonally.

⚠ WARNING

- Spilled gasoline should be wipe off immediately.
- Keep away from fire or spark.
- Work in a well-ventilated area.




I815H1170018-02

- 3) Disconnect the lead wires (2).



I815H1170019-01


- 4) Remove the fuel level gauge (3).



I815H1170020-03


- 5) Disconnect the ground read wire (4).

- 6) Remove the fuel pump plate (5).



I815H1170021-02


- 7) Remove the O-ring (6).



I823H1170015-02


- 8) Remove the fuel pump holder (7) and cushion (8).

- 9) Remove the fuel mesh filter (9).




I823H1170016-02

- 10) Remove the fuel pump (10) from the fuel filter cartridge (case) (11).



I823H1170017-03

11) Remove the bushing (12) and lead wires (13).



I823H1170018-05


Assembly

Refer to "Fuel Mesh Filter Inspection and Cleaning (Page 1G-14)".


Assemble the fuel tank pump in the reverse order of the disassembly. Pay attention to the following points:

⚠ CAUTION

- To prevent fuel leakage, the bushing and O-ring must be replaced with new ones.
- Apply engine oil lightly to the bushing and O-ring.




I823H1170019-01




I823H1170020-01

- Connect all lead wires securely so as not to cause contact failure.



I815H1170022-01



I815H1170023-01


1.	Fuel pump (+) lead wire (BI)
2.	Fuel level gauge (+) lead wire (R)
3.	Fuel pump (-) lead wire (B)
4.	Fuel level gauge (-) lead wire (B)
5.	Ground lead wire

- Install a new O-ring and apply grease to it.

⚠ : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)

⚠ WARNING

The O-ring must be replaced with a new one to prevent fuel leakage.



I815H1170024-01

1G-14 Fuel System:

- When installing the fuel pump assembly, first tighten all the fuel pump mounting bolts lightly and then to the specified torque.

Tightening torque

Fuel pump mounting bolt: 10 N·m (1.0 kgf-m, 7.0 lb-ft)



I815H1170026-01

Fuel Mesh Filter Inspection and Cleaning


B815H21706012

Inspect the fuel mesh filter in the following procedures:

- 1) Remove the fuel mesh filter. Refer to "Fuel Pump Disassembly and Assembly (Page 1G-12)".
- 2) If the fuel mesh filter is clogged with foreign particles, it hinders smooth gasoline flow resulting in loss of engine power. Such a filter should be cleaned by blowing with compressed air.

NOTE

When the fuel mesh filter is dirtied excessively, replace the fuel filter cartridge with a new one.



I823H1170025-01

- 3) After finishing the fuel mesh filter inspection, reinstall the fuel mesh filter. Refer to "Fuel Pump Disassembly and Assembly (Page 1G-12)".

Fuel Injector / Fuel Delivery Pipe / T-joint Removal and Installation

B815H21706013

Refer to "Throttle Body Disassembly and Assembly in Section 1D (Page 1D-12)".

Fuel Injector Inspection and Cleaning

B815H21706014

Inspect the fuel injector in the following procedures:

- 1) Remove the fuel injector. Refer to "Throttle Body Disassembly and Assembly in Section 1D (Page 1D-12)".
- 2) Check the fuel injector filter for evidence of dirt and contamination. If present, clean and check for presence of dirt in the fuel lines and fuel tank.



I823H1170026-01

- 3) Install the fuel injector. Refer to "Throttle Body Disassembly and Assembly in Section 1D (Page 1D-12)".

Specifications

Service Data

B815H21707001

Injector + Fuel Pump + Fuel Pressure Regulator

Item	Specification	Note
Injector resistance	11 – 13 Ω at 20 °C (68 °F)	
Fuel pump discharge amount	220 ml (7.4/7.7 US/lmp oz) and more/10 sec.	
Fuel pressure regulator operating set pressure	Approx. 300 kPa (3.0 kgf/cm ² , 43 psi)	

Fuel

Item	Specification	Note
Fuel type	Use only unleaded gasoline of at least 90 pump octane (R/2 + M/2). Gasoline containing MTBE (Methyl Tertiary Butyl Ether), less than 10% ethanol, or less than 5% methanol with appropriate cosolvents and corrosion inhibitor is permissible. Gasoline used should be graded 95 octane or higher. An unleaded gasoline type is recommended.	E-03, 28, 33
		Others
Fuel tank capacity	Including reserve	20 L (5.3/4.4 US/lmp gal)
		21 L (5.5/4.6 US/lmp gal)
		E-33
		Others

Tightening Torque Specifications

B815H21707002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Fuel pump mounting bolt	10	1.0	7.0	☞ (Page 1G-14)

NOTE

The specified tightening torque is also described in the following.
“Fuel Pump Components (Page 1G-11)”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Tightening Torque List in Section 0C (Page 0C-9)”.

Special Tools and Equipment

Recommended Service Material

B815H21708001





Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI SUPER GREASE A or equivalent	P/No.: 99000-25010	☞ (Page 1G-13)

NOTE

Required service material is also described in the following.
“Fuel Pump Components (Page 1G-11)”

Special Tool

B815H21708002


09900-25008 Multi-circuit tester set ☞ (Page 1G-7) 	09915-74521 Oil pressure gauge hose ☞ (Page 1G-5) 
09915-77331 Meter (for high pressure) ☞ (Page 1G-5) 	09940-40211 Fuel pressure gauge adapter ☞ (Page 1G-5) 
09940-40220 Fuel pressure gauge hose attachment ☞ (Page 1G-5) 	

Ignition System


General Description

Immobilizer Description (For E-02, 19, 24)

The immobilizer, an anti-theft system, is installed as a standard equipment. The immobilizer verifies that the key ID agrees with ECM ID by means of radio communication through the immobilizer antenna. When the ID agreement is verified, the system makes the engine ready to start.



1. Immobilizer antenna	2. Indicator light
------------------------	--------------------




1. Immobilizer antenna	3. Transponder
2. Indicator light	4. ID

Operation

When the ignition switch is turned ON with the engine stop switch in ON, the immobi-antenna and ECM are powered ON.


The ECM transmits a signal to the transponder through the immobi-antenna in order to make comparison between the key ID and ECM ID.

With the signal received, the transponder transmits the key ID signal to ECM so that ECM can make comparison with its own ID, and if it matches, the engine is made ready to start.



1. Immobilizer antenna	3. Ignition switch
2. Transponder	4. ECM

Also, when the ignition switch is turned ON, the indicator light flashes as many as the number of IDs registered in ECM. Thereafter, if the IDs are in agreement, the indicator light turns on for two seconds to notify of completion in successful communication. If the indicator light (LED) flashes fast, it notifies of communication error or disagreement of ID.



NOTE

If the indicator light flashes fast, turn the ignition switch OFF then ON to make judgment again as there is possible misjudgment due to environmental radio interference.

⚠ CAUTION

When the battery performance is lowered in winter (low temperature), the system may at times makes a re-judgment at the time of beginning the starter motor operation. In this case, the indicator light operation starts immediately after the starter operation.




I815H1180004-01

5. Indicator light

Drive Mode Selector Description

B815H21801002

Engine power characteristics can be changed in 3 modes by operating the drive mode selector to meet various riding conditions and rider's preference.



I815H1180019-01

Operation

Drive mode is preset at A-mode when the ignition switch and engine stop switch are turned on. Follow the procedure below to operate drive mode selector.

- 1) Turn on the ignition switch and engine stop switch.
- 2) Start the engine.
- 3) Push the driving mode switch for 2 seconds until the driving mode indicator shows A.
- 4) Push the driving mode switch to change driving mode. Pushing the upper part can change from A to C to B to A. Pushing the lower part can change from A to B to C to A. The driving mode indicator indicates actual driving mode.

NOTE

- Operating the drive mode selector while riding with the throttle opened will change the engine speed because of engine power characteristics change.
- Drive mode indicator blinks when drive mode change operation is failed.
- Turning off the ignition switch or engine stop switch will return the drive mode to A-mode. Start the engine and reset the drive mode.

Drive Mode

A-mode


A-mode provides sharp throttle response at all throttle opening range to obtain maximum engine power.

B-mode

B-mode provides softer throttle response than A-mode at all throttle opening range.

C-mode

C-mode provides softer throttle response than B-mode at all throttle opening range.




I815H1180005-01

Schematic and Routing Diagram

Ignition System Diagram

B815H21802001

Refer to “Wire Color Symbols in Section 0A (Page 0A-6)”.



I823H1180025-01

Ignition System Components Location

B815H21802002

Refer to “Electrical Components Location in Section 0A (Page 0A-8)”.

Diagnostic Information and Procedures

Ignition System Symptom Diagnosis

B815H21804001

Condition	Possible cause	Correction / Reference Item
Spark plug not sparking	Damaged spark plug.	<i>Replace.</i>
	Fouled spark plugs.	<i>Clean or replace.</i>
	Wet spark plugs.	<i>Clean and dry or replace.</i>
	Defective ignition coil/plug caps.	<i>Replace.</i>
	Defective CKP sensor.	<i>Replace.</i>
	Defective ECM.	<i>Replace.</i>
	Open-circuited wiring connections.	<i>Repair or replace.</i>
Engine stalls easily (No spark)	Fouled spark plugs.	<i>Clean or replace.</i>
	Defective CKP sensor.	<i>Replace.</i>
	Defective ECM.	<i>Replace.</i>
Spark plug is wet or quickly becomes fouled with carbon	Excessively rich air/fuel mixture.	<i>Inspect FI system.</i>
	Excessively high idling speed.	<i>Inspect FI system.</i>
	Incorrect gasoline.	<i>Change.</i>
	Dirty air cleaner element.	<i>Clean or replace.</i>
	Incorrect spark plug (Cold type).	<i>Change to hot type spark plug.</i>
Spark plug quickly becomes fouled with oil or carbon	Worn piston rings.	<i>Replace.</i>
	Worn pistons.	<i>Replace.</i>
	Worn cylinders.	<i>Replace.</i>
	Excessive valve-stem to valve-guide clearance.	<i>Replace.</i>
	Worn valve stem oil seals.	<i>Replace.</i>
Spark plug electrodes overheat or burn	Incorrect spark plug (Hot type).	<i>Change to cold type spark plug.</i>
	Overheated engine.	<i>Tune-up.</i>
	Loose spark plugs.	<i>Tighten.</i>
	Excessively lean air/fuel mixture.	<i>Inspect FI system.</i>

No Spark or Poor Spark

B815H21804002

Troubleshooting

NOTE

Check that the transmission is in neutral and the engine stop switch is in the "RUN" position. Grasp the clutch lever. Check that the fuse is not blown and the battery is fully-charged before diagnosing.

Step	Action	Yes	No
1	Check the ignition system couplers for poor connections. <i>Is there connection in the ignition system couplers?</i>	Go to Step 2.	Poor connection of couplers.
2	Measure the battery voltage between input lead wires at the ECM with the ignition switch in the "ON" position. (E-02, 19, 24: O/G and B/W, E-03, 28, 33: O/W and B/W) <i>Is the voltage OK?</i>	Go to Step 3.	<ul style="list-style-type: none"> Faulty ignition switch. Faulty turn signal/ side-stand relay. Faulty engine stop switch. Broken wire harness or poor connection of related circuit couplers.
3	Measure the ignition coil primary peak voltage. Refer to "Ignition Coil / Plug Cap Inspection (Page 1H-7)". NOTE This inspection method is applicable only with the multi-circuit tester and the peak volt adaptor. <i>Is the peak voltage OK?</i>	Go to Step 4.	Go to Step 5.
4	Inspect the spark plugs. Refer to "Spark Plug Inspection and Cleaning in Section 0B (Page 0B-9)". <i>Is the spark plug(-s) OK?</i>	Go to Step 5.	Faulty spark plug(-s).
5	Inspect the ignition coil/plug cap(-s). Refer to "Ignition Coil / Plug Cap Inspection (Page 1H-7)". <i>Is the ignition coil/plug cap(-s) OK?</i>	Go to Step 6.	<ul style="list-style-type: none"> Faulty ignition coil/ plug cap(-s). Poor connection of the ignition coil/plug cap(-s).
6	Measure the CKP sensor peak voltage and its resistance. Refer to "CKP Sensor Inspection (Page 1H-10)". NOTE The CKP sensor peak voltage inspection is applicable only with the multi-circuit tester and peak volt adaptor. <i>Are the peak voltage and resistance OK?</i>	<ul style="list-style-type: none"> Faulty ECM. Open or short circuit in wire harness. Poor connection of ignition couplers. 	<ul style="list-style-type: none"> Faulty CKP sensor. Metal particles or foreign material being stuck on the CKP sensor and rotor tip.

Repair Instructions

Ignition Coil / Plug Cap and Spark Plug Removal and Installation

B815H21806001

Removal

⚠ WARNING

**The hot engine can burn you.
Wait until the engine is cool enough to touch.**

- 1) Turn the ignition switch OFF.
- 2) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation in Section 1D (Page 1D-6)".
- 3) Disconnect all lead wire couplers (1) from ignition coil/plug caps (2).



I815H1180006-03


⚠ CAUTION

Disconnect the lead wire coupler before removing the ignition coil/plug cap to avoid lead wire coupler damage.

- 4) Remove the ignition coils/plug caps (2).

⚠ CAUTION

- Do not pry up the ignition coil/plug cap with a screwdriver or a bar to avoid its damage.
- Be careful not to drop the ignition coil/plug cap to prevent short/open circuit.



I815H1180007-02

- 5) Remove the spark plugs with a spark plug wrench.

Special tool

🔧 (A): 09930-10121 (Spark plug wrench set)



I815H1180008-04

Installation

Install the spark plugs in the reverse order of removal. Pay attention to the following points:

- Screw the spark plugs into the cylinder head with fingers, and then tighten them to the specified torque.

⚠ CAUTION


Do not cross thread or over tighten the spark plug, or such an operation will damage the aluminum threads of the cylinder head.

Special tool

🔧 (A): 09930-10121 (Spark plug wrench set)

Tightening torque

Spark plug: 11 N·m (1.1 kgf-m, 8.0 lb-ft)




I815H1180009-02

- Install the ignition coil/plug caps and connect their lead wire couplers.

⚠ CAUTION

Do not hit the ignition coil/plug cap with a plastic hammer when installing it.




INCORRECT

I718H1180012-01

NOTE

The coupler of #1 ignition coil/plug cap faces left side.



I815H1180020-02

Spark Plug Inspection and Cleaning

B815H21806002

Refer to "Spark Plug Inspection and Cleaning in Section 0B (Page 0B-9)".


Ignition Coil / Plug Cap Inspection

B815H21806003

Refer to "Electrical Components Location in Section 0A (Page 0A-8)".

Ignition Coil Primary Peak Voltage

- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation in Section 1D (Page 1D-6)".
- 2) Disconnect all ignition coil/plug caps. Refer to "Ignition Coil / Plug Cap and Spark Plug Removal and Installation (Page 1H-6)".



I815H1180022-01


- 3) Connect the new spark plugs to each ignition coil/ spark plug cap.

1H-8 Ignition System:

- 4) Connect all the ignition coil/plug cap lead wire couplers to the ignition coil/plug caps respectively, and ground them on the cylinder head (each spark plug hole).
- ⚠ CAUTION

Avoid grounding the spark plugs and supplying the electrical shock to the cylinder head cover (magnesium parts) to prevent the magnesium material from damage.
- NOTE

Be sure that all the spark plugs are connected properly and the battery used is in fully-charged condition.



I823H1180011-02

1. New spark plug
“A”: Contact the spark plug to the cylinder head.

- 5) Insert the needle pointed probe to the lead wire coupler.
- ⚠ CAUTION


Use the special tool to prevent the rubber of the water proof coupler from damage.
- 6) Connect the multi-circuit tester with the peak voltage adaptor as follows.
- ⚠ CAUTION

Before using the multi-circuit tester and peak voltage adaptor, refer to the appropriate instruction manual.


Special tool
TOOL (A): 09900-25008 (Multi-circuit tester set)
TOOL (B): 09900-25009 (Needle pointed probe set)

Tester knob indication: Voltage (---)

	(+) Probe	(-) Probe
Ignition coil/Plug cap #1	W/BI wire terminal	Ground
Ignition coil/Plug cap #2	Black wire terminal	Ground
Ignition coil/Plug cap #3	Yellow wire terminal	Ground
Ignition coil/Plug cap #4	Green wire terminal	Ground



I718H1180003-02



I823H1180026-01

2. ECM	“B”: (+) probe
3. Peak voltage adaptor	“C”: (-) probe
4. New spark plug	“D”: To engine stop switch
5. Ignition coil	

- 7) Measure the ignition coil primary peak voltage in the following procedures:

⚠ WARNING

Do not touch the tester probes and spark plugs to prevent an electric shock while testing.

- Shift the transmission into neutral, turn the ignition switch ON and grasp the clutch lever.
 - Press the starter button and allow the engine to crank for a few seconds, and then measure the ignition coil primary peak voltage.
- 8) Repeat the b) procedure several times and measure the highest peak voltage.
If the voltage is lower than standard range, inspect the ignition coil/plug cap and the CKP sensor.

Ignition coil primary peak voltage
80 V and more

- 9) After measuring the ignition coil primary peak voltage, reinstall the removed parts.

Ignition Coil / Plug Cap Resistance

- Remove the ignition coil/plug caps. Refer to "Ignition Coil / Plug Cap and Spark Plug Removal and Installation (Page 1H-6)".
- Measure the ignition coil/plug cap for resistance in both primary and secondary coils. If the resistance is not within the standard range, replace the ignition coil/plug cap with a new one.

Special tool

TOOL (A): 09900-25008 (Multi-circuit tester set)


Tester knob indication

Resistance (Ω)


Ignition coil resistance

Primary: 1.0 – 1.9 Ω ((+) terminal – (–) terminal)

Secondary: 10.0 – 16.2 k Ω (Spark plug cap – (–) terminal)



I718H1180005-01



I718H1180006-01

- 3) After measuring the ignition coil/plug cap resistance, reinstall the removed parts.

CKP Sensor Inspection

B815H21806004


Refer to “Electrical Components Location in Section 0A (Page 0A-8)”.

CKP Sensor Peak Voltage

- 1) Lift and support the fuel tank. Refer to “Fuel Tank Removal and Installation in Section 1G (Page 1G-9)”.
- 2) Disconnect the CKP sensor coupler (1).

NOTE

Be sure that all of the couplers are connected properly and the battery is fully-charged.



I815H1180011-01

- 3) Connect the multi-circuit tester with the peak volt adaptor as follows.

CAUTION


Before using the multi-circuit tester and peak voltage adaptor, refer to the appropriate instruction manual.

Special tool

 (A): 09900-25008 (Multi-circuit tester set)

Tester knob indication: Voltage (---)

CKP sensor	(+) Probe	(-) Probe
	BI	G



I815H1180023-01

1. CKP sensor coupler	3. Peak voltage adaptor
2. CKP sensor	

- 4) Measure the CKP sensor peak voltage in the following procedures:
 - a) Shift the transmission into neutral, turn the ignition switch ON and grasp the clutch lever.
 - b) Press the starter button and allow the engine to crank for a few seconds, and then measure the CKP sensor peak voltage.
- 5) Repeat the b) procedure several times and measure the highest CKP sensor peak voltage.

CKP sensor peak voltage

3.0 V and more (BI – Green)

- 6) If the peak voltage is within the specification, check the continuity between the CKP sensor coupler and ECM coupler.


CAUTION

Normally, use the needle pointed probe to the backside of the lead wire coupler to prevent the terminal bend and terminal alignment.

- 7) After measuring the CKP sensor peak voltage, connect the CKP sensor coupler.

CKP Sensor Resistance

- 1) Lift and support the fuel tank. Refer to “Fuel Tank Removal and Installation in Section 1G (Page 1G-9)”.
- 2) Disconnect the CKP sensor coupler (1).




I815H1180011-01

- 3) Measure the resistance between the lead wires and ground. If the resistance is not within the standard range, replace the CKP sensor with a new one. Refer to “CKP Sensor Removal and Installation (Page 1H-11)”.

Tester knob indication
Resistance (Ω)

CKP sensor resistance
180 – 280 Ω (BI – Green)
∞ Ω (BI – Ground)



I815H1180024-01

1. CKP sensor coupler	2. CKP sensor
-----------------------	---------------

- 4) After measuring the CKP sensor resistance, connect the CKP sensor coupler.
- 5) Reinstall the fuel tank. Refer to “Fuel Tank Removal and Installation in Section 1G (Page 1G-9)”.

CKP Sensor Removal and Installation

B815H21806005


Refer to “Generator Removal and Installation in Section 1J (Page 1J-6)”.

Engine Stop Switch Inspection

B815H21806006

Inspect the engine stop switch in the following procedures:

- 1) Turn the ignition switch OFF.
- 2) Remove the left upper panel. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.
- 3) Disconnect the right handlebar switch coupler (1).



I815H1180010-01

- 4) Inspect the engine stop switch for continuity with a tester.
If any abnormality is found, replace the right handlebar switch assembly with a new one. Refer to “Handlebar Removal and Installation in Section 6B (Page 6B-3)”.

Special tool
TOOL : 09900-25008 (Multi-circuit tester set)

Tester knob indication
Continuity (•))

Color	O/B	O/W
Position		
OFF (X)		
RUN (C)		

I815H1180012-01

- 5) After finishing the engine stop switch inspection, reinstall the removed parts.

Ignition Switch Inspection

B815H21806007

Refer to "Ignition Switch Inspection in Section 9C (Page 9C-8)".

Ignition Switch Removal and Installation

B815H21806008


Removal

- 1) Remove the upper cover and body cowling cover.
Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Disconnect the ignition switch lead wire coupler (1).



I815H1180013-01

- 3) Release the ignition switch lead wires from its clamps (2).




I815H1180014-01

- 4) Remove the ignition switch (3) with the special tools.

Special tool

 (A): 09930-11920 (Torx bit (JT40H))

 (B): 09930-11940 (Bit holder)



I815H1180015-01

Installation

Install the ignition switch in the reverse order of removal. Pay attention to the following points:

- Tighten the ignition switch mounting bolts (1), right and left with the special tools.

CAUTION


When reusing the ignition switch bolts, clean the threaded part and apply a thread lock to them.

Special tool

 (A): 09930-11920 (Torx bit (JT40H))

 (B): 09930-11940 (Bit holder)

 : Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER 1322 or equivalent)



I815H1180016-01

Drive Mode Selector Inspection

B815H21806009

Inspect the drive mode selector in the following procedures:


- 1) Set up the SDS tool. (Refer to the SDS operation manual for further details.)
- 2) Turn the ignition switch ON.
- 3) Click "Date monitor".
- 4) Make sure each of "Driving mode selection" on the monitor is indicated "Open".

Item	Value	Unit
☐ Gear position	N	
☐ Driving mode selection 1	Open	
☐ Driving mode selection 2	Open	
☐ Engine coolant / oil tempera...	55.3	°C


I823H1180029-02

- 5) Push each of drive mode selector (1) and (2). At this time, if the indication is changed to "GND", the function is normal.

Item	Value	Unit
☐ Gear position	N	
☐ Driving mode selection 1	GND	
☐ Driving mode selection 2	Open	
☐ Engine coolant / oil tempera...	56.0	°C



Item	Value	Unit
☐ Gear position	N	
☐ Driving mode selection 1	Open	
☐ Driving mode selection 2	GND	
☐ Engine coolant / oil tempera...	55.3	°C



I815H1180021-01

1H-14 Ignition System:

Immobilizer Antenna Removal and Installation (For E-02, 19, 24)

B815H21806010


Removal

- 1) Turn the ignition switch OFF.
- 2) Remove the upper cover and body cowling cover.
Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 3) Disconnect the immobilizer antenna lead wire coupler (1).



I815H1180017-01

- 4) Remove the ignition switch. Refer to "Ignition Switch Removal and Installation (Page 1H-12)".
- 5) Remove the immobilizer antenna (2).



I815H1180018-01

Installation

Install the immobilizer antenna in the reverse order of removal.

Specifications

Service Data

B815H21807001

Electrical

Unit: mm (in)

Item	Specification		Note
Firing order	1 · 2 · 4 · 3		
Spark plug	Type	NGK: CR9EIA-9 DENSO: IU27D	
	Gap	0.8 – 0.9 (0.031 – 0.035)	
Spark performance	Over 8 (0.3) at 1 atm.		
CKP sensor resistance	180 – 280 Ω		
CKP sensor peak voltage	3.0 V and more		
Ignition coil resistance	Primary	1.0 – 1.9 Ω	Terminal – Terminal
	Secondary	10.0 – 16.2 k Ω	Plug cap – Terminal
Ignition coil primary peak voltage	80 V and more		When cranking

Tightening Torque Specifications

B815H21807002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Spark plug	11	1.1	8.0	☞ (Page 1H-6)

Reference:

For the tightening torque of fastener not specified in this section, refer to "Tightening Torque List in Section 0C (Page 0C-9)".

Special Tools and Equipment






Recommended Service Material

B815H21808001

Material	SUZUKI recommended product or Specification		Note
Thread lock cement	THREAD LOCK CEMENT SUPER 1322 or equivalent	P/No.: 99000-32110	☞ (Page 1H-12)

Special Tool

B815H21808002

09900-25008 Multi-circuit tester set ☞ (Page 1H-8) / ☞ (Page 1H-9) / ☞ (Page 1H-10) / ☞ (Page 1H-11)		09900-25009 Needle pointed probe set ☞ (Page 1H-8)	
09930-10121 Spark plug wrench set ☞ (Page 1H-6) / ☞ (Page 1H-6)		09930-11920 Torx bit (JT40H) ☞ (Page 1H-12) / ☞ (Page 1H-12)	
09930-11940 Bit holder ☞ (Page 1H-12) / ☞ (Page 1H-12)			


Starting System

Schematic and Routing Diagram

Starting System Diagram

B815H21902001

Refer to “Wire Color Symbols in Section 0A (Page 0A-6)”.



Component Location

Starting System Components Location

B815H21903001

Refer to “Electrical Components Location in Section 0A (Page 0A-8)”.

Diagnostic Information and Procedures

Starting System Symptom Diagnosis

B815H21904001

Condition	Possible cause	Correction / Reference Item
Engine does not turn though the starter motor runs	Faulty starter clutch.	<i>Replace.</i>
Starter button is not effective	Run down battery.	<i>Repair or replace.</i>
	Defective switch contacts.	<i>Replace.</i>
	Brushes not seating properly on starter motor commutator.	<i>Repair or replace.</i>
	Defective starter relay or starter interlock switch.	<i>Replace.</i>
	Defective main fuse.	<i>Replace.</i>

Starter Motor Will Not Run

B815H21904002

NOTE

Make sure the fuses are not blown and the battery is fully-charged before diagnosing.

Troubleshooting

Step	Action	Yes	No
1	1) Shift the transmission into neutral. 2) Grasp the clutch lever, turn on the ignition switch with the engine stop switch in the "RUN" position and listen for a click from the starter relay when the starter button is pushed. <i>Is the click sound heard?</i>	Go to Step 2.	Go to Step 3.
2	Check if the starter motor runs when its terminal is connected to the battery (+) terminal. (Do not use thin "wire" because a large amount of current flows.) <i>Does the starter motor run?</i>	<ul style="list-style-type: none"> Faulty starter relay. Loose or disconnected starter motor lead wire. Loose or disconnected between starter relay and battery (+) terminal. 	Faulty starter motor.
3	Measure the starter relay voltage at the starter relay terminal (between Y/G (+) and B/Y (-)) when the starter button is pushed. <i>Is the voltage OK?</i>	Go to Step 4.	<ul style="list-style-type: none"> Faulty ignition switch. Faulty engine stop switch. Faulty clutch lever position switch. Faulty gear position switch. Faulty turn signal/ side-stand relay. Faulty starter button. Faulty side-stand switch. Poor contact of the coupler. Open circuit in wire harness.
4	Check the starter relay. Refer to "Starter Relay Inspection (Page 1I-7)". <i>Is the starter relay OK?</i>	Poor contact of the starter relay.	Faulty starter relay.

Starter Motor Runs But Does Not Crank The Engine

B815H21904003


The starter motor runs when the transmission is in neutral, but does not run when the transmission is in any position other than neutral, with the side-stand up.

Step	Action	Yes	No
1	Check the side-stand switch. Refer to "Side-stand / Ignition Interlock System Parts Inspection (Page 1I-8)". <i>Is the side-stand switch OK?</i>	Go to Step 2.	Faulty side-stand switch.
2	Check the starter clutch. Refer to "Starter Clutch Inspection (Page 1I-12)". <i>Is the starter clutch OK?</i>	<ul style="list-style-type: none"> Open circuit in wire harness. Poor contact of connector. 	Faulty starter clutch.

Repair Instructions

Starter Motor Components

B815H21906001



I823H1190037-06


1. O-ring	5. O-ring	⌚(a) : 5 N·m (0.5 kgf-m, 3.5 lb-ft)
2. Housing end (Inside)	6. Starter motor case	⌚(b) : 6 N·m (0.6 kgf-m, 4.5 lb-ft)
3. O-ring	7. Housing end assembly (Outside)	⌚AH : Apply grease to sliding surface.
4. Armature	8. Starter motor lead wire nut	⊗ : Do not reuse.

Starter Motor Removal and Installation

B815H21906002

Removal

- 1) Turn the ignition switch OFF and disconnect the battery (–) lead wire. Refer to “Battery Removal and Installation in Section 1J (Page 1J-14)”.
- 2) Remove the throttle body. Refer to “Throttle Body Removal and Installation in Section 1D (Page 1D-10)”.
- 3) Disconnect the starter motor lead wire (1).
- 4) Remove the starter motor (2).



I815H1190002-01

Installation

Install the starter motor in the reverse order of removal. Pay attention to the following points:

- Apply grease to the O-ring.

 **Grease 99000–25010 (SUZUKI SUPER GREASE A or equivalent)**

CAUTION

Replace the O-ring with a new one.



I815H1190003-01

- Install the starter motor. Refer to “Wiring Harness Routing Diagram in Section 9A (Page 9A-5)”.

Starter Motor Disassembly and Assembly

B815H21906003

Refer to “Starter Motor Removal and Installation (Page 1I-4)”.

Disassembly

Disassemble the starter motor as shown in the starter motor components diagram. Refer to “Starter Motor Components (Page 1I-3)”.

Assembly

Reassemble the starter motor in the reverse order of removal. Pay attention to the following points:

CAUTION

Replace the O-rings with new ones to prevent oil leakage and moisture.

- Apply grease to the lip of the oil seal.

 **Grease 99000–25010 (SUZUKI SUPER GREASE A or equivalent)**



I823H1190003-01

- Apply grease to the bearing.

 **Grease 99000–25010 (SUZUKI SUPER GREASE A or equivalent)**



I823H1190004-02

- Align the match marks on the starter motor case with the match mark on each housing end.

1I-5 Starting System:

- Tighten the starter motor housing bolts to the specified torque.

Tightening torque

Starter motor housing bolt (a): 5 N·m (0.5 kgf-m, 3.5 lb-ft)



I823H1190005-02



I823H1190006-01

Starter Motor Inspection

B815H21906004

Refer to "Starter Motor Disassembly and Assembly (Page 1I-4)".

Carbon Brush

Inspect the carbon brushes for abnormal wear, cracks or smoothness in the brush holder.

If either carbon brush is defective, replace the brush holder set with a new one.


Measure the length "a" of the carbon brushes using a vernier calipers. If the measurement is less than the service limit, replace the housing end assembly (outside) with a new one.

Brush length "a"

Service limit: 8.5 mm (0.33 in)

Special tool

TOOL : 09900-20102 (Vernier calipers (1/20 mm, 200 mm))



I718H1190013-01


Commutator

Inspect the commutator for discoloration, abnormal wear or undercut "A".

If the commutator is abnormally worn, replace the armature assembly.

If the commutator surface is discolored, polish it with #400 sandpaper and wipe it using a clean, dry cloth.

If there is no undercut, scrape out the insulator (1) with a saw blade.



I823H1190007-01

Armature Coil

Inspect for continuity between each segment.

Inspect for continuity between each segment and the armature shaft.


If there is no continuity between the segments or there is continuity between the segments and shaft, replace the armature assembly with a new one.

Special tool

 (A): 09900-25008 (Multi-circuit tester set)

Tester knob indication

Continuity set (•))




I823H1190008-01

Bearing

Check the bearings for damage.

If any damage is found, replace the armature assembly with a new one.



I823H1190033-01

Oil Seal

Check the seal lip for damage.

If any damage is found, replace the housing end (inside).




I823H1190034-01

Starter Relay Removal and Installation

B815H21906005


Removal

- 1) Turn the ignition switch OFF.
- 2) Disconnect the battery (–) lead wire from the battery.
- 3) Remove the frame cover. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.
- 4) Remove the starter relay cover (1) and disconnect the starter relay coupler (2) .



I815H1190004-01

- 5) Disconnect the starter motor lead wire (3) and battery (+) lead wire (4).
- 6) Remove the starter relay (5).



I815H1190005-03

Installation

Install the starter relay in the reverse order of removal.

Starter Relay Inspection

B815H21906006

Inspect the starter relay in the following procedures:

- 1) Remove the starter relay. Refer to "Starter Relay Removal and Installation (Page 1I-6)".
- 2) Apply 12 V to "A" and "B" terminals and check for continuity between the positive and negative terminals using the multi-circuit tester. If the starter relay clicks and continuity is found, the relay is ok.

⚠ CAUTION


Do not apply battery voltage to the starter relay for five seconds and more, since the relay coil may overheat and get damaged.

Special tool


 (A): 09900-25008 (Multi-circuit tester set)

Tester knob indication

Continuity test (•)))



I649G1190021-04



I823H1190040-02


- 3) Measure the relay coil resistance between the terminals using the multi-circuit tester. If the resistance is not within the specified value, replace the starter relay with a new one.

Special tool

 (A): 09900-25008 (Multi-circuit tester set)

Starter relay resistance

3 – 5 Ω



I649G1190023-03


- 4) Install the starter relay. Refer to "Starter Relay Removal and Installation (Page 1I-6)".

Turn Signal / Side-stand Relay Removal and Installation

B815H21906007

Removal

- 1) Turn the ignition switch OFF.
- 2) Remove the left upper panel. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 3) Remove the turn signal/side-stand relay (1).



I815H1190006-01

Installation

Install the turn signal/side-stand relay in the reverse order of removal.


Side-stand / Ignition Interlock System Parts Inspection

B815H21906008

Check the interlock system for proper operation. If the interlock system does not operate properly, check each component for damage or abnormalities. If any abnormality is found, replace the component with a new one.

Side-stand Switch

- 1) Turn the ignition switch OFF.
- 2) Remove the left side cowling. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 3) Disconnect the side-stand switch coupler (1).



I815H1190007-01

- 4) Measure the voltage between G and B/W lead wires.

Special tool

TOOL : 09900-25008 (Multi-circuit tester set)

Tester knob indication

Diode test ($\rightarrow \leftarrow$)

	G (+) probe)	B/W (-) probe)
ON (Side-stand up)	0.4 – 0.6 V	
OFF (Side-stand down)	1.4 V and more (Tester's battery voltage)	

NOTE

If the tester reads 1.4 V and below when the tester probes are not connected, replace its battery.




I815H1190008-01

- 5) Connect the side-stand switch coupler.
- 6) Install the left side cowling. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".

Turn Signal / Side-stand Relay

The turn signal/side-stand relay is composed of the turn signal relay, side-stand relay and diode.



I649G1190027-02

Side-stand relay



- 1) Remove the turn signal/side-stand relay. Refer to "Turn Signal / Side-stand Relay Removal and Installation (Page 1I-7)".
- 2) Check the insulation between "D" and "E" terminals using the multi-circuit tester.
- 3) Apply 12 V to terminals "D" and "C" ((+) to "D" and (-) to "C") and check the continuity between "D" and "E". If there is no continuity, replace the turn signal/side-stand relay with a new one.

Special tool

TOOL : 09900-25008 (Multi-circuit tester set)

Tester knob indication

Continuity test ($\bullet$)



I649G1190028-02

1I-9 Starting System:


- 4) Install the turn signal/side-stand relay. Refer to “Turn Signal / Side-stand Relay Removal and Installation (Page 1I-7)”.

Diode inspection

- 1) Remove the turn signal/side-stand relay. Refer to “Turn Signal / Side-stand Relay Removal and Installation (Page 1I-7)”.
- 2) Measure the voltage between the “A”, “B” and “C” terminals using the multi-circuit tester.

Special tool
 : 09900–25008 (Multi-circuit tester set)

Tester knob indication
Diode test ()



I649G1190029-02

⊕ Probe of tester to:			
① Probe of tester to:		"B", "C"	"A"
	"B", "C"	—	1.4 V and more (Tester's battery voltage)
	"A"	0.4 – 0.6 V	—

I649G1190046-04


- NOTE**
- If the multi circuit tester reads 1.4 V and below when the tester probes are not connected, replace its battery.**
- 3) Install the turn signal/side-stand relay. Refer to “Turn Signal / Side-stand Relay Removal and Installation (Page 1I-7)”.

Gear Position Switch

- 1) Lift and support the fuel tank. Refer to “Fuel Tank Removal and Installation in Section 1G (Page 1G-9)”.
- 2) Disconnect the gear position switch coupler (1).

⚠ CAUTION

When disconnecting and connecting the gear position switch coupler, make sure to turn off the ignition switch, or electronic parts may get damaged.



I823H1110072-01

- 3) Check the continuity between BI and B lead wires with the transmission in “neutral”.

Special tool
 : 09900–25008 (Multi-circuit tester set)

Tester knob indication
Continuity test ()

	BI	B
ON (Neutral)		
OFF (Except neutral)		

I823H1190016-01

- 4) Connect the gear position switch coupler to the wiring harness.
- 5) Insert the needle pointed probes to the lead wire coupler.
- 6) Turn the ignition switch ON and side-stand to upright position.

- 7) Measure the voltage between R and B lead wires using the multi-circuit tester when shifting the gearshift lever from low to top.

Special tool

TOOL (A): 09900-25008 (Multi-circuit tester set)


TOOL (B): 09900-25009 (Needle pointed probe set)

Tester knob indication

Voltage (---)

Gear position switch voltage (Except neutral position)

0.6 V and more ((+) R - (-) B)



I823H1110073-02


- 8) Turn the ignition switch OFF.
9) Install the removed parts.

Starter Torque Limiter / Starter Clutch Removal and Installation

B815H21906009


Removal

- 1) Drain engine oil.
- 2) Remove the right side cowling. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 3) Remove the starter torque limiter cover (1).



I815H1190009-01

- 4) Remove the gasket (2) and dowel pins.
- 5) Remove the starter torque limiter (3) and its shaft (4).




I815H1190010-01

- 6) Remove the starter clutch cover (5).



I815H1190011-02

- 7) Remove the gasket (6) and dowel pins.
- 8) Remove the wave washer (7), starter idle gear (8) and its shaft (9).




I815H1190012-01

1I-11 Starting System:

- 9) Hold the starter clutch with the special tool.
- 10) Remove the starter clutch.

Special tool

TOOL (A): 09920-34830 (Starter clutch holder)



I815H1190013-01

Installation

Installation is in the reverse order of removal. Pay attention to the following points:

⚠ CAUTION

Replace the gaskets with new ones to prevent oil leakage.

- When installing the starter clutch, align the wide spline tooth of starter clutch with that of crankshaft.



I815H1190014-03


- With the starter clutch held immovable using the special tool, tighten the starter clutch bolt to the specified torque.

Special tool

TOOL (A): 09920-34830 (Starter clutch holder)

Tightening torque

Starter clutch bolt: 55 N·m (5.5 kgf-m, 40.0 lb-ft)



I815H1190015-01


- Apply a bond lightly to the mating surfaces at the parting line between the upper and lower crankcases.

1207B : Sealant 99000-31140 (SUZUKI BOND No.1207B or equivalent)

- Apply grease to the starter motor O-ring.


FAH : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)

- Fit a new gasket.



I815H1190016-01

- Fit the new gasket to the bolt "A" and clamp to the bolt "B".
- Fit a new gasket (1).



I815H1190017-02

Starter Torque Limiter Inspection

B815H21906010

CAUTION

- Do not attempt to disassemble the starter torque limiter.
- The starter torque limiter is available only as an assembly part.

- 1) Hold the starter torque limiter with the special tools and vise.

Special tool


 (A): 09930-73170 (Starter torque limiter holder)

 (B): 09930-73140 (Starter torque limiter socket)

- 2) Turn the starter torque limiter with a torque wrench and check the slip torque. If the slip torque is not within the specification, replace the starter torque limiter with a new one.

Starter torque limiter slip torque

Standard: 33.3 – 52.0 N·m (3.3 – 5.2 kgf-m, 24.0 – 37.5 lb-ft)



I823H1190028-01

Starter Clutch Inspection

B815H21906011

Refer to “Starter Torque Limiter / Starter Clutch Removal and Installation (Page 1I-10)”.

Starter Clutch

- 1) Install the starter driven gear onto the starter clutch.
- 2) Turn the starter driven gear by hand to inspect the starter clutch for a smooth movement. The gear turns in one direction only. If a large resistance is felt for rotation, inspect the starter clutch or the starter clutch contacting surface on the starter driven gear for wear or damage.

If they are found to be damaged, replace them with new ones.



I823H1190029-01

Starter Clutch Bearing and Starter Driven Gear

Inspect the starter clutch bearing and starter clutch contacting surface on the starter driven gear for wear and damage. If they are found to be damaged, replace them with new ones.



I823H1190030-01



I823H1190031-03


1I-13 Starting System:

Starter Button Inspection

B815H21906012

Inspect the starter button in the following procedures:

- 1) Remove the left upper panel. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.
- 2) Disconnect the right handlebar switch coupler (1).



I815H1190018-01

- 3) Inspect the starter button for continuity with the tester.

If any abnormality is found, replace the right handle switch assembly with a new one. Refer to “Handlebar Removal and Installation in Section 6B (Page 6B-3)”.

Special tool

 : 09900-25008 (Multi-circuit tester set)

Tester knob indication

Continuity (•)))

Color Position	O/W	Y/G	O/R	Y/W
•			○	○
PUSH	○	○		

I815H1190019-01

- 4) After finishing the starter button inspection, reinstall the removed parts.

Specifications

Service Data

B815H21907001

Electrical

Unit: mm

Item	Specification		Note
Starter motor brush length	Standard	12.0 (0.47)	
	Limit	8.5 (0.33)	
Starter torque limiter slip torque	Standard	33.3 – 52.0 N·m (3.3 – 5.2 kgf-m, 24.0 – 37.5 lb-ft)	
Starter relay resistance		3 – 5 Ω	

Tightening Torque Specifications

B815H21907002

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
Starter motor housing bolt	5	0.5	3.5	☞ (Page 1I-5)
Starter clutch bolt	55	5.5	40.0	☞ (Page 1I-11)

NOTE

The specified tightening torque is also described in the following.

“Starter Motor Components (Page 1I-3)”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Tightening Torque List in Section 0C (Page 0C-9)”.

Special Tools and Equipment

Recommended Service Material

B815H21908001







Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI SUPER GREASE A or equivalent	P/No.: 99000-25010	☞ (Page 1I-4) / ☞ (Page 1I-4) / ☞ (Page 1I-4) / ☞ (Page 1I-11)
Sealant	SUZUKI BOND No.1207B or equivalent	P/No.: 99000-31140	☞ (Page 1I-11)

NOTE

Required service material is also described in the following.
 “Starter Motor Components (Page 1I-3)”

Special Tool

B815H21908002


09900-20102 Vernier calipers (1/20 mm, 200 mm) ☞ (Page 1I-5)		09900-25008 Multi-circuit tester set ☞ (Page 1I-6) / ☞ (Page 1I-7) / ☞ (Page 1I-7) / ☞ (Page 1I-8) / ☞ (Page 1I-8) / ☞ (Page 1I-9) / ☞ (Page 1I-9) / ☞ (Page 1I-10) / ☞ (Page 1I-13)	
09900-25009 Needle pointed probe set ☞ (Page 1I-10)		09920-34830 Starter clutch holder ☞ (Page 1I-11) / ☞ (Page 1I-11)	
09930-73140 Starter torque limiter socket ☞ (Page 1I-12)		09930-73170 Starter torque limiter holder ☞ (Page 1I-12)	

Charging System

Schematic and Routing Diagram

Charging System Diagram

B815H21A02001



I718H11A0001-01

Component Location

Charging System Components Location

Refer to "Electrical Components Location in Section 0A (Page 0A-8)".

B815H21A03001

Diagnostic Information and Procedures

Charging System Symptom Diagnosis

B815H21A04001

Condition	Possible cause	Correction / Reference Item
Generator does not charge	Open- or short-circuited lead wires, or loose lead connections.	<i>Repair, replace or connect properly.</i>
	Short-circuited, grounded or open generator coil.	<i>Replace.</i>
	Short-circuited or punctured regulator/rectifier.	<i>Replace.</i>
Generator does charge, but charging rate is below the specification	Lead wires tend to get short- or open-circuited or loosely connected at terminals.	<i>Repair or retighten.</i>
	Grounded or open-circuited generator coil.	<i>Replace.</i>
	Defective regulator/rectifier.	<i>Replace.</i>
	Defective cell plates in the battery.	<i>Replace the battery.</i>
Generator overcharges	Internal short-circuit in the battery.	<i>Replace the battery.</i>
	Damaged or defective regulator/rectifier.	<i>Replace.</i>
	Poorly grounded regulator/rectifier.	<i>Clean and tighten ground connection.</i>
Unstable charging	Lead wire insulation frayed due to vibration, resulting in intermittent short-circuiting.	<i>Repair or replace.</i>
	Internally short-circuited generator.	<i>Replace.</i>
	Defective regulator/rectifier.	<i>Replace.</i>

Condition	Possible cause	Correction / Reference Item
Battery overcharges	Faulty regulator/rectifier.	<i>Replace.</i>
	Faulty battery.	<i>Replace.</i>
	Poor contact of generator lead wire coupler.	<i>Repair.</i>
Battery runs down quickly	Trouble in charging system.	<i>Check the generator, regulator/rectifier and circuit connections and make necessary adjustments to obtain specified charging operation.</i>
	Cell plates have lost much of their active materials a result of overcharging.	<i>Replace the battery and correct the charging system.</i>
	Internal short-circuit in the battery.	<i>Replace the battery.</i>
	Too low battery voltage.	<i>Recharge the battery fully.</i>
	Too old battery.	<i>Replace the battery.</i>
Battery "sulfation"	Incorrect charging rate. (When not in use battery should be checked at least once a month to avoid sulfation.)	<i>Replace the battery.</i>
	The battery was left unused in a cold climate for too long.	<i>Replace the battery if badly sulfated.</i>

Battery Runs Down Quickly

B815H21A04002


Troubleshooting

Step	Action	Yes	No
1	Check accessories which use excessive amounts of electricity. <i>Are accessories being installed?</i>	Remove accessories.	Go to Step 2.
2	Check the battery for current leakage. Refer to "Battery Current Leakage Inspection (Page 1J-4)". <i>Is the battery for current leakage OK?</i>	Go to Step 3.	<ul style="list-style-type: none"> • Short circuit of wire harness. • Faulty electrical equipment.
3	Measure the regulated voltage between the battery terminals. Refer to "Regulated Voltage Inspection (Page 1J-4)". <i>Is the regulated voltage OK?</i>	<ul style="list-style-type: none"> • Faulty battery. • Abnormal driving condition. 	Go to Step 4.
4	Measure the resistance of the generator coil. Refer to "Generator Inspection (Page 1J-5)". <i>Is the resistance of generator coil OK?</i>	Go to Step 5.	<ul style="list-style-type: none"> • Faulty generator coil. • Disconnected lead wires.
5	Measure the generator no-load performance. Refer to "Generator Inspection (Page 1J-5)". <i>Is the generator no-load performance OK?</i>	Go to Step 6.	Faulty generator.
6	Inspect the regulator/rectifier. Refer to "Regulator / Rectifier Inspection (Page 1J-10)". <i>Is the regulator/rectifier OK?</i>	Go to Step 7.	Faulty regulator/rectifier.
7	Inspect wirings. <i>Is the wirings OK?</i>	Faulty battery.	<ul style="list-style-type: none"> • Short circuit of wire harness. • Poor contact of couplers.

Repair Instructions

Battery Cushion Rubber Attachment Construction

B815H21A06001



"a": 25 mm (1.0 in)	"b": 30 mm (1.2 in)
---------------------	---------------------

I815H11A0001-06

Battery Current Leakage Inspection

B815H21A06002

Inspect the battery current leakage in the following procedures:

- 1) Turn the ignition switch OFF.
- 2) Remove the seat. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 3) Disconnect the battery (-) lead wire.
- 4) Measure the current between battery (-) terminal and the battery (-) lead wire using the multi-circuit tester. If the reading exceeds the specified value, leakage is evident.

⚠ CAUTION

- In case of a large current leak, turn the tester to high range first to avoid tester damage.
- Do not turn the ignition switch ON when measuring current.

Special tool


 (A): 09900-25008 (Multi-circuit tester set)

Tester knob indication

Current (---, 20 mA)

Battery current (Leak)

Under 3 mA



I649G11A0002-02

- 5) Connect the battery (-) terminal and install the seat. Refer to "Battery Removal and Installation (Page 1J-14)" and "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".

Regulated Voltage Inspection

B815H21A06003

Inspect the regulated voltage in the following procedures:

- 1) Remove the seat. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Start the engine and keep it running at 5 000 r/min with the dimmer switch turned HI position.
- 3) Measure the DC voltage between the battery (+) and (-) terminals using the multi-circuit tester. If the voltage is not within the specified value, inspect the generator and regulator/rectifier. Refer to "Generator Inspection (Page 1J-5)" and "Regulator / Rectifier Inspection (Page 1J-10)".

NOTE

When making this test, be sure that the battery is in fully charged condition.

Special tool


 (A): 09900-25008 (Multi-circuit tester set)

Tester knob indication

Voltage (---)

Regulated voltage (Charging output)

Standard: 13.5 – 15.5 V at 5 000 r/min



I649G11A0003-02


- 4) Install the seat. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".

Generator Inspection

B815H21A06004

Generator Coil Resistance

- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".
- 2) Disconnect the generator coupler (1).



I815H11A0002-01

- 3) Measure the resistance between the three lead wires.
If the resistance is out of specified value, replace the stator with a new one. Also, check that the generator core is insulated properly.

NOTE

When making this test, be sure that the battery is in fully charged condition.

Special tool

 : 09900-25008 (Multi-circuit tester set)


Tester knob indication

Resistance (Ω)

Generator coil resistance

0.2 – 0.7 Ω (B – B)

∞ Ω (B – Ground)




I718H11A0005-02

- 4) Connect the generator coupler.
- 5) Install the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".

No-load Performance

- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".
- 2) Disconnect the generator coupler (1).



I815H11A0002-01

- 3) Start the engine and keep it running at 5 000 r/min.
- 4) Using the multi-circuit tester, measure the voltage between three lead wires.
If the tester reads under the specified value, replace the generator with a new one.

Special tool


 : 09900-25008 (Multi-circuit tester set)

Tester knob indication

Voltage ($\sim$)

Generator no-load performance (When engine is cold)

70 V (AC) and more at 5 000 r/min



I718H11A0006-02


- 5) Connect the generator coupler.
- 6) Install the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".

Generator Removal and Installation

B815H21A06005


Removal

- 1) Disconnect the battery (–) lead wire. Refer to “Battery Removal and Installation (Page 1J-14)”.
- 2) Drain engine oil. Refer to “Engine Oil and Filter Replacement in Section 0B (Page 0B-10)”.
- 3) Remove the left side cowling. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.
- 4) Lift and support the fuel tank.
- 5) Disconnect the CKP sensor coupler (1) and generator coupler (2).




I815H11A0003-01

- 6) Remove the generator cover (3).



I815H11A0004-01

- 7) Remove the gasket (4) and dowel pins (5).




I815H11A0005-01

- 8) Hold the generator rotor with the special tool.

Special tool

TOOL (A): 09930-44530 (Rotor holder)

- 9) Remove the generator rotor bolt and washer.




I815H11A0006-02

- 10) Remove the generator rotor (6) with the special tool.

Special tool

TOOL (A): 09930-44530 (Rotor holder)


TOOL (B): 09930-30450 (Rotor remover bolt)



I815H11A0007-01


1J-7 Charging System:

11) Remove the key (7).



I815H11A0008-01

12) Remove the generator stator (8) along with the CKP sensor (9).



I815H11A0009-01

Installation

Install the generator in the reverse order of removal. Pay attention to the following points:

- Tighten the generator stator set bolts and CKP sensor mounting bolts to the specified torque.


NOTE

Be sure the grommet (1) is set to the generator cover.

Tightening torque


Generator stator set bolt (a): 11 N·m (1.1 kgf-m, 8.0 lb-ft)

CKP sensor mounting bolt (b): 6.5 N·m (0.65 kgf-m, 4.7 lb-ft)



I823H11A0012-01

- Degrease the tapered portion "A" of generator rotor and also the crankshaft "B". Use nonflammable cleaning solvent to wipe off oily or greasy matter and make these surfaces completely dry.
- Fit the key (2) in the key slot on the crankshaft.
- Install the generator rotor onto crankshaft.



I815H11A0010-01


- Install the rotor bolt with the washer.
- Hold the generator rotor with the special tool and tighten its bolt (3) to the specified torque.

Special tool

TOOL (A): 09930-44530 (Rotor holder)

Tightening torque

Generator rotor bolt (c): 120 N·m (12.0 kgf-m, 87.0 lb-ft)



I815H11A0011-01

- Apply a bond lightly to the mating surfaces at the parting line between the upper and lower crankcases as shown.

1207B : Sealant 99000-31140 (SUZUKI BOND No.1207B or equivalent)




I815H11A0012-01

- Install the dowel pins (4) and new gasket (5).

⚠ CAUTION

Use a new gasket to prevent oil leakage.




I815H11A0013-01

- Install the generator cover (6) and tighten the generator cover bolts.

⚠ WARNING


Be careful not to pinch the finger between the generator cover and crankcase.



I815H11A0014-01

Regulator / Rectifier Construction

B815H21A06006



I815H11A0015-01

1. Regulator/Rectifier	"a": 15 mm (0.6 in)
2. Clamp	"b": 50 mm (2.0 in)
3. Bracket	"c": 30 mm (1.2 in)
4. Protection tape : Before adhering the protection tape, clean its adhesive surface of the frame.	(a) : 10 N·m (1.0 kgf-m, 7.0 lb-ft)
5. Welded seam	

Regulator / Rectifier Removal and Installation

B815H21A06007

Removal

- 1) Turn the ignition switch OFF.
- 2) Remove the rear under cowling. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 3) Disconnect the regulator/rectifier couplers.
- 4) Remove the regulator/rectifier as shown in the regulator/rectifier construction. Refer to "Regulator / Rectifier Construction (Page 1J-9)".

Installation

Install the regulator/rectifier as shown in the regulator/rectifier construction. Refer to "Regulator / Rectifier Construction (Page 1J-9)".

Regulator / Rectifier Inspection

B815H21A06008

Inspect the regulator/rectifier in the following procedures:

- 1) Turn the ignition switch OFF.
- 2) Remove the rear under cowling. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 3) Disconnect the regulator/rectifier couplers as shown in the regulator/rectifier construction. Refer to "Regulator / Rectifier Construction (Page 1J-9)".
- 4) Measure the voltage between the terminals using the multi-circuit testers as indicated in the following table. If the voltage is not within the specified value, replace the regulator/rectifier with a new one. Refer to "Regulator / Rectifier Construction (Page 1J-9)".

NOTE


If the tester reads 1.4 V and below when the tester probes are not connected, replace its battery.

Special tool

 : 09900-25008 (Multi-circuit tester set)

Tester knob indication

Diode test ()



I823H11A0020-04


Unit: V

		(+) probe of tester to:						
		B/R ₁	B/R ₂	B ₁	B ₂	B ₃	B/W ₁	B/W ₂
(-) probe of tester to:	B/R ₁	—	0	0.1 – 0.8	0.1 – 0.8	0.1 – 0.8	0.2 – 0.9	0.2 – 0.9
	B/R ₂	0	—	0.1 – 0.8	0.1 – 0.8	0.1 – 0.8	0.2 – 0.9	0.2 – 0.9
	B ₁	*	*	—	0.5 – 1.2	0.5 – 1.2	0.1 – 0.8	0.1 – 0.8
	B ₂	*	*	0.5 – 1.2	—	0.5 – 1.2	0.1 – 0.8	0.1 – 0.8
	B ₃	*	*	0.5 – 1.2	0.5 – 1.2	—	0.1 – 0.8	0.1 – 0.8
	B/W ₁	*	*	0.3 – 1.0	0.3 – 1.0	0.3 – 1.0	—	0
	B/W ₂	*	*	0.3 – 1.0	0.3 – 1.0	0.3 – 1.0	0	—
*1.4 V and more (tester's battery voltage)								

- 5) Connect the regulator/rectifier couplers and bind the clamp.

Battery Components

B815H21A06009



I649G11A0046-03

1. Anode plates	5. Stopper
2. Separator (Fiberglass plate)	6. Filter
3. Cathode plates	7. Terminal
4. Upper cover breather	8. Safety valve

Battery Charging

Initial Charging


B815H21A06010

Filling electrolyte

NOTE

When filling electrolyte, the battery must be removed from the vehicle and must be put on the level ground.

- 1) Remove the aluminum tape (1) which seals the battery filler holes "A".




I649G11A0039-03

- 2) Remove the caps (2) from the electrolyte container.

NOTE

- Do not remove or pierce the sealed areas "B" of the electrolyte container.
- After filling the electrolyte completely, use the removed cap (2) as sealing caps of battery-filler holes.




I649G11A0040-03

- 3) Insert the nozzles of the electrolyte container (3) into the electrolyte filler holes of the battery.
- 4) Hold the electrolyte container firmly so that it does not fall.


NOTE

Do not allow any of the electrolyte to spill.



I649G11A0041-03


- 5) Make sure that air bubbles (4) rise to the top of each electrolyte container, and leave in this position for about more than 20 minutes.



I649G11A0042-03

NOTE

If no air bubbles come out from a filler port, tap the bottom of the electrolyte container two or three times.
Never remove the container from the battery.




I310G11A0024-01

- 6) After confirming that the electrolyte has entered the battery completely, remove the electrolyte containers from the battery.
- 7) Wait for about 20 minutes.
- 8) Insert the caps (2) into the filler holes, pressing in firmly so that the top of the caps do not protrude above the upper surface of the battery's top cover.


⚠ CAUTION

- Once the caps are installed to the battery, do not remove the caps.
- Do not tap the caps with a hammer when installing them.




I718H11A0027-01

Correct



Incorrect



I649G11A0047-02

1J-13 Charging System:

Charging

For initial charging, use the charger specially designed for MF battery.

⚠ CAUTION

- For charging the battery, make sure to use the charger specially designed for MF battery. Otherwise, the battery may be overcharged resulting in shortened service life.
- Do not remove the cap during charging.
- Position the battery with the cap facing upward during charging.

Battery Recharging

⚠ CAUTION

Do not remove the caps on the battery top while recharging.

NOTE

When the motorcycle is not used for a long period, check the battery every 1 month to prevent the battery discharge.

- 1) Remove the battery from the motorcycle. Refer to "Battery Removal and Installation (Page 1J-14)".
- 2) Measure the battery voltage using the multi-circuit tester.
If the voltage reading is less than the 12 V (DC), recharge the battery with a battery charger.


Recharging time

1.2 A for 5 to 10 hours or 5 A for 1 hour

⚠ CAUTION

Be careful not to permit the charging current to exceed 5 A at any time.

- 3) After recharging, wait at least 30 minutes and then measure the battery voltage using the multi-circuit tester.
If the battery voltage is less than 12.5 V, recharge the battery again.
If the battery voltage is still less than 12.5 V after recharging, replace the battery with a new one.




I649G11A0045-02

"A": Charging period

"B": Stop charging

- 4) Install the battery to the motorcycle. Refer to "Battery Removal and Installation (Page 1J-14)".



I705H11A0029-02

Battery Removal and Installation

B815H21A06011


Removal

- 1) Remove the seat. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Disconnect the battery (–) lead wire (1).
- 3) Disconnect the battery (+) lead wire (2).

NOTE

Be sure to disconnect the battery (–) lead wire (1) first, then disconnect the battery (+) lead wire (2).

- 4) Remove the battery (3) from the motorcycle.



I815H11A0016-01

Installation


Install the battery in the reverse order of removal.

Pay attention to following points:

⚠ CAUTION

Never use anything except the specified battery.

- Install the rubber band.
- Tighten the battery lead wire mounting bolts securely.



I815H11A0017-01

Battery Visual Inspection

B815H21A06012

Inspect the battery in the following procedures:

- 1) Remove the seat. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Visually inspect the surface of the battery container. If any signs of cracking or electrolyte leakage from the sides of the battery have occurred, replace the battery with a new one.
If the battery terminals are found to be coated with rust or an acidic white powdery substance, clean the battery terminals with sandpaper.
- 3) Install the seat. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".

Specifications

Service Data

B815H21A07001

Electrical

Unit: mm

Item		Specification	Note
Generator coil resistance		0.2 – 0.7 Ω	
Generator maximum output		Approx. 400 W at 5 000 r/min	
Generator no-load voltage (When engine is cold)		70 V (AC) and more at 5 000 r/min	
Regulated voltage		13.5 – 15.5 V at 5 000 r/min	
Battery	Type designation	YTX12-BS	
	Capacity	12 V 36 kC (10 Ah)/10 HR	
	Standard electrolyte S.G.	1.320 at 20 °C (68 °F)	

CAUTION

Never use anything except the specified battery.

Tightening Torque Specifications

B815H21A07002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Generator stator set bolt	11	1.1	8.0	☞(Page 1J-7)
CKP sensor mounting bolt	6.5	0.65	4.7	☞(Page 1J-7)
Generator rotor bolt	120	12.0	87.0	☞(Page 1J-8)

NOTE

The specified tightening torque is also described in the following.
 “Regulator / Rectifier Construction (Page 1J-9)”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Tightening Torque List in Section 0C (Page 0C-9)”.

Special Tools and Equipment




Recommended Service Material

B815H21A08001

Material	SUZUKI recommended product or Specification		Note
Sealant	SUZUKI BOND No.1207B or equivalent	P/No.: 99000-31140	☞ (Page 1J-8)

Special Tool

B815H21A08002

09900-25008 Multi-circuit tester set ☞ (Page 1J-4) / ☞ (Page 1J-4) / ☞ (Page 1J-5) / ☞ (Page 1J-5) / ☞ (Page 1J-10)		09930-30450 Rotor remover bolt ☞ (Page 1J-6)	
09930-44530 Rotor holder ☞ (Page 1J-6) / ☞ (Page 1J-6) / ☞ (Page 1J-8)			

Exhaust System

Precautions

Precautions for Exhaust System

B815H21B00001

⚠ WARNING

To avoid the risk of being burned, do not touch the exhaust system when the system is hot. Any service on the exhaust system should be performed when the system is cool.


⚠ CAUTION

Make sure that the exhaust pipes and mufflers have enough clearance from the rubber parts and plastic parts to avoid melting.

Repair Instructions

Exhaust System Construction

B815H21B06001



I815H11B0001-06

1. Gasket	5. HO2 sensor	: 9 N-m (0.9 kgf-m, 6.5 lb-ft)
2. Connector	"a": 30 – 45°	: 4 N-m (0.4 kgf-m, 3.0 lb-ft)
3. Gasket	: 23 N-m (2.3 kgf-m, 16.5 lb-ft)	: Apply muffler seal.
4. O-ring	: 25 N-m (2.5 kgf-m, 18.0 lb-ft)	: Do not reuse.

⚠ CAUTION

Replace the gaskets, connectors and O-rings with new ones when reassembling.

1K-3 Exhaust System:

Exhaust Pipe / Muffler Removal and Installation


B815H21B06002

Removal


- 1) Loosen the muffler connecting bolt(-s) (1).
- 2) Remove the muffler assembly(-ies) (2) by removing the mounting bolt(-s) (3) and nut(-s).

NOTE

Support the muffler to prevent it from falling.




I815H11B0003-02




I815H11B0004-02

- 3) Remove the muffler joint cover (4).



I815H11B0005-01

- 4) Separate the muffler body and muffler joint pipe (5).



I815H11B0006-01

- 5) Remove the gasket (6) and O-rings from the muffler body.



I815H11B0007-01


- 6) Remove the side cowlings. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".

- 7) Remove the horn (7).




I815H11B0008-01

- 8) Remove the radiator/oil cooler mounting bolts.
- 9) Remove the oil cooler bracket (8).
- 10) Move the radiator/oil cooler forward.




I815H11B0009-01



I815H11B0010-01

- 11) Disconnect the HO2 sensor coupler (9).



I815H11B0011-01


- 12) Remove the exhaust pipe assembly by removing the exhaust pipe bolts and exhaust pipe mounting bolt.

⚠ CAUTION


Take care not to bend the radiator/oil cooler fins.

NOTE

Support the exhaust pipe assembly to prevent it from falling.




I815H11B0012-02



I815H11B0020-01

1K-5 Exhaust System:

13) Remove the exhaust pipe gaskets (10).




I815H11B0013-01

14) Remove the HO2 sensor (11) from the exhaust pipe.

CAUTION

- Be careful not to expose the HO2 sensor to an excessive shock.
- Be careful not to twist or damage the HO2 sensor lead wire.



I815H11B0014-01

Installation

Installation is in the reverse order of removal. Pay attention to the following points:


- Tighten the HO2 sensor (1) to the specified torque.

Tightening torque

HO2 sensor (a): 25 N·m (2.5 kgf·m, 18.0 lb·ft)

CAUTION

- Be careful not to expose the HO2 sensor to an excessive shock.
- Do not use an impact wrench when installing the HO2 sensor.
- Be careful not to twist or damage the HO2 sensor lead wires.
- Do not apply oil or other materials to the sensor air holes.




I815H11B0015-01

- Install the exhaust pipe gaskets (2).

CAUTION

Replace the gaskets with new ones.




I815H11B0016-01

- Tighten the exhaust pipe bolts (3) and exhaust pipe mounting bolt (4) to the specified torque.


Tightening torque

Exhaust pipe bolt (b): 23 N·m (2.3 kgf-m, 16.5 lb-ft)

Exhaust pipe mounting bolt (c): 23 N·m (2.3 kgf-m, 16.5 lb-ft)



I815H11B0017-02



I815H11B0018-01

- Install the connectors (5).

⚠ CAUTION

Replace the connectors with new ones.

NOTE

When installing a new connector, remove all of the old sealer from the exhaust pipe and muffler. Apply the exhaust gas sealer to both the inside and outside of the new connector.

SEAL : Muffler seal (MUFFLER SEAL LOCTITE 5920 (commercially available) or equivalent)



I815H11B0019-01

- Tighten the muffler mounting nut and muffler connecting bolts to the specified torque. Refer to "Exhaust System Construction (Page 1K-2)".

Exhaust System Inspection

B815H21B06003

Inspect the exhaust pipe connection and muffler connection for exhaust gas leakage and mounting condition. If any defect is found, replace the exhaust pipe assembly or muffler with a new one.

Check the exhaust pipe bolts, muffler connecting bolts and muffler mounting bolts are tightened to their specified torque.

Tightening torque


Exhaust pipe bolt (a): 23 N·m (2.3 kgf-m, 16.5 lb-ft)

Exhaust pipe mounting bolt (b): 23 N·m (2.3 kgf-m, 16.5 lb-ft)

Muffler connecting bolt (c): 23 N·m (2.3 kgf-m, 16.5 lb-ft)

Muffler mounting bolt (d): 25 N·m (2.5 kgf-m, 18.0 lb-ft)

Muffler joint nut (e): 25 N·m (2.5 kgf-m, 18.0 lb-ft)



I815H11B0002-03

Specifications

Tightening Torque Specifications

B815H21B07001

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
HO2 sensor	25	2.5	18.0	☞ (Page 1K-5)
Exhaust pipe bolt	23	2.3	16.5	☞ (Page 1K-6) / ☞ (Page 1K-7)
Exhaust pipe mounting bolt	23	2.3	16.5	☞ (Page 1K-6) / ☞ (Page 1K-7)
Muffler connecting bolt	23	2.3	16.5	☞ (Page 1K-7)
Muffler mounting bolt	25	2.5	18.0	☞ (Page 1K-7)
Muffler joint nut	25	2.5	18.0	☞ (Page 1K-7)

NOTE

The specified tightening torque is also described in the following.
 “Exhaust System Construction (Page 1K-2)”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Tightening Torque List in Section 0C (Page 0C-9)”.

Special Tools and Equipment

Recommended Service Material

B815H21B08001

Material	SUZUKI recommended product or Specification		Note
Muffler seal	MUFFLER SEAL LOCTITE 5920 (commercially available) or equivalent	—	☞ (Page 1K-6)

NOTE

Required service material is also described in the following.
 “Exhaust System Construction (Page 1K-2)”

Section 2

Suspension

CONTENTS

Precautions	2-1	Swingarm Related Parts Inspection	2C-11
Precautions.....	2-1	Swingarm Bearing Removal and Installation	2C-12
Precautions for Suspension	2-1	Specifications	2C-13
Suspension General Diagnosis.....	2A-1	Service Data.....	2C-13
Diagnostic Information and Procedures.....	2A-1	Tightening Torque Specifications.....	2C-13
Suspension and Wheel Symptom Diagnosis	2A-1	Special Tools and Equipment	2C-14
Front Suspension	2B-1	Recommended Service Material	2C-14
Repair Instructions	2B-1	Special Tool	2C-14
Front Fork Components	2B-1	Wheels and Tires	2D-1
Front Fork Removal and Installation	2B-2	Precautions.....	2D-1
Front Suspension Adjustment.....	2B-5	Precautions for Wheel and Tire.....	2D-1
Front Fork Disassembly and Assembly.....	2B-6	Repair Instructions	2D-2
Front Fork Parts Inspection.....	2B-12	Front Wheel Components	2D-2
Specifications.....	2B-13	Front Wheel Assembly Construction.....	2D-3
Service Data	2B-13	Front Wheel Assembly Removal and	
Tightening Torque Specifications.....	2B-13	Installation	2D-4
Special Tools and Equipment	2B-14	Front Wheel Related Parts Inspection	2D-6
Recommended Service Material.....	2B-14	Front Wheel Dust Seal / Bearing Removal	
Special Tool	2B-14	and Installation	2D-7
Rear Suspension	2C-1	Rear Wheel Components.....	2D-9
Repair Instructions	2C-1	Rear Wheel Assembly Construction	2D-10
Rear Suspension Components.....	2C-1	Rear Wheel Assembly Removal and	
Rear Suspension Assembly Construction.....	2C-2	Installation	2D-11
Rear Shock Absorber / Cushion Lever		Rear Wheel Related Parts Inspection	2D-12
Removal and Installation.....	2C-3	Rear Wheel Dust Seal / Bearing Removal and	
Rear Suspension Inspection	2C-4	Installation	2D-13
Rear Shock Absorber Inspection	2C-4	Tire Removal and Installation.....	2D-15
Rear Suspension Adjustment	2C-4	Wheel / Tire / Air Valve Inspection and	
Rear Shock Absorber Disposal.....	2C-5	Cleaning	2D-16
Cushion Lever Removal and Installation.....	2C-6	Air Valve Removal and Installation	2D-17
Cushion Lever Inspection	2C-6	Wheel Balance Check and Adjustment.....	2D-18
Cushion Lever Bearing Removal and		Specifications.....	2D-18
Installation.....	2C-7	Service Data.....	2D-18
Swingarm / Cushion Rod Removal and		Tightening Torque Specifications.....	2D-19
Installation.....	2C-8	Special Tools and Equipment	2D-19
		Recommended Service Material	2D-19
		Special Tool	2D-19

Precautions

Precautions

Precautions for Suspension

B815H22000001

Refer to “General Precautions in Section 00 (Page 00-1)”.

⚠ WARNING

All suspensions, bolts and nuts are an important part in that it could affect the performance of vital parts. They must be tightened to the specified torque periodically and if the suspension effect is lost, replace it with a new one.

⚠ CAUTION

Never attempt to heat, quench or straighten any suspension part. Replace it with a new one, or damage to the part may result.

Suspension General Diagnosis

Diagnostic Information and Procedures

Suspension and Wheel Symptom Diagnosis

B815H22104001


Condition	Possible cause	Correction / Reference Item
Wobbly front wheel	Distorted wheel rim.	<i>Replace.</i>
	Worn front wheel bearings.	<i>Replace.</i>
	Defective or incorrect tire.	<i>Replace.</i>
	Loose front axle nut.	<i>Tighten.</i>
	Loose front axle pinch bolt.	<i>Tighten.</i>
	Incorrect fork oil level.	<i>Adjust.</i>
Front suspension too soft	Weak spring.	<i>Replace.</i>
	Insufficient fork oil.	<i>Check level and add.</i>
	wrong weight fork oil.	<i>Replace.</i>
	Improperly set front fork spring adjuster.	<i>Adjust.</i>
	Improperly set front fork damping force adjuster.	<i>Adjust.</i>
Front suspension too stiff	Excessively viscous fork oil.	<i>Replace.</i>
	Excessive fork oil.	<i>Check level and drain.</i>
	Bent front axle.	<i>Replace.</i>
Front suspension too noisy	Insufficient fork oil.	<i>Check level and add.</i>
	Loose front suspension fastener.	<i>Tighten.</i>
Wobbly rear wheel	Distorted wheel rim.	<i>Replace.</i>
	Worn rear wheel bearing.	<i>Replace.</i>
	Defective or incorrect tire.	<i>Replace.</i>
	Worn swingarm bearing.	<i>Replace.</i>
	Worn rear suspension bearing.	<i>Replace.</i>
	Loose rear suspension fastener.	<i>Tighten.</i>
Rear suspension too soft	Weak rear shock absorber spring.	<i>Replace.</i>
	Rear shock absorber leaks oil.	<i>Replace.</i>
	Improperly set rear spring pre-load adjuster.	<i>Adjust.</i>
	Improperly set damping force adjuster.	<i>Adjust.</i>
Rear suspension too stiff	Bent rear shock absorber shaft.	<i>Replace.</i>
	Bent swingarm.	<i>Replace.</i>
	Worn swingarm and rear suspension related. bearings.	<i>Replace.</i>
	Improperly set rear spring pre-load adjuster.	<i>Adjust.</i>
	Improperly set damping force adjuster.	<i>Adjust.</i>
Rear suspension too noisy	Loose nuts or bolts on rear suspension.	<i>Retighten.</i>
	Worn rear suspension bearing.	<i>Replace.</i>
	Worn swingarm bearing.	<i>Replace.</i>

Front Suspension

Repair Instructions

Front Fork Components

B815H22206001



I815H1220001-03

1. Front fork cap bolt	9. Inner rod/Damper rod (cartridge)	17. Front axle pinch bolt
2. O-ring	10. Oil seal retainer	(a) : 15 N-m (1.5 kgf-m, 11.0 lb-ft)
3. Outer tube	11. Oil seal	(b) : 23 N-m (2.3 kgf-m, 16.5 lb-ft)
4. Spring retainer	12. Oil seal stopper ring	1322 : Apply thread lock to the thread part.
5. Spacer	13. Dust seal	FORK : Apply fork oil.
6. Spring	14. Inner tube	X : Do not reuse.
7. Adjuster rod	15. Gasket	
8. Lock-nut	16. Damper rod bolt	

Front Fork Removal and Installation

B815H22206002

NOTE

The right and left front forks are installed symmetrically and therefore the removal procedure for one side is the same as that for the other side.


Removal

- 1) Remove the front wheel assembly. Refer to "Front Wheel Assembly Removal and Installation in Section 2D (Page 2D-4)".

⚠ CAUTION

- Make sure that the motorcycle is supported securely.
- Do not operate the front brake lever with the front wheel removed.

- 2) Remove the body cowlings. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 3) Remove the handlebar holder mounting bolt caps, mounting bolts (1) and nuts.




I815H1220002-01

- 4) Move the handlebar holder assembly forward.

NOTE

Place a rag on the combination meter to prevent the combination meter scratched.

- 5) Remove the collars (2).



I815H1220003-01

- 6) Loosen the front fork upper clamp bolt (3).

NOTE

- Slightly loosen the front fork cap bolt (4) to facilitate later disassembly.
- Be sure to adjust the rebound damping force adjuster (5) to the softest position before removing the front fork.




I815H1220004-01

- 7) Loosen the front fork lower clamp bolts (6) and remove the front fork.

NOTE

Hold the front fork by hand to prevent it sliding out of the steering stem.




I815H1220005-01

2B-3 Front Suspension:

Installation

- 1) Set the front fork to the front fork lower bracket temporarily by tightening the lower clamp bolts (1).



I823H1220005-01

- 2) Tighten the front fork cap bolt (2) to the specified torque.

Tightening torque

Front fork cap bolt (a): 23 N·m (2.3 kgf-m, 16.5 lb-ft)

- 3) Loosen the lower clamp bolts.
- 4) Set the front fork with the upper surface "T" of the outer tube positioned 5.0 mm (0.20 in) "a" from the upper surface of the upper bracket.




I823H1220006-01

"a": 5.0 mm (0.20 in)

- 5) Tighten the front fork lower clamp bolts (1).

Tightening torque

Front fork lower clamp bolt (b): 23 N·m (2.3 kgf-m, 16.5 lb-ft)




I823H1220007-01

- 6) Tighten the front fork upper clamp bolt (3).

Tightening torque


Front fork upper clamp bolt (c): 23 N·m (2.3 kgf-m, 16.5 lb-ft)

- 7) Adjust the spring pre-load (4), if necessary. Refer to "Front Suspension Adjustment (Page 2B-5)".



I815H1220006-01

- 8) Install the collars (5).



I815H1220007-01

- 9) Install the handlebar holder assembly.
- 10) Tighten the handlebar holder mounting bolts and nuts (6).

Tightening torque

Handlebar holder mounting nut (d): 35 N·m (3.5 kgf-m, 25.5 lb-ft)



I815H1220008-01



I815H1220009-01

- 11) Install the front wheel assembly. Refer to "Front Wheel Assembly Removal and Installation in Section 2D (Page 2D-4)".

NOTE

Before tightening the front axle and front axle pinch bolts, move the front fork up and down four or five times.

⚠ WARNING

After remounting the brake calipers, pump the brake lever until the pistons push the pads correctly.



I815H1220010-01

- 12) Install the body cowlings. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 13) Adjust the headlight beam. Refer to "Headlight Beam Adjustment in Section 9B (Page 9B-3)".

Front Suspension Adjustment

B815H22206003

After installing the front fork, adjust the spring pre-load and two kinds of damping force as follows:

⚠ WARNING

Adjust the left and right front forks to the same setting.

Spring Pre-load Adjustment


- There are five grooved lines on the side of the spring adjuster. Position 0 provides the maximum spring pre-load and position 5 provides the minimum spring pre-load.
- Turn the adjustment (1) to the desired position.

STD position

3-1/2 (6 turns out from the maximum position)



I815H1220011-01



I815H1220012-04

[A]:	Position 0
[B]:	Position 3-1/2 (STD: 6 turns out)
[C]:	Position 5 (10 turns out)

Damping Force Adjustment

NOTE

Make sure to check the 1st click position by the last click sound when turning in the adjuster.

Rebound damping force

Fully turn the damping force adjuster (2) clockwise. From that position (stiffest), turn it out to standard setting position.

STD position

8 clicks out from stiffest position




I815H1220013-01

Compression damping force

Fully turn the damping force adjuster (3) clockwise. From that position (stiffest), turn it out to the standard setting position.

STD position

8 clicks out from stiffest position



I815H1220014-01

Front Fork Disassembly and Assembly

B815H22206004

Refer to "Front Fork Removal and Installation (Page 2B-2)".

NOTE

The right and left front forks are installed symmetrically and therefore the disassembly procedure for one side is the same as that for the other side.

Disassembly

- 1) Loosen the front fork cap bolt (1).


⚠ CAUTION

Align the holes "A" of the spacer with the cutaway "B" of the fork cap bolt before installing the special tool.

- 2) Install the special tool to the holes "A".

Special tool

TOOL (A): 09940-94930 (Front fork spacer holder)




I815H1220015-01

- 3) Compress the fork spring with the special tool (A) and insert the special tool (B) between the lock-nut (2) and spring retainer (3).

Special tool

TOOL (A): 09940-94930 (Front fork spacer holder)

TOOL (B): 09940-94922 (Front fork spring stopper plate)



I815H1220016-02

- 4) Remove the front fork cap bolt (1) from the inner rod by loosening the lock-nut (2).

⚠ CAUTION


- Do not disassemble the front fork cap bolt (1).
- After removing the front fork cap bolt (1), avoid holding the outer tube vertically by hand to prevent the inner tube from falling and damaged.

- 5) Compress the fork spring with the special tool (A) and remove the special tool (B).

Special tool


TOOL (A): 09940-94930 (Front fork spacer holder)

TOOL (B): 09940-94922 (Front fork spring stopper plate)



I815H1220017-01


- 6) Remove the spring retainer (3), spacer (4), spring (5) and adjuster rod (6).



I815H1220018-01

- 7) Invert the fork and stroke it several times to drain out fork oil.

- 8) Hold the fork inverted for a few minutes to drain oil.



I823H1220018-01


2B-7 Front Suspension:

9) Remove the outer tube from the inner tube.



I815H1220019-01

10) Remove the outside of the front axle pinch bolt (7).




I815H1220020-01

11) Remove the damper rod bolt with the special tool.

Special tool

TOOL (C): 09940-30221 (Front fork assembling tool)




I815H1220021-01

12) Remove the inner rod/damper rod (cartridge) (8).

⚠ CAUTION

Do not disassemble the inner rod/damper rod (cartridge).



I815H1220022-01

13) Remove the dust seal (9) and oil seal stopper ring (10).



I815H1220023-01

14) Remove the oil seal (11) with the special tool.


15) Remove the oil seal retainer (12).

Special tool

TOOL (D): 09913-50121 (Oil seal remover)

⚠ CAUTION

The removed oil seal must be replaced with a new one.



I815H1220024-01

Assembly

Assemble the front fork in the reverse order of disassembly. Pay attention to the following points:

Oil seal and dust seal


- Install the following parts onto the inner tube.
 - Dust seal (1)
 - Oil seal stopper ring (2)
 - Oil seal (3)
 - Oil seal retainer (4)

⚠ CAUTION

- The oil seal and dust seal must be replaced with new ones when assembling front fork.
- When installing the oil seal to inner tube, be careful not to damage the oil seal lip.

- Apply fork oil to the oil seal lip.


FORK : Fork Oil 99000-99044-L01 (SUZUKI FORK OIL L01 or equivalent)



I823H1220024-01

- Apply fork oil to the anti-friction metals "A" and "B".

FORK : Fork Oil 99000-99044-L01 (SUZUKI FORK OIL L01 or equivalent)




I815H1220028-01

- Install the inner tube into the outer tube and fit the oil seal (3) using the special tool.

Special tool

TOOL (A): 09940-52861 (Front fork oil seal installer)



I823H1220025-01


2B-9 Front Suspension:

- Install the oil seal stopper ring (2).

CAUTION

Make sure that the oil seal stopper ring is fitted securely.


- Install the dust seal (1).



I823H1220066-01

Damper rod bolt

- Install the inner rod/damper rod (cartridge) (1) into the inner tube.



I815H1220025-01

- Apply thread lock to the damper rod bolt (2) and tighten it to the specified torque with the special tools.

CAUTION

Use a new damper rod bolt gasket (3) to prevent oil leakage.


 : Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER 1322 or equivalent)

Special tool


 (A): 09940-30221 (Front fork assembling tool)

Tightening torque

Front fork damper rod bolt (a): 23 N·m (2.3 kgf-m, 16.5 lb-ft)



I815H1220026-01




I815H1220027-02

Fork oil

- Place the front fork vertically without spring.
- Compress it fully.
- Pour specified front fork oil up to the top level of the outer tube.

FOIL : Fork Oil 99000-99044-L01 (SUZUKI FORK OIL L01 or equivalent)

Front fork oil capacity (each leg)
532 ml (18.0/18.7 US/Imp oz)



I649G1220026-02


- Move the inner rod slowly with the special tool more than ten times until bubbles do not come out from the oil.

NOTE

Refill front fork oil up to the top of the outer tube to find bubbles while bleeding air.

Special tool

TOOL (A): 09940-52841 (Inner rod holder)




I649G1220027-05

- Refill specified front fork oil up to the top level of the outer tube again. Move the outer tube up and down several strokes until bubbles do not come out from the oil.
- Keep the front fork vertically and wait 5 – 6 minutes.

NOTE

- Always keep oil level over the cartridge top end, or air may enter the cartridge during this procedure.
- Take extreme attention to pump out air completely.



I649G1220028-03

- Hold the front fork vertically and adjust fork oil level with the special tool.

NOTE


When adjusting the fork oil level, remove the fork spring and compress the outer tube fully.

Special tool

TOOL (B): 09943-74111 (Fork oil level gauge)

Fork oil level "a"

95 mm (3.7 in)




I823H1220028-01

Fork spring


NOTE

The larger diameter "a" should face to the bottom side of the front fork.



I815H1220029-01


- Install the spring (1), spacer (2) and spring retainer (3).



I815H1220030-01

Front fork cap bolt

- Adjust the height "a" of the inner rod threads by turning the lock-nut (1) as shown in the figure.



I823H1220029-02

"a": 11 mm (0.43 in)


- Pull up the inner rod with the special tool (A).
- Compress the spring with the special tool (B) and then insert the special tool (C) between the lock-nut and spring retainer.

Special tool

TOOL (A): 09940-52841 (Inner rod holder)


TOOL (B): 09940-94930 (Front fork spacer holder)

TOOL (C): 09940-94922 (Front fork spring stopper plate)



I823H1220031-02

- Make sure that the height "a" of the inner rod threads after removing the special tool.




I823H1220075-01

- Insert the adjuster rod in to the inner rod.
- Apply fork oil to the O-ring.

⚠ CAUTION

- Make sure that the rebound damping force adjuster (1) to the softest position before installing the cap bolt.
- Use a new O-ring to prevent oil leakage.

FORK : Fork Oil 99000-99044-L01 (SUZUKI FORK OIL L01 or equivalent)




I815H1220031-01

- Slowly turn the cap bolt completely by hand until the end of the cap bolt seats on the lock-nut.
- Hold the cap bolt (2) and tighten the lock-nut (3) to the specified torque.

Tightening torque

Front fork inner rod lock-nut (a): 15 N·m (1.5 kgf-m, 11.0 lb-ft)



I815H1220032-01

- Remove the special tools.
- Tighten the front fork cap to the outer tube temporarily.

Front Fork Parts Inspection

B815H22206005


Refer to "Front Fork Disassembly and Assembly (Page 2B-6)".

Inner and Outer Tubes

- Inspect the inner tube outer surface and outer tube inner surface for scratches.
- Inspect the "ANTI-FRICTION" metal surfaces for scratches.
- If any defects are found, replace them with the new ones.

⚠ CAUTION

Do not remove the "ANTI-FRICTION" metals "A" and "B".




I815H1220033-01

Fork Spring

Measure the fork spring free length. If it is shorter than the service limit, replace it with a new one.

Front fork spring free length

Service limit: 257 mm (10.1 in)




I815H1220034-01

Damper Rod

Move the inner rod by hand to examine it for smoothness.

If any defects are found, replace inner rod/damper rod (cartridge) with a new one.



I815H1220035-01

Specifications

Service Data

B815H22207001

Suspension

Unit: mm (in)

Item	Standard	Limit
Front fork stroke	120 (4.7)	—
Front fork spring free length	263 (10.4)	257 (10.1)
Front fork oil level (Without spring, outer tube fully compressed)	95 (3.7)	—
Front fork oil type	SUZUKI FORK OIL L01 or an equivalent fork oil	—
Front fork oil capacity (Each leg)	532 ml (18.0/18.7 US/Imp oz)	—
Front fork inner tube O.D	43 (1.7)	—
Front fork spring adjuster	3-1/2 grooves from top	—
Front fork damping force adjuster	Rebound	8 clicks out from stiffest position
	Compression	

Tightening Torque Specifications

B815H22207002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Front fork cap bolt	23	2.3	16.5	☞ (Page 2B-3)
Front fork lower clamp bolt	23	2.3	16.5	☞ (Page 2B-3)
Front fork upper clamp bolt	23	2.3	16.5	☞ (Page 2B-3)
Handlebar holder mounting nut	35	3.5	25.5	☞ (Page 2B-4)
Front fork damper rod bolt	23	2.3	16.5	☞ (Page 2B-9)
Front fork inner rod lock-nut	15	1.5	11.0	☞ (Page 2B-12)

NOTE

The specified tightening torque is also described in the following.
 “Front Fork Components (Page 2B-1)”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Tightening Torque List in Section 0C (Page 0C-9)”.

Special Tools and Equipment

Recommended Service Material

B815H22208001







Material	SUZUKI recommended product or Specification	Note
Fork Oil	SUZUKI FORK OIL L01 or equivalent P/No.: 99000–99044–L01	☞ (Page 2B-8) / ☞ (Page 2B-8) / ☞ (Page 2B-10) / ☞ (Page 2B-11)
Thread lock cement	THREAD LOCK CEMENT SUPER 1322 or equivalent P/No.: 99000–32110	☞ (Page 2B-9)

NOTE

Required service material is also described in the following.
“Front Fork Components (Page 2B-1)”

Special Tool

B815H22208002


09913–50121 Oil seal remover ☞ (Page 2B-8)		09940–30221 Front fork assembling tool ☞ (Page 2B-7) / ☞ (Page 2B-9)	
09940–52841 Inner rod holder ☞ (Page 2B-10) / ☞ (Page 2B-11)		09940–52861 Front fork oil seal installer ☞ (Page 2B-8)	
09940–94922 Front fork spring stopper plate ☞ (Page 2B-6) / ☞ (Page 2B-6) / ☞ (Page 2B-11)		09940–94930 Front fork spacer holder ☞ (Page 2B-6) / ☞ (Page 2B-6) / ☞ (Page 2B-11)	
09943–74111 Fork oil level gauge ☞ (Page 2B-10)			

Rear Suspension

Repair Instructions

Rear Suspension Components

B815H22306001




I815H1230001-03

1. Rear shock absorber	8. Swingarm pivot shaft	⚙️(a) : 50 N-m (5.0 kgf-m, 36.0 lb-ft)
2. Rear shock absorber mounting nut	9. Swingarm pivot nut	⚙️(b) : 78 N-m (7.8 kgf-m, 56.5 lb-ft)
3. Cushion rod	10. Swingarm	⚙️(c) : 90 N-m (9.0 kgf-m, 65.0 lb-ft)
4. Cushion rod mounting nut	11. Chain case	⚙️(d) : 15 N-m (1.5 kgf-m, 11.0 lb-ft)
5. Cushion lever	12. Plate	⚙️(e) : 100 N-m (10.0 kgf-m, 72.5 lb-ft)
6. Cushion lever mounting nut	13. Chain adjuster	⚙️AH : Apply grease to the bearing.
7. Swingarm pivot lock-nut	14. Chain buffer	⊗ : Do not reuse.

Rear Suspension Assembly Construction

B815H22306002



I815H1230002-02


1. Rear shock absorber mounting nut (Upper)	6. Swingarm pivot shaft	(c) : 15 N·m (1.5 kgf-m, 11.0 lb-ft)
2. Rear shock absorber mounting nut (Lower)	7. Swingarm pivot lock-nut	(d) : 100 N·m (10.0 kgf-m, 72.5 lb-ft)
3. Cushion rod mounting nut (Upper)	8. Swingarm pivot lock-nut	(e) : 90 N·m (9.0 kgf-m, 65.0 lb-ft)
4. Cushion rod mounting nut (Lower)	(a) : 50 N·m (5.0 kgf-m, 36.0 lb-ft)	AH : Apply grease to the bearing and dust seal lip.
5. Cushion lever mounting nut	(b) : 78 N·m (7.8 kgf-m, 56.5 lb-ft)	

Rear Shock Absorber / Cushion Lever Removal and Installation

B815H22306003


Removal

- 1) Remove the rear under cowlings and side cowlings. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Support the motorcycle with a jack to relieve load on the rear shock absorber.
- 3) Remove the regulator/rectifier mounting bolts (1). Refer to "Regulator / Rectifier Removal and Installation in Section 1J (Page 1J-10)".



I815H1230003-01

- 4) Remove the shock absorber lower mounting bolt and nut (2).
- 5) Remove the cushion lever mounting bolt and nut (3).



I815H1230004-01

- 6) Lift and support the fuel tank.
- 7) Remove the rear shock absorber upper mounting bolt and nut.



I815H1230005-01

- 8) Remove the rear shock absorber downward.



I815H1230006-01

Installation

Install the rear shock absorber in the reverse order of removal. Pay attention to the following points:

- Temporarily install the rear shock absorber and cushion lever mounting bolt.
- Tighten the rear shock absorber upper/lower mounting bolts and nuts.

Tightening torque

Rear shock absorber mounting nut (a): 50 N·m (5.0 kgf-m, 36.0 lb-ft)


- Tighten the cushion lever mounting bolt and nut.

Tightening torque

Cushion lever mounting nut (b): 78 N·m (7.8 kgf-m, 56.5 lb-ft)



I815H1230007-01



I815H1230008-01

Rear Suspension Inspection

B815H22306004

Refer to "Rear Suspension Inspection in Section 0B (Page 0B-20)".

Rear Shock Absorber Inspection

B815H22306005

Inspect the rear shock absorber in the following procedures:

- 1) Remove the rear shock absorber. Refer to "Rear Shock Absorber / Cusion Lever Removal and Installation (Page 2C-3)".
- 2) Inspect the rear shock absorber for damage and oil leakage, and absorber bushing for wear and damage. If any defect is found, replace the rear shock absorber with a new one.

⚠ CAUTION

Do not attempt to disassemble the rear shock absorber. It is unserviceable.



I815H1230009-01



I815H1230010-01

- 3) Install the rear shock absorber. Refer to "Rear Shock Absorber / Cusion Lever Removal and Installation (Page 2C-3)".

Rear Suspension Adjustment

B815H22306006


After installing the rear suspension, adjust the spring pre-load and damping force as follows:

Spring Pre-load Adjustment

- The set length 190 mm provides the maximum spring pre-load.
- The set length 200 mm provides the minimum spring pre-load.

STD position

195 mm (7.68 in)



I815H1230011-01

Damping Force Adjustment

NOTE

Turn the adjuster clockwise to stiffen the damping force and turn it counterclockwise to soften the damping force.

Rebound side

Turn the damping force adjuster (1) to the desired position.

STD position

12 clicks out from stiffest position



I815H1230012-01


2C-5 Rear Suspension:

Compression side

Turn the damping force adjuster (2) to the desired position.

STD position

8 clicks out of from stiffest position



I815H1230013-01

Rear Shock Absorber Disposal

B815H22306007

Refer to "Rear Shock Absorber / Cushion Lever Removal and Installation (Page 2C-3)".

The rear shock absorber unit contains high-pressure nitrogen gas.

⚠ WARNING

- Mishandling can cause explosion.
- Keep away from fire and heat. High gas pressure caused by heat can cause an explosion.
- Release gas pressure before disposing.


Gas Pressure Release

Make sure to observe the following precautions:

⚠ WARNING

- Never apply heat or disassemble the damper unit since it can explode or oil can splash hazardously.
- When discarding the rear cushion unit, be sure to release gas pressure from the unit following the procedures.

- 1) Mark the drill center at the location "A" using a center punch.



I823H1230009-01


"a": 9 mm (0.35 in)

"A": Mark the drill hole

- 2) Wrap rear shock absorber (1) with a plastic bag (2) and fix it on a vise as shown in the figure.
- 3) Drill a 2 – 3 mm (0.08 – 0.12 in) hole at the marked drill center using a drilling machine and let out gas while taking care not to get the plastic bag entangled with the drill bit.

⚠ WARNING

- Be sure to wear protective glasses since drilling chips and oil may fly off with blowing gas when the drill bit has penetrated through the body.
- Make sure to drill at the specified position. Otherwise, pressurized oil may spout out forcefully.



I823H1230010-01

Cushion Lever Removal and Installation

B815H22306008

Removal

- 1) Support the motorcycle with a jack to relieve load on the cushion lever.
- 2) Remove the cushion lever by removing its related bolts, nuts and washers.



I815H1230014-01

Installation

Install the cushion lever in the reverse order of removal. Pay attention to the following point:


- Tighten each nut to the specified torque.

Tightening torque

Cushion lever mounting nut (a): 78 N·m (7.8 kgf-m, 56.5 lb-ft)

Cushion rod mounting nut (b): 78 N·m (7.8 kgf-m, 56.5 lb-ft)

Rear shock absorber lower mounting nut (c): 50 N·m (5.0 kgf-m, 36.0 lb-ft)



I815H1230015-01

Cushion Lever Inspection

B815H22306009

Refer to "Cushion Lever Removal and Installation (Page 2C-6)".

Spacer

- 1) Remove the spacers from the cushion lever.
- 2) Inspect the spacers for any flaws or other damage. If any defects are found, replace the spacers with new ones.



I815H1230016-01

Cushion Lever Bearing

- 1) Insert the spacers into bearings.
- 2) Check the play by moving the spacers up and down. If excessive play is noted, replace the bearing with a new one. Refer to "Cushion Lever Bearing Removal and Installation (Page 2C-7)".



I815H1230017-02

Cushion Lever

Inspect the cushion lever for damage. If any defect is found, replace the cushion lever with a new one.



I815H1230018-01

2C-7 Rear Suspension:

Cushion Rod

Refer to "Swingarm Related Parts Inspection (Page 2C-11)".

Cushion Lever Bearing Removal and Installation

B815H22306010

Removal

- 1) Remove the cushion lever. Refer to "Cushion Lever Removal and Installation (Page 2C-6)".
- 2) Remove the cushion lever bearings using the special tools.


Special tool

 (A): 09921-20240 (Bearing remover set)


 (B): 09913-70210 (Bearing installer set)



I815H1230019-01



I815H1230020-01



I815H1230021-01

Installation

⚠ CAUTION

The removed bearings must be replaced with new ones.

- 1) Press the bearings into the cushion lever with the special tool.

NOTE

When installing the bearing, stamped mark on the bearing must face outside.

Special tool


 (A): 09924-84521 (Bearing installer set)



I815H1230022-01

- 2) Apply grease to the bearings.

 : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)



I815H1230023-01

- 3) Install the cushion lever. Refer to "Cushion Lever Removal and Installation (Page 2C-6)".

Swingarm / Cushion Rod Removal and Installation

B815H22306011


Removal

- 1) Cut the drive chain. Refer to "Drive Chain Replacement in Section 3A (Page 3A-7)".
- 2) Remove the rear wheel assembly. Refer to "Rear Wheel Assembly Removal and Installation in Section 2D (Page 2D-11)".
- 3) Remove the brake hose clamp bolt (1).
- 4) Remove the brake caliper from the swingarm.



I815H1230024-01

- 5) Remove the rear shock absorber (2). Refer to "Rear Shock Absorber / Cushion Lever Removal and Installation (Page 2C-3)".




I815H1230025-01

- 6) Remove the swingarm pivot shaft lock-nut with the special tool.

Special tool

TOOL (A): 09940-14970 (Swingarm pivot thrust adjuster socket wrench)




I815H1230026-02

- 7) Hold the swingarm pivot shaft (3) and remove the swingarm pivot nut (4).

Special tool


TOOL (B): 09900-18740 (Hexagon socket (24 mm))



I815H1230027-02


2C-9 Rear Suspension:

- 8) Remove the swingarm pivot shaft.
- 9) Remove the swingarm.
- 10) Remove the cushion lever (5) and cushion rods (6).




I815H1230028-02

- 11) Remove the mudguard (7), chain case (8) and chain buffer (9) from the swingarm.



I815H1230029-02

- 12) Remove the plate (10).



I815H1230030-01


Installation

Install the swingarm in the reverse order of removal. Pay attention to the following points:

- Temporarily install the cushion rod mounting nut.

NOTE

The stamped marks "A" on the cushion rod should be face out side.



I815H1230031-01


- Adjust swingarm pivot thrust clearance in the following procedures:
 - Insert the swingarm pivot shaft (1) and tighten it to the specified torque.

Special tool

 (A): 09900-18740 (Hexagon socket (24 mm))

Tightening torque

Swingarm pivot shaft (a): 15 N·m (1.5 kgf-m, 11.0 lb-ft)




I815H1230032-01

- Hold the swingarm pivot shaft and tighten the swingarm pivot nut (2) to the specified torque.

Tightening torque

Swingarm pivot nut (b): 100 N·m (10.0 kgf-m, 72.5 lb-ft)



I815H1230033-01


- Tighten the swingarm pivot lock-nut (3) to the specified torque with the special tool.

Special tool

TOOL (B): 09940-14970 (Swingarm pivot thrust adjuster socket wrench)

Tightening torque

Swingarm pivot lock-nut (c): 90 N·m (9.0 kgf-m, 65.0 lb-ft)



I815H1230034-01

- Tighten the cushion lever, cushion rod and rear shock absorber mounting nut to the specified torque.

Tightening torque

Rear shock absorber mounting nut (d): 50 N·m (5.0 kgf-m, 36.0 lb-ft)

Cushion rod mounting nut (e): 78 N·m (7.8 kgf-m, 56.5 lb-ft)


Cushion lever mounting nut (f): 78 N·m (7.8 kgf-m, 56.5 lb-ft)

NOTE

Install the washers between cushion lever and frame.



I815H1230035-01



I815H1230036-02

2C-11 Rear Suspension:

Swingarm Related Parts Inspection

B815H22306012

Refer to "Swingarm / Cushion Rod Removal and Installation (Page 2C-8)".

Spacers

- 1) Remove the dust seal and spacers from the swingarm.
- 2) Inspect the spacers for wear and damage. If any defects are found, replace the spacers with new ones.



I815H1230037-01

Chain Buffer


Inspect the chain buffer for wear and damage. If any defect is found, replace the chain buffer with a new one.



I815H1230038-01

Swingarm Bearing and Cushion Rod Bearing

- 1) Insert the spacers into bearings.
- 2) Check the play by moving the spacers up and down. If excessive play is noted, replace the bearing with a new one. Refer to "Swingarm Bearing Removal and Installation (Page 2C-12)".



I815H1230039-01

Swingarm

Inspect the swingarm for damage. If any defect is found, replace the swingarm with a new one.



I815H1230040-01

Cushion Rod

Inspect the cushion rods for damage and bend. If any defects are found, replace the cushion rods with new ones.



I815H1230041-01

Swingarm Pivot Shaft

Measure the swingarm pivot shaft runout using the dial gauge. If the runout exceeds the service limit, replace the pivot shaft.

Special tool


TOOL (A): 09900-20607 (Dial gauge (1/100 mm, 10 mm))

TOOL (B): 09900-20701 (Magnetic stand)

TOOL (C): 09900-21304 (V-block (100 mm))

Swingarm pivot shaft runout

Service limit: 0.3 mm (0.01 in)



I823H1230048-01

Swingarm Bearing Removal and Installation


B815H22306013

Removal

- 1) Remove the swingarm. Refer to "Swingarm / Cushion Rod Removal and Installation (Page 2C-8)".
- 2) Remove the swingarm pivot bearings (1) using the special tool.


Special tool

 (A): 09921-20240 (Bearing remover set)



I815H1230042-01

- 3) Remove the center spacer (2).




I815H1230043-01

- 4) Remove the swingarm cushion rod bearings (3) using the special tools.

Special tool

 (A): 09921-20240 (Bearing remover set)



I815H1230044-02

Installation

⚠ CAUTION

The removed bearings must be replaced with new ones.


- 1) Press the swingarm cushion rod bearings with the special tool.

NOTE

When installing the bearing, stamped mark on the bearing must face outside.

Special tool

 (A): 09924-84521 (Bearing installer set)



I815H1230045-01

- 2) Install the center spacer.
- 3) Press the bearings into the swingarm pivot with the special tool.

NOTE

When installing the bearing, stamped mark on the bearing must face outside.

Special tool

 (B): 09941-34513 (Steering race installer)




I815H1230046-01

- 4) Apply grease to the bearings.

 : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)

2C-13 Rear Suspension:



I815H1230047-01

- 5) Install the swingarm. Refer to “Swingarm / Cushion Rod Removal and Installation (Page 2C-8)”.

Specifications

Service Data

B815H22307001

Suspension

Unit: mm (in)

Item	Standard		Limit
Rear shock absorber spring pre-set length	195 (7.7)		—
Rear shock absorber damping force adjuster	Rebound	12 clicks out from stiffed position	—
	Compression	8 clicks out from stiffed position	
Rear wheel travel	140 (5.5)		—
Swingarm pivot shaft runout	—		0.3 (0.01)

Tightening Torque Specifications

B815H22307002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Rear shock absorber mounting nut	50	5.0	36.0	☞(Page 2C-3) / ☞(Page 2C-10)
Cushion lever mounting nut	78	7.8	56.5	☞(Page 2C-3) / ☞(Page 2C-6) / ☞(Page 2C-10)
Cushion rod mounting nut	78	7.8	56.5	☞(Page 2C-6) / ☞(Page 2C-10)
Rear shock absorber lower mounting nut	50	5.0	36.0	☞(Page 2C-6)
Swingarm pivot shaft	15	1.5	11.0	☞(Page 2C-9)
Swingarm pivot nut	100	10.0	72.5	☞(Page 2C-10)
Swingarm pivot lock-nut	90	9.0	65.0	☞(Page 2C-10)

NOTE

The specified tightening torque is also described in the following.

“Rear Suspension Components (Page 2C-1)”

“Rear Suspension Assembly Construction (Page 2C-2)”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Tightening Torque List in Section 0C (Page 0C-9)”.

Special Tools and Equipment

Recommended Service Material

B815H22308001

Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI SUPER GREASE A or equivalent	P/No.: 99000-25010	☞ (Page 2C-7) / ☞ (Page 2C-12)

NOTE










Required service material is also described in the following.

“Rear Suspension Components (Page 2C-1)”

“Rear Suspension Assembly Construction (Page 2C-2)”

Special Tool

B815H22308002

09900-18740 Hexagon socket (24 mm) ☞ (Page 2C-8) / ☞ (Page 2C-9)		09900-20607 Dial gauge (1/100 mm, 10 mm) ☞ (Page 2C-11)	
09900-20701 Magnetic stand ☞ (Page 2C-11)		09900-21304 V-block (100 mm) ☞ (Page 2C-11)	
09913-70210 Bearing installer set ☞ (Page 2C-7)		09921-20240 Bearing remover set ☞ (Page 2C-7) / ☞ (Page 2C-12) / ☞ (Page 2C-12)	
09924-84521 Bearing installer set ☞ (Page 2C-7) / ☞ (Page 2C-12)		09940-14970 Swingarm pivot thrust adjuster socket wrench ☞ (Page 2C-8) / ☞ (Page 2C-10)	
09941-34513 Steering race installer ☞ (Page 2C-12)			

Wheels and Tires

Precautions

Precautions for Wheel and Tire

B815H22400001


⚠ WARNING

- Proper tire pressure and proper tire loading are important factors. Over loading tire can lead to tire failure and loss of motorcycle control.
 - Under-inflated tires make smooth cornering difficult, and can result in rapid tire wear.
 - Over-inflated tires have a smaller amount of tire in contact with the load, which can contribute to skidding and loss of control.
 - Replace the wheel when wheel runout exceed the service limit or if find damage such as distortion, crack, nick or scratch.
 - When tire replacement is necessary, the original equipment type tire should be used.
 - Do not mix different types of tires on the same vehicle such as radial and bias-belted tires except in emergencies, because handling may be seriously affected and may result in loss of control.
 - Replacement wheel must be equivalent to the original equivalent wheel.
-

Repair Instructions

Front Wheel Components

B815H22406001




I815H1240001-01

1. Front axle bolt	5. Bearing	9. Wheel balancer	 (b) : 100 N·m (10.0 kgf·m, 72.5 lb·ft)
2. Collar	6. Tire	10. Spacer	 AH : Apply grease.
3. Brake disc	7. Front wheel	11. Front axle	 (a) : 23 N·m (2.3 kgf·m, 16.5 lb·ft)
4. Dust seal	8. Air valve		 : Do not reuse.

Front Wheel Assembly Construction

B815H22406002



I815H1240003-01

1. Brake disc bolt	"a": Clearance	A : Apply grease.
2. Brake caliper mounting bolt	(a) : 23 N-m (2.3 kgf-m, 16.5 lb-ft)	1360 : Apply thread lock to the thread part.
3. Front axle bolt	(b) : 39 N-m (3.9 kgf-m, 28.0 lb-ft)	
4. Front axle pinch bolt	(c) : 100 N-m (10.0 kgf-m, 72.5 lb-ft)	

Front Wheel Assembly Removal and Installation

B815H22406003


Removal

- 1) Remove the rear under cowlings and side cowlings. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Raise the front wheel off the ground and support the motorcycle with a jack or a wooden block.


⚠ CAUTION

Do not carry out the work with the motorcycle resting on the side-stand. Do not support the motorcycle with the exhaust pipes. Make sure that the motorcycle is supported securely.

- 3) Remove the reflex reflector for E-03, 24, 28, 33.
- 4) Disconnect the brake hose clamp (1) from the front fender.
- 5) Disconnect the brake hose (2) from the brake hose clamp (3).
- 6) Remove the front fender by removing the bolts (4), left and right.



I815H1240004-01




I815H1240005-01

- 7) Remove the brake calipers, left and right.


⚠ CAUTION

Do not operate the brake lever with the caliper removed.



I823H1240003-01

- 8) Loosen two axle pinch bolts (5) on the right front fork leg.
- 9) Remove the front axle bolt (6).




I815H1240006-01

- 10) Loosen two axle pinch bolts (7) on the left front fork leg.
- 11) Draw out the front axle and remove the front wheel.
- 12) Remove the collar (8) (RH only).

NOTE


After removing the front wheel, fit the calipers temporarily to the original positions.



I815H1240007-02

Installation

- 1) Install the collar (1) to the right side of the wheel.



I823H1240006-01

- 2) Install the front wheel with the front axle and tighten the front axle bolt temporarily.

⚠ WARNING

The directional arrow on the tire should point to the wheel rotation, when remounting the wheel.



I823H1240007-02


- 3) Tighten the brake caliper mounting bolts (2) to the specified torque.

Tightening torque

Front brake caliper mounting bolt (a): 39 N·m (3.9 kgf-m, 28.0 lb-ft)

⚠ WARNING

After remounting the brake calipers, pump the brake lever until the pistons push the pads correctly.



I815H1240008-01

- 4) Hold the front axle with the special tool and tighten the front axle bolt (3) to the specified torque.

Special tool

 (A): 09900-18740 (Hexagon socket (24 mm))


Tightening torque

Front axle bolt (b): 100 N·m (10.0 kgf-m, 72.5 lb-ft)

- 5) Tighten two axle pinch bolts (4) on the right fork leg to the specified torque.

Tightening torque

Front axle pinch bolt (c): 23 N·m (2.3 kgf-m, 16.5 lb-ft)



I815H1240009-01

- 6) Move the front fork up and down 4 or 5 times.



I823H1240010-02

- 7) Tighten two axle pinch bolts (5) on the left front fork leg to the specified torque.

Tightening torque

Front axle pinch bolt (d): 23 N·m (2.3 kgf-m, 16.5 lb-ft)



I815H1240010-01

- 8) Install the front fender, side cowlings and rear under cowlings.

Front Wheel Related Parts Inspection

B815H22406004

Refer to "Front Wheel Assembly Removal and Installation (Page 2D-4)".

Tire

Refer to "Tire Inspection in Section 0B (Page 0B-19)".

Front Brake Disc

Refer to "Front Brake Disc Inspection in Section 4B (Page 4B-7)".

Dust Seal

Inspect the dust seal lips for wear or damage. If any defects are found, replace the dust seal with a new ones. Refer to "Front Wheel Dust Seal / Bearing Removal and Installation (Page 2D-7)".



I823H1240012-01

Wheel Axle

Using a dial gauge, check the wheel axle for runout. If the runout exceeds the limit, replace the axle shaft.

Special tool


 (A): 09900-20607 (Dial gauge (1/100 mm, 10 mm))

 (B): 09900-20701 (Magnetic stand)

 (C): 09900-21304 (V-block (100 mm))

Wheel axle runout

Service limit: 0.25 mm (0.010 in)




I649G1240054-02

Wheel

- 1) Remove the brake pads. Refer to "Front Brake Pad Replacement in Section 4B (Page 4B-2)".
- 2) Make sure that the wheel runout checked as shown in the figure does not exceed the service limit. An excessive runout is usually due to worn or loosened wheel bearings and can be reduced by replacing the bearings. If bearing replacement fails to reduce the runout, replace the wheel.
- 3) Install the brake pads. Refer to "Front Brake Pad Replacement in Section 4B (Page 4B-2)".

Wheel rim runout


Service limit (Axial and Radial): 2.0 mm (0.08 in)



I649G1240014-02

Wheel Bearing

Inspect the play of the wheel bearings by finger while they are in the wheel. Rotate the inner race by finger to inspect for abnormal noise and smooth rotation. Replace the bearing if there is anything unusual. Refer to "Front Wheel Dust Seal / Bearing Removal and Installation (Page 2D-7)".



I649G1240015-02

Front Wheel Dust Seal / Bearing Removal and Installation


B815H22406005

Removal

- 1) Remove the front wheel assembly. Refer to "Front Wheel Assembly Removal and Installation (Page 2D-4)".
- 2) Remove the dust seals (1) using the special tool.

Special tool

TOOL (A): 09913-50121 (Oil seal remover)



I823H1240013-01

- 3) Remove the bearings (2) using the special tool.

Special tool

TOOL (B): 09921-20240 (Bearing remover set)



I823H1240014-01

- 4) Remove the spacer (3).



I823H1240015-01


Installation

⚠ CAUTION

The removed dust seals and bearings must be replaced with new ones.

- 1) Apply grease to the wheel bearings.

⚠ : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)



I649G1240019-02


- 2) First install the right wheel bearing, then install the spacer (1) and left wheel bearing with the special tool.

Special tool



TOOL (A): 09924-84510 (Bearing installer set)

⚠ CAUTION

The sealed cover of the bearing must face outside.



I649G1240020-03



I823H1240058-02

1. Spacer

"a": Clearance

- 3) Install the dust seals with the special tool.

Special tool

TOOL (B): 09913-70210 (Bearing installer set)



I823H1240016-01

- 4) Apply grease to the lip of dust seals.

FAH: Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)




I823H1240017-01

- 5) Install the front wheel assembly. Refer to "Front Wheel Assembly Removal and Installation (Page 2D-4)".

Rear Wheel Components

B815H22406006




I815H1240002-05

1. Rear axel nut	9. Wheel damper	⚙️(a) : 100 N·m (10.0 kgf·m, 72.5 lb·ft)
2. Rear brake disc	10. Wheel balancer	⚙️(b) : 35 N·m (3.5 kgf·m, 25.5 lb·ft)
3. Collar	11. Air valve	⚙️(c) : 60 N·m (6.0 kgf·m, 43.5 lb·ft)
4. Dust seal	12. Sprocket mounting drum	🛢️ : Apply grease.
5. Bearing	13. Rear sprocket	🔒1360 : Apply thread lock to the thread part.
6. Tire	14. Retainer	⊗ : Do not reuse.
7. Rear wheel	15. Spacer	
8. Spacer	16. Rear axle	

Rear Wheel Assembly Construction

B815H22406007



I815H1240011-01

1. Rear sprocket nut	: 60 N·m (6.0 kgf·m, 43.5 lb·ft)
2. Rear axle nut	: 100 N·m (10.0 kgf·m, 72.5 lb·ft)
3. Brake disc bolt	: 35 N·m (3.5 kgf·m, 25.5 lb·ft)
4. Brake caliper mounting bolt	: 33 N·m (3.3 kgf·m, 24.0 lb·ft)
"A": Three protrusions "A" on the damper must face sprocket side.	: Apply grease.
"a": Clearance	: Apply silicone grease.
	: Apply thread lock to the thread part.

Rear Wheel Assembly Removal and Installation

B815H22406008


Removal

- 1) Loosen the axle nut (1).
- 2) Raise the rear wheel off the ground and support the motorcycle with a jack or wooden block.

⚠ CAUTION

Make sure that the motorcycle is supported securely.

- 3) Remove the axle nut (1) and draw out the rear axle.



I823H1240018-01

- 4) Remove the rear wheel by disengaging the drive chain.


⚠ CAUTION

Do not operate the rear brake pedal with the rear wheel removed.



I823H1240019-01


- 5) Remove the spacer (2) and collar (3).



I823H1240020-01

Installation

- 1) Install the spacer (1) and collar (2).



I823H1240021-03

- 2) Remount the rear wheel and rear axle shaft, tighten the rear axle nut (3) temporarily.
- 3) Adjust the chain slack after installing the rear wheel. Refer to "Drive Chain Inspection and Adjustment in Section 0B (Page 0B-15)".
- 4) Tighten the rear axle nut (3) to the specified torque.


Tightening torque

Rear axle nut (a): 100 N·m (10.0 kgf-m, 72.5 lb-ft)

⚠ WARNING

After remounting the rear wheel, pump the brake pedal several times to check for proper brake operation.

- 5) Tighten both chain adjuster lock nuts (4) securely.



I815H1240013-01

Rear Wheel Related Parts Inspection

B815H22406009

Refer to "Rear Wheel Assembly Removal and Installation (Page 2D-11)".

Tire

Refer to "Tire Inspection in Section 0B (Page 0B-19)".

Rear Brake Disc

Refer to "Rear Brake Disc Inspection in Section 4C (Page 4C-7)".

Wheel Damper


Refer to "Drive Chain Related Parts Inspection in Section 3A (Page 3A-5)".

Sprocket

Refer to "Drive Chain Related Components in Section 3A (Page 3A-1)".

Dust Seal

Inspect the dust seal lip for wear or damage. If any defects is found, replace the dust seal with a new one. Refer to "Rear Wheel Dust Seal / Bearing Removal and Installation (Page 2D-13)".



I823H1240028-01

Wheel Axle

Using a dial gauge, check the wheel axle for runout. If the runout exceeds the limit, replace the axle shaft.

Wheel axle runout


Service limit: 0.25 mm (0.010 in)

Special tool

TOOL (A): 09900-20607 (Dial gauge (1/100 mm, 10 mm))

TOOL (B): 09900-20701 (Magnetic stand)

TOOL (C): 09900-21304 (V-block (100 mm))




I649G1230034-03

Wheel

- 1) Remove the brake pads. Refer to "Rear Brake Pad Replacement in Section 4C (Page 4C-2)".
- 2) Make sure that the wheel runout checked as shown in the figure does not exceed the service limit. An excessive runout is usually due to worn or loosened wheel bearings and can be reduced by replacing the bearings. If bearing replacement fails to reduce the runout, replace the wheel.
- 3) Install the brake pads. Refer to "Rear Brake Pad Replacement in Section 4C (Page 4C-2)".

Wheel rim runout

Service limit (Axial and Radial): 2.0 mm (0.08 in)




I649G1240014-02

2D-13 Wheels and Tires:

Bearing

Inspect the play of the wheel bearings by hand while they are in the wheel. Rotate the inner race by hand to inspect for abnormal noise and smooth rotation. Replace the bearing if there is anything unusual. Refer to "Rear Wheel Dust Seal / Bearing Removal and Installation (Page 2D-13)".




I649G1240015-02

Rear Wheel Dust Seal / Bearing Removal and Installation

B815H22406010

Removal

- 1) Remove the rear wheel assembly. Refer to "Rear Wheel Assembly Removal and Installation (Page 2D-11)".
- 2) Remove the spacer (1).
- 3) Remove the rear sprocket mounting drum assembly (2) from the rear wheel.




I823H1240023-03

- 4) Remove the dust seal (3).

Special tool

TOOL (A): 09913-50121 (Oil seal remover)




I823H1240024-01

- 5) Remove the bearings (3) on both sides using the special tool.

Special tool

TOOL (B): 09921-20240 (Bearing remover set)



I823H1240053-01

- 6) Remove the spacer.


Installation

⚠ CAUTION

The removed dust seal and bearings must be replaced with new ones.

- 1) Apply grease to the wheel bearings.

⚠ : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)



I649G1240019-02

- 2) First install the right wheel bearing, then install the spacer (1) and left wheel bearing with the special tools.


Special tool

TOOL (A): 09941-34513 (Steering race installer)



TOOL (B): 09924-84510 (Bearing installer set)

CAUTION

The sealed cover of the bearing must face outside.



I649G1240030-02



I815H1240012-05

1. Spacer

"a": Clearance

- 3) Install a new dust seal with the special tool.

Special tool

TOOL (C): 09913-70210 (Bearing installer set)



I823H1240025-01

- 4) Apply grease to the dust seal lip.

FAH: Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)



I823H1240026-01

- 5) Install the rear sprocket mounting drum assembly.



I823H1240027-01

- 6) Install the rear wheel assembly. Refer to "Rear Wheel Assembly Removal and Installation (Page 2D-11)".

Tire Removal and Installation

B815H22406011

Removal

The most critical factor of a tubeless tire is the seal between the wheel rim and the tire bead. For this reason, it is recommended to use a tire changer that can satisfy this sealing requirement and can make the operation efficient as well as functional.


- 1) Removal the wheel assembly. Refer to "Front Wheel Assembly Removal and Installation (Page 2D-4)" and "Rear Wheel Assembly Removal and Installation (Page 2D-11)".
- 2) Remove the mounting drum from the rear wheel.
(For rear wheel)
Refer to "Rear Wheel Assembly Removal and Installation (Page 2D-11)".
- 3) Remove the valve core.
- 4) Remove the tire using the tire changer.

⚠ CAUTION

For operating procedures, refer to the instructions supplied by the tire changer manufacturer.

NOTE

When removing the tire in case of repair or inspection, mark the tire with a chalk to indicate the tire position relative to the valve position. Even though the tire is refitted to the original position after repairing puncture, the tire may have to be balanced again since such a repair can cause imbalance.



I649G1240037-02

Installation


⚠ CAUTION

Do not reuse the valve which has been once removed.

- 1) Apply tire lubricant to the tire bead.

⚠ CAUTION

Never use oil, grease or gasoline on the tire bead in place of tire lubricant.



I649G1240038-02


- 2) Install the tire onto the wheel.

⚠ CAUTION

For installation procedure of tire onto the wheel, follow the instructions given by the tire changer manufacturer.

NOTE

- When installing the tire, the arrow "A" on the side wall should point to the direction of wheel rotation.
- Align the chalk mark put on the tire at the time of removal with the valve position.




I649G1240039-02

- 3) Bounce the tire several times while rotating. This makes the tire bead expand outward to contact the wheel, thereby facilitating air inflation.
- 4) Install the valve core and inflate the tire.

▲ WARNING

- **Do not inflate the tire to more than 400 kPa (4.0 kgf/cm², 57 psi). If inflated beyond this limit, the tire can burst and possibly cause injury. Do not stand directly over the tire while inflating.**
 - **In the case of preset pressure air inflator, pay special care for the set pressure adjustment.**
- 5) In this condition, check the “grim line” “B” cast on the tire side walls. The line must be equidistant from the wheel rim all around.
 - 6) If the distance between the rim line and wheel rim varies, this indicates that the bead is not properly seated. If this is the case, deflate the tire completely and unseat the bead for both sides. Coat the bead with lubricant and fit the tire again.



I649G1240040-02

- 7) When the bead has been fitted properly, adjust the pressure to specification.
- 8) As necessary, adjust the tire balance. Refer to “Wheel Balance Check and Adjustment (Page 2D-18)”.

Cold inflation tire pressure

	Front	Rear
	290 kPa	290 kPa
Solo riding	(2.90 kgf/cm ² , 42 psi)	(2.90 kgf/cm ² , 42 psi)
	290 kPa	290 kPa
Dual riding	(2.90 kgf/cm ² , 42 psi)	(2.90 kgf/cm ² , 42 psi)

- 9) Install the mounting drum to the rear wheel.
(For rear wheel) Refer to “Rear Wheel Assembly Removal and Installation (Page 2D-11)”.
- 10) Install the wheel assembly. Refer to “Front Wheel Assembly Removal and Installation (Page 2D-4)” and “Rear Wheel Assembly Removal and Installation (Page 2D-11)”.

Wheel / Tire / Air Valve Inspection and Cleaning


B815H22406012

Refer to “Tire Removal and Installation (Page 2D-15)”.

Wheel

Wipe the wheel clean and check for the following points:

- Distortion and crack
- Any flaws and scratches at the bead seating area.
- Wheel rim runout. Refer to “Front Wheel Related Parts Inspection (Page 2D-6)” and “Rear Wheel Related Parts Inspection (Page 2D-12)”.




I649G1240041-02


Tire

Tire must be checked for the following points:

- Nick and rupture on side wall
- Tire tread depth (Refer to “Tire Inspection in Section 0B (Page 0B-19)”.)
- Tread separation
- Abnormal, uneven wear on tread
- Surface damage on bead
- Localized tread wear due to skidding (Flat spot)
- Abnormal condition of inner liner




I649G1240042-02



I649G1240043-02


Air Valve

Inspect the air valve for peeling and damage. If any defect is found, replace the air valve with a new one. Refer to “Air Valve Removal and Installation (Page 2D-17)”.



I649G1240044-02

Inspect the valve core seal (1) for wear and damage. If any defect is found, replace the valve core with a new one. Refer to “Air Valve Removal and Installation (Page 2D-17)”.




I649G1240045-02

Air Valve Removal and Installation

B815H22406013

Removal

- 1) Remove the wheel assembly. Refer to “Front Wheel Assembly Removal and Installation (Page 2D-4)” and “Rear Wheel Assembly Removal and Installation (Page 2D-11)”.
- 2) Remove the tire. Refer to “Tire Removal and Installation (Page 2D-15)”.
- 3) Remove the air valve (1) from the wheel.




I649G1240046-02

Installation

Install the air valve in the reverse order of removal. Pay attention to the following points:

- Any dust or rust around the valve hole (1) must be cleaned off.



I718H1240054-01


- Install the air valve (2) in the wheel (3).

CAUTION

- Be careful not to damage the lip (4) of the valve.
- Replace the air valve with a new one.

NOTE

To properly install the valve into the valve hole, apply a special tire lubricant or neutral soapy liquid to the valve.



I718H1240055-01

2. Valve	3. Wheel	4. Valve lip
----------	----------	--------------

Wheel Balance Check and Adjustment

B815H22406014


Check and adjust the wheel balance in the following procedures:

- 1) Removal the wheel assembly. Refer to "Front Wheel Assembly Removal and Installation (Page 2D-4)" and "Rear Wheel Assembly Removal and Installation (Page 2D-11)".
- 2) Remove the mounting drum from the rear wheel.
(For rear wheel)
Refer to "Rear Wheel Assembly Removal and Installation (Page 2D-11)".
- 3) Check the wheel balance using the balancer and adjust the wheel balance if necessary.

⚠ CAUTION

For operating procedures, refer to the instructions supplied by the wheel balancer manufacturer.

- 4) When installing the balancer weight to the wheel, set the balancer weight on center rib of the wheel.



I823H1240057-01

- 5) Recheck the wheel balance.
- 6) Install the mounting drum to the rear wheel. (For rear wheel)
Refer to "Rear Wheel Assembly Removal and Installation (Page 2D-11)".
- 7) Install the wheel assembly. Refer to "Front Wheel Assembly Removal and Installation (Page 2D-4)" and "Rear Wheel Assembly Removal and Installation (Page 2D-11)".

Specifications

Service Data

Wheel

B815H22407001

Unit: mm (in)

Item	Standard		Limit
Wheel rim runout	Axial	—	2.0 (0.08)
	Radial		
Wheel axle runout	Front	—	0.25 (0.010)
	Rear		
Wheel rim size	Front	17 M/C x MT3.50	—
	Rear	17 M/C x MT6.00	—

Tire

Item	Standard		Limit
Cold inflation tire pressure (Solo/Dual riding)	Front	290 kPa (2.90 kgf/cm ² , 42 psi)	—
	Rear		
Tire size	Front	120/70 ZR17M/C (58 W)	—
	Rear	190/50 ZR17M/C (73 W)	—
Tire type	Front	BRIDGESTONE BT015F RADIAL M	—
	Rear	BRIDGESTONE BT015R RADIAL M	—
Tire tread depth (Recommended depth)	Front	—	1.6 mm (0.06 in)
	Rear	—	2.0 mm (0.08 in)

Tightening Torque Specifications

B815H22407002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Front brake caliper mounting bolt	39	3.9	28.0	☞ (Page 2D-5)
Front axle bolt	100	10.0	72.5	☞ (Page 2D-5)
Front axle pinch bolt	23	2.3	16.5	☞ (Page 2D-5) / ☞ (Page 2D-5)
Rear axle nut	100	10.0	72.5	☞ (Page 2D-11)

NOTE

The specified tightening torque is also described in the following.

“Front Wheel Components (Page 2D-2)”

“Front Wheel Assembly Construction (Page 2D-3)”

“Rear Wheel Components (Page 2D-9)”

“Rear Wheel Assembly Construction (Page 2D-10)”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Tightening Torque List in Section 0C (Page 0C-9)”.

Special Tools and Equipment

Recommended Service Material

B815H22408001

Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI SUPER GREASE A or equivalent	P/No.: 99000-25010	☞ (Page 2D-7) / ☞ (Page 2D-8) / ☞ (Page 2D-13) / ☞ (Page 2D-14)

NOTE

Required service material is also described in the following.

“Front Wheel Components (Page 2D-2)”





“Front Wheel Assembly Construction (Page 2D-3)”






“Rear Wheel Components (Page 2D-9)”

“Rear Wheel Assembly Construction (Page 2D-10)”

Special Tool

B815H22408002

09900-18740 Hexagon socket (24 mm) ☞ (Page 2D-5)		09900-20607 Dial gauge (1/100 mm, 10 mm) ☞ (Page 2D-6) / ☞ (Page 2D-12)	
09900-20701 Magnetic stand ☞ (Page 2D-6) / ☞ (Page 2D-12)		09900-21304 V-block (100 mm) ☞ (Page 2D-6) / ☞ (Page 2D-12)	

<p>09913-50121 Oil seal remover 🔧 (Page 2D-7) / 🔧 (Page 2D-13)</p> 	<p>09913-70210 Bearing installer set 🔧 (Page 2D-8) / 🔧 (Page 2D-14)</p> 
<p>09921-20240 Bearing remover set 🔧 (Page 2D-7) / 🔧 (Page 2D-13)</p> 	<p>09924-84510 Bearing installer set 🔧 (Page 2D-8) / 🔧 (Page 2D-14)</p> 
<p>09941-34513 Steering race installer 🔧 (Page 2D-14)</p> 	

Section 3

Driveline / Axle

CONTENTS

Precautions.....	3-1			
Precautions.....	3-1			
Precautions for Driveline / Axle.....	3-1			
Drive Chain / Drive Train / Drive Shaft... 3A-1				
Diagnostic Information and Procedures.....	3A-1			
Drive Chain and Sprocket Symptom				
Diagnosis	3A-1			
Repair Instructions	3A-1			
Drive Chain Related Components.....	3A-1			
Engine Sprocket Removal and Installation	3A-2			
			Rear Sprocket / Rear Sprocket Mounting	
			Drum Removal and Installation.....	3A-4
			Drive Chain Related Parts Inspection	3A-5
			Sprocket Mounting Drum Dust Seal / Bearing	
			Removal and Installation.....	3A-5
			Drive Chain Replacement	3A-7
			Specifications	3A-11
			Service Data.....	3A-11
			Tightening Torque Specifications.....	3A-11
			Special Tools and Equipment	3A-11
			Recommended Service Material	3A-11
			Special Tool	3A-12

Precautions

Precautions

Precautions for Driveline / Axle

B815H23000001

Refer to "General Precautions in Section 00 (Page 00-1)".

⚠ WARNING

Never inspect or adjust the drive chain while the engine is running.

⚠ CAUTION

-
- Do not use trichloroethylene, gasoline or such similar solvent. These fluids will damage the O-rings of the drive chain.
 - Clean the drive chain with a spray-type chain cleaner and blow dry with compressed air. If the drive chain cannot be cleaned with a spray cleaner, it may be necessary to use a kerosine. Always follow the chemical manufacturer's instructions on proper use, handling and storage.
 - Lubricate the drive chain with a heavy weight motor oil. Wipe off any excess oil or chain lubricant. Do not use any oil sold commercially as "drive chain oil". Such oil can damage the O-rings.
 - The standard drive chain is RK GB50GSVZ4. Suzuki recommends to use this standard drive chain as a replacement.
-

Drive Chain / Drive Train / Drive Shaft

Diagnostic Information and Procedures

Drive Chain and Sprocket Symptom Diagnosis


B815H23104001

Condition	Possible cause	Correction / Reference Item
Noisy Drive Chain	Worn sprocket.	Replace.
	Worn drive chain.	Replace.
	Stretched drive chain.	Replace.
	Too large drive chain slack.	Adjust.
	Drive chain out of adjustment.	Adjust.

Repair Instructions

Drive Chain Related Components

B815H23106001



I823H1310025-01

1. Engine sprocket	6. Sprocket mounting drum	(A) : Apply grease.
2. Drive chain	7. Retainer	1322 : Apply thread lock to the thread part.
3. Dust seal	8. Wheel damper	(X) : Do not reuse.
4. Bearing	(a) : 145 N·m (14.5 kgf-m, 105.0 lb-ft)	
5. Rear sprocket	(b) : 60 N·m (6.0 kgf-m, 43.5 lb-ft)	

Engine Sprocket Removal and Installation


B815H23106002

Removal

- 1) Remove the side cowlings. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Support the motorcycle with a jack or wooden block.
- 3) Remove the gearshift link arm (1) by removing the bolt.


NOTE

Mark the gearshift shaft head at which the gearshift link arm slit set for correct reinstallation.




I815H1310001-01

- 4) Remove the speed sensor (2).
- 5) Remove the engine sprocket cover (3) along with the clutch release cylinder.




I815H1310002-01

- 6) Remove the speed sensor rotor (4) by removing its bolt while depressing the rear brake pedal.




I815H1310003-01

- 7) Remove the engine sprocket nut (5) while depressing the rear brake pedal.
- 8) Remove the washer (6).




I815H1310004-01

- 9) Loosen the rear axle nut (7).
- 10) Loosen the chain adjusters (8) to provide additional chain slack.



I815H1310005-01

- 11) Remove the engine sprocket (9).



I815H1310006-01

Installation

Install the engine sprocket in the reverse order of removal. Pay attention to the following points:


- Apply thread lock to the driveshaft.

 **1322** : Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER 1322 or equivalent)

- Tighten the engine sprocket nut (1) to the specified torque.

Tightening torque

Engine sprocket nut (a): 145 N·m (14.5 kgf-m, 105.0 lb-ft)



I815H1310007-01


- Tighten the speed sensor rotor bolt (2) to the specified torque.

Tightening torque

Speed sensor rotor bolt (b): 28 N·m (2.8 kgf-m, 20.0 lb-ft)

- Before installing the engine sprocket cover, apply a small quantity of grease to the clutch push rod.

 **6H** : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)




I815H1310008-01

- Install the engine sprocket cover (3).
- Tighten the speed sensor mounting bolt (4) to the specified torque.

Tightening torque

Speed sensor bolt (c): 6.5 N·m (0.65 kgf-m, 4.7 lb-ft)




I815H1310009-01

- Fit the gearshift link arm to the gearshift shaft so that the gearshift lever is located at height "a" above the footrest.

Gearshift lever height "a"

Standard: 50 – 60 mm (2.0 – 2.4 in)



I815H1310010-01


- Adjust the drive chain slack. Refer to "Drive Chain Inspection and Adjustment in Section 0B (Page 0B-15)".

Rear Sprocket / Rear Sprocket Mounting Drum Removal and Installation

B815H23106003

Removal

- 1) Remove the rear wheel assembly by disengaging the drive chain. Refer to "Rear Wheel Assembly Removal and Installation in Section 2D (Page 2D-11)".
- 2) Draw out the rear sprocket mounting drum (2) along with the rear sprocket (1) from the wheel hub.
- 3) Remove the rear sprocket nuts and separate the rear sprocket (1) from its mounting drum (2).




I823H1310012-01

- 4) Remove the retainer (3).



I823H1310013-01

- 5) Remove the wheel dampers (4).



I823H1310014-01

Installation

Install the rear sprocket and rear sprocket mounting drum in the reverse order of removal. Pay attention to the following points:

- Apply grease to the contacting surface between the rear wheel hub and rear sprocket mounting drum.
⚠ : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)
- Apply a special tire lubricant or neutral soapy liquid to the wheel damper surface.

⚠ CAUTION

- Never use oil, grease or gasoline on the wheel damper in place of the tire lubricant.
- Three protrusions on the wheel damper must face outside.




I823H1310015-01

- Tighten the rear sprocket nuts to the specified torque.

Tightening torque

Rear sprocket nut (a): 60 N·m (6.0 kgf-m, 43.5 lb-ft)



I823H1310016-01

- Install the rear wheel assembly. Refer to "Rear Wheel Assembly Removal and Installation in Section 2D (Page 2D-11)".

Drive Chain Related Parts Inspection

B815H23106004

Refer to "Rear Sprocket / Rear Sprocket Mounting Drum Removal and Installation (Page 3A-4)".

Dust Seal


Inspect the dust seal for wear or damage. If any damage is found, replace the dust seal with a new one.



I823H1310017-01

Bearing


Inspect the play of the sprocket mounting drum bearing by hand while it is in the drum. Rotate the inner race by hand to inspect for abnormal noise and smooth rotation. Replace the bearing if there is anything unusual.



I649G1310015-02

Engine Sprocket and Rear Sprocket

Inspect the sprocket teeth for wear. If they are worn as shown, replace the engine sprocket, rear sprocket and drive chain as a set.



I649G1310016-02

"A": Normal wear

"B": Excessive wear

Wheel Damper

Inspect the dampers for wear and damage. Replace the damper if there is anything unusual.



I823H1310018-01

Drive Chain

Refer to "Drive Chain Inspection and Adjustment in Section 0B (Page 0B-15)".

Sprocket Mounting Drum Dust Seal / Bearing Removal and Installation

B815H23106005

Removal

- 1) Remove the rear sprocket mounting drum assembly from the rear wheel hub. Refer to "Rear Sprocket / Rear Sprocket Mounting Drum Removal and Installation (Page 3A-4)".
- 2) Remove the retainer (1).




I823H1310019-01

- 3) Remove the sprocket mounting drum dust seal (2) using the special tool.

Special tool

TOOL (A): 09913-50121 (Oil seal remover)




I823H1310020-01

3A-6 Drive Chain / Drive Train / Drive Shaft:

- 4) Remove the sprocket mounting drum bearing using the special tool.

Special tool

 (B): 09921-20240 (Bearing remover set)



I823H1310021-01


Installation

CAUTION

The removed dust seal and bearing must be replaced with new ones.

- 1) Apply grease to the bearing before installing.

 : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)



I649G1310020-02

- 2) Install the bearing (1) and dust seal (2) to the sprocket mounting drum using the special tools.



CAUTION

The sealed cover of the bearing must face wheel hub side.

Special tool

 (A): 09924-84510 (Bearing installer set)



 (B): 09913-70210 (Bearing installer set)



I823H1310022-03

- 3) Apply grease to the dust seal lip.
- 4) Apply grease to the retainer before installing the rear sprocket mounting drum.

 : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)



I823H1310023-02

- 5) Install the rear sprocket mounting drum assembly to rear wheel hub. Refer to "Rear Sprocket / Rear Sprocket Mounting Drum Removal and Installation (Page 3A-4)".
- 6) Install the rear wheel assembly. Refer to "Rear Wheel Assembly Removal and Installation in Section 2D (Page 2D-11)".

Drive Chain Replacement

B815H23106006


Use the special tool in the following procedures, to cut and rejoin the drive chain.

NOTE

When using the special tool, apply a small quantity of grease to the threaded parts of the special tool.

Special tool


 : 09922-22711 (Drive chain cutting and joining tool)



I649G1310023-02

Drive Chain Cutting

- 1) Set up the special tool as shown in the figure.




I649G1310024-02

1. Tool body
2. Grip handle
3. Pressure bolt [A]
4. Pressure bolt [B]
5. Bar
6. Adjuster bolt (With through hole)
7. Pin remover
8. Chain holder (Engraved mark 500) with reamer bolt M5 x 10

NOTE

The tip of pin remover (1) should be positioned inside "a" approximately 5 mm (0.2 in) from the end face of pressure bolt [A] (2) as shown in the figure.




I649G1310025-02

"a": 5 mm (0.2 in)

3A-8 Drive Chain / Drive Train / Drive Shaft:

- 2) Place the drive chain link being disjointed on the holder part (8) of the tool.
- 3) Turn in both the adjuster bolt (6) and pressure bolt [A] (3) so that each of their end hole fits over the chain joint pin properly.
- 4) Tighten the pressure bolt [A] (3) with the bar.



I718H1310032-01

- 5) Turn in the pressure bolt [B] (4) with the bar (5) and force out the drive chain joint pin (9).

⚠ CAUTION

Continue turning in the pressure bolt [B] (4) until the joint pin should be completely pushed out of the chain.


NOTE

After the joint pin (9) is removed, loosen the pressure bolt [B] (4) and then pressure bolt [A] (3).


- 6) Remove the joint pin (9) of the other side of joint plate.

⚠ CAUTION

Never reuse joint pins, O-rings and plates.



I649G1310027-02



I649G1310028-02


Drive Chain Connecting

⚠ WARNING

Do not use joint clip type of drive chain. The joint clip may have a chance to drop which may cause severe damage to motorcycle and severe injury.

Joint plate installation

- 1) Set up the special tool as shown in the figure.



I823H1310024-01

1. Tool body
2. Grip handle
3. Joint plate holder (Engraved mark "F50")
4. Wedge holder & wedge pin
5. Adjuster bolt (Without hole)
6. Pressure bolt [A]
7. Bar

- 2) Apply grease to the joint pins (8), O-rings (9) and plates (10).


⚠ CAUTION

Replace the joint pins (8), O-rings (9) and plates (10) with new ones.

- 3) Connect both ends of the drive chain with the joint pin (8) inserted from the wheel side "A" as installed on the motorcycle.

Joint set part number

RK: 27620 – 24F60




I649G1310030-02

- 4) Apply grease on the recessed portion of the joint plate holder (3) and set the joint plate (10).

NOTE


When positioning the joint plate (10) on the tool, its stamp mark must face the joint plate holder (3) side.

- 5) Set the drive chain on the tool as illustrated and turn in the adjuster bolt (5) to secure the wedge holder and wedge pin (4).



I649G1310031-02

- 6) Turn in the pressure bolt [A] (6) and align two joint pins (11) properly with the respective holes of the joint plate (10).
- 7) Turn in the pressure bolt [A] (6) further using the bar (7) to press the joint plate over the joint pins.



I649G1310032-02


- 8) Continue pressing the joint plate until the distance between the two joint plates comes to the specification.

Joint plate distance specification "a"

22.25 – 22.55 mm (0.876 – 0.888 in)

⚠ CAUTION


If pressing of the joint plate makes the dimension out of specification excessively, the work must be carried out again by using new joint parts.



I649G1310033-03

Joint pin staking

1) Set up the special tool as shown in the figure.



I649G1310034-02

1.	Tool body
2.	Grip handle
3.	Pressure bolt [A]
4.	Adjuster bolt (Without hole)
5.	Staking pin (Stowed inside grip handle behind rubber cap)
6.	Bar

NOTE


Before staking the joint pin, apply a small quantity of grease to the staking pin (5).

2) Stake the joint pin by turning (approximately 7/8 turn) the pressure bolt [A] (3) with the bar until the pin end diameter becomes the specified dimension.


⚠ CAUTION

- After joining of the chain has been completed, check to make sure that the link is smooth and no abnormal condition is found.
- Should any abnormal condition be found, reassemble the chain link using the new joint parts.

Pin end diameter specification “a”
RK: 5.55 – 5.95 mm (0.219 – 0.234 in)



I649G1310035-02



I649G1310036-03

3) Adjust the drive chain slack, after connecting it. Refer to “Drive Chain Inspection and Adjustment in Section 0B (Page 0B-15)”.

Specifications

Service Data

B815H23107001

Drive Train

Unit: mm (in)

Item	Standard		Limit
Final reduction ratio	2.388 (43/18)		—
Drive chain	Type	RK GB50GSVZ4	—
	Links	114 links	—
	20-pitch length	—	319.4 (12.57)
Drive chain slack (on center stand)	20 – 30 (0.8 – 1.2)		—
Gearshift lever height	50 – 60 (2.0 – 2.4)		—

Tightening Torque Specifications

B815H23107002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Engine sprocket nut	145	14.5	105.0	☞ (Page 3A-3)
Speed sensor rotor bolt	28	2.8	20.0	☞ (Page 3A-3)
Speed sensor bolt	6.5	0.65	4.7	☞ (Page 3A-3)
Rear sprocket nut	60	6.0	43.5	☞ (Page 3A-4)

NOTE

The specified tightening torque is also described in the following.

“Drive Chain Related Components (Page 3A-1)”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Tightening Torque List in Section 0C (Page 0C-9)”.

Special Tools and Equipment

Recommended Service Material

B815H23108001

Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI SUPER GREASE A or equivalent	P/No.: 99000–25010	☞ (Page 3A-3) / ☞ (Page 3A-4) / ☞ (Page 3A-6) / ☞ (Page 3A-6)
Thread lock cement	THREAD LOCK CEMENT SUPER 1322 or equivalent	P/No.: 99000–32110	☞ (Page 3A-3)






NOTE

Required service material is also described in the following.

“Drive Chain Related Components (Page 3A-1)”

Special Tool

B815H23108002

<div>09913-50121</div> <div>Oil seal remover</div> <div></div> <div>(Page 3A-5)</div>	<div>09913-70210</div> <div>Bearing installer set</div> <div></div> <div>(Page 3A-6)</div>
<div>09921-20240</div> <div>Bearing remover set</div> <div></div> <div>(Page 3A-6)</div>	<div>09922-22711</div> <div>Drive chain cutting and joining tool</div> <div></div> <div>(Page 3A-7)</div>
<div>09924-84510</div> <div>Bearing installer set</div> <div></div> <div>(Page 3A-6)</div>	

Brake

CONTENTS

4

Precautions

Precautions

Precautions for Brake System

B815H24000001

Refer to "General Precautions in Section 00 (Page 00-1)".

Brake Fluid Information

B815H24000002

⚠ WARNING

- This brake system is filled with an ethylene glycol-based DOT 4 brake fluid. Do not use or mix different types of fluid, such as silicone-based or petroleum-based.
 - Do not use any brake fluid taken from old, used or unsealed containers. Never reuse brake fluid left over from the last servicing or which has been stored for a long period of time.
 - When storing brake fluid, seal the container completely and keep it away from children.
 - When replenishing brake fluid, take care not to get dust into the fluid.
 - When washing brake components, use new brake fluid. Never use cleaning solvent.
 - A contaminated brake disc or brake pad reduces braking performance. Discard contaminated pads and clean the disc with high quality brake cleaner or neutral detergent.
-

⚠ CAUTION



Immediately and completely wipe off any brake fluid contacting any part of the motorcycle. The brake fluid reacts chemically with paint, plastics and rubber materials, etc., and will damage them severely.

Brake Control System and Diagnosis

Schematic and Routing Diagram

Front Brake Hose Routing Diagram

B815H24102001




I815H1410003-04

1. Front brake hose No.1	7. Brake hose clamp : Insert the brake hose clamp to the hole of the front fender firmly.
2. Front brake hose No.2	"a": 14°
3. Stopper : After the brake hose union has contacted the stopper, tighten the union bolt.	"b": 42°
4. Brake hose clamp : After positioning the hose clamp with the stopper, tighten the clamp bolt.	(a) : 23 N·m (2.3 kgf-m, 16.5 lb-ft)
5. Brake hose guide : Attach the brake hose No. 1 to the brake hose guide firmly.	(b) : 7.5 N·m (0.75 kgf-m, 5.5 lb-ft)
6. Brake hose clamp : Clamp the brake hose No. 1 firmly.	(c) : 39 N·m (3.9 kgf-m, 28.0 lb-ft)

Rear Brake Hose Routing Diagram

B815H24102002



I815H1410004-02

 1. Brake hose clamp : Brake hose clamp ends should face outside.	"b": 21°
 2. Brake hose clamp : Brake hose clamp ends should face backward.	 (a) : 23 N·m (2.3 kgf·m, 16.5 lb·ft)
 3. Stopper : After the brake hose union has contacted the stopper, tighten the union bolt.	 (b) : 33 N·m (3.3 kgf·m, 24.0 lb·ft)
 4. Brake hose clamp : Clamp the brake hose firmly.	 (c) : 7.5 N·m (0.75 kgf·m, 5.5 lb·ft)
"A": White paint	 (d) : 17 N·m (1.7 kgf·m, 12.5 lb·ft)
"a": 14°	

Diagnostic Information and Procedures

Brake Symptom Diagnosis

B815H24104001

Condition	Possible cause	Correction / Reference Item
Insufficient brake power	Leakage of brake fluid from hydraulic system.	Repair or replace.
	Worn pads and disc.	Replace.
	Oil adhesion on friction surface of pads.	Clean disc and pads.
	Air in hydraulic system.	Bleed air.
	Not enough brake fluid in the reservoir.	Replenish.
Brake squeaking	Carbon adhesion on pad surface.	Repair surface with sandpaper.
	Tilted pad.	Correct pad fitting or replace.
	Damaged wheel bearing.	Replace.
	Loose front-wheel axle or rear-wheel axle.	Tighten to specified torque.
	Worn pads and disc.	Replace.
	Foreign material in brake fluid.	Replace brake fluid.
	Clogged return port of master cylinder.	Disassemble and clean master cylinder.
Excessive brake lever stroke	Air in hydraulic system.	Bleed air.
	Insufficient brake fluid.	Replenish fluid to specified level; bleed air.
	Improper quality of brake fluid.	Replace with correct fluid.
Leakage of brake fluid	Insufficient tightening of connection joints.	Tighten to specified torque.
	Cracked hose.	Replace.
	Worn piston and/or cup.	Replace piston and/or cup.
	Worn piston seals and dust seals.	Replace piston seals and dust seals.
Brake drags	Rusty part.	Clean and lubricate.
	Insufficient brake lever or brake pedal pivot lubrication.	Lubricate.

Repair Instructions

Brake Pedal Height Inspection and Adjustment

B815H24106001


Refer to "Brake System Inspection in Section 0B (Page 0B-17)".

Front Brake Light Switch Inspection

B815H24106002

Inspect the front brake light switch in the following procedures:

- 1) Disconnect the front brake light switch lead wire coupler (1).



I815H1410005-01

- 2) Inspect the switch for continuity with a tester. If any abnormality is found, replace the front brake light switch with a new one. Refer to "Front Brake Master Cylinder / Brake Lever Disassembly and Assembly (Page 4A-11)".

Special tool

TOOL : 09900-25008 (Multi-circuit tester set)

Tester knob indication

Continuity (•)))

Color Position	Terminal (B/R)	Terminal (B/BI)
OFF		
ON	○ —————	○ —————

I815H1410006-01


- 3) Connect the front brake light switch lead wire coupler.

Rear Brake Light Switch Inspection

B815H24106003

Inspect the rear brake light switch in the following procedures:

- 1) Disconnect the rear brake light switch lead wire coupler (1).



I815H1410007-01

- 2) Inspect the switch for continuity with a tester. If any abnormality is found, replace the rear brake light switch with a new one.

Special tool

: 09900–25008 (Multi-circuit tester set)

Tester knob indication

Continuity (●))

Rear brake light switch

Color Position	Terminal (O/G)	Terminal (W/B)
OFF		
ON		


I815H1410008-01

- 3) Connect the rear brake light switch lead wire coupler.

Rear Brake Light Switch Inspection and Adjustment

B815H24106004

Check the rear brake light switch so that the brake light will come on just before pressure is felt when the brake pedal is depressed. If the brake light switch adjustment is necessary, turn the adjuster nut (1) in or out while holding the brake pedal.



I815H1410009-01

Brake Fluid Level Check

B815H24106005

Refer to “Brake System Inspection in Section 0B (Page 0B-17)”.

Brake Hose Inspection

B815H24106006

Refer to “Brake System Inspection in Section 0B (Page 0B-17)”.

Air Bleeding from Brake Fluid Circuit

B815H24106007

Air trapped in the brake fluid circuit acts like a cushion to absorb a large proportion of the pressure developed by the master cylinder and thus interferes with the full braking performance of the brake caliper. The presence of air is indicated by “sponginess” of the brake lever and also by lack of braking force. Considering the danger to which such trapped air exposes the machine and rider, it is essential that after remounting the brake and restoring the brake system to the normal condition, the brake fluid circuit be purged of air in the following manner:

CAUTION

Handle brake fluid with care: the fluid reacts chemically with paint, plastic, rubber materials, etc.

Front Brake


- 1) Fill the master cylinder reservoir to the top of the inspection window. Place the reservoir cap to prevent dirt from entering.



I815H1410010-01

- 2) Attach a hose to the air bleeder valve, and insert the free end of the hose into a receptacle.

- 3) Squeeze and release the brake lever several times in rapid succession and squeeze the lever fully without releasing it.



I815H1410011-02

- 4) Loosen the air bleeder valve by turning it a quarter of a turn so that the brake fluid runs into the receptacle, this will remove the tension of the brake lever causing it to touch the handlebar grip.



I815H1410012-01

- 5) Close the air bleeder valve, pump and squeeze the lever, and open the valve.
6) Repeat this process until the fluid flowing into the receptacle no longer contains air bubbles.

NOTE


While bleeding the brake system, replenish the brake fluid in the reservoir as necessary. Make sure that there is always some fluid visible in the reservoir.

- 7) Close the air bleeder valve and disconnect the hose.

Tightening torque

Air bleeder valve (Front): 7.5 N·m (0.75 kgf-m, 5.5 lb-ft)

- 8) Fill the reservoir with brake fluid to the upper mark of the reservoir.



I815H1410013-01

- 9) Install the reservoir cap.

Rear Brake

Bleed air from the rear brake system as the same manner of front brake.


- Remove the frame cover. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".

NOTE


The only difference of bleeding operation from the front brake is that the rear master cylinder is actuated by a pedal.

Tightening torque

Air bleeder valve (Rear): 7.5 N·m (0.75 kgf-m, 5.5 lb-ft)




I815H1410014-01



I815H1410015-02

4A-6 Brake Control System and Diagnosis:

- Fill the reservoir with brake fluid to the upper mark of the reservoir.



I815H1410016-02

- Install the frame cover. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.

Brake Fluid Replacement

B815H24106008

⚠ CAUTION

Handle brake fluid with care: the fluid reacts chemically with paint, plastic, rubber materials, etc.

Front Brake

- 1) Place the motorcycle on a level surface and keep the handlebars straight.
- 2) Remove the brake fluid reservoir cap and diaphragm.
- 3) Suck up the old brake fluid as much as possible.



I815H1410017-01

- 4) Fill the reservoir with new brake fluid.


BF: Brake fluid (DOT 4)

- 5) Connect a clear hose to the air bleeder valve and insert the other end of the hose into a receptacle.

- 6) Loosen the air bleeder valve and pump the brake lever until the old brake fluid flows out of the brake system.



I815H1410018-01



I815H1410019-02

- 7) Close the air bleeder valve (1) and disconnect the clear hose.

Tightening torque

Air bleeder valve (Front) (a): 7.5 N·m (0.75 kgf-m, 5.5 lb-ft)



I815H1410020-01

- 8) Fill the reservoir with brake fluid to the upper mark of the reservoir.




I815H1410021-01

- 9) Install the reservoir cap.

Rear Brake

- 1) Place the motorcycle on a level surface.
- 2) Remove the frame cover. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 3) Remove the brake fluid reservoir cap and diaphragm.
- 4) Suck up the old brake fluid as much as possible.




I815H1410022-01

- 5) Fill the reservoir with new brake fluid.


BF: Brake fluid (DOT 4)

- 6) Connect a clear hose to the air bleeder valve and insert the other end of the hose into a receptacle.

- 7) Loosen the air bleeder valve and pump the brake pedal until the old brake fluid flows out of the brake system.



I815H1410023-01




I815H1410024-01

- 8) Close the air bleeder valve (1) and disconnect the clear hose.

Tightening torque


Air bleeder valve (Rear) (a): 7.5 N·m (0.75 kgf·m, 5.5 lb·ft)



I815H1410025-03

4A-8 Brake Control System and Diagnosis:

- 9) Fill the reservoir with brake fluid to the upper mark of the reservoir.



I815H1410026-01

- 10) Reinstall the removed part.

Front Brake Hose Removal and Installation

B815H24106009

Removal

- 1) Remove the upper panel. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Drain brake fluid. Refer to "Brake Fluid Replacement (Page 4A-6)".
- 3) Remove the front brake hoses as shown in the front brake hose routing diagram. Refer to "Front Brake Hose Routing Diagram (Page 4A-1)".

Installation

⚠ CAUTION

The seal washers should be replaced with the new ones to prevent fluid leakage.

- 1) Install the front brake hose as shown in the front brake hose routing diagram. Refer to "Front Brake Hose Routing Diagram (Page 4A-1)".
- 2) Bleed air from the front brake system. Refer to "Air Bleeding from Brake Fluid Circuit (Page 4A-4)".
- 3) Reinstall the removed parts.

Rear Brake Hose Removal and Installation

B815H24106010

Removal

- 1) Remove the frame cover. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Drain brake fluid. Refer to "Brake Fluid Replacement (Page 4A-6)".
- 3) Remove the rear brake hoses as shown in the rear brake hose routing diagram. Refer to "Rear Brake Hose Routing Diagram (Page 4A-2)".

Installation


⚠ CAUTION

The seal washers should be replaced with the new ones to prevent fluid leakage.

- 1) Install the rear brake hose as shown in the rear brake hose routing diagram. Refer to "Rear Brake Hose Routing Diagram (Page 4A-2)".
- 2) Bleed air from the rear brake system. Refer to "Air Bleeding from Brake Fluid Circuit (Page 4A-4)".
- 3) Reinstall the removed parts.

Front Brake Master Cylinder Components

B815H24106011



I815H1410054-01

1. Reservoir cap	7. Brake hose union bolt	(c) : 6.0 N·m (0.6 kgf-m, 4.5 lb-ft)
2. Plate	8. Brake lever	BF : Apply brake fluid.
3. Diaphragm	9. Brake lever pivot bolt	SH : Apply silicone grease.
4. Master cylinder	10. Brake lever pivot bolt lock-nut	X : Do not reuse.
5. Dust boot	(a) : 23 N·m (2.3 kgf-m, 16.5 lb-ft)	
6. Piston set	(b) : 10 N·m (1.0 kgf-m, 7.0 lb-ft)	

Front Brake Master Cylinder Assembly Removal and Installation

B815H24106012


Removal

- 1) Drain brake fluid. Refer to "Brake Fluid Replacement (Page 4A-6)".
- 2) Disconnect the front brake light switch lead wire coupler (1).



I815H1410028-01

- 3) Place a rag underneath the brake hose union bolt (2) on the master cylinder to catch any spilt brake fluid.
- 4) Remove the brake hose union bolt (2) and disconnect the brake hose.
- 5) Remove the master cylinder assembly (3).



I815H1410029-01

Installation


Install the front brake master cylinder in the reverse order of removal. Pay attention to the following points:

- When installing the master cylinder (1) onto the handlebars (2), align the master cylinder holder's mating surface "A" with the punch mark "B" on the handlebars (2) and tighten the upper holder bolt first. Refer to "Handlebar Construction in Section 6B (Page 6B-2)".


Tightening torque

Master cylinder holder bolt (Upper and Lower)

(a): 10 N·m (1.0 kgf-m, 7.0 lb-ft)



I815H1410031-01



I815H1410030-02

- After setting the brake hose union to the stopper, tighten the union bolt (3) to the specified torque.

⚠ CAUTION

The seal washers should be replaced with the new ones to prevent fluid leakage.

Tightening torque

Brake hose union bolt (b): 23 N·m (2.3 kgf-m, 16.5 lb-ft)



I815H1410032-01

- Bleed air from brake system. Refer to "Air Bleeding from Brake Fluid Circuit (Page 4A-4)".


Front Brake Master Cylinder / Brake Lever Disassembly and Assembly

B815H24106013

Refer to "Front Brake Master Cylinder Assembly Removal and Installation (Page 4A-10)".


Disassembly

- 1) Remove the reservoir cap (1), plate (2) and diaphragm (3).



I815H1410033-01

- 2) Remove the brake lever (4) and brake light switch (5).




I815H1410034-01

- 3) Pull out the dust boot (6).

- 4) Remove the snap ring (7).

Special tool


 : 09900-06108 (Snap ring pliers)



I815H1410035-01

- 5) Remove the following parts from the master cylinder.

- Secondary cup (9)
- Piston (10)
- Primary cup (11)
- Spring (12)



I815H1410036-01


Assembly

Assemble the master cylinder in the reverse order of disassembly. Pay attention to the following points:

CAUTION

- Wash the master cylinder components with new brake fluid before reassembly.
- Do not wipe the brake fluid off after washing the components.
- When washing the components, use the specified brake fluid. Never use different types of fluid or cleaning solvents such as gasoline, kerosine, etc.
- Apply brake fluid to the master cylinder bore and all of the master cylinder component to be inserted into the bore.


BF: Brake fluid (DOT 4)



I815H1410037-01

4A-12 Brake Control System and Diagnosis:

- When installing the brake light switch, align the projection on the switch with the hole in the master cylinder.



I718H1410055-01

- Apply grease to the brake lever pivot bolt.
- Apply grease to the contacting surfaces between piston and brake lever.

SH : Grease 99000–25100 (SUZUKI Silicone Grease or equivalent)




I815H1410039-01

- Tighten the pivot bolt (1) and lock-nut (2) to the specified torque.

Tightening torque

Brake lever pivot bolt (a): 6 N·m (0.6 kgf-m, 4.5 lb-ft)

Brake lever pivot bolt lock-nut (b): 6 N·m (0.6 kgf-m, 4.5 lb-ft)



I815H1410040-01

Front Brake Master Cylinder Parts Inspection

B815H24106014

Refer to “Front Brake Master Cylinder / Brake Lever Disassembly and Assembly (Page 4A-11)”.

Master Cylinder

Inspect the master cylinder bore for any scratches or other damage.




I815H1410041-01

Piston / Rubber Parts

Inspect the piston surface for any scratches or other damage.


Inspect the primary cup, secondary cup and dust boot for wear or damage.



I815H1410042-01

Rear Brake Master Cylinder Components

B815H24106015



I815H1410043-01

1. Reservoir tank	6. Master cylinder	: 18 N·m (1.8 kgf-m, 13.0 lb-ft)
2. Reservoir hose	7. Piston/Cup set	: Apply silicone grease.
3. Brake hose union bolt	8. Push rod	: Apply brake fluid.
4. Brake hose	: 23 N·m (2.3 kgf-m, 16.5 lb-ft)	: Do not reuse.
5. Brake hose connector	: 10 N·m (1.0 kgf-m, 0.7 lb-ft)	

Rear Brake Master Cylinder Assembly Removal and Installation

B815H24106016


Removal

- 1) Remove the frame cover. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Drain brake fluid. Refer to "Brake Fluid Replacement (Page 4A-6)".
- 3) Remove the reservoir mounting bolt (1).



I815H1410044-01

- 4) Place a rag underneath the brake hose union bolt (2) on the master cylinder to catch any spilt brake fluid.
- 5) Remove the brake hose union bolt (2) and disconnect the brake hose.
- 6) Loosen the lock-nut (3).
- 7) Remove the master cylinder mounting bolts (4).
- 8) Remove the master cylinder along with the reservoir by turning the push rod (5).



I815H1410045-01

Installation

Install the rear brake master cylinder in the reverse order of removal. Pay attention to the following points:

⚠ CAUTION

The seal washers should be replaced with the new ones to prevent fluid leakage.


- Tighten the master cylinder mounting bolts (1) to the specified torque.
- Tighten the lock-nut (2) to the specified torque.
- After setting the brake hose union to the stopper, tighten the union bolt (3) to the specified torque.

Tightening torque

Rear brake master cylinder mounting bolt (a): 10 N·m (1.0 kgf-m, 7.0 lb-ft)

Rear brake master cylinder rod lock-nut (b): 18 N·m (1.8 kgf-m, 13.0 lb-ft)

Brake hose union bolt (c): 23 N·m (2.3 kgf-m, 16.5 lb-ft)



I815H1410046-01

- Bleed air from the brake system after reassembling the master cylinder. Refer to "Air Bleeding from Brake Fluid Circuit (Page 4A-4)".
- Adjust the brake pedal height. Refer to "Brake System Inspection in Section 0B (Page 0B-17)".


Rear Brake Master Cylinder Disassembly and Assembly

B815H24106017

Refer to "Front Brake Master Cylinder Assembly Removal and Installation (Page 4A-10)".

Disassembly

- 1) Disconnect the reservoir hose (1).
- 2) Remove the lock-nut (2).




I815H1410047-01

- 3) Remove the brake hose connector (3) and O-ring (4).

Special tool

TOOL : 09900-06108 (Snap ring pliers)




I815H1410048-02

- 4) Pull out the dust boot (5) and remove the snap ring (6).


Special tool

TOOL : 09900-06108 (Snap ring pliers)



I815H1410049-01

- 5) Remove the push rod (7), piston/cup set (8) and spring (9).



I815H1410050-01


Assembly

Assemble the master cylinder in the reverse order of disassembly. Pay attention to the following points:

⚠ CAUTION

- Wash the master cylinder components with new brake fluid before reassembly.
- Do not wipe the brake fluid off after washing the components.
- When washing the components, use the specified brake fluid. Never use different types of fluid or cleaning solvents such as gasoline, kerosene, etc.
- Apply brake fluid to the master cylinder bore and all of the master cylinder component to be inserted into the bore.

BF: Brake fluid (DOT 4)




I649G1410036-02

4A-16 Brake Control System and Diagnosis:

- Apply grease to the push rod end.

 **Grease 99000-25100 (SUZUKI Silicone Grease or equivalent)**



I815H1410051-01

- Install the O-ring (1).

⚠ CAUTION

Replace the O-ring (1) with a new one.



I815H1410052-01


Rear Brake Master Cylinder Parts Inspection

B815H24106018

Refer to “Rear Brake Master Cylinder Disassembly and Assembly (Page 4A-15)”.

Master Cylinder

Inspect the master cylinder bore for any scratches or other damage.




I649G1410038-02

Piston / Rubber Parts

Inspect the piston surface for any scratches or other damage.


Inspect the primary cup, secondary cup and dust boot for wear or damage.



I649G1410039-02

Rear Brake Pedal Construction

B815H24106019



I815H1410053-02

1. Washer	3. Rear brake return spring hook	: Apply grease.	: Do not reuse.
2. Snap ring	: 5.5 N·m (0.55 kgf-m, 4.0 lb-ft)	: Apply thread lock to the thread part.	

Rear Brake Pedal Removal and Installation

B815H24106020

Removal

- 1) Remove the master cylinder assembly. Refer to "Rear Brake Master Cylinder Assembly Removal and Installation (Page 4A-14)".
- 2) Disconnect the rear brake light switch lead wire coupler.
- 3) Remove the rear brake pedal as shown in the rear brake pedal construction. Refer to "Rear Brake Pedal Construction (Page 4A-17)".

Installation

CAUTION

Replace the snap ring with a new one.

Install the rear brake pedal as shown in the rear brake pedal construction. Refer to "Rear Brake Pedal Construction (Page 4A-17)".

Specifications

Service Data

B815H24107001

Brake

Unit: mm (in)

Item	Standard		Limit
Rear brake pedal height	50 – 60 (2.0 – 2.4)		—
Master cylinder bore	Front	14.000 – 14.043 (0.5512 – 0.5529)	—
	Rear	12.700 – 12.743 (0.5000 – 0.5017)	—
Master cylinder piston diam.	Front	13.957 – 13.984 (0.5495 – 0.5506)	—
	Rear	12.657 – 12.684 (0.4983 – 0.4994)	—
Brake fluid type	DOT 4		—

Tightening Torque Specifications

B815H24107002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Air bleeder valve (Front)	7.5	0.75	5.5	☞(Page 4A-5) / ☞(Page 4A-6)
Air bleeder valve (Rear)	7.5	0.75	5.5	☞(Page 4A-5) / ☞(Page 4A-7)
Master cylinder holder bolt (Upper and Lower)	10	1.0	7.0	☞(Page 4A-10)
Brake hose union bolt	23	2.3	16.5	☞(Page 4A-10) / ☞(Page 4A-14)
Brake lever pivot bolt	6	0.6	4.5	☞(Page 4A-12)
Brake lever pivot bolt lock-nut	6	0.6	4.5	☞(Page 4A-12)
Rear brake master cylinder mounting bolt	10	1.0	7.0	☞(Page 4A-14)
Rear brake master cylinder rod lock-nut	18	1.8	13.0	☞(Page 4A-14)

NOTE

The specified tightening torque is also described in the following.

“Front Brake Hose Routing Diagram (Page 4A-1)”

“Rear Brake Hose Routing Diagram (Page 4A-2)”

“Front Brake Master Cylinder Components (Page 4A-9)”

“Rear Brake Master Cylinder Components (Page 4A-13)”

“Rear Brake Pedal Construction (Page 4A-17)”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Tightening Torque List in Section 0C (Page 0C-9)”.

Special Tools and Equipment

Recommended Service Material

B815H24108001

Material	SUZUKI recommended product or Specification		Note
Brake fluid	DOT 4	—	☞ (Page 4A-6) / ☞ (Page 4A-7) / ☞ (Page 4A-11) / ☞ (Page 4A-15)
Grease	SUZUKI Silicone Grease or equivalent	P/No.: 99000–25100	☞ (Page 4A-12) / ☞ (Page 4A-16)

NOTE

Required service material is also described in the following.



“Front Brake Master Cylinder Components (Page 4A-9)”

“Rear Brake Master Cylinder Components (Page 4A-13)”

“Rear Brake Pedal Construction (Page 4A-17)”

Special Tool

B815H24108002


09900–06108 Snap ring pliers ☞ (Page 4A-11) / ☞ (Page 4A-15) / ☞ (Page 4A-15)		09900–25008 Multi-circuit tester set ☞ (Page 4A-3) / ☞ (Page 4A-4)	
---	---	--	---

Front Brakes

Repair Instructions

Front Brake Components

B815H24206001



I815H1420001-04

1. O-ring	7. Front brake disc	1360 : Apply thread lock to the thread part.
2. Piston seal	(a) : 22 N·m (2.2 kgf-m, 16.0 lb-ft)	: Apply brake fluid.
3. Dust seal	(b) : 7.5 N·m (0.75 kgf-m, 5.5 lb-ft)	: Do not reuse.
4. Piston	(c) : 15 N·m (1.5 kgf-m, 11.0 lb-ft)	
5. Brake pad spring	(d) : 39 N·m (3.9 kgf-m, 28.0 lb-ft)	
6. Front brake pad set	(e) : 23 N·m (2.3 kgf-m, 16.5 lb-ft)	


Front Brake Pad Inspection

B815H24206002

The extent of brake pads wear can be checked by observing the grooved limit line "A" on the pads. When the wear exceeds the grooved limit line, replace the pads with new ones. Refer to "Front Brake Pad Replacement (Page 4B-2)".

⚠ CAUTION

Replace the brake pad as a set, otherwise braking performance will be adversely affected.



I815H1420002-01


Front Brake Pad Replacement

B815H24206003

- 1) Loosen the pad mounting pins (1).
- 2) Remove the brake caliper by removing the caliper mounting bolts (2).
- 3) Remove the pad mounting pins (1), brake pads and spring.

NOTE

When removing the pads and pad spring, push the piston all the way into the brake caliper.




I815H1420003-01

⚠ CAUTION

Do not operate the brake lever while dismantling the pads.

- 4) Clean up the caliper especially around the caliper piston.
- 5) Install the spring to caliper, bring its wider side of pawl "A" facing top.



I815H1420004-01


- 6) Install the new brake pads and pad spring with the pad mounting pins.

⚠ CAUTION

Replace the brake pads as a set, otherwise braking performance will be adversely affected.

NOTE

The arrow mark on the brake pad shim (3) must face to the direction of brake disc rotation.



I815H1420005-01


4B-3 Front Brakes:

- 7) Install the brake caliper.
- 8) Tighten the front brake caliper mounting bolts (4) and front brake pad mounting pins (5) to the specified torque.

Tightening torque

Front brake caliper mounting bolt (a): 39 N·m (3.9 kgf-m, 28.0 lb-ft)

Front brake pad mounting pin (b): 15 N·m (1.5 kgf-m, 11.0 lb-ft)



I815H1420006-01

NOTE

After replacing the brake pads, pump the brake lever several times to check for proper brake operation and then check the brake fluid level.

Front Brake Caliper Removal and Installation

B815H24206004

NOTE


The right and left calipers are installed symmetrically and therefore the removal procedure for one side is the same as that for the other side.

Removal

- 1) Drain brake fluid. Refer to “Brake Fluid Replacement in Section 4A (Page 4A-6)”.
- 2) Remove the brake hose from the caliper by removing the union bolt (1) and catch the brake fluid in a suitable receptacle.

NOTE

Place a rag underneath the union bolt on the brake caliper to catch any spilt brake fluid.



I815H1420007-01


NOTE

Slightly loosen the brake caliper housing bolts (2) with special tool to facilitate later disassembly, if necessary.

Special tool


 : 09930-11920 (Torx bit (JT40H))

 : 09930-11940 (Bit holder)



I815H1420008-02

- 3) Remove the brake caliper by removing its mounting bolts (3).



I815H1420022-02

Installation

Install the brake caliper in the reverse order of removal. Pay attention to the following points:

- Tighten each bolt to the specified torque.

Tightening torque

Front brake caliper mounting bolt (a): 39 N·m (3.9 kgf-m, 28.0 lb-ft)

Front brake caliper housing bolt (b): 22 N·m (2.2 kgf-m, 16.0 lb-ft)

Front brake pad mounting pin (c): 15 N·m (1.5 kgf-m, 11.0 lb-ft)


- After setting the brake hose union to the stopper, tighten the union bolt to the specified torque.

⚠ CAUTION


The seal washers should be replaced with the new ones to prevent fluid leakage.

Tightening torque

Brake hose union bolt (d): 23 N·m (2.3 kgf-m, 16.5 lb-ft)



I815H1420009-03



I815H1420010-01

- Bleed air from the brake system after installing the caliper. Refer to "Air Bleeding from Brake Fluid Circuit in Section 4A (Page 4A-4)".
- Check the brake fluid leakage and brake operation.

⚠ WARNING

Brake fluid, if it leaks, will interfere with safe running and discolor painted surfaces. Check the brake hose and hose joints for cracks and fluid leakage.

Front Brake Caliper Disassembly and Assembly

B815H24206005


Refer to "Front Brake Caliper Removal and Installation (Page 4B-3)".

NOTE

The right and left calipers are installed symmetrically and therefore the disassembly procedure for one side is the same as that for the other side.

Disassembly

- 1) Remove the brake pads and spring from the caliper by removing the pad mounting pins (1).




I815H1420023-01

- 2) Separate the caliper halves by removing the caliper housing bolts (2) with the special tools.

Special tool

TOOL (A): 09930-11920 (Torx bit (JT40H))

TOOL (B): 09930-11940 (Bit holder)



I815H1420011-02

- 3) Remove the O-ring.




I815H1420012-01

4B-5 Front Brakes:

- 4) Place a rag over the pistons to prevent it from popping out and then force out the pistons using compressed air.

⚠ CAUTION

Do not use high pressure air to prevent piston damage.




I815H1420013-01



I815H1420014-01

- 5) Remove the dust seals (1) and piston seals (2).



I815H1420015-01

Assembly


Assemble the caliper in the reverse order of disassembly. Pay attention to the following points:

- Wash the caliper bores and pistons with specified brake fluid. Particularly wash the dust seal grooves and piston seal grooves.

BF: Brake fluid (DOT 4)

⚠ CAUTION

- Wash the caliper components with fresh brake fluid before reassembly. Never use cleaning solvent or gasoline to wash them.
- Do not wipe the brake fluid off after washing the components.
- When washing the components, use the specified brake fluid. Never use different types of fluid or cleaning solvent such as gasoline, kerosine or the others.



I649G1420012-02


- Apply the brake fluid to piston seals (1) and dust seals (2).

⚠ CAUTION

Replace the piston seals (1) and dust seals (2) with new ones.

BF: Brake fluid (DOT 4)

- Install the piston seals as shown in the figure.



I649G1420013-02

- Install a new O-ring and reassemble caliper halves.

⚠ CAUTION

Replace the O-ring with a new one.



I815H1420016-01

- Temporarily tighten the brake caliper housing bolts (3) with the special tools.


⚠ CAUTION

After installing the brake caliper to the front fork, tighten the brake caliper housing bolts to the specified torque. Refer to “Front Brake Caliper Removal and Installation (Page 4B-3)”.

Special tool

TOOL (A): 09930-11920 (Torx bit (JT40H))

TOOL (B): 09930-11940 (Bit holder)



I815H1420017-01

- Install the brake pads and pad spring with the pad mounting pins (4).



I815H1420024-01

Front Brake Caliper Parts Inspection

B815H24206006

Refer to “Front Brake Caliper Disassembly and Assembly (Page 4B-4)”.

Brake Caliper Cylinder

Inspect the brake caliper cylinder wall for nicks, scratches or other damage. If any damage is found, replace the caliper with a new one.



I815H1420018-01

Brake Caliper Piston

Inspect the brake caliper piston surface for any scratches or other damage. If any damage is found, replace the piston with a new one.



I815H1420019-01

Brake Pad Mounting Pin

Inspect the brake pad mounting pin for wear and other damage. If any damage is found, replace the mounting pin with a new one.



I815H1420020-01

4B-7 Front Brakes:

Brake Pad Spring

Inspect the brake pad spring for damage and excessive bend. If any damage is found, replace it with a new one.



I815H1420021-01

Front Brake Disc Removal and Installation

B815H24206007

Removal

- 1) Remove the front wheel assembly. Refer to “Front Wheel Assembly Removal and Installation in Section 2D (Page 2D-4)”.
- 2) Remove the front brake disc.



I823H1420021-01

Installation


Install the front brake disc in the reverse order of removal. Pay attention to the following points:

- Make sure that the brake disc is clean and free of any grease.
- Apply thread lock to the brake disc bolts (1) and tighten them to the specified torque.

 **1360** : Thread lock cement 99000–32130 (Thread Lock Cement Super 1360 or equivalent)

Tightening torque

Brake disc bolt (Front) (a): 23 N·m (2.3 kgf-m, 16.5 lb-ft)



I823H1420022-01

Front Brake Disc Inspection

B815H24206008

Brake Disc Thickness

Check the brake disc for damage or cracks and measure the thickness using the micrometer.


Replace the brake disc if the thickness is less than the service limit or if defect is found.

Special tool

 **(A): 09900–20205 (Micrometer (0 – 25 mm))**

Brake disc thickness

Service limit (Front): 5.0 mm (0.20 in)



I649G1420019-03

Brake Disc Runout

- 1) Dismount the front brake caliper. Refer to “Front Brake Caliper Removal and Installation (Page 4B-3)”.
- 2) Measure the runout using the dial gauge.
Replace the disc if the runout exceeds the service limit.


Special tool

 (A): 09900-20607 (Dial gauge (1/100 mm, 10 mm))

 : 09900-20701 (Magnetic stand)

Brake disc runout

Service limit: 0.30 mm (0.012 in)



I649G1420020-03

- 3) Remount the front brake caliper. Refer to “Front Brake Caliper Removal and Installation (Page 4B-3)”.

Specifications**Service Data**

B815H24207001

Brake

Unit: mm (in)

Item	Standard			Limit
Brake disc thickness	Front	5.3 – 5.7 (0.21 – 0.22)		5.0 (0.20)
Brake disc runout	—			0.30 (0.012)
Brake caliper cylinder bore	Front	Leading	30.280 – 30.330 (1.1921 – 1.1941)	—
		Trailing	32.080 – 32.130 (1.2630 – 1.2650)	—
Brake caliper piston diam.	Front	Leading	30.167 – 30.200 (1.1877 – 1.1890)	—
		Trailing	31.967 – 32.000 (1.2585 – 1.2598)	—
Brake fluid type	DOT 4			—

Tightening Torque Specifications

B815H24207002

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
Front brake caliper mounting bolt	39	3.9	28.0	☞ (Page 4B-3) / ☞ (Page 4B-4)
Front brake pad mounting pin	15	1.5	11.0	☞ (Page 4B-3) / ☞ (Page 4B-4)
Front brake caliper housing bolt	22	2.2	16.0	☞ (Page 4B-4)
Brake hose union bolt	23	2.3	16.5	☞ (Page 4B-4)
Brake disc bolt (Front)	23	2.3	16.5	☞ (Page 4B-7)

NOTE

The specified tightening torque is also described in the following.

“Front Brake Components (Page 4B-1)”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Tightening Torque List in Section 0C (Page 0C-9)”.

Special Tools and Equipment

Recommended Service Material

B815H24208001





Material	SUZUKI recommended product or Specification		Note
Brake fluid	DOT 4	—	☞ (Page 4B-5) / ☞ (Page 4B-5)
Thread lock cement	Thread Lock Cement Super 1360 or equivalent	P/No.: 99000–32130	☞ (Page 4B-7)

NOTE

Required service material is also described in the following.
“Front Brake Components (Page 4B-1)”

Special Tool

B815H24208002


09900–20205 Micrometer (0 – 25 mm) ☞ (Page 4B-7) 	09900–20607 Dial gauge (1/100 mm, 10 mm) ☞ (Page 4B-8) 
09900–20701 Magnetic stand ☞ (Page 4B-8) 	09930–11920 Torx bit (JT40H) ☞ (Page 4B-3) / ☞ (Page 4B-4) / ☞ (Page 4B-6) 
09930–11940 Bit holder ☞ (Page 4B-3) / ☞ (Page 4B-4) / ☞ (Page 4B-6) 	

Rear Brakes

Repair Instructions

Rear Brake Components

B815H24306001



I823H1430025-04

1. Rear caliper	7. Rear brake disc	U(e) : 35 N-m (3.5 kgf-m, 2.5 lb-ft)
2. Piston seal	8. Brake pad spring	S : Apply silicone grease to sliding surface.
3. Dust seal	U(a) : 15 N-m (1.5 kgf-m, 11.0 lb-ft)	1360 : Apply thread lock to the thread part.
4. Piston	U(b) : 7.5 N-m (0.75 kgf-m, 5.5 lb-ft)	BF : Apply brake fluid.
5. Rear caliper bracket	U(c) : 33 N-m (3.3 kgf-m, 24.0 lb-ft)	X : Do not reuse.
6. Rear brake pad set	U(d) : 17 N-m (1.7 kgf-m, 12.5 lb-ft)	

4C-2 Rear Brakes:


Rear Brake Pad Inspection

B815H24306002

The extent of brake pads wear can be checked by observing the grooved limit line "A" on the pads. When the wear exceeds the grooved limit line, replace the pads with new ones. Refer to "Rear Brake Pad Replacement (Page 4C-2)".

⚠ CAUTION

Replace the brake pad as a set, otherwise braking performance will be adversely affected.



I815H1430002-02


Rear Brake Pad Replacement

B815H24306003

- 1) Remove the pad mounting pin (1).
- 2) Remove the caliper mounting bolt (2).

⚠ CAUTION

Do not operate the brake pedal while dismantling the pads.




I815H1430003-01

- 3) Remove the brake pads (3) with the rear caliper pivoted up.

NOTE

When removing the pads, push the piston all the way into brake caliper.



I815H1430004-01

- 4) Clean up the caliper, especially around the caliper piston.

⚠ CAUTION

Replace the brake pads as a set, otherwise braking performance will be adversely affected.




I815H1430007-01

- 5) Install the new brake pads.

NOTE

Make sure that the detent of the pad is seated onto the retainer on the caliper bracket.




I823H1430005-01

- 6) Tighten the caliper mounting bolt (4) and pad mounting pin (5) to the specified torque.

Tightening torque

Rear brake caliper mounting bolt (a): 17 N·m (1.7 kgf-m, 12.5 lb-ft)

Rear brake pad mounting pin (b): 15 N·m (1.5 kgf-m, 11.0 lb-ft)



I815H1430008-01

NOTE

After replacing the brake pads, pump the brake pedal several times to check for proper brake operation and then check the brake fluid level.

Rear Brake Caliper Removal and Installation


B815H24306004

Removal

- 1) Drain brake fluid. Refer to "Brake Fluid Replacement in Section 4A (Page 4A-6)".
- 2) Remove the brake hose from the caliper by removing the union bolt (1) and catch the brake fluid in a suitable receptacle.


NOTE

Place a rag underneath the union bolt on the brake caliper to catch any spilt brake fluid.



I815H1430009-01

- 3) Remove the brake pads. Refer to "Rear Brake Pad Replacement (Page 4C-2)".
- 4) Pivot the caliper up and remove the caliper from the caliper bracket.



I815H1430013-01

Installation

Install the brake caliper in the reverse order of removal. Pay attention to the following points:


- Install the brake pad and remount the brake caliper. Refer to "Rear Brake Pad Replacement (Page 4C-2)".
- After setting the brake hose union to the stopper, tighten the union bolt (1) to the specified torque.

⚠ CAUTION

The seal washers should be replaced with the new ones to prevent fluid leakage.

Tightening torque

Brake hose union bolt (a): 23 N·m (2.3 kgf-m, 16.5 lb-ft)



I815H1430012-01

- Bleed air from the brake system after installing the caliper. Refer to "Air Bleeding from Brake Fluid Circuit in Section 4A (Page 4A-4)".
- Check the brake fluid leakage and brake operation.

⚠ WARNING

Brake fluid, if it leaks, will interfere with safe running and discolor painted surfaces. Check the brake hose and hose joints for cracks and fluid leakage.

4C-4 Rear Brakes:


Rear Brake Caliper Disassembly and Assembly

B815H24306005

Refer to "Rear Brake Caliper Removal and Installation (Page 4C-3)".


Disassembly

- 1) Remove the pad spring (1), rubber boot (2) and sliding pin (3).



I823H1430010-01

- 2) Remove the pad spring (4).
- 3) Remove the spacer (5) and rubber boot (6) from the caliper.



I823H1430011-02

- 4) Place a rag over the piston to prevent it from popping out and then force out the piston using compressed air.


⚠ CAUTION

Do not use high pressure air to prevent piston damage.



I823H1430012-01

- 5) Remove the dust seal (7) and piston seal (8).



I823H1430013-01

Assembly

Assemble the caliper in the reverse order of disassembly. Pay attention to the following points:

- Wash the caliper bore and piston with specified brake fluid. Particularly wash the dust seal groove and piston seal groove.

BF: Brake fluid (DOT 4)

⚠ CAUTION

- Wash the caliper components with fresh brake fluid before reassembly. Never use cleaning solvent or gasoline to wash them.
- Do not wipe the brake fluid off after washing the components.
- When washing the components, use the specified brake fluid. Never use different types of fluid or cleaning solvent such as gasoline, kerosine or the others.



I649G1430018-02


- Apply the brake fluid to piston seal (1) and dust seal (2).

⚠ CAUTION

Replace the piston seal (1) and dust seal (2) with new ones.

BF: Brake fluid (DOT 4)

- Install the piston seal (1) as shown in the figure.




I649G1420013-02

- Apply grease to the inside of the rubber boot.

⚠ : Grease 99000–25100 (SUZUKI Silicone Grease or equivalent)

- Set the rubber boot to the caliper.
- Install the spacer into the rubber boot.




I823H1430014-01

- Tighten the sliding pin (3) and apply grease to the sliding pin.

⚠ : Grease 99000–25100 (SUZUKI Silicone Grease or equivalent)


Tightening torque

Rear brake caliper sliding pin (a): 33 N·m (3.3 kgf-m, 24.0 lb-ft)



I823H1430015-01

- Set the rubber boot onto the brake caliper and sliding pin.
- Install the brake caliper to its bracket.



I823H1430024-01

4C-6 Rear Brakes:

Rear Brake Caliper Parts Inspection

B815H24306006

Refer to "Rear Brake Caliper Disassembly and Assembly (Page 4C-4)".

Brake Caliper Cylinder

Inspect the brake caliper cylinder wall for nicks, scratches or other damage. If any damage is found, replace the caliper with a new one.



I823H1430018-01

Brake Caliper Piston

Inspect the brake caliper piston surface for any scratches or other damage. If any damage is found, replace the piston with a new one.



I823H1430017-01

Brake Caliper Sliding Pin

Inspect the brake caliper sliding pin for wear and other damage. If any damage is found, replace the sliding pin with a new one.



I823H1430019-01

Boot and Spacer

Inspect the boots and spacer for damage and wear. If any defects are found, replace them with new ones.



I823H1430020-01

Brake Pad Spring

Inspect the brake pad springs for damage and excessive bend. If any defects are found, replace them with new ones.



I823H1430021-01

Rear Brake Disc Removal and Installation

B815H24306007

Removal

- 1) Remove the rear wheel assembly. Refer to "Rear Wheel Assembly Removal and Installation in Section 2D (Page 2D-11)".
- 2) Remove the rear brake disc.



I823H1430022-01

Installation


Install the rear brake disc in the reverse order of removal. Pay attention to the following points:

- Make sure that the brake disc is clean and free of any grease.
- Apply thread lock to the brake disc bolts (1) and tighten them to the specified torque.

 : Thread lock cement 99000-32130 (Thread Lock Cement Super 1360 or equivalent)

Tightening torque

Brake disc bolt (Rear) (a): 35 N·m (3.5 kgf-m, 25.5 lb-ft)



I823H1430023-01

Rear Brake Disc Inspection

Brake Disc Thickness

Check the brake disc for damage or cracks and measure the thickness using the micrometer.


Replace the brake disc if the thickness is less than the service limit or if defect is found.

Special tool

 (A): 09900-20205 (Micrometer (0 – 25 mm))

Brake disc thickness

Service limit (Rear): 5.0 mm (0.20 in)



I649G1430027-03

Brake Disc Runout

- 1) Dismount the rear brake caliper. Refer to "Rear Brake Caliper Removal and Installation (Page 4C-3)".
- 2) Measure the runout using the dial gauge. Replace the disc if the runout exceeds the service limit.


Special tool

 (A): 09900-20607 (Dial gauge (1/100 mm, 10 mm))

 : 09900-20701 (Magnetic stand)

Brake disc runout

Service limit: 0.30 mm (0.012 in)



I649G1430028-03

- 3) Remount the rear brake caliper. Refer to "Rear Brake Caliper Removal and Installation (Page 4C-3)".

Specifications

Service Data

B815H24307001

Brake

Unit: mm (in)

Item	Standard		Limit
Brake disc thickness	Rear	5.3 – 5.7 (0.21 – 0.22)	5.0 (0.20)
Brake disc runout	—		0.30 (0.012)
Brake caliper cylinder bore	Rear	38.180 – 38.256 (1.5031 – 1.5061)	—
Brake caliper piston diam.	Rear	38.098 – 38.148 (1.4999 – 1.5019)	—
Brake fluid type	DOT 4		—

Tightening Torque Specifications

B815H24307002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Rear brake caliper mounting bolt	17	1.7	12.5	☞ (Page 4C-3)
Rear brake pad mounting pin	15	1.5	11.0	☞ (Page 4C-3)
Brake hose union bolt	23	2.3	16.5	☞ (Page 4C-3)
Rear brake caliper sliding pin	33	3.3	24.0	☞ (Page 4C-5)
Brake disc bolt (Rear)	35	3.5	25.5	☞ (Page 4C-7)

NOTE

The specified tightening torque is also described in the following.
 “Rear Brake Components (Page 4C-1)”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Tightening Torque List in Section 0C (Page 0C-9)”.

Special Tools and Equipment

Recommended Service Material

B815H24308001



Material	SUZUKI recommended product or Specification		Note
Brake fluid	DOT 4	—	☞ (Page 4C-4) / ☞ (Page 4C-5)
Grease	SUZUKI Silicone Grease or equivalent	P/No.: 99000-25100	☞ (Page 4C-5) / ☞ (Page 4C-5)
Thread lock cement	Thread Lock Cement Super 1360 or equivalent	P/No.: 99000-32130	☞ (Page 4C-7)

NOTE

Required service material is also described in the following.
 “Rear Brake Components (Page 4C-1)”

Special Tool

B815H24308002

09900-20205 Micrometer (0 – 25 mm) ☞ (Page 4C-7)		09900-20607 Dial gauge (1/100 mm, 10 mm) ☞ (Page 4C-7)	
09900-20701 Magnetic stand ☞ (Page 4C-7)			

Section 5

Transmission / Transaxle

CONTENTS

Precautions	5-1	Clutch	5C-1
Precautions.....	5-1	Precautions.....	5C-1
Precautions for Transmission / Transaxle.....	5-1	Precautions for Clutch System.....	5C-1
		Clutch Fluid (Brake Fluid) Information.....	5C-1
Manual Transmission.....	5B-1	Schematic and Routing Diagram.....	5C-2
Diagnostic Information and Procedures.....	5B-1	Clutch Hose Routing Diagram.....	5C-2
Manual Transmission Symptom Diagnosis.....	5B-1	Diagnostic Information and Procedures.....	5C-3
Repair Instructions	5B-2	Clutch System Symptom Diagnosis	5C-3
Transmission Components	5B-2	Repair Instructions	5C-3
Transmission Removal.....	5B-3	Clutch Lever Position Switch Inspection	5C-3
Transmission Installation	5B-4	Clutch Fluid Level Check	5C-3
Transmission Construction.....	5B-7	Clutch Hose Inspection	5C-3
Countershaft Gear / Driveshaft Gear		Air Bleeding from Clutch Fluid Circuit	5C-4
Disassembly and Assembly	5B-7	Clutch Fluid Replacement	5C-4
Transmission Related Parts Inspection.....	5B-10	Clutch Hose Removal and Installation	5C-5
Gear Position (GP) Switch Inspection.....	5B-11	Clutch Control System Components	5C-6
Gear Position (GP) Switch Removal and		Clutch Master Cylinder Assembly Removal	
Installation.....	5B-11	and Installation.....	5C-7
Gearshift Lever Construction	5B-13	Clutch Master Cylinder / Clutch Lever	
Gearshift Lever Removal and Installation	5B-14	Disassembly and Assembly	5C-8
Gearshift Lever Height Inspection and		Clutch Master Cylinder Components	
Adjustment	5B-14	Inspection.....	5C-10
Gearshift Shaft / Gearshift Cam Plate		Clutch Release Cylinder / Push Rod Removal	
Components.....	5B-14	and Installation.....	5C-10
Gearshift Shaft Construction	5B-15	Clutch Push Rod Inspection	5C-12
Gearshift Shaft / Gearshift Cam Plate		Clutch Release Cylinder Disassembly and	
Removal and Installation.....	5B-16	Assembly.....	5C-12
Gearshift Linkage Inspection	5B-17	Clutch Release Cylinder Inspection	5C-12
Gearshift Shaft Oil Seal / Bearing Removal		Clutch Components.....	5C-13
and Installation.....	5B-17	Clutch Removal.....	5C-14
Specifications.....	5B-19	Clutch Installation.....	5C-17
Service Data	5B-19	Clutch Parts Inspection	5C-21
Tightening Torque Specifications.....	5B-19	Specifications.....	5C-23
Special Tools and Equipment.....	5B-20	Service Data.....	5C-23
Recommended Service Material.....	5B-20	Tightening Torque Specifications.....	5C-23
Special Tool	5B-20	Special Tools and Equipment	5C-24
		Recommended Service Material	5C-24
		Special Tool	5C-24

Precautions

Precautions

Precautions for Transmission / Transaxle

B815H25000001

Refer to “General Precautions in Section 00 (Page 00-1)”.

Manual Transmission

Diagnostic Information and Procedures

Manual Transmission Symptom Diagnosis



B815H25204001

Condition	Possible cause	Correction / Reference Item
Engine is noisy (Noise seems to come from the transmission)	Worn or rubbing gear.	<i>Replace.</i>
	Worn countershaft spline.	<i>Replace countershaft.</i>
	Worn driveshaft spline.	<i>Replace driveshaft.</i>
	Worn or rubbing primary gear.	<i>Replace.</i>
	Worn bearing.	<i>Replace.</i>
Transmission will not shift	Broken gearshift cam.	<i>Replace.</i>
	Distorted gearshift fork.	<i>Replace.</i>
	Worn gearshift pawl.	<i>Replace.</i>
Transmission will not shift back	Broken gearshift shaft return spring.	<i>Replace.</i>
	Rubbing or stuck gearshift shaft.	<i>Repair or replace.</i>
	Worn or distorted gearshift fork.	<i>Replace.</i>
Transmission jumps out of gear	Worn shifting gears on driveshaft or countershaft.	<i>Replace.</i>
	Worn or distorted gearshift fork.	<i>Replace.</i>
	Weakened gearshift stopper spring.	<i>Replace.</i>
	Worn gearshift cam plate.	<i>Replace.</i>

Repair Instructions

Transmission Components

B815H25206001



I815H1520016-01

1. 2nd drive gear	12. 5th driven gear	: 145 N·m (14.5 kgf-m, 105.0 lb-ft)
2. 6th drive gear	13. 1st driven gear	: 10 N·m (1.0 kgf-m, 7.0 lb-ft)
3. 3rd/4th drive gears	14. Gearshift cam stopper	: 13 N·m (1.3 kgf-m, 9.5 lb-ft)
4. 5th drive gear	15. Gearshift cam plate	: 8 N·m (0.8 kgf-m, 6.0 lb-ft)
5. Countershaft/1st drive gear	16. Gearshift cam	: 6.5 N·m (0.65 kgf-m, 4.7 lb-ft)
6. Driveshaft	17. Gearshift fork shaft	: Apply engine oil.
7. Friction ring	18. Gearshift fork (For 3rd/4th drive gears)	: Apply molybdenum oil solution.
8. 2nd driven gear	19. Gearshift fork shaft	: Apply grease to the oil seal lip.
9. 6th driven gear	20. Gearshift fork (For 6th driven gear)	: Apply thread lock to the thread part.
10. 3rd driven gear	21. Gearshift fork (For 5th driven gear)	: Do not reuse.
11. 4th driven gear	22. GP switch	


Transmission Removal

B815H25206002

- 1) Remove the engine assembly from the frame. Refer to "Engine Assembly Removal in Section 1D (Page 1D-19)".
- 2) Remove the engine top side. Refer to "Engine Top Side Disassembly in Section 1D (Page 1D-27)".
- 3) Separate the upper and lower crankcases. Refer to "Engine Bottom Side Disassembly in Section 1D (Page 1D-63)".


Driveshaft Assembly / Countershaft Assembly

- 1) Remove the driveshaft assembly (1) and countershaft assembly (2).
- 2) Remove the oil seal (3).



I823H1520001-01


- 3) Remove the bearing pins (4) and C-ring (5).



I823H1520002-01


Gearshift Fork and Gearshift Cam

- 1) Remove the gearshift cam bearing retainer (1) from the lower crankcase.




I815H1520002-01

- 2) Remove the gearshift fork shafts (2) and gearshift forks (3) from the lower crankcase.



I823H1520004-01

- 3) Remove the gearshift cam (4) along with its bearing.




I823H1520005-01

Bearing

- 1) Remove the gearshift shaft bearing using the special tool.

Special tool

TOOL (A): 09921-20240 (Bearing remover set)




I823H1520006-01

- 2) Remove the gearshift cam bearing using the special tools.

Special tool

TOOL (B): 09923-74511 (Bearing remover)

TOOL (C): 09930-30104 (Rotor remover slide shaft)



I823H1520007-01

Transmission Installation

B815H25206003

Install the transmission in the reverse order of removal.
Pay attention to the following points:

Bearing

⚠ CAUTION

Replace the removed bearings with new ones.


- Install the gearshift shaft bearing using the special tool.

Special tool

TOOL (A): 09913-70210 (Bearing installer set)

NOTE

The stamped mark side of the gearshift shaft bearing faces outside.



I823H1520008-01


- Install the gearshift cam bearing using the special tool.

Special tool

TOOL (A): 09913-70210 (Bearing installer set)

NOTE

The stamped mark side of gearshift cam bearing faces the gearshift cam.



I823H1520009-01

- Install the gearshift cam along with the bearing.


NOTE

The stamped mark side of the gearshift cam bearing faces outside.




I823H1520010-01

- Install the gearshift forks and their shafts in position.



I823H1520011-02



I823H1520012-02

"A": For 3rd/ 4th drive gears

"B": For 6th driven gear

"C": For 5th driven gear

- Install the bearing retainer (4).


NOTE

Apply a small quantity of thread lock to the bearing retainer screws and tighten them to the specified torque.

⑬③② : Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER 1322 or equivalent)

Tightening torque

Bearing retainer screw: 8 N·m (0.8 kgf-m, 6.0 lb-ft)




I823H1520013-01

Driveshaft / Countershaft Assembly

- Install the bearing pins (1), (2) and C-ring (3) on the upper crankcase.

NOTE

Before installing the transmission assembly, use a nonflammable cleaning solvent to wipe off oily or greasy matter from the crankcase mating surfaces and outside of the oil seal fitting surfaces.




I815H1520003-01

5B-6 Manual Transmission:

- Install the driveshaft assembly on the upper crankcase.

NOTE

Align the bearing ring "A" with the groove "B" on the crankcase and the bearing pin (1) with the indent "C" on the bearing.




I823H1520015-01

- Install the countershaft assembly on the upper crankcase.


NOTE

Align the C-ring (3) with the groove "D" on the bearing and the bearing pin (2) with the indent "E" on the bearing.



I815H1520004-01

- Install the oil seal (4).
- Turn each bearing to set the bearing dowel pin "F" and "G" in position.




I815H1520005-01

- Assemble the engine. Refer to "Engine Bottom Side Assembly in Section 1D (Page 1D-71)" and "Engine Top Side Assembly in Section 1D (Page 1D-31)".
- Remount the engine assembly. Refer to "Engine Assembly Installation in Section 1D (Page 1D-24)".

Transmission Construction

B815H25206004



I823H1520086-02

Countershaft Gear / Driveshaft Gear Disassembly and Assembly

B815H25206005

Refer to "Transmission Removal (Page 5B-3)" and "Transmission Installation (Page 5B-4)".

Disassembly

⚠ CAUTION

Identify the position of each removed part. Organize the parts in their respective groups (i.e., drive or driven) so that they can be reinstalled in their original positions.

Disassemble the countershaft and driveshaft as shown in the transmission construction. Refer to "Transmission Construction (Page 5B-7)".


Pay attention to the following points:

Countershaft

- Remove the 6th drive gear snap ring (1) from its groove and slide it towards the 3rd/4th drive gears (2).

Special tool


Tool : 09900-06104 (Snap ring pliers)



I823H1520018-01


5B-8 Manual Transmission:

- Slide the 6th (3) and 2nd (4) drive gears toward the 3rd/4th drive gears (2), then remove the 2nd drive gear circlip (5).
- Remove the 2nd drive gear (4) and 6th drive gear (3).



I823H1520019-01


- Remove the countershaft bearing (6) using hydraulic press.



I823H1520020-01


Driveshaft

- Remove the friction ring (1) on the driveshaft by using a screwdriver.



I823H1520087-01

- Remove the driveshaft bearing (2) along with the spacer (3) using a hydraulic press.



I823H1520021-02

Assembly

NOTE

When reassembling the transmission gears, attention must be given to the locations and positions of washers and snap rings. The cross sectional view shows the correct position of the gears, bushings, washers and snap rings. Refer to "Transmission Construction (Page 5B-7)".

⚠ CAUTION

- Never reuse a snap ring. After a snap ring has been removed from the shaft, it should be discarded and a new snap ring must be installed.
- When installing a new snap ring, do not expand the end gap larger than required to slip the snap ring over the shaft.
- After installing a snap ring, make sure that it is completely seated in the groove and securely fitted.


NOTE

- Rotate the bearing by hand to inspect if there is any abnormal noise and for smooth rotation. Replace the bearing if there is anything unusual.
- Before installing the gears, apply molybdenum oil to the driveshaft and countershaft.
- Before installing the oil seal, apply grease to the oil seal lip.

M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)

⚠: Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)

- When installing a new snap ring (1), pay attention to its direction. Fit it to the side where the thrust is as shown in the figure.



I649G1520049-02

"A": Thrust

"B": Sharp edge

Driveshaft


- Install the driveshaft bearing (1) using a hydraulic press and special tool.

⚠ CAUTION

Never reuse driveshaft bearing (1).

Special tool

TOOL (A): 09913-70210 (Bearing installer set)




I823H1520022-01

- Install the spacer (2) using a hydraulic press and special tool.

Special tool

TOOL (A): 09913-70210 (Bearing installer set)




I823H1520023-02


- Press fit the friction ring (3) of the driveshaft with the special tool until the dimension "a" becomes 4.5 – 4.8 mm (0.18 – 0.19 in).

Special tool

TOOL (A): 09913-70210 (Bearing installer set)



I823H1520088-01




I823H1520089-02


"a": 4.5 – 4.8 mm (0.18 – 0.19 in)

5B-10 Manual Transmission:

- When installing the gear bushings onto the driveshaft, align the shaft oil holes "A" with the bushing oil hole "B".



I823H1520024-01




I823H1520025-01

Countershaft

- Install the countershaft bearing (1) using a hydraulic press and special tool.


Special tool

TOOL (A): 09913-70210 (Bearing installer set)



I823H1520026-02

- When installing the gear bushing onto the countershaft, align the shaft oil hole "A" with the bushing oil hole "B".



I823H1520027-01

Transmission Related Parts Inspection

B815H25206006

Refer to "Transmission Removal (Page 5B-3)", "Transmission Installation (Page 5B-4)" and "Countershaft Gear / Driveshaft Gear Disassembly and Assembly (Page 5B-7)".

Gearshift Fork to Groove Clearance

NOTE

The clearance for each gearshift fork plays an important role in the smoothness and positiveness of the shifting action.

Using the thickness gauge, check the gearshift fork clearance in the groove of its gear. If the clearance checked is noted to exceed the limit specified, replace the fork or its gear, or both.


Special tool

TOOL (A): 09900-20803 (Thickness gauge)

Gearshift fork to gearshift fork groove clearance

Standard: 0.1 – 0.3 mm (0.004 – 0.012 in)

Service limit: 0.5 mm (0.02 in)



I649G1520056-03

Gearshift Fork Groove Width


Measure the gearshift fork groove width using the vernier calipers.

Special tool

 (A): 09900-20102 (Vernier calipers (1/20 mm, 200 mm))

Gearshift fork groove width

Standard: 5.0 – 5.1 mm (0.197 – 0.201 in)



I649G1520057-03

Gearshift Fork Thickness


Measure the gearshift fork thickness using the vernier calipers.

Special tool

 (A): 09900-20102 (Vernier calipers (1/20 mm, 200 mm))

Gearshift fork thickness

Standard: 4.8 – 4.9 mm (0.189 – 0.193 in)




I649G1520058-03

Gearshift Cam Bearing

Inspect the gearshift cam bearings, left and right for abnormal noise and smooth rotation.

Replace the bearing if there is anything unusual. Refer to "Transmission Removal (Page 5B-3)" and "Transmission Installation (Page 5B-4)".



I815H1520006-01

Gear Position (GP) Switch Inspection

B815H25206007

Refer to "Side-stand / Ignition Interlock System Parts Inspection in Section 1I (Page 1I-8)".

Gear Position (GP) Switch Removal and Installation

B815H25206008


Removal

- 1) Turn the ignition switch OFF.
- 2) Drain engine oil.
- 3) Remove the primary driven gear assembly. Refer to "Clutch Removal in Section 5C (Page 5C-14)" and "Clutch Installation in Section 5C (Page 5C-17)".
- 4) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation in Section 1G (Page 1G-9)".
- 5) Disconnect the gear position switch coupler (1).



I815H1520007-01

- 6) Remove the gear position switch (2).




I815H1520008-01

Installation

Install the gear position switch in the reverse order of removal. Pay attention to the following points:

NOTE

Align the gear position switch pin "A" with the gearshift cam hole "B".




I815H1520009-01

- Apply a bond lightly to the gear position switch bolt lead wire grommet (1).

1207B : Sealant 99000-31140 (SUZUKI BOND No.1207B or equivalent)

NOTE

- The flat surface of the clamp faces the lead wire.
- After contacting the clamp to the stopper "C" of the crankcase, tighten the clamp bolt.
- Be sure to install the grommet (1) to the crankcase.




I815H1520010-01

Tightening torque

Gear position switch mounting bolt (a): 6.5 N·m (0.65 kgf-m, 4.7 lb-ft)

Gear position switch lead wire clamp bolt (b): 6.5 N·m (0.65 kgf-m, 4.7 lb-ft)




I815H1520011-01

- Route the gear position switch lead wire. Refer to "Wiring Harness Routing Diagram in Section 9A (Page 9A-5)".

Gearshift Lever Construction

B815H25206009



I815H1520012-01

"a": Approx. 14°	(a) : 10 N·m (1.0 kgf-m, 7.0 lb-ft)	A : Apply grease.
"b": 50 – 60 mm (2.0 – 2.4 in)	(b) : 40 N·m (4.0 kgf-m, 29.0 lb-ft)	

Gearshift Lever Removal and Installation

B815H25206010

Removal

Remove the gearshift lever as shown in the gearshift lever construction. Refer to “Gearshift Lever Construction (Page 5B-13)”.

Installation

- 1) Install the gearshift lever as shown in the gearshift lever construction. Refer to “Gearshift Lever Construction (Page 5B-13)”.
- 2) After installing the gearshift lever, check the gearshift lever height. Refer to “Gearshift Lever Height Inspection and Adjustment (Page 5B-14)”.


Gearshift Lever Height Inspection and Adjustment

B815H25206011

Inspect and adjust the gearshift lever height in the following procedures:


- 1) Inspect the gearshift lever height “a” between the lever top and footrest. Adjust the gearshift lever height if necessary.

Gearshift lever height “a”
Standard: 50 – 60 mm (2.0 – 2.4 in)



I823H1520029-02


- 2) Loosen the lock-nuts (1).
- 3) Turn the gearshift link rod (2) until the gearshift lever is 50 – 60 mm (2.0 – 2.4 in) below the top of the footrest.
- 4) Tighten the lock-nuts securely.



I823H1520030-01

Gearshift Shaft / Gearshift Cam Plate Components


B815H25206012



1.	Gearshift shaft
2.	Gearshift shaft return spring
3.	Gearshift cam drive plate
4.	Gearshift plate return spring
(a)	: 19 N·m (1.9 kgf·m, 13.5 lb·ft)
1303	: Apply thread lock to the thread part.
⊗	: Do not reuse.

Gearshift Shaft Construction

B815H25206013



I815H1520013-02

1. Gearshift shaft	6. Gearshift cam drive plate	1303 : Apply thread lock to the thread part.
2. Washer	(a) : 10 N·m (1.0 kgf-m, 7.0 lb-ft)	1322 : Apply thread lock to the thread part.
3. Snap ring	(b) : 13 N·m (1.3 kgf-m, 9.5 lb-ft)	: Do not reuse.
4. Gearshift shaft return spring	(c) : 19 N·m (1.9 kgf-m, 13.5 lb-ft)	
5. Gearshift plate return spring	: Apply grease.	

Gearshift Shaft / Gearshift Cam Plate Removal and Installation

B815H25206014

Refer to “Engine Assembly Removal in Section 1D (Page 1D-19)”.
Refer to “Engine Assembly Installation in Section 1D (Page 1D-24)”.

Removal


NOTE

It is necessary to remove the engine assembly from the frame for gearshift system related parts removal.

- 1) Remove the gearshift shaft, gearshift cam plate and gearshift cam stopper. Refer to “Engine Bottom Side Disassembly in Section 1D (Page 1D-63)”.
- 2) Remove the parts in the figure from the gearshift shaft.

Special tool

Tool : 09900-06107 (Snap ring pliers)



I823H1520031-02

1.	Washer
2.	Snap ring
3.	Gearshift shaft return spring
4.	Gearshift cam drive plate
5.	Gearshift plate return spring
6.	Washer
7.	Snap ring

Installation


Refer to “Engine Bottom Side Assembly in Section 1D (Page 1D-71)”.

Install the gearshift shaft and gearshift cam plate in the reverse order of removal. Pay attention to the following points:

CAUTION

The removed snap rings must be replaced with new ones.

- When installing the gearshift shaft return spring, position the stopper “A” of gearshift arm between the shaft return spring ends “B”.



I823H1520039-03

- After installing the gearshift lever, check the gearshift lever height. Refer to “Gearshift Lever Height Inspection and Adjustment (Page 5B-14)”.

Gearshift Linkage Inspection

B815H25206015

Refer to “Gearshift Shaft / Gearshift Cam Plate Removal and Installation (Page 5B-16)”.

Gearshift Shaft

Check the gearshift shaft for bend or wear.
Check the return spring for damage or fatigue.
If any defects are found, replace the defective part(s).



I823H1520041-01

Gearshift Shaft Oil Seal


Inspect the gearshift shaft oil seal lip for damage or wear. If any defect is found, replace the oil seal with a new one.



I823H1520042-01

Gearshift Shaft Bearing

Inspect the gearshift shaft bearings for abnormal noise and smooth rotation. Replace the bearing if there is anything unusual.



I823H1520043-01

Gearshift Shaft Oil Seal / Bearing Removal and Installation

B815H25206016

Removal

- 1) Remove the gearshift shaft. Refer to “Gearshift Shaft / Gearshift Cam Plate Removal and Installation (Page 5B-16)”.
- 2) Remove the gearshift shaft oil seal.




I823H1520044-01


- 3) Remove the bearings (1) and (2) with the special tools.

Special tool

TOOL (A): 09921-20240 (Bearing remover set)



I823H1520045-01



I815H1520014-01

Installation

Install the oil seal and bearings in the reverse order of removal. Pay attention to the following points:

⚠ CAUTION

The removed oil seal and bearings must be replaced with new ones.


- Install the bearings with the special tool.

NOTE


The stamped mark side of gearshift shaft bearing faces outside.

Special tool

TOOL (A): 09913-70210 (Bearing installer set)



I823H1520008-01



I823H1520046-02

- Install the oil seal with the special tool.

Special tool

TOOL (A): 09913-70210 (Bearing installer set)

- Apply grease to the oil seal lip.

⚠ : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)



I815H1520015-01

Specifications

Service Data

B815H25207001

Drive Train

Unit: mm (in) Except ratio

Item		Standard	Limit
Primary reduction ratio		1.596 (83/52)	—
Final reduction ratio		2.388 (43/18)	—
Gear ratios	Low	2.615 (34/13)	—
	2nd	1.937 (31/16)	—
	3rd	1.526 (29/19)	—
	4th	1.285 (27/21)	—
	5th	1.136 (25/22)	—
	Top	1.043 (24/23)	—
Shift fork to groove clearance		0.1 – 0.3 (0.004 – 0.012)	0.5 (0.02)
Shift fork groove width		5.0 – 5.1 (0.197 – 0.201)	—
Shift fork thickness		4.8 – 4.9 (0.189 – 0.193)	—
Drive chain	Type	RK GB50GSVZ4	—
	Links	114 links	—
	20-pitch length	—	319.4 (12.57)
Drive chain slack (on side-stand)		20 – 30 (0.8 – 1.2)	—
Gearshift lever height		50 – 60 (2.0 – 2.4)	—

Tightening Torque Specifications

B815H25207002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Bearing retainer screw	8	0.8	6.0	☞ (Page 5B-5)
Gear position switch mounting bolt	6.5	0.65	4.7	☞ (Page 5B-12)
Gear position switch lead wire clamp bolt	6.5	0.65	4.7	☞ (Page 5B-12)

NOTE

The specified tightening torque is also described in the following.

“Transmission Components (Page 5B-2)”

“Gearshift Lever Construction (Page 5B-13)”

“Gearshift Shaft / Gearshift Cam Plate Components (Page 5B-14)”

“Gearshift Shaft Construction (Page 5B-15)”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Tightening Torque List in Section 0C (Page 0C-9)”.

Special Tools and Equipment

Recommended Service Material

B815H25208001

Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI SUPER GREASE A or equivalent	P/No.: 99000-25010	☞ (Page 5B-9) / ☞ (Page 5B-18)
Molybdenum oil	MOLYBDENUM OIL SOLUTION	—	☞ (Page 5B-9)
Sealant	SUZUKI BOND No.1207B or equivalent	P/No.: 99000-31140	☞ (Page 5B-12)
Thread lock cement	THREAD LOCK CEMENT SUPER 1322 or equivalent	P/No.: 99000-32110	☞ (Page 5B-5)

NOTE

Required service material is also described in the following.

“Transmission Components (Page 5B-2)”









“Gearshift Lever Construction (Page 5B-13)”

“Gearshift Shaft / Gearshift Cam Plate Components (Page 5B-14)”

“Gearshift Shaft Construction (Page 5B-15)”

Special Tool

B815H25208002

09900-06104 Snap ring pliers ☞ (Page 5B-7)		09900-06107 Snap ring pliers ☞ (Page 5B-16)	
09900-20102 Vernier calipers (1/20 mm, 200 mm) ☞ (Page 5B-11) / ☞ (Page 5B-11)		09900-20803 Thickness gauge ☞ (Page 5B-10)	
09913-70210 Bearing installer set ☞ (Page 5B-4) / ☞ (Page 5B-4) / ☞ (Page 5B-9) / ☞ (Page 5B-9) / ☞ (Page 5B-10) / ☞ (Page 5B-18) / ☞ (Page 5B-18)		09921-20240 Bearing remover set ☞ (Page 5B-4) / ☞ (Page 5B-17)	
09923-74511 Bearing remover ☞ (Page 5B-4)		09930-30104 Rotor remover slide shaft ☞ (Page 5B-4)	

Clutch

Precautions

Precautions for Clutch System

B815H25300001

Refer to “General Precautions in Section 00 (Page 00-1)”.

Clutch Fluid (Brake Fluid) Information

B815H25300002

⚠ WARNING

- This clutch system is filled with an ethylene glycol-based DOT 4 brake fluid. Do not use or mix different types of fluid such as silicone-based or petroleum-based.
- Do not use any brake fluid taken from old, used or unsealed containers. Never reuse brake fluid left over from the last servicing or stored for long periods.
- When storing brake fluid, seal the container completely and keep away from children.
- When replenishing brake fluid, take care not to get dust into fluid.
- When washing clutch components, use fresh brake fluid. Never use cleaning solvent.


⚠ CAUTION

Immediately and completely wipe off any brake fluid contacting any part of the motorcycle. The brake fluid reacts chemically with paint, plastics and rubber materials, etc., and will damage them severely.

Schematic and Routing Diagram

Clutch Hose Routing Diagram

B815H25302001



I815H1530001-05

1. Stopper : After the clutch hose union has contacted the stopper, tighten the union bolt.	"a": 28°
2. Hose guide : Install the hose guide (2) to the grommet (4) on the clutch oil hose properly.	"b": Clearance
3. Clamp : Equalize the edge "b" of the protective rubber.	(a) : 23 N·m (2.3 kgf-m, 16.5 lb-ft)
4. Grommet	(b) : 6 N·m (0.6 kgf-m, 4.5 lb-ft)
5. Clutch oil pipe	

Diagnostic Information and Procedures

Clutch System Symptom Diagnosis

B815H25304001

Condition	Possible cause	Correction / Reference Item
Engine is noisy (Noise seems to come from the clutch)	Worn countershaft spline.	Replace countershaft.
	Worn clutch hub spline.	Replace clutch hub.
	Worn clutch plate teeth.	Replace clutch plate.
	Distorted clutch plate.	Replace.
	Worn clutch release bearing.	Replace.
	Weakened clutch damper.	Replace primary driven gear.
	Worn clutch lifter related parts.	Replace clutch lifter related parts as a set.
Clutch slips	Weakened clutch spring.	Replace.
	Worn or distorted clutch pressure plate.	Replace.
	Distorted clutch plate.	Replace.
Clutch drags	Leakage of clutch fluid.	Repair or replace.
	Worn or damaged clutch cylinder/ release cylinder.	Replace.
	Some clutch springs are weak, while others are not.	Replace.
	Worn or distorted clutch pressure plate.	Replace.
	Distorted clutch plate.	Replace.
Leakage of clutch fluid	Leakage of clutch fluid from system.	Repair or replace.
Excessive clutch lever stroke	Air in hydraulic system.	Bleed air.


Repair Instructions

Clutch Lever Position Switch Inspection

B815H25306001

Inspect the clutch lever position switch in the following procedures:

- 1) Disconnect the clutch lever position switch lead wires (1).



I815H1530002-02

- 2) Inspect the clutch lever position switch for continuity with the tester.
If any abnormality is found, replace the switch with a new one.

Special tool

TOOL : 09900-25008 (Multi-circuit tester set)

Tester knob indication

Continuity (•)))

Clutch lever position switch

Color Position	Terminal (B/Y)	Terminal (B/W)
FREE		
•	○	○

I649G1530004-03

- 3) Connect the clutch lever position switch lead wires.

Clutch Fluid Level Check

B815H25306002

Refer to "Clutch System Inspection in Section 0B (Page 0B-14)".

Clutch Hose Inspection

B815H25306003

Refer to "Clutch System Inspection in Section 0B (Page 0B-14)".

Air Bleeding from Clutch Fluid Circuit

B815H25306004

CAUTION

Handle brake fluid with care: the fluid reacts chemically with paint, plastics, rubber materials, etc.

The clutch fluid circuit may be purged of air in the following manner:

- 1) Remove the left side cowling. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Keep the motorcycle upright and place the handlebars straight.
- 3) Fill up the clutch master cylinder reservoir with brake fluid. Replace the reservoir cap to prevent entry of dirt.

BF: Brake fluid (DOT 4)

- 4) Connect a clear hose to the air bleeder valve and insert the free end of the hose into a receptacle.



I815H1530003-01

- 5) Squeeze and release the clutch lever several times in rapid succession, and squeeze the lever fully without releasing it.



I815H1530004-01

- 6) Loosen the air bleeder valve by turning it a quarter of a turn so that the fluid runs into the receptacle; this will remove the tension of the clutch lever causing it to touch the handlebar grip.
- 7) Close the air bleeder valve, pump and squeeze the lever, and open the valve.
- 8) Repeat this process until the fluid flowing into the receptacle no longer contains air bubbles.

- 9) Close the air bleeder valve and disconnect the hose.

Tightening torque

Air bleeder valve (Clutch): 6 N·m (0.6 kgf-m, 4.5 lb-ft)

- 10) Fill the reservoir with brake fluid to the upper mark "A" of the reservoir.



I815H1530005-01

- 11) Reinstall the removed parts.

Clutch Fluid Replacement

B815H25306005

CAUTION

Handle brake fluid with care: the fluid reacts chemically with paint, plastic, rubber materials, etc.

- 1) Remove the left side cowling. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Place the motorcycle on a level surface and keep the handlebars straight.
- 3) Remove the clutch master cylinder reservoir cap and diaphragm.
- 4) Suck up the old clutch fluid as much as possible.



I815H1530006-01

- 5) Fill the reservoir with new clutch fluid.


BF: Brake fluid (DOT 4)

- 6) Connect a clear hose to the air bleeder valve and insert the other end of hose into a receptacle.



I815H1530003-01

- 7) Loosen the air bleeder valve and pump the clutch lever until old clutch fluid flows out of the clutch fluid circuit.




I815H1530004-01

- 8) Close the air bleeder valve (2) and disconnect the hose.


Tightening torque

Air bleeder valve (Clutch) (a): 6 N·m (0.6 kgf-m, 4.5 lb-ft)



I815H1530007-01

- 9) Fill the reservoir with brake fluid to the upper mark "A" of the reservoir.



I815H1530008-01

- 10) Reinstall the removed parts.

Clutch Hose Removal and Installation

B815H25306006

Removal


- 1) Remove the left side cowling. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation in Section 1D (Page 1D-6)".
- 3) Drain clutch fluid. Refer to "Clutch Fluid Replacement (Page 5C-4)".
- 4) Remove the clutch hose as shown in the clutch hose routing diagram. Refer to "Clutch Hose Routing Diagram (Page 5C-2)".

Installation

- 1) Install the clutch hose as shown in the clutch hose routing diagram. Refer to "Clutch Hose Routing Diagram (Page 5C-2)".
- 2) Bleed air from the clutch system. Refer to "Air Bleeding from Clutch Fluid Circuit (Page 5C-4)".
- 3) Reinstall the removed parts.

Clutch Control System Components

B815H25306007



I815H1530009-03


1. Push rod	7. Push rod	 : Apply brake fluid.
2. Piston/Cup set	8. Clutch release cylinder set	 : Apply grease.
3. Clutch hose	9. Air bleeder valve	 : Apply silicone grease.
4. Reservoir cap	 : 23 N·m (2.3 kgf-m, 16.5 lb-ft)	 : Do not reuse.
5. Plate	 : 6 N·m (0.6 kgf-m, 4.5 lb-ft)	
6. Diaphragm	 : 1 N·m (0.1 kgf-m, 0.7 lb-ft)	

Clutch Master Cylinder Assembly Removal and Installation

B815H25306008

Removal

- 1) Drain clutch fluid. Refer to "Clutch Fluid Replacement (Page 5C-4)".
- 2) Disconnect the clutch lever position switch lead wires (1).
- 3) Place a rag under the clutch hose union bolt (2) to catch any spilt brake fluid.
- 4) Disconnect the clutch hose by removing the clutch hose union bolt (2).



I815H1530010-02

- 5) Remove the clutch master cylinder assembly.



I815H1530011-01


Installation

Install the clutch master cylinder in the reverse order of removal. Pay attention to the following points:


- When installing the clutch master cylinder (1) onto the left handlebar (2), align the master cylinder holder's mating surface "A" with the punch mark "B" on the handlebar and tighten the upper holder bolt first. Refer to "Handlebar Construction in Section 6B (Page 6B-2)".

Tightening torque

Clutch master cylinder holder bolt (a): 10 N·m (1.0 kgf-m, 7.0 lb-ft)



I815H1530012-02



I815H1530013-04

"C": "UP" mark	"a": Clearance
----------------	----------------

5C-8 Clutch:

- After setting the clutch hose union to the stopper, tighten the union bolt (3) to the specified torque.

⚠ CAUTION

The seal washers should be replaced with new ones to prevent fluid leakage.

Tightening torque

Clutch hose union bolt (b): 23 N·m (2.3 kgf-m, 16.5 lb-ft)



I815H1530014-01

- Bleed air from the clutch system. Refer to “Air Bleeding from Clutch Fluid Circuit (Page 5C-4)”.


Clutch Master Cylinder / Clutch Lever Disassembly and Assembly

B815H25306009

Refer to “Clutch Master Cylinder Assembly Removal and Installation (Page 5C-7)”.


Disassembly

- Remove the reservoir cap (1), plate (2) and diaphragm (3).




I815H1530015-01

- Remove the clutch lever (4).



I815H1530016-01

- Remove the clutch lever position switch (5).




I815H1530017-01

- Pull out the push rod (6) and dust boot (7).

- Remove the snap ring (8).

Special tool


 : 09900-06108 (Snap ring pliers)



I815H1530018-01

6) Remove the piston/cup set from the master cylinder.

- Secondary cup (9)
- Piston (10)
- Primary cup (11)
- Spring (12)



I815H1530019-01


Assembly

Assemble the master cylinder in the reverse order of disassembly. Pay attention to the following points:

⚠ CAUTION

- Wash the master cylinder components with new brake fluid before reassembly.
- Do not wipe the clutch fluid off after washing the components.
- When washing the components, use the specified clutch fluid (Brake fluid). Never use different types of fluid or cleaning solvents such as gasoline, kerosine, etc.
- Apply brake fluid to the master cylinder bore and to all of the master cylinder components to be inserted into the bore.


BF: Brake fluid (DOT 4)



I815H1530020-01


- Apply silicone grease to the push rod ends.

 **Grease 99000-25100 (SUZUKI Silicone Grease or equivalent)**



I815H1530021-01

- When installing the clutch lever position switch, align the projection "A" on the switch with the hole "B" on the master cylinder.



I815H1530022-01


- Apply silicone grease to the clutch lever pivot bolt.

 **Grease 99000-25100 (SUZUKI Silicone Grease or equivalent)**

Tightening torque

Clutch lever pivot bolt: 1 N·m (0.1 kgf-m, 0.7 lb-ft)

Clutch lever pivot bolt lock-nut: 6 N·m (0.6 kgf-m, 4.5 lb-ft)



I815H1530023-01

Clutch Master Cylinder Components Inspection

B815H25306010

Refer to “Clutch Master Cylinder / Clutch Lever Disassembly and Assembly (Page 5C-8)”.

Master Cylinder

Inspect the master cylinder bore for any scratches or other damage.



I815H1530024-01

Piston

Inspect the piston surface for any scratches or other damage.

Rubber Parts

Inspect the primary cup, secondary cup and dust boot for wear or damage.




I815H1530025-01

Clutch Release Cylinder / Push Rod Removal and Installation

B815H25306011


Removal

- 1) Drain clutch fluid. Refer to “Clutch Fluid Replacement (Page 5C-4)”.
- 2) Remove the left side cowling. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.
- 3) Place a rag under the clutch hose union bolt (1) to catch any spilt brake fluid.
- 4) Remove the clutch hose union bolt (1).
- 5) Remove the air bleeder valve (2).
- 6) Remove the clutch release cylinder mounting bolts (3).




I815H1530026-01

- 7) Remove the gearshift link arm (4) and engine sprocket cover bolts.




I815H1530027-01

- 8) Remove the clutch release cylinder cover (5).




I815H1530028-01

- 9) Remove the clutch release cylinder (6) from the engine sprocket cover.



I815H1530029-01

- 10) Remove the push rod (7).




I815H1530030-01

Installation

Install the clutch release cylinder in the reverse order of removal. Pay attention to the following points:

- Fit the dowel pins.
- Install the sprocket cover protector (1).



I815H1530031-03

- Apply a small quantity of grease to the push rod.

 : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)



I815H1530032-02

- Tighten each bolt and air bleeder valve to the specified torque.

Tightening torque


Clutch release cylinder mounting bolt (a): 10 N·m (1.0 kgf-m, 7.0 lb-ft)

Clutch hose union bolt (b): 23 N·m (2.3 kgf-m, 16.5 lb-ft)

Air bleeder valve (clutch) (c): 6 N·m (0.6 kgf-m, 4.5 lb-ft)

⚠ CAUTION

The seal washers should be replaced with the new ones to prevent fluid leakage.



I815H1530033-01

- Bleed air from the clutch system. Refer to "Air Bleeding from Clutch Fluid Circuit (Page 5C-4)".

Clutch Push Rod Inspection

B815H25306012

Inspect the push rod in the following procedures:

- 1) Remove the clutch push rod. Refer to "Clutch Release Cylinder / Push Rod Removal and Installation (Page 5C-10)".
- 2) Inspect the push rod for wear or bend. If any defects are found, replace it with a new one.



I718H1530025-01

- 3) Reinstall the removed parts. Refer to "Clutch Release Cylinder / Push Rod Removal and Installation (Page 5C-10)".

Clutch Release Cylinder Disassembly and Assembly

B815H25306013

Refer to "Clutch Release Cylinder / Push Rod Removal and Installation (Page 5C-10)".

Disassembly

- 1) Place a rag over the piston to prevent it popping out.
- 2) Force out the piston using compressed air.

⚠ CAUTION

Do not use high pressure air to prevent piston damage.



I815H1530034-01

Assembly

Assemble the clutch release cylinder in the reverse order of disassembly. Pay attention to the following points:

- Wash the cylinder bore and piston with specified brake fluid.

BF: Brake fluid (DOT 4)

⚠ CAUTION

- Wash the cylinder components with fresh brake fluid before reassembling. Never use cleaning solvent or gasoline to wash them.
- Do not wipe the brake fluid off after washing the components.
- When washing the components, use the specified brake fluid. Never use different types of fluid or cleaning solvent such as gasoline, kerosine or the others.



I815H1530035-01

- Bleed air from the clutch system. Refer to "Air Bleeding from Clutch Fluid Circuit (Page 5C-4)".

Clutch Release Cylinder Inspection

B815H25306014

Refer to "Clutch Release Cylinder Disassembly and Assembly (Page 5C-12)".

Inspect the clutch cylinder bore wall for nicks, scratches or other damage.


Inspect the piston surface for any scratches or other damage.



I815H1530036-01

Clutch Components

B815H25306015




I823H1530059-06

1. Clutch pressure plate	7. No. 1 driven plate (8 – 5 pcs.)	13. Push rod
2. Clutch push piece	8. No. 2 driven plate (1 – 4 pcs.)	⚙️ "A": The No. 1 and No. 2 driven plates are 9 in total.
3. Clutch lifter drive/driven cam set	9. Spring washer	⚙️ (a) : 150 N·m (15.0 kgf·m, 108.5 lb·ft)
4. No. 2 drive plate	10. Spring washer seat	⚙️ (b) : 23 N·m (2.3 kgf·m, 16.5 lb·ft)
5. No. 3 drive plate	11. Clutch sleeve hub	⚙️ (c) : 10 N·m (1.0 kgf·m, 7.0 lb·ft)
6. No. 1 drive plate	12. Primary driven gear assembly	🛢️ : Apply engine oil.

Clutch Removal


B815H25306016

- 1) Drain engine oil. Refer to "Engine Oil and Filter Replacement in Section 0B (Page 0B-10)".
- 2) Remove the right side cowling. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 3) Disconnect the HO2 sensor coupler (1) and oil pressure switch lead wire (2).




I815H1530037-01

- 4) Remove the clutch cover (3).



I815H1530038-01

- 5) Remove the clutch outer cover (4) and cushion (5) from the clutch cover.



I815H1530039-01

- 6) Remove the gasket (6) and dowel pins.




I815H1530040-01

- 7) Remove the clutch springs and pressure plate (7).


NOTE

Loosen the clutch spring set bolts little by little and diagonally.




I815H1530041-01

- 8) Remove the clutch drive plates (8) and driven plates (9).




I815H1530042-01

9) Remove the spring washer (10) and its seat (11).



I815H1530043-01

10) Remove the thrust washer (12), bearing (13) and clutch push piece (14).




I815H1530044-01

11) Remove the clutch push rod (15).

NOTE

If it is difficult to pull out the push rod (15), use a magnetic hand or wire.



I815H1530045-01

12) Unlock the clutch sleeve hub nut.




I815H1530046-01

13) Hold the clutch sleeve hub with the special tool.

Special tool


 (A): 09920-53740 (Clutch sleeve hub holder)

14) Remove the clutch sleeve hub nut.



I815H1530047-01


15) Remove the conical spring washer (16).



I815H1530048-02

5C-16 Clutch:

- 16) Remove the clutch sleeve hub (17), clutch lifter drive cam (18) and its driven cam (19).




I815H1530049-01

- 17) Remove the thrust washer (20), spacer (21) and bearing (22).

- 18) Remove the primary driven gear assembly (23).


NOTE

If it is difficult to remove the primary driven gear, rotate the crankshaft.




I815H1530050-01

- 19) Remove the oil pump drive gear (24) from the primary driven gear assembly.



I815H1530062-01

- 20) Remove the thrust washer (25).



I815H1530052-01

Clutch Installation


B815H25306017

Installation is in the reverse order of removal. Pay attention to the following points:

- Install the thrust washer onto the countershaft.

NOTE

The chamfer side "A" of the thrust washer faces crankcase side.




I815H1530051-02


- Install the oil pump drive gear to the primary driven gear assembly.

NOTE

The off-set side "B" of the oil pump drive gear faces the primary driven gear side.



I823H1530037-01




I823H1530038-02

- Install the primary driven gear assembly.

NOTE

- If it is difficult to install the primary driven gear, rotate the crankshaft.
- Be sure to engage the oil pump drive and driven gears, primary drive and driven gears.

- Install the bearing (1) and spacer (2) and apply engine oil to them.
- Install the trust washer (3).



I815H1530053-02

5C-18 Clutch:

- Install the clutch lifter drive cam (4), driven cam (5) to the clutch sleeve hub (6).


NOTE

- Align the punch mark “C” on the clutch lifter drive cam (4) with the punch mark “D” on its driven cam (5).
- The clutch lifter drive (4) and driven (5) cams should be replaced as a set.
- When replacing the clutch spring support bolts (7), apply thread lock and tighten them to the specified torque.


 **1303** : Thread lock cement 99000-32030 (THREAD LOCK CEMENT SUPER 1303 or equivalent)

Tightening torque

Clutch spring support bolt (a): 23 N·m (2.3 kgf-m, 16.5 lb-ft)



I823H1530040-01




I823H1530041-03


- Install the clutch sleeve hub along with the clutch lifter drive and driven cams onto the countershaft.
- Install the conical spring washer (8).

NOTE

The conical curve side of the spring washer (8) faces outside.



I815H1530054-01




I823H1530043-01

- Hold the clutch sleeve hub using the special tool.

Special tool

 (A): 09920-53740 (Clutch sleeve hub holder)



I815H1530055-01

- Tighten the clutch sleeve hub nut to the specified torque.

Tightening torque


Clutch sleeve hub nut: 150 N·m (15.0 kgf·m, 108.5 lb-ft)

- Lock the clutch sleeve hub nut with a center punch.



I815H1530046-01

- Install the spring washer seat (9) and spring washer (10) onto the clutch sleeve hub correctly.




I823H1530047-01


- Insert the clutch drive plates and driven plate one by one into the clutch sleeve hub in the prescribed order.

NOTE

Insert the outermost No. 2 drive plate claws "E" to the other slits "F" of clutch housing as shown in the figure.



I815H1530056-01




I823H1530049-03

11.	No. 3 drive plate
12.	No. 1 drive plate
13.	No. 2 drive plate
14.	No. 2 driven plate (1 – 4 pcs.) : The No. 1 and No. 2 driven plates are 9 in total.
15.	No. 1 driven plate (8 – 5 pcs.) : The No. 1 and No. 2 driven plates are 9 in total.
"G": Direction of outside	

NOTE

Three kinds of the drive plate (No. 1, No. 2 and No. 3) are equipped in the clutch system, they can be distinguished by the inside diameter and clutch facing "H".



I823H1530050-02

	"H": Clutch facing : Make sure to check the numbers of clutch facing, before installing them.
--	---

Drive plate	I.D.	Clutch facing "H"
No. 1	126 mm (4.96 in)	36 pcs.
No. 2	127 mm (5.00 in)	60 pcs.
No. 3	135 mm (5.31 in)	60 pcs.

NOTE

Two kinds of the driven plate (No. 1 and No. 2) are equipped in the clutch system, they can be distinguished by the thickness. The No. 1 and No. 2 driven plates are 9 pcs. in total. 5 – 8 pcs. of No. 1 driven plates are used with 4 – 1 pc(-s) of No. 2 driven plate(-s) as a set.

The No. 2 driven plate(-s) must be installed to 4th to 7th position of driven plates order from the sleeve hub side.

Driven plate	Thickness
No. 1	2.0 mm (0.08 in)
No. 2	2.3 mm (0.09 in)

5C-20 Clutch:


- Tighten the clutch spring set bolts (16) to the specified torque.

Tightening torque

Clutch spring set bolt (b): 10 N·m (1.0 kgf-m, 7.0 lb-ft)

NOTE


Tighten the clutch spring set bolt diagonally.



I815H1530057-01

- Apply a bond lightly to the mating surfaces at the parting line between the upper and lower crankcase as shown in the figure.

1207B : Sealant 99000-31140 (SUZUKI BOND No.1207B or equivalent)




I815H1530058-01

- Install the gasket (17) and the dowel pins.


⚠ CAUTION

Use the new gasket to prevent oil leakage.




I815H1530059-01

- Install the cushion (18) and clutch outer cover (19) to the clutch cover.



I815H1530060-01

- Tighten the clutch outer cover bolts (20) with the washers (21) securely.



I823H1530055-01


- Install the clutch cover and tighten its bolts (22) to the specified torque.

Tightening torque

Clutch cover bolt (c): 10 N·m (1.0 kgf-m, 7.0 lb-ft)

NOTE

Fit the clamp to the bolt (22).



I815H1530061-02

- Rout the HO2 sensor and oil pressure switch lead wires properly. Refer to "Wiring Harness Routing Diagram in Section 9A (Page 9A-5)".

Clutch Parts Inspection

B815H25306018

Refer to "Clutch Removal (Page 5C-14)" and "Clutch Installation (Page 5C-17)".

Clutch Drive and Driven Plate

NOTE

Wipe off the engine oil from the drive and driven plates with a clean rag.

Measure the thickness of drive plates with a vernier calipers. If the drive plate thickness is found to have reached the limit, replace it with a new one.


Special tool

TOOL (A): 09900-20102 (Vernier calipers (1/20 mm, 200 mm))

Clutch drive plate thickness

Service limit (No. 1 drive plate): 2.62 mm (0.103 in)

Service limit (No. 2 and No. 3 drive plates): 3.42 mm (0.135 in)



I649G1530056-03

Measure the claw width of drive plates with a vernier calipers. Replace the drive plates found to have worn down to the limit.

Special tool


TOOL (A): 09900-20102 (Vernier calipers (1/20 mm, 200 mm))

5C-22 Clutch:

Clutch drive plate claw width

Service limit (No. 1 drive plate): 13.05 mm (0.514 in)

Service limit (No. 2 and No. 3 drive plate): 13.10 mm (0.516 in)



I649G1530057-03

Measure each driven plate for distortion with a thickness gauge and surface plate.


Replace driven plates which exceed the limit.

Special tool

TOOL (B): 09900-20803 (Thickness gauge)

Clutch driven plate distortion

Service limit: 0.10 mm (0.004 in)



I649G1530058-03

Clutch Spring


Measure the free length of each coil spring with a vernier calipers, and compare the length with the specified limit. Replace all the springs if any spring is not within the limit.

Special tool

TOOL (A): 09900-20102 (Vernier calipers (1/20 mm, 200 mm))

Clutch spring free length

Service limit: 35.3 mm (1.39 in)




I718H1530062-01

Clutch Release Bearing

Inspect the clutch release bearing for any abnormality, especially cracks. When removing the bearing from the clutch, decide whether it can be reused or if it should be replaced.

Smooth engagement and disengagement of the clutch depends on the condition of this bearing.



I649G1530059-02

Push Rod

Inspect the push rod for wear and damage.

If any defects are found, replace the push rod with a new one.



I718H1530063-01

Clutch Sleeve Hub and Primary Driven Gear Assembly

Inspect the slot of the clutch sleeve hub and primary driven gear assembly for damage or wear caused by the clutch plates. If necessary, replace it with a new one.



I823H1530057-01

Specifications

Service Data

B815H25307001

Clutch

Unit: mm (in)

Item	Standard		Limit
Clutch drive plate thickness	No. 1	2.92 – 3.08 (0.115 – 0.121)	2.62 (0.103)
	No. 2 & 3	3.72 – 3.88 (0.146 – 0.153)	3.42 (0.135)
Clutch drive plate claw width	No. 1	13.85 – 13.96 (0.542 – 0.550)	13.05 (0.514)
	No. 2 & 3	13.90 – 14.00 (0.547 – 0.551)	13.10 (0.516)
Clutch driven plate distortion	—		0.10 (0.004)
Clutch spring free length	37.13 (1.462)		35.3 (1.39)
Clutch master cylinder bore	14.000 – 14.043 (0.5512 – 0.5529)		—
Clutch master cylinder piston diam.	13.957 – 13.984 (0.5495 – 0.5506)		—
Clutch release cylinder bore	33.600 – 33.662 (1.3228 – 1.3253)		—
Clutch release cylinder piston diam.	33.550 – 33.575 (1.3209 – 1.3218)		—
Clutch fluid type	Brake fluid DOT 4		—

Tightening Torque Specifications

B815H25307002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Air bleeder valve (Clutch)	6	0.6	4.5	☞ (Page 5C-4) / ☞ (Page 5C-5) / ☞ (Page 5C-11)
Clutch master cylinder holder bolt	10	1.0	7.0	☞ (Page 5C-7)
Clutch hose union bolt	23	2.3	16.5	☞ (Page 5C-8) / ☞ (Page 5C-11)
Clutch lever pivot bolt	1	0.1	0.7	☞ (Page 5C-9)
Clutch lever pivot bolt lock-nut	6	0.6	4.5	☞ (Page 5C-9)
Clutch release cylinder mounting bolt	10	1.0	7.0	☞ (Page 5C-11)
Clutch spring support bolt	23	2.3	16.5	☞ (Page 5C-18)
Clutch sleeve hub nut	150	15.0	108.5	☞ (Page 5C-19)
Clutch spring set bolt	10	1.0	7.0	☞ (Page 5C-20)
Clutch cover bolt	10	1.0	7.0	☞ (Page 5C-21)

NOTE

The specified tightening torque is also described in the following.

“Clutch Hose Routing Diagram (Page 5C-2)”

“Clutch Control System Components (Page 5C-6)”

“Clutch Components (Page 5C-13)”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Tightening Torque List in Section 0C (Page 0C-9)”.

Special Tools and Equipment

Recommended Service Material

B815H25308001

Material	SUZUKI recommended product or Specification		Note
Brake fluid	DOT 4	—	☞ (Page 5C-4) / ☞ (Page 5C-4) / ☞ (Page 5C-9) / ☞ (Page 5C-12)
Grease	SUZUKI SUPER GREASE A or equivalent	P/No.: 99000-25010	☞ (Page 5C-11)
	SUZUKI Silicone Grease or equivalent	P/No.: 99000-25100	☞ (Page 5C-9) / ☞ (Page 5C-9)
Sealant	SUZUKI BOND No.1207B or equivalent	P/No.: 99000-31140	☞ (Page 5C-20)
Thread lock cement	THREAD LOCK CEMENT SUPER 1303 or equivalent	P/No.: 99000-32030	☞ (Page 5C-18)

NOTE






Required service material is also described in the following.

“Clutch Control System Components (Page 5C-6)”

“Clutch Components (Page 5C-13)”

Special Tool

B815H25308002

09900-06108 Snap ring pliers ☞ (Page 5C-8)		09900-20102 Vernier calipers (1/20 mm, 200 mm) ☞ (Page 5C-21) / ☞ (Page 5C-21) / ☞ (Page 5C-22)	
09900-20803 Thickness gauge ☞ (Page 5C-22)		09900-25008 Multi-circuit tester set ☞ (Page 5C-3)	
09920-53740 Clutch sleeve hub holder ☞ (Page 5C-15) / ☞ (Page 5C-18)			

Section 6

Steering

CONTENTS

Precautions	6-1	Steering Components	6B-5
Precautions.....	6-1	Steering Damper Construction.....	6B-6
Precautions for Steering	6-1	Steering Removal and Installation	6B-6
Steering General Diagnosis.....	6A-1	Steering Related Parts Inspection.....	6B-10
Diagnostic Information and Procedures.....	6A-1	Steering System Inspection	6B-10
Steering Symptom Diagnosis.....	6A-1	Steering Stem Bearing Removal and	
Steering / Handlebar.....	6B-1	Installation	6B-11
Repair Instructions	6B-1	Steering Tension Adjustment	6B-12
Handlebar Components	6B-1	Specifications	6B-13
Handlebar Construction	6B-2	Tightening Torque Specifications.....	6B-13
Handlebar Removal and Installation	6B-3	Special Tools and Equipment	6B-13
Handlebars Inspection	6B-4	Recommended Service Material	6B-13
		Special Tool	6B-14

Precautions

Precautions

Precautions for Steering

Refer to “General Precautions in Section 00 (Page 00-1)”.

B815H26000001

Steering General Diagnosis

Diagnostic Information and Procedures

Steering Symptom Diagnosis

B815H26104001


Condition	Possible cause	Correction / Reference Item
Heavy steering	Over tightened steering stem nut.	<i>Adjust.</i>
	Broken bearing in steering stem.	<i>Replace.</i>
	Distorted steering stem.	<i>Replace.</i>
	Not enough pressure in tires.	<i>Adjust.</i>
	Defective steering damper unit.	<i>Replace.</i>
Wobbly handlebars	Loss of balance between right and left front forks.	<i>Replace fork, adjust fork oil level or replace spring.</i>
	Distorted front fork.	<i>Repair or replace.</i>
	Distorted front axle or crooked tire.	<i>Replace.</i>
	Loose steering stem nut.	<i>Adjust.</i>
	Worn or incorrect tire or wrong tire pressure.	<i>Adjust or replace.</i>
	Worn bearing/race in steering stem.	<i>Replace.</i>

Steering / Handlebar

Repair Instructions

Handlebar Components

B815H26206001




I815H1620001-02

I815H1620002-01

1. Throttle grip	6. Handlebar holder	(b) : 5.5 N-m (0.55 kgf-m, 4.0 lb-ft)
2. Grip rubber	7. Left handlebar	(c) : 35 N-m (3.5 kgf-m, 25.5 lb-ft)
3. Right handlebar switch box	8. Handlebar balancer	A: Apply grease.
4. Left handlebar switch box	"A": Apply handle grip bond.	1322 : Apply thread lock to the thread part.
5. Right handlebar	(a) : 10 N-m (1.0 kgf-m, 7.0 lb-ft)	

Handlebar Construction

B815H26206002



I815H1620038-02

1. Front brake master cylinder	"B": UP mark	(c) : 5.5 N·m (0.55 kgf-m, 4.0 lb-ft)
2. Clutch master cylinder	"a": Clearance	1322 : Apply thread lock to the thread part.
3. Handlebar holder	(a) : 10 N·m (1.0 kgf-m, 7.0 lb-ft)	
"A": Punch mark	(b) : 35 N·m (3.5 kgf-m, 25.5 lb-ft)	

Handlebar Removal and Installation

B815H26206003


Removal

- 1) Remove the following parts from the left handlebar.
 - a) Clutch master cylinder/clutch lever (1)

⚠ CAUTION

Do not turn the clutch master cylinder upside down.

- b) Left handlebar switch box (2)
- c) Handlebar balancer (3)
- d) Grip rubber (4)




I815H1620003-01

- 2) Remove the following parts from the right handlebar.
 - a) Front brake master cylinder/Front brake lever (5)

⚠ CAUTION


Do not turn the front brake master cylinder upside down.

- b) Right handlebar switch box (6)
- c) Handlebar balancer (7)
- d) Throttle grip (8)



I815H1620004-01

- 3) Remove the handlebar clamp bolts (9).
- 4) Detach the right and left handlebars (10).




I815H1620005-01

Installation

Install the handlebars in the reverse order of removal. Pay attention to the following points:

- Install the handlebars and align the cutaway of the handlebar with the handlebar clamp bolts hole "A".




I815H1620006-01

- Tighten the handlebar clamp bolts (1).

Tightening torque

Handlebar clamp bolt (a): 10 N·m (1.0 kgf·m, 7.0 lb·ft)




I815H1620007-01

- Apply grease to the end of the throttle cables and cable pulley.

 **Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)**


- Insert the projection "B" of the right handlebar switch box into the hole of the handlebars.



I815H1620008-01


- Install the front brake master cylinder. Refer to "Front Brake Master Cylinder Assembly Removal and Installation in Section 4A (Page 4A-10)".
- Apply a handle grip bond "C" onto the left handlebar before installing the handlebar grip.

 **Handle grip bond (Handle Grip Bond (commercially available))**



I823H1620004-02

- Insert the projection "D" of the left handlebar switch box into the hole of the handlebars.



I815H1620009-01

- Install the clutch master cylinder. Refer to "Clutch Master Cylinder Assembly Removal and Installation in Section 5C (Page 5C-7)".
- After installing the steering, the following adjustments are required before driving.
 - Cable routing (Refer to "Throttle Cable Routing Diagram in Section 1D (Page 1D-2)".)
 - Throttle cable play (Refer to "Throttle Cable Play Inspection and Adjustment in Section 0B (Page 0B-12)".)


Handlebars Inspection

B815H26206004

Refer to "Handlebar Removal and Installation (Page 6B-3)".

Inspect the handlebars for distortion and damage.


If any defect is found, replace the handlebars with a new one.



I815H1620010-02

Steering Components

B815H26206005




I815H1620011-02

1. Handlebar holder	9. Washer	⌚(a) : 10 N-m (1.0 kgf-m, 7.0 lb-ft)
2. Handlebars	10. Steering stem nut	⌚(b) : 35 N-m (3.5 kgf-m, 25.5 lb-ft)
3. Handlebar damper	11. Dust seal cover	⌚(c) : 90 N-m (9.0 kgf-m, 65.0 lb-ft)
4. spacer	12. Dust seal	⌚(d) : 80 N-m (8.0 kgf-m, 58.0 lb-ft)
5. Handlebar holder mounting nut	13. Steering stem upper bearing	⌚(e) : 45 N-m (4.5 kgf-m, 32.5 lb-ft) then turn back 1/2 – 1/4
6. Steering stem head nut	14. Steering stem lower bracket	⌚AH : Apply grease.
7. Steering stem upper bracket	15. Steering stem lower bearing	⊗ : Do not reuse.
8. Steering stem lock-nut	16. Lower seal	

Steering Damper Construction

B815H26206006



I815H1620012-02


1. Steering damper	2. Dust seal	3. Bearing	(a) : 23 N·m (2.3 kgf-m, 16.5 lb-ft)	Ⓐ : Apply grease.
--------------------	--------------	------------	--------------------------------------	-------------------

Steering Removal and Installation

B815H26206007


Removal

- 1) Remove the body cowlings. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Support the motorcycle with a jack or a wooden block.
- 3) Remove the front wheel assembly. Refer to "Front Wheel Assembly Removal and Installation in Section 2D (Page 2D-4)".
- 4) Remove the steering damper (1).




I815H1620013-01

- 5) Disconnect the ignition switch lead wire coupler (2), left handle switch lead wire coupler (3), right handle switch lead wire coupler (4), drive mode selector switch lead wire coupler (5) and immobilizer antenna lead wire coupler (For E-02, 19, 24) (6).



I815H1620014-03


- 6) Remove the wire harnesses from the clamp/guide.



I815H1620015-01


6B-7 Steering / Handlebar:

- 7) Remove the handlebars and handlebar holder. Refer to "Handlebar Removal and Installation (Page 6B-3)" and "Front Fork Removal and Installation in Section 2B (Page 2B-2)".
- 8) Remove the front forks. Refer to "Front Fork Removal and Installation in Section 2B (Page 2B-2)".
- 9) Remove the brake hose clamp bolt (5).



I815H1620016-01

- 10) Remove the steering stem head nut (6) and washer (7).
- 11) Remove the steering stem upper bracket assembly (8).



I815H1620017-02

- 12) It is not necessary to remove the ignition switch from the upper bracket when servicing the steering system. Refer to "Ignition Switch Removal and Installation in Section 1H (Page 1H-12)", if necessary.

- 13) Remove the steering stem lock-nut, washer and steering stem nut with the special tools.


NOTE

When loosening the stem nuts, hold the steering stem lower bracket to prevent it from falling.

Special tool


 (A): 09940-14911 (Steering stem nut wrench)

 (B): 09940-14960 (Steering nut wrench socket)



I815H1620018-01

- 14) Remove the steering stem lower bracket.
- 15) Remove the dust seal cover (10), dust seal (11), upper bearing inner race (12) and bearing (13).



I815H1620019-01

Installation

Install the steering in the reverse order of removal.
Pay attention to the following points:


Bearing

- Apply grease to the bearings, bearing races and dust seals before remounting the steering stem.

 **TAH**: Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)



I815H1620020-01



I815H1620021-01

Steering stem nut

- Tighten the steering stem nut (1) to the specified torque using the special tools.


Special tool

 **(A)**: 09940-14911 (Steering stem nut wrench)

 **(B)**: 09940-14960 (Steering nut wrench socket)

Tightening torque

Steering stem nut (a): 45 N·m (4.5 kgf-m, 32.5 lb-ft) then turn back 1/2 – 1/4




I815H1620022-01

- Turn the steering stem lower bracket about five or six times to the left and right so that the angular ball bearings seat properly.
- Loosen the steering stem nut 1/4 – 1/2 turn "a".

NOTE

This adjustment will vary from motorcycle to motorcycle.



I649G1620026-02

6B-9 Steering / Handlebar:

- When installing the washer (2), align the lug of the washer to the groove of the steering stem.



I815H1620023-01

- Tighten the steering stem lock-nut (3) to the specified torque using the special tools.


Special tool

 (A): 09940-14911 (Steering stem nut wrench)

 (B): 09940-14960 (Steering nut wrench socket)

Tightening torque

Steering stem lock-nut (b): 80 N·m (8.0 kgf-m, 58.0 lb-ft)



I815H1620024-01

Steering stem upper bracket

Install the front forks and steering stem upper bracket in the following steps:

- Temporarily install the upper bracket, washer (1) and steering stem head nut (2).



I815H1620025-01

- Temporarily install the front forks.
- Tighten the steering stem head nut (2).

Tightening torque

Steering stem head nut (a): 90 N·m (9.0 kgf-m, 65.0 lb-ft)



I815H1620026-01


- Tighten the front fork upper and lower clamp bolts. Refer to "Front Fork Removal and Installation in Section 2B (Page 2B-2)".

Handlebar holder

- Tighten the handlebar holder mounting nuts (1) to the specified torque.

Tightening torque

Handlebar holder mounting nut (a): 35 N·m (3.5 kgf-m, 25.5 lb-ft)




I815H1620027-03

- Install the handlebars. Refer to "Handlebar Removal and Installation (Page 6B-3)".

Steering damper

- Apply grease to the bearings and dust seals.

 : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)




I823H1620019-02

- Install the steering damper and tighten the bolt (1) and nut (2).

Tightening torque

Steering damper bolt (a): 23 N·m (2.3 kgf-m, 16.5 lb-ft)

Steering damper nut (b): 23 N·m (2.3 kgf-m, 16.5 lb-ft)



I815H1620028-01

Inspection after installation

- Check the steering tension. Refer to “Steering Tension Adjustment (Page 6B-12)”.

Steering Related Parts Inspection

B815H26206008

Refer to “Steering Removal and Installation (Page 6B-6)”.

Inspect the removed parts for the following abnormalities:

- Distortion of the steering stem
- Bearing wear or damage
- Abnormal bearing noise
- Race wear or damage
- Bearing lower seal damage
- Rubber seat and damper bushing wear or damage
- Inspect the steering damper body, bearing dust seal and oil seal for damage and oil leaking.
- Move the steering damper rod by hand to inspect for a smooth movement.


If any abnormal points are found, replace defective parts with new ones.




I815H1620029-01



I815H1620030-01



I815H1620031-01



I815H1620032-01

Steering System Inspection

B815H26206009


Refer to “Steering System Inspection in Section 0B (Page 0B-20)”.

Steering Stem Bearing Removal and Installation

B815H26206010


Removal

- 1) Remove the steering stem lower bracket. Refer to "Steering Removal and Installation (Page 6B-6)".
- 2) Remove the dust seal cover (1), dust seal (2), steering stem upper bearing inner race (3) and bearing (4).



I815H1620033-01


- 3) Remove the steering stem lower bearing and inner race using a chisel.



I649G1620033-02

- 4) Remove the steering stem upper and lower bearing races using the special tools.

Special tool

TOOL (A): 09941-54911 (Bearing outer race remover)
TOOL (B): 09941-74911 (Steering bearing installer)


I649G1620034-03

Installation

Install the steering stem bearings in the reverse order of removal. Pay attention to the following points:



⚠ CAUTION

The removed bearings and races should be replaced with new ones.

Outer race

- Press in the upper and lower outer races using the special tool.

Special tool

TOOL (A): 09941-34513 (Steering race installer)


I815H1620034-01

Inner race

- Press in the lower bearing inner race and bearing using the special tool.

Special tool

TOOL (A): 09925-18011 (Steering bearing installer)


I815H1620035-01

- Install the steering. Refer to "Steering Removal and Installation (Page 6B-6)".

Steering Tension Adjustment

B815H26206011

Check the steering movement in the following procedures:


- 1) By supporting the motorcycle with a jack, lift the front wheel unit is off the floor 20 – 30 mm (0.8 – 1.2 in).
- 2) Remove the steering damper. Refer to “Steering Damper Construction (Page 6B-6)”.
- 3) Check to make sure that the cables and wire harnesses are properly routed.
- 4) With the front wheel in the straight ahead state, hitch the spring scale (special tool) on one handlebar grip end as shown in the figure and read the graduation when the handlebar starts moving.

Initial force

200 – 500 grams

Special tool

TOOL (A): 09940-92720 (Spring scale)




I649G1620040-02

- 5) Do the same on the other grip end.

- 6) If the initial force read on the scale when the handlebar starts turning is either too heavy or too light, adjust it till it satisfies the specification.
 - a) First, loosen the front fork upper and lower clamp bolts, steering stem head nut and steering stem lock-nut, and then adjust the steering stem nut by loosening or tightening it.

Special tool

TOOL (B): 09910-60611 (Universal clamp wrench)



I815H1620036-01

- b) Tighten the steering stem lock-nut, stem head nut and front fork upper and lower clamp bolts to the specified torque and recheck the initial force with the spring scale according to the previously described procedure.
- c) If the initial force is found within the specified range, adjustment has been completed.

NOTE

Hold the front fork legs, move them back and forth and make sure that the steering is not loose.

Specifications

Tightening Torque Specifications

B815H26207001

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Handlebar clamp bolt	10	1.0	7.0	☞ (Page 6B-3)
Steering stem nut	45 N·m (4.5 kgf·m, 32.5 lb·ft) then turn back 1/2 – 1/4			☞ (Page 6B-8)
Steering stem lock-nut	80	8.0	58.0	☞ (Page 6B-9)
Steering stem head nut	90	9.0	65.0	☞ (Page 6B-9)
Handlebar holder mounting nut	35	3.5	25.5	☞ (Page 6B-9)
Steering damper bolt	23	2.3	16.5	☞ (Page 6B-10)
Steering damper nut	23	2.3	16.5	☞ (Page 6B-10)

NOTE

The specified tightening torque is also described in the following.

“Handlebar Components (Page 6B-1)”

“Handlebar Construction (Page 6B-2)”

“Steering Components (Page 6B-5)”

“Steering Damper Construction (Page 6B-6)”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Tightening Torque List in Section 0C (Page 0C-9)”.

Special Tools and Equipment

Recommended Service Material

B815H26208001

Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI SUPER GREASE A or equivalent	P/No.: 99000–25010	☞ (Page 6B-4) / ☞ (Page 6B-8) / ☞ (Page 6B-9)
Handle grip bond	Handle Grip Bond (commercially available)	—	☞ (Page 6B-4)

NOTE

Required service material is also described in the following.

“Handlebar Components (Page 6B-1)”








“Handlebar Construction (Page 6B-2)”

“Steering Components (Page 6B-5)”

“Steering Damper Construction (Page 6B-6)”

Special Tool

B815H26208002

<p>09910-60611 Universal clamp wrench 🔧 (Page 6B-12)</p> 	<p>09925-18011 Steering bearing installer 🔧 (Page 6B-11)</p> 
<p>09940-14911 Steering stem nut wrench 🔧 (Page 6B-7) / 🔧 (Page 6B-8) / 🔧 (Page 6B-9)</p> 	<p>09940-14960 Steering nut wrench socket 🔧 (Page 6B-7) / 🔧 (Page 6B-8) / 🔧 (Page 6B-9)</p> 
<p>09940-92720 Spring scale 🔧 (Page 6B-12)</p> 	<p>09941-34513 Steering race installer 🔧 (Page 6B-11)</p> 
<p>09941-54911 Bearing outer race remover 🔧 (Page 6B-11)</p> 	<p>09941-74911 Steering bearing installer 🔧 (Page 6B-11)</p> 

Section 9

Body and Accessories

CONTENTS

Precautions	9-1	Dimmer Switch Inspection.....	9B-11
Precautions.....	9-1	Specifications	9B-12
Precautions for Electrical System	9-1	Service Data.....	9B-12
Component Location	9-1	Tightening Torque Specifications.....	9B-12
Electrical Components Location	9-1	Special Tools and Equipment	9B-12
Wiring Systems.....	9A-1	Recommended Service Material	9B-12
Schematic and Routing Diagram.....	9A-1	Special Tool	9B-12
Wiring Diagram	9A-1	Combination Meter / Fuel Meter / Horn..	9C-1
Wiring Harness Routing Diagram.....	9A-5	General Description	9C-1
Specifications.....	9A-9	Combination Meter System Description	9C-1
Service Data	9A-9	Repair Instructions	9C-2
Tightening Torque Specifications.....	9A-9	Combination Meter Components	9C-2
Special Tools and Equipment.....	9A-9	Combination Meter Removal and Installation	9C-2
Recommended Service Material.....	9A-9	Combination Meter Disassembly and	
Lighting Systems.....	9B-1	Assembly.....	9C-3
Repair Instructions	9B-1	Combination Meter Inspection	9C-3
Headlight Components	9B-1	Engine Coolant Temperature Meter and	
Headlight Removal and Installation	9B-2	Indicator Light Inspection	9C-4
Headlight Bulb and Position Light Bulb		ECT Sensor Removal and Installation	9C-5
Replacement.....	9B-2	Fuel Meter Inspection.....	9C-5
Headlight Beam Adjustment	9B-3	Fuel Level Gauge Inspection	9C-6
Front Turn Signal Light Components	9B-3	Speedometer Inspection	9C-6
Front Turn Signal Light Removal and		Speed Sensor Removal and Installation	9C-6
Installation	9B-4	Speed Sensor Inspection	9C-7
Front Turn Signal Light Bulb Replacement	9B-4	Oil Pressure Indicator Inspection	9C-7
Rear Lighting System Construction.....	9B-5	Oil Pressure Switch Removal and Installation	9C-7
Rear Combination Light Removal and		Oil Pressure Switch Inspection	9C-8
Installation	9B-5	Ignition Switch Inspection.....	9C-8
Rear Combination Light Replacement	9B-6	Ignition Switch Removal and Installation.....	9C-8
License Plate Light Components	9B-6	Horn Inspection	9C-9
License Plate Light Removal and Installation	9B-7	Horn Removal and Installation	9C-9
License Plate Light Bulb Replacement	9B-7	Specifications	9C-10
Rear Turn Signal Light Components.....	9B-8	Service Data.....	9C-10
Rear Turn Signal Light Removal and		Tightening Torque Specifications.....	9C-10
Installation	9B-8	Special Tools and Equipment	9C-10
Rear Turn Signal Light Bulb Replacement.....	9B-8	Special Tool	9C-10
Reflex Reflector Construction	9B-9	Exterior Parts	9D-1
Turn Signal / Side-Stand Relay Inspection	9B-9	Schematic and Routing Diagram.....	9D-1
Turn Signal / Side-Stand Relay Removal and		Seat Lock Cable Routing Diagram.....	9D-1
Installation	9B-9	Repair Instructions	9D-2
Hazard Switch Inspection	9B-10	Exterior Parts Construction	9D-2
Turn Signal Switch Inspection.....	9B-10	Rear Under Cowling Head Shield Attachment	9D-3
Passing Light Switch Inspection	9B-11		

Intake Cover Protection Tape Attachment9D-3

Inner Under Cowling Cushion Attachment.....9D-4

Under Cowling Heat Shield Attachment.....9D-4

Pillion Rider Handlebar Construction9D-5

Panel Cushion Attachment.....9D-6

Rear Fender Construction.....9D-7

Frame Cover Construction9D-8

Cowling Cushion Attachment.....9D-9

Flame Cover Cushion Attachment9D-10

Mudguard Construction.....9D-11

Rear Fender Cushion Attachment.....9D-12

Body Cowling Cover Cushion Attachment9D-12

Fastener Removal and Installation.....9D-13

Exterior Parts Removal and Installation9D-14

Specifications9D-22

 Tightening Torque Specifications.....9D-22

Special Tools and Equipment9D-22

 Recommended Service Material9D-22

 Special Tool9D-22

Body Structure..... 9E-1

Repair Instructions9E-1

 Body Frame Construction9E-1

 Front Footrest Bracket Construction9E-2

 Side-stand Construction.....9E-3

 Pillion Footrest Bracket Construction9E-3

 Footrest Construction.....9E-4

 Side-stand Removal and Installation.....9E-5

Specifications9E-5

 Tightening Torque Specifications.....9E-5

Special Tools and Equipment9E-5

 Recommended Service Material9E-5

Precautions

Precautions

Precautions for Electrical System

B815H29000001

Refer to “General Precautions in Section 00 (Page 00-1)” and “Precautions for Electrical Circuit Service in Section 00 (Page 00-2)”.

Component Location

Electrical Components Location

B815H29003001

Refer to “Electrical Components Location in Section 0A (Page 0A-8)”.

Wiring Systems


Schematic and Routing Diagram


Wiring Diagram

Refer to “Wire Color Symbols in Section 0A (Page 0A-6)”.


B815H29102001

For E-02, 19, 24






For E-33



Wiring Harness Routing Diagram


B815H29102002



I815H1910904-06


1. Clamp : Bind the wiring harness, starter motor lead wire, generator lead wire, gear position switch lead wire and HO2 sensor lead wire with the clamp.	15. Clutch pipe
2. Clamp : Bind the wiring harness with the clamp.	16. Water air bleed hose
3. Clamp : Bind the wiring harness and battery (-) lead wire.	17. TP sensor
4. Clamp : Bind the battery (-) lead wire with the clamp.	18. STVA
5. Clamp : Bind the battery (+) lead wire with the clamp.	19. STP sensor
6. Clamp : Bind the starter motor lead wire, generator lead wire, gear position switch lead wire and HO2 sensor lead wire with the clamp.	20. Secondary fuel injector
7. Clamp : Bind the wiring harness and handlebar switch lead wire (RH) with the clamp.	21. Black tape

 8. Clamp : Bind the handlebar switch lead wires (LH/RH), ignition switch lead wire and immobilizer antenna lead wire (E-02, 19, 24) with the clamp.	22. IAP sensor
 9. Guide : Pass the handlebar switch lead wires (LH/RH) and immobilizer antenna lead wire (E-02, 19, 24) into the guide.	23. Combination meter coupler
 10. Clamp : Bind the IAP sensor lead wire, secondary fuel injector lead wire and TP sensor lead wire with the clamp.	24. EVAP purge control solenoid valve (E-33 only)
 11. Clamp : Bind the wiring harness No. 2 with the clamp.	 "A": The coupler of #1 ignition coil/plug cap faces left side.
12. Wiring harness	 "B": Do not make a wire slacked at part [B].
13. Starter motor lead wire	[A]: Backside of the headlight
14. Fixed clamp	



1815H1910908-01

<p>1. Clamp : Bind the wiring harness, starter motor lead wire, generator lead wire, gear position switch lead wire and HO2 sensor lead wire with the clamp.</p>	<p>13. Seat rail</p>
<p>2. Clamp : Bind the wiring harness, speed sensor lead wire and side-stand lead wire with the clamp.</p>	<p>14. Oil pressure switch</p>
<p>3. Clamp : Bind the starter motor lead wire, generator lead wire, gear position switch lead wire and HO2 sensor lead wire with the clamp.</p>	<p>15. HO2 sensor</p>
<p>4. Clamp : Bind the battery (+) lead wire with the clamp.</p>	<p>16. Ignition switch lead wire : Pass the ignition switch lead wire on the outside of other lead wires.</p>
<p>5. Clamp : Bind the wiring harness with the clamp.</p>	<p>17. Gray taping : Fasten the clamp on the gray taping. The width of the gray taping on both the right and left of the clamp be at least 1 mm.</p>
<p>6. Clamp : Bind the license plate light lead wire with the clamp. Cut off the excess end of the clamp and set the locked part facing inside.</p>	<p>"A": The ignition switch lead wire should not be hidden by other lead wires when viewed within the range "b".</p>
<p>7. Clamp : Bind the wiring harness and handlebar switch lead wire (RH) with the clamp.</p>	<p>"a": 5 – 10 mm (0.2 – 0.4 in)</p>
<p>8. Clamp : Bind the handlebar switch lead wires (LH/RH), ignition switch lead wire and immobilizer antenna lead wire (E-02, 19, 24) with the clamp.</p>	<p>"b": 90°</p>
<p>9. Clamp : Bind the rear turn signal light lead wire with the clamp.</p>	<p>"c": 1 mm (0.039 in) and more</p>
<p>10. Clamp : Bind the license plate light lead wire with the clamp.</p>	<p>[A]: Inside of the rear frame cover</p>
<p>11. IAT sensor</p>	<p>[B]: Inside of the rear fender</p>
<p>12. Wiring harness</p>	



9A-9 Wiring Systems:

1. Gear position switch	8. Battery (–) lead wire	 (d) : 120 N·m (12.0 kgf-m, 87 lb-ft)
2. Oil pressure switch	 "A": When tightening the starter motor mounting bolts, tighten rear one first.	 (e) : 10 N·m (1.0 kgf-m, 7.0 lb-ft)
3. Starter motor	"a": Within 20°	 (f) : 1.5 N·m (0.15 kgf-m, 1.0 lb-ft)
4. CMP sensor	"b": Approx. 30°	 (g) : 14 N·m (1.4 kgf-m, 10.0 lb-ft)
5. CKP sensor	 (a) : 6.5 N·m (0.65 kgf-m, 4.7 lb-ft)	 (h) : 5 N·m (0.5 kgf-m, 3.5 lb-ft)
6. Speed sensor	 (b) : 6 N·m (0.6 kgf-m, 4.3 lb-ft)	 1207B : Apply bond to the thread part.
7. Clamp	 (c) : 11 N·m (1.1 kgf-m, 8.0 lb-ft)	 i322 : Apply threaded lock to the threaded part.

Specifications

Service Data

B815H29107001

Electrical

Item			Specification	Note
Fuse size	Headlight	HI	10 A	
		LO	10 A	
	Signal		10 A	
	Ignition		15 A	
	Fuel		10 A	
	Fan (LH)		15 A	
	Fan (RH)			
	Main		30 A	

Tightening Torque Specifications

B815H29107002

NOTE

The specified tightening torque is also described in the following.

“Wiring Harness Routing Diagram (Page 9A-5)”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Tightening Torque List in Section 0C (Page 0C-9)”.

Special Tools and Equipment

Recommended Service Material

B815H29108001

NOTE

Required service material is also described in the following.


“Wiring Harness Routing Diagram (Page 9A-5)”

Lighting Systems

Repair Instructions

Headlight Components

B815H29206001



I815H1920001-03


1. Headlight Low beam bulb (12 V 55 W, H7)	3. Position light bulb (12 V 5 W x 2)
2. Socket	4. Headlight High beam bulb (12 V 65 W, H9)

Headlight Removal and Installation

B815H29206002

Removal

- 1) Remove the body cowlings. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Disconnect the High beam headlight coupler (1), Low beam headlight coupler (2) and position light couplers (3).
- 3) Remove the headlight assembly (4).



I815H1920003-02

Installation

Installation is in the reverse order of removal. Pay attention to the following point:

- After installing, be sure to inspect the headlight beam. Refer to "Headlight Beam Adjustment (Page 9B-3)".


Headlight Bulb and Position Light Bulb Replacement

B815H29206003

⚠ CAUTION


When you touch the bulb with your bare hands, clean the bulb with a cloth moistened with alcohol or soap water to prevent premature bulb failure.

- 1) Remove the body cowlings. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Disconnect the headlight (Low beam) coupler (1) and remove the rubber cap (2).




I815H1920004-01

- 3) Unhook the bulb holder spring (3) and remove the headlight bulb/socket (Low beam) (4).




I815H1920005-02

- 4) Disconnect the headlight bulb (5) from its adapter (6).
- 5) Replace the headlight bulb with a new one.




I815H1920006-01

- 6) Disconnect the headlight (High beam) coupler (7).
- 7) Remove the headlight bulb/socket (High beam) (8) by turning it counter clockwise.




I815H1920007-01

- 8) Replace the headlight bulb with a new one.




I815H1920008-01

9) Remove the position light socket (9).



I815H1920009-01

10) Replace the position light bulb (10) with a new one.




I815H1920010-01

11) Reinstall the removed parts.

Headlight Beam Adjustment


B815H29206004

Insert a (+) screwdriver as shown in the figure and adjust the headlight beam horizontally and vertically.



I815H1920011-01

"A": Vertical adjuster




I815H1920012-01

"B": Horizontal adjuster

Front Turn Signal Light Components

B815H29206005



I815H1920013-02

1. Turn signal light bulb (12 V 21 W x 2)

2. Front turn signal light


3. Socket

Front Turn Signal Light Removal and Installation

B815H29206006

Removal

- 1) Remove the body cowlings. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Disconnect the front turn signal coupler (1).
- 3) Remove the front turn signal light (2).



I815H1920014-01

Installation

Install the front turn signal light in the reverse order of removal.


Front Turn Signal Light Bulb Replacement

B815H29206007

⚠ CAUTION


When you touch the bulb with your bare hands, clean the bulb with a cloth moistened with alcohol or soap water to prevent premature bulb failure.

- 1) Remove the upper panels. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Remove the socket (1) by turning it counterclockwise.



I815H1920015-01


- 3) Replace the front turn signal light bulb (2).



I815H1920016-01

Rear Lighting System Construction

B815H29206008



I815H1920017-02


1. Spacer x 2 pcs.	5. License plate light	9. Combination light
2. Washer x 2 pcs.	6. Turn signal light x 2 pcs.	⚙️(a) : 5 N·m (0.5 kgf-m, 3.5 lb-ft)
3. Clamp (Only for LH)	7. Combination light bracket, upper	⚙️(b) : 2.8 N·m (0.28 kgf-m, 2.0 lb-ft)
4. Nut x 2 pcs.	8. Combination light bracket, lower	🔧1322 : Apply thread lock to the thread part.

Rear Combination Light Removal and Installation

B815H29206009

Removal


- 1) Remove the frame cover. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.
- 2) Disconnect the combination light coupler (1).
- 3) Disconnect the combination light lead wire from its clamp (2).
- 4) Remove the rear fender assembly (3).



I815H1920018-01

9B-6 Lighting Systems:

- 5) Remove the combination light brackets (upper and lower) (4).



I815H1920019-01

Installation

Install the rear combination light in the reverse order of removal. Pay attention to the following point:

- Tighten the combination light mounting bolts (1) to the specified torque.


NOTE

When reusing the removed bolts (1), apply a small quantity of the thread lock to them.

Tightening torque

Combination light mounting bolt (a): 2.8 N·m (0.28 kgf-m, 2.0 lb-ft)

1322 : Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER 1322 or equivalent)



I815H1920020-01

Rear Combination Light Replacement


B815H29206010

⚠ CAUTION

If LED operation is abnormal, replace the rear combination light with a new one.

License Plate Light Components

B815H29206011



I815H1920022-01


1. License plate light bulb (12 V 5 W)	3. Lens
2. Lens cover	(a) : 5 N·m (0.5 kgf-m, 3.5 lb-ft)

License Plate Light Removal and Installation

B815H29206012

Removal

- 1) Remove the frame cover. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Disconnect the license plate light coupler (1).



I815H1920023-01

- 3) Remove the license plate light (2).



I815H1920045-01


Installation

Install the license plate light in the reverse order of removal. Pay attention to the following point:

- Tighten the license plate light mounting nuts (1) to the specified torque.

Tightening torque

License plate light mounting nut (a): 5 N·m (0.5 kgf-m, 3.5 lb-ft)




I815H1920025-01

License Plate Light Bulb Replacement

B815H29206013

- 1) Remove the license plate light mounting nuts (1).




I815H1920026-01

- 2) Remove the lens by removing the screws.



I815H1920027-01

- 3) Replace the bulb (1).




I815H1920028-01

- 4) Reinstall the removed parts.

Rear Turn Signal Light Components

B815H29206014



I815H1920029-01


1. Rear turn signal light	2. Rear turn signal light bulb (12 V 21 W x 2)	3. Socket
---------------------------	--	-----------

Rear Turn Signal Light Removal and Installation

B815H29206015


Removal

- 1) Remove the rear seat. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.
- 2) Disconnect the rear turn signal light coupler (1).



I815H1920030-01

- 3) Remove the rear turn signal light (2).



I815H1920031-01

"A": Hooking point

Installation

Install the rear turn signal light in the reverse order of removal.


Rear Turn Signal Light Bulb Replacement

B815H29206016

⚠ CAUTION

When you touch the bulb with your bare hands, clean the bulb with a cloth moistened with alcohol or soap water to prevent premature bulb failure.


- 1) Remove the rear turn signal light (1).



I815H1920032-01


"A": Hooking point

- 2) Remove the socket (2) by turning it counterclockwise.



I815H1920033-01

- 3) Replace the bulb (3).





I815H1920034-01

- 4) Reinstall the removed parts.

Reflex Reflector Construction

B815H29206017



I815H1920035-07

1. Front reflex reflector x 2 pcs. (For E-03, 24, 28, 33)	3. Reflector bracket x 2 pcs.	⌚(b) : 10 N·m (1.0 kgf-m, 7.0 lb-ft)
2. Reflector x 2 pcs. (For E-03, 28, 33)	⌚(a) : 1.8 N·m (0.18 kgf-m, 1.3 lb-ft)	

Turn Signal / Side-Stand Relay Inspection

B815H29206018

Refer to "Electrical Components Location in Section 0A (Page 0A-8)".

NOTE

Make sure that the battery is fully charged.

Before removing the turn signal/side-stand relay, check the operation of the turn signal light.

If the turn signal light does not illuminate, inspect the bulb, turn signal switch and circuit connection.

If the bulb, turn signal switch and circuit connection are OK, the turn signal relay may be faulty; therefore, replace the turn signal/side-stand relay with a new one. Refer to "Turn Signal / Side-Stand Relay Removal and Installation (Page 9B-9)".

Turn Signal / Side-Stand Relay Removal and Installation


B815H29206019

Removal

- 1) Remove the left upper panel. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".

9B-10 Lighting Systems:

- 2) Remove the turn signal/side-stand relay (1).



I815H1920036-01

Installation


Install the turn signal/side-stand relay in the reverse order of removal.

Hazard Switch Inspection

B815H29206020

Inspect the hazard switch in the following procedures:

- 1) Remove the left upper panel. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.
- 2) Disconnect the left handlebar switch coupler (1).



I815H1920037-01

- 3) Inspect the hazard switch for continuity with a tester. If any abnormality is found, replace the left handlebar switch assembly with a new one. Refer to “Handlebar Removal and Installation in Section 6B (Page 6B-3)”.

Special tool

 : 09900-25008 (Multi-circuit tester set)

Tester knob indication

Continuity (••))

Color Position	B	Sb	Lg
OFF			
ON			

I815H1920038-01


- 4) After finishing the hazard switch inspection, reinstall the removed parts.

Turn Signal Switch Inspection

B815H29206021

Inspect the turn signal switch in the following procedures:

- 1) Remove the left upper panel. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.
- 2) Disconnect the left handlebar switch coupler (1).



I815H1920039-01

- 3) Inspect the turn signal switch for continuity with a tester. If any abnormality is found, replace the left handlebar switch assembly with a new one. Refer to “Handlebar Removal and Installation in Section 6B (Page 6B-3)”.

Special tool

 : 09900-25008 (Multi-circuit tester set)

Tester knob indication

Continuity (••))

Color Position	Lg	Sb	B
L			
PUSH			
R			

I815H1920040-02


- 4) After finishing the turn signal switch inspection, reinstall the removed parts.

Passing Light Switch Inspection

B815H29206022

Inspect the passing light switch in the following procedures:

- 1) Remove the left upper panel. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.
- 2) Disconnect the left handlebar switch coupler (1).



I815H1920041-01

- 3) Inspect the passing light switch for continuity with a tester.
If any abnormality is found, replace the left handlebar switch assembly with a new one. Refer to “Handlebar Removal and Installation in Section 6B (Page 6B-3)”.

Special tool
TOOL : 09900-25008 (Multi-circuit tester set)

Tester knob indication
Continuity (●)))

Color	O	Y
Position		
•		
PUSH	○	○

I815H1920042-01


- 4) After finishing the passing light switch inspection, reinstall the removed parts.

Dimmer Switch Inspection

B815H29206023

Inspect the dimmer switch in the following procedures:

- 1) Remove the left upper panel. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.
- 2) Disconnect the left handlebar switch coupler (1).



I815H1920043-01

- 3) Inspect the dimmer switch for continuity with a tester.
If any abnormality is found, replace the left handlebar switch assembly with a new one. Refer to “Handlebar Removal and Installation in Section 6B (Page 6B-3)”.

Special tool
TOOL : 09900-25008 (Multi-circuit tester set)

Tester knob indication
Continuity (●)))

Color	W	Y	O
Position			
HI		○	○
LO	○		○

I815H1920044-01

- 4) After finishing the dimmer switch inspection, reinstall the removed parts.

Specifications

Service Data

B815H29207001

Wattage

Unit: W

Item		Specification
Headlight	HI	65
	LO	55
Position/Parking light		5 x 2
Brake light/Taillight		LED
Turn signal light		21 x 4
License plate light		5

Tightening Torque Specifications

B815H29207002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Combination light mounting bolt	2.8	0.28	2.0	☞ (Page 9B-6)
License plate light mounting nut	5	0.5	3.5	☞ (Page 9B-7)

NOTE

The specified tightening torque is also described in the following.

“Rear Lighting System Construction (Page 9B-5)”

“License Plate Light Components (Page 9B-6)”

“Reflex Reflector Construction (Page 9B-9)”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Tightening Torque List in Section 0C (Page 0C-9)”.

Special Tools and Equipment

Recommended Service Material

B815H29208001

Material	SUZUKI recommended product or Specification		Note
Thread lock cement	THREAD LOCK CEMENT SUPER 1322 or equivalent	P/No.: 99000–32110	☞ (Page 9B-6)


NOTE

Required service material is also described in the following.

“Rear Lighting System Construction (Page 9B-5)”

Special Tool

B815H29208002

09900–25008 Multi-circuit tester set ☞ (Page 9B-10) / ☞ (Page 9B-10) / ☞ (Page 9B-11) / ☞ (Page 9B-11)		
---	---	--

Combination Meter / Fuel Meter / Horn

General Description

Combination Meter System Description

B815H29301001

This combination meter mainly consists of the stepping motor, LCD (Liquid Crystal Display) and LED (Light Emitting Diode).

The speed, engine RPM, fuel and engine coolant temperature pointers are driven by the stepping motor.

The LCDs indicate Gear position, Drive mode, Clock and Odo / Trip 1 / Trip 2 / FI (DTC) respectively.


LED (Light Emitting Diode)

LED is used for the illumination light and each indicator light.

LED is maintenance free. LED is less power consuming and more resistant to vibration resistance compared to the bulb.

Engine Revolution Indicator Light

This speedometer is equipped the engine revolution indicator light. The engine revolution indicator light is adjustable from 4 000 – 11 500 r/min. (from 4 000 r/min to 8 000 r/min, every 500 r/min and 8 000 r/min to 11 500 r/min, every 250 r/min: Initial setting: 10 000 r/min)




I815H1930001-01

1. Fuel meter	11. Engine coolant temperature meter
2. LED (Turn signal indicator light)	12. LED (Engine coolant temperature indicator light)
3. Tachometer	13. LED (Engine RPM indicator light)
4. LCD (Gear position indicator)	14. LED (FI indicator light)
5. LED (Fuel indicator light)	15. LCD (Engine RPM indicator)
6. LED (Neutral indicator light)	16. SEL button
7. LED (Oil pressure indicator light)	17. LCD (Odo / Trip 1 / Trip 2 / FI)
8. LCD (Clock)	18. ADJ button
9. LCD (Drive mode indicator)	19. LED (High-beam indicator light)
10. Speedometer	

Repair Instructions

Combination Meter Components

B815H29306001



I815H1930002-02

1. Combination meter unit	2. Combination meter case	3. Combination meter cover
---------------------------	---------------------------	----------------------------

Combination Meter Removal and Installation

B815H29306002


Removal

- 1) Remove the upper and lower meter panels. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.
- 2) Remove the combination meter mounting bolts.



I815H1930003-01

- 3) Disconnect the coupler (1) and remove the combination meter assembly.



I815H1930004-01

Installation

Install the combination meter in the reverse order of removal.

NOTE

Fix the boot of the combination meter coupler firmly.

Combination Meter Disassembly and Assembly

B815H29306003

Refer to “Combination Meter Removal and Installation (Page 9C-2)”.

Disassembly

Disassemble the combination meter as shown in the combination meter components. Refer to “Combination Meter Components (Page 9C-2)”.

Assembly

Assemble the combination meter as shown in the combination meter components. Refer to “Combination Meter Components (Page 9C-2)”.

Combination Meter Inspection


B815H29306004

LED Inspection

Check that the LEDs (FI, oil pressure, fuel, engine RPM, engine coolant temperature indicator lights and meter panel illumination) immediately light up when the ignition switch is turned ON.

Check that other LEDs (neutral, high-beam and turn signal indicator lights) light up/go off by operating each switch.


If abnormal condition is found, replace the combination meter assembly with a new one after checking its wire harness/coupler. Refer to “Combination Meter Removal and Installation (Page 9C-2)”.



I815H1930005-01

Stepping Motor Inspection and Adjustment

- 1) Check that the pointers calibrate immediately after turning the ignition switch ON and stop at zero point (tachometer and speedometer) or at present level (fuel and engine coolant temperature meters). If abnormal condition is found, replace the combination meter assembly with a new one after checking its wire harness/coupler.




I815H1930006-02

NOTE

- The pointers may not return to the proper position even turning the ignition switch on under low temperature condition. In that case, you can reset the pointers to the proper position by the following instruction.
- Complete the operation within 10 seconds after the ignition switch has been turned on.

- 2) With the ADJ button (1) pressed, turn the ignition switch ON.
- 3) Keep pushing the ADJ button for more than 3 sec.



I815H1930007-01

Time	Ignition switch	ADJ button (1)
	OFF	PUSH
0	ON	
•		
•		
3 sec.		*
•		Reset
•		
•		
•		
•		

I815H1930025-01


Pointers will return to the proper position right after the completion of the operation. In the case of the pointers not returning to the proper position after doing above, replace the combination meter unit. Refer to “Combination Meter Removal and Installation (Page 9C-2)”.

*: At this point, release the ADJ button and push the button 2 times within 1 second.


Engine Coolant Temperature Meter and Indicator Light Inspection

Inspect the engine coolant temperature meter and indicator light (LED) in the following procedures:


- 1) Lift and support the fuel tank. Refer to “Fuel Tank Removal and Installation in Section 1G (Page 1G-9)”.
2) Disconnect the ECT sensor coupler (1).



- 3) Connect a variable resistor (2) between the terminals.



- 4) Turn the ignition switch ON.
- 5) Check the engine coolant temperature meter (3) and indicator light (LED) (4) operations when the resistance is adjusted to the specified values. If either one or both indications are abnormal, replace the combination meter assembly with a new one. Refer to “Combination Meter Removal and Installation (Page 9C-2)”.



Engine coolant temperature meter		Resistance
Needle position	LED	
	OFF	Approx. 0.8 kΩ
	OFF	Approx. 0.14 kΩ
	ON	Approx. 0.1 kΩ

- 6) Connect the ECT sensor coupler.
- 7) Install the removed parts.

ECT Sensor Removal and Installation

B815H29306006


Refer to “ECT Sensor Removal and Installation in Section 1C (Page 1C-5)”.

Fuel Meter Inspection

B815H29306007


Inspect the fuel meter in the following procedures:

- 1) Lift and support the fuel tank. Refer to “Fuel Tank Removal and Installation in Section 1G (Page 1G-9)”.
- 2) Disconnect the fuel pump lead wire coupler (1).




I815H1930024-01

- 3) Connect a variable resistor (2) between the B/Lg and B/W lead wires of the wire harness side coupler.



I823H1930010-03

- 4) Turn the ignition switch ON.
- 5) Check the fuel meter (3) and indicator light (LED) (4) operations when the resistance is adjusted to the specified values.
If either one or both indications are abnormal, replace the combination meter with a new one. Refer to “Combination Meter Removal and Installation (Page 9C-2)”.



I815H1930011-02

NOTE

It takes approx. 30 seconds that the fuel meter indicates the detected fuel level.

Fuel meter		Resistance
Needle position	LED	
	ON	Approx. 118 Ω
	ON	Approx. 96 Ω
	OFF	Approx. 63 Ω
	OFF	Approx. 23 Ω

I815H1930012-04

- 6) Connect the fuel level gauge coupler and reinstall the fuel tank.
Refer to “Fuel Tank Removal and Installation in Section 1G (Page 1G-9)”.

Fuel Level Gauge Inspection

B815H29306008

Inspect the fuel level gauge in the following procedures:

- 1) Remove the fuel pump. Refer to “Fuel Pump Disassembly and Assembly in Section 1G (Page 1G-12)”.
- 2) Measure the resistance at each fuel level gauge in float position. If the resistance is incorrect, replace fuel level gauge with a new one.


Special tool

 : 09900-25008 (Multi-circuit tester set)

Tester knob indication

Resistance (Ω)

Float position	Resistance
Full “a”	11 – 13 Ω
Empty “b”	130 – 135 Ω



I815H1930013-01

“a”: 241.2 mm (9.50 in)	“b”: 55 mm (2.17 in)
-------------------------	----------------------

- 3) Install the fuel pump. Refer to “Fuel Pump Disassembly and Assembly in Section 1G (Page 1G-12)”.

Speedometer Inspection

B815H29306009


If the speedometer, odometer or tripmeter does not function properly, inspect the speed sensor and the coupler connections. If the speed sensor and coupler connections are OK, replace the combination meter unit with a new one. Refer to “Combination Meter Removal and Installation (Page 9C-2)”.

Speed Sensor Removal and Installation

B815H29306010


Removal

- 1) Remove the left side cowling. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.
- 2) Disconnect the speed sensor lead wire coupler (1).



I815H1930014-01

- 3) Remove the speed sensor (2).



I815H1930015-01


Installation

Install the speed sensor in the reverse order of removal. Pay attention to the following points:

- Tighten the speed sensor mounting bolt (1) to the specified torque.

Tightening torque

Speed sensor mounting bolt (a): 6.5 N·m (0.65 kgf·m, 4.7 lb·ft)



I815H1930016-01

- Route the speed sensor lead wire. Refer to “Wiring Harness Routing Diagram in Section 9A (Page 9A-5)”.

Speed Sensor Inspection

B815H29306011

Inspect the speed sensor in the following procedures:


- 1) Remove the speed sensor. Refer to "Speed Sensor Removal and Installation (Page 9C-6)".
- 2) Connect a 12 V battery (between B and B/W), 10 k Ω resistor (between B/R and B) and multi-circuit tester (tester (+) probe to B and tester (-) probe to B/R) as shown in the figure.

Special tool

TOOL : 09900-25008 (Multi-circuit tester set)

Tester knob indication

Voltage (---)




I649G1930016-02

1. Speed sensor

- 3) Move a screwdriver back and forth across the pick-up surface of the speed sensor. The voltage readings should cycle as follows (0 V → 12 V or 12 V → 0 V). If the voltage reading does not change, replace the speed sensor with a new one.

NOTE

While testing, the highest voltage reading should be the same as the battery voltage (12 V).



I649G1930017-02

Oil Pressure Indicator Inspection


B815H29306012

Inspect the oil pressure indicator in the following procedures:

NOTE


Before inspecting the oil pressure switch, check if the engine oil level is correct. Refer to "Engine Oil and Filter Replacement in Section 0B (Page 0B-10)".

- 1) Remove the right side cowling. Refer to "Exterior Parts Removal and Installation in Section 9D (Page 9D-14)".
- 2) Disconnect the oil pressure switch lead wire (1) from the oil pressure switch.



I815H1930017-01

- 3) Turn the ignition switch ON.
- 4) Check if the oil pressure indicator (LED) will light up when grounding the lead wire (1). If the oil pressure indicator does not light up, replace the combination meter assembly with a new one after checking the connection of couplers.



I815H1930018-01

Oil Pressure Switch Removal and Installation

B815H29306013

Refer to "Oil Pressure Switch Removal and Installation in Section 1E (Page 1E-9)".

Oil Pressure Switch Inspection

B815H29306014

Inspect the oil pressure switch in the following procedures:

NOTE

Before inspecting the oil pressure switch, check if the engine oil level is correct. Refer to “Engine Oil and Filter Replacement in Section 0B (Page 0B-10)”.

- 1) Remove the right side cowling. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.
- 2) Disconnect the oil pressure switch lead wire from the oil pressure switch.
- 3) Inspect the oil pressure switch for continuity with the tester. If any abnormality is found, replace the oil pressure switch with a new one.

Special tool

 : 09900–25008 (Multi-circuit tester set)

Tester knob indication
Continuity (●)))

Position \ Color	G/Y	Ground
ON (Engine is at stop.)		
OFF (Engine is running.)		

I823H1930033-01


- 4) After finishing the oil pressure switch inspection, reinstall the removed parts.

Ignition Switch Inspection

B815H29306015

Inspect the ignition switch in the following procedures:

- 1) Remove the upper cover and body cowling cover. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.
- 2) Disconnect the ignition switch lead wire coupler (1).



I815H1180013-01

- 3) Inspect the ignition switch for continuity with a tester. If any abnormality is found, replace the ignition switch with a new one.

Special tool

 : 09900–25008 (Multi-circuit tester set)

Tester knob indication
Continuity (●)))

E-02, 19, 24

Color \ Position	R	O	Gr	Br
ON				
OFF				
LOCK				
P				

I823H1930019-02

E-03, 28, 33

Color \ Position	R	O	O/Y	Bl	Gr	Br
ON						
OFF						
LOCK						
P						

I815H1930023-01

- 4) After finishing the ignition switch inspection, reinstall the removed parts.

Ignition Switch Removal and Installation

B815H29306016

Refer to “Ignition Switch Removal and Installation in Section 1H (Page 1H-12)”.

Horn Inspection

B815H29306017

NOTE


If the horn sound condition is normal, it is not necessary to inspect the horn button continuity.

Horn Button Inspection

- 1) Remove the left fuel tank cover. Refer to “Exterior Parts Removal and Installation in Section 9D (Page 9D-14)”.
- 2) Disconnect the left handlebar switch lead wire coupler (1).

NOTE

Blue tape “A” is sicked on the left handle bar switch harness.



I815H1930019-01

- 3) Inspect the horn button for continuity with a tester. If any abnormality is found, replace the left handlebar switch assembly with a new one. Refer to “Handlebar Removal and Installation in Section 6B (Page 6B-3)”.

Special tool

 : 09900-25008 (Multi-circuit tester set)

Tester knob indication
Continuity (•)))

Color Position	B/BI	B/W
•		
PUSH		

I718H1930028-03


Horn Inspection

- 1) Disconnect the horn coupler (1).



I815H1930020-01

- 2) Connect a 12 V battery to the horn terminals. If the sound is not heard from the horn, replace the horn with a new one.



I815H1930021-01


- 3) Connect the horn coupler.

Horn Removal and Installation

B815H29306018

Removal

- 1) Disconnect the horn coupler (1).
- 2) Remove the horn (2) by removing the mounting bolts.



I815H1930022-01

Installation

Install the horn in the reverse order of removal.

Specifications

Service Data

B815H29307001

Wattage

Unit: W

Item	Specification
Tachometer light	LED
Speedometer light	LED
Turn signal indicator light	LED
High beam indicator light	LED
Neutral position indicator light	LED
Oil pressure indicator light	LED
FI indicator light	LED
Engine coolant temp. indicator light	LED
Fuel level indicator light	LED
Engine R.P.M. indicator light	LED

Tightening Torque Specifications

B815H29307002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Speed sensor mounting bolt	6.5	0.65	4.7	☞ (Page 9C-6)


Reference:

For the tightening torque of fastener not specified in this section, refer to “Tightening Torque List in Section 0C (Page 0C-9)”.

Special Tools and Equipment

Special Tool

B815H29308001


09900–25008 Multi-circuit tester set ☞ (Page 9C-6) / ☞ (Page 9C-7) / ☞ (Page 9C-8) / ☞ (Page 9C-8) / ☞ (Page 9C-9)		
---	---	--

Exterior Parts

Schematic and Routing Diagram

Seat Lock Cable Routing Diagram

B815H29402001




I815H1940012-03

1. Frame cover	3. Seat lock cable guide
2. Seat lock cable	 4. Plate : Set the plate in the reverse side of the guide.

Repair Instructions

Exterior Parts Construction

B815H29406001




"A": To the steering under bracket	"B": To the frame
------------------------------------	-------------------

I815H1940005-02

Rear Under Cowling Head Shield Attachment

B815H29406002




1. Head shield, rear under cowling	"a": 3 mm (0.12 in)
------------------------------------	---------------------

I815H1940013-01

Intake Cover Protection Tape Attachment

B815H29406003




1. Protection tape	"b": 3 mm (0.12 in)	"d": 10 mm (0.39 in)
"a": 2 mm (0.08 in)	"c": 3.5 mm (0.14 in)	"e": 4 mm (0.16 in)

I815H1940014-01

Inner Under Cowling Cushion Attachment

B815H29406004




I815H1940015-01

1. Cushion	2. Under cowling, inner (LH)	"a": 3 mm (0.12 in)	"b": 5 mm (0.20 in)
------------	------------------------------	---------------------	---------------------

Under Cowling Heat Shield Attachment

B815H29406005




I815H1940016-03

1. Heat shield No. 1 (RH)	4. Heat shield No. 1 (LH)
2. Heat shield No. 2 (RH)	5. Heat shield No. 2 (LH)
3. Heat shield No. 3 (RH)	"A": Clean the adhesive surface before adhering the heat shield.

Pillion Rider Handlebar Construction

B815H29406006




I815H1940017-04

1. Pillion rider handle	3. Cushion, frame cover	5. Frame, seat rail	"b": 2.5 mm (0.10 in)
2. Cushion, pillion rider handle	4. Frame cover	"a": 1.5 mm (0.06 in)	(a) : 33 N·m (3.3 kgf-m, 24.0 lb-ft)

Panel Cushion Attachment

B815H29406007




I815H1940001-04

"a": 20 mm (0.79 in)	"b": 30 mm (1.18 in)	"c": 5 mm (0.20 in)	"d": 3 mm (0.12 in)
----------------------	----------------------	---------------------	---------------------

Rear Fender Construction


B815H29406008



I815H1940002-03

Frame Cover Construction

B815H29406009




(a) : 33 N·m (3.3 kgf-m, 24.0 lb-ft)

I815H1940004-04

Cowling Cushion Attachment

B815H29406010




"a": 5 mm (0.2 in)

I815H1940006-03


Flame Cover Cushion Attachment

B815H29406011



I815H1940007-02

	1. Cushion rubber : Clean the adhesive surface before adhering the cushion rubber.
	2. Protection tape : Clean the adhesive surface before adhering the protection tape.
	"A": Align the corner of the cushion rubber to the end of the rib.
	"B": Inside of the frame




I815H1940008-02

 1. Cushion rubber : Align the cushion rubber with the edge.	"a": 30 mm (1.2 in)	"b": 6.5 mm (0.26 in)
--	---------------------	-----------------------

Mudguard Construction

B815H29406012




I815H1940009-03

1. Mudguard	 "A": Clean the adhesive surface before adhering the cushion rubber.
2. Cushion rubber	 (a) : 8 N·m (0.8 kgf-m, 6.0 lb-ft)
3. Front fender	

Rear Fender Cushion Attachment

B815H29406013




I815H1940010-02

1. Rear fender	 3. Cushion rubber No. 2 : Clean the adhesive surface before adhering the cushion rubber.
 2. Cushion rubber No. 1 : Clean the adhesive surface before adhering the cushion rubber.	"a": 5 mm (0.2 in)

Body Cowling Cover Cushion Attachment

B815H29406014



I815H1940011-01


1. Cushion rubber	 "A": Clean the adhesive surface before adhering the cushion rubber. Align the cushion rubber with the ruled line on the cover.
-------------------	--

Fastener Removal and Installation

B815H29406015

Type A Removal


- 1) Depress the head of fastener center piece (1).
- 2) Pull out the fastener (2).



I649G1940005-02

Installation

- 1) Let the center piece stick out toward the head so that the pawls "A" closes.




I649G1940006-02

- 2) Insert the fastener into the installation hole.

NOTE

To prevent the pawl "A" from damage, insert the fastener all the way into the installation hole.


- 3) Push in the head of center piece until it becomes flush with the fastener outside face.



I649G1940007-02

Type B Removal

- 1) Pry up the head of fastener center piece (1) with a screw driver.
- 2) Pull out the fastener "A".




I823H1940001-01

Installation

- 1) Insert the fastener into the installation hole.


NOTE

To prevent the pawl (2) from damage, insert the fastener all the way into the installation hole.



I823H1940002-01

- 2) Push in the head of center piece.



I823H1940003-01

Exterior Parts Removal and Installation

B815H29406016

Front Seat

Removal


Remove the front seat by removing the bolts.



I823H1940004-02

Installation

Slide the seat hooks into the seat hook retainers on the frame and tighten the bolts securely.



I823H1940005-02

Rear Seat

Removal


Remove the rear seat with the ignition key.



I823H1940006-02

Installation

Slide the seat hooks into the seat hook retainers and push down firmly until the seat snaps into the locked position.




I823H1940008-02


Seat Tail Cover

Installation

- 1) Remove the rear seat.
- 2) Remove the pillion rider handle.
- 3) Install the spacers (bundled parts).




I823H1940007-01



I815H1940019-01

- 4) Slide the hooks into the seat hook retainers and push down firmly until the seat tail cover snaps into the locked position.




I823H1940011-02

Removal

Remove the seat tail cover in the reverse order of installation.

Windscreen**Removal**

- 1) Remove the bolts and nuts (1).
- 2) Remove the windscreen (2) upward.




I823H1940009-01

Installation

Install the windscreen in the reverse order of removal.

Lower Meter Panel**Removal**

- 1) Remove the fasteners and bolt.
- 2) Remove the lower meter panel (1).




I823H1940012-01

Installation

Install the lower meter panel in the reverse order of removal.

Upper Meter Panel**Removal**

- 1) Remove the lower meter panel.
- 2) Remove the fasteners.
- 3) Remove the upper meter panel (1).




I823H1940013-02

Installation


Install the upper meter panel in the reverse order of removal.

Upper Panel**Removal**

- 1) Remove the lower and upper meter panels.
- 2) Remove the upper panels (1). (LH & RH)



I823H1940014-03



I823H1940015-04

Installation

Install the upper panels in the reverse order of removal.

Body Cowling Cover

Removal

- 1) Remove the fasteners (6 pcs.).
- 2) Remove the body cowling cover (1).



I823H1940016-02


Installation

Install the body cowling cover in the reverse order of removal.

Right Inner Under Cowling

Removal

- 1) Remove the body cowling cover.
- 2) Remove the right inner under cowling (1).



I823H1940017-02


Installation

Install the right inner under cowling in the reverse order of removal.


Center Under Cowling

Removal

- 1) Remove the body cowling cover and inner under cowlings.
- 2) Remove the center under cowling (1).



I823H1940019-01



I823H1940020-02

Installation

Install the center under cowling in the reverse order of removal.


Rear Under Cowling Removal

1) Remove the fasteners.



I823H1940021-01

2) Remove the rear under cowling (1) backward.



I815H1940020-01

Installation

Install the rear under cowling in the reverse order of removal.

Side Cowling Removal

- 1) Remove the body cowling cover.
- 2) Remove the right inner under cowling. (for right side cowling removal).
- 3) Remove the rear under cowling (for right side cowling removal).

4) Remove the following bolts and fasteners.



I823H1940023-01




I823H1940024-01



I823H1940026-01

5) Remove the bolt (1).

6) Pull out the hooked points "A" from each lug hole and remove the side cowling (2) forward.



I815H1940021-01

"A": Hooked point

Installation

Install each side cowling in the reverse order of removal.

Body Cowling

Removal

- 1) Remove the side cowlings. (LH & RH)
- 2) Remove the upper panels. (LH & RH)
- 3) Remove the rear view mirrors. (LH & RH)




I823H1940027-01

- 4) Disconnect the lead wire coupler (1).
- 5) Remove the screws.



I823H1940028-01

- 6) Remove the body cowling (2) forward.



I815H1940018-02

Installation

Install the body cowling in the reverse order of removal. Pay attention to the following points:

- Push in the hooked points on the body cowling to the lug holes on the cowling brace.




I823H1940029-01

- Adjust the headlight beam if necessary. Refer to "Headlight Beam Adjustment in Section 9B (Page 9B-3)".


Intake Pipe

Removal

- 1) Remove the body cowling.
- 2) Remove the relay/fuse box bracket (1). (LH only)
- 3) Remove the intake pipes (2). (LH & RH)



I823H1940030-01




I823H1940031-02

Installation


Install the intake pipes in the reverse order of removal.

Cowling Brace Removal

- 1) Remove the body cowling.
- 2) Remove the intake pipes.
- 3) Remove the combination meter (1).




I823H1940032-01




I823H1940033-01

- 4) Remove the wire clamps (2).



I823H1940034-01

- 5) Remove the steering damper mounting bolt (3).



I823H1940035-01

- 6) Remove the cowling brace (4).



I823H1940036-01


Installation

Install the cowling brace in the reverse order of removal. Pay attention to the following points:

- Tighten the cowling brace mounting bolts to the specified torque.

Tightening torque


Cowling brace mounting bolt (a): 32 N·m (3.2 kgf-m, 23.0 lb-ft)



I823H1940037-01

- Before installing the steering damper mounting bolt, apply grease to the steering damper bearing and dust seals.

 : Grease 99000-25010 (SUZUKI SUPER GREASE A or equivalent)



I823H1940038-01

- Tighten the steering damper mounting bolt to the specified torque.

Tightening torque

Steering damper mounting bolt (b): 23 N·m (2.3 kgf-m, 16.5 lb-ft)




I823H1940039-01

- Rout the wire harness and brake hose properly. Refer to "Wiring Harness Routing Diagram in Section 9A (Page 9A-5)".

Pillion Rider Handle

Removal

- 1) Remove the rear seat.
- 2) Remove the pillion rider handle (1) by removing the bolts.



I823H1940040-02

Installation

- 1) Install the pillion rider handle.
- 2) Tighten the bolts to the specified torque.

Tightening torque


Pillion rider handle bolt: 33 N·m (3.3 kgf-m, 24.0 lb-ft)

- 3) Install the rear seat.

Frame Cover

Removal

- 1) Remove the front and rear seats.
- 2) Remove the pillion rider handle.
- 3) Disconnect the rear combination light coupler (1) and seat lock cable (2).



I823H1940041-01

- 4) Remove the following fasteners, screws and bolts.



I815H1940022-01



I823H1940043-01



I823H1940044-01


- 5) Remove the caps (3).

- 6) Remove the seat rail hooks (4) using the special tools.

Special tool

 : 09930-11930 (Torx bit (JT30H))

 : 09930-11940 (Bit holder)



I823H1940045-01

- 7) Remove the frame cover assembly from the frame.

Installation

Install the frame cover assembly in the reverse order of removal.

Front Fender**Removal**

Refer to "Front Fork Removal and Installation in Section 2B (Page 2B-2)".

Installation

Refer to "Front Fork Removal and Installation in Section 2B (Page 2B-2)".

Rear Fender**Removal**

Refer to "Rear Fender Construction (Page 9D-7)".

Installation

Refer to "Rear Fender Construction (Page 9D-7)".

Specifications

Tightening Torque Specifications

B815H29407001

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Cowling brace mounting bolt	32	3.2	23.0	☞ (Page 9D-19)
Steering damper mounting bolt	23	2.3	16.5	☞ (Page 9D-20)
Pillion rider handle bolt	33	3.3	24.0	☞ (Page 9D-20)

NOTE

The specified tightening torque is also described in the following.

“Pillion Rider Handlebar Construction (Page 9D-5)”

“Frame Cover Construction (Page 9D-8)”

“Mudguard Construction (Page 9D-11)”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Tightening Torque List in Section 0C (Page 0C-9)”.

Special Tools and Equipment

Recommended Service Material

B815H29408001

Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI SUPER GREASE A or equivalent	P/No.: 99000-25010	☞ (Page 9D-19)

Special Tool

B815H29408002


09930-11930 Torx bit (JT30H) ☞ (Page 9D-21)		09930-11940 Bit holder ☞ (Page 9D-21)	
---	--	---	--

Body Structure

Repair Instructions

Body Frame Construction

B815H29506001




I815H1950001-03

1. Frame	5. Adjuster	(b) : 10 N·m (1.0 kgf-m, 7.0 lb-ft)
2. Seat rail	6. Adjuster lock-nut	(c) : 45 N·m (4.5 kgf-m, 32.5 lb-ft)
3. Seat rail bolt	7. Engine mounting pinch bolt	(d) : 35 N·m (3.5 kgf-m, 25.5 lb-ft)
4. Spacer	(a) : 50 N·m (5.0 kgf-m, 36.0 lb-ft)	

Front Footrest Bracket Construction

B815H29506002




I815H1950002-03

1. Washer	2. Washer	2. Bushing	"a": 2.0 mm (0.08 in)	 : 23 N·m (2.3 kgf-m, 16.5 lb-ft)
-----------	-----------	------------	-----------------------	--

Side-stand Construction

B815H29506003




(a) : 50 N·m (5.0 kgf·m, 36.0 lb·ft)	(c) : 95 N·m (9.5 kgf·m, 68.5 lb·ft)
(b) : 60 N·m (6.0 kgf·m, 43.5 lb·ft)	AH : Apply grease to sliding surface.

I815H1950003-02

Pillion Footrest Bracket Construction

B815H29506004





I815H1950004-01

(a) : 35 N·m (3.5 kgf·m, 25.5 lb·ft)

Footrest Construction

B815H29506005



1. Front footrest	2. Pillion footrest	 : Apply grease to sliding surface.
-------------------	---------------------	--

I815H1950005-02

Side-stand Removal and Installation

B815H29506006

Removal

- 1) Support the motorcycle with a jack or wooden block.

CAUTION

- Do not support the motorcycle with the exhaust pipes.
 - Make sure that the motorcycle is supported securely.
-

- 2) Remove the side-stand as shown in the side-stand construction. Refer to “Side-stand Construction (Page 9E-3)”.

Installation

Install the side-stand as shown in the side-stand construction. Refer to “Side-stand Construction (Page 9E-3)”.

Specifications

Tightening Torque Specifications

B815H29507001

NOTE

The specified tightening torque is also described in the following.

“Body Frame Construction (Page 9E-1)”

“Front Footrest Bracket Construction (Page 9E-2)”

“Side-stand Construction (Page 9E-3)”

“Pillion Footrest Bracket Construction (Page 9E-3)”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Tightening Torque List in Section 0C (Page 0C-9)”.

Special Tools and Equipment

Recommended Service Material

B815H29508001

NOTE

Required service material is also described in the following.

“Side-stand Construction (Page 9E-3)”

“Footrest Construction (Page 9E-4)”

GSX1300RK9 (2009 MODEL)

CONTENTS	
	PAGE
SPECIFICATIONS	10-2
Wiring Harness Routing Diagram	10-3

NOTE:

- * Difference between K9-MODEL and K8-MODEL specification is indicated as an asterisk mark (*).
- * The service data is the same as the K8-MODEL.

SPECIFICATIONS

DIMENSIONS AND CURB MASS

Overall length	2 190 mm (86.2 in)
Overall width	735 mm (28.9 in)
Overall height	1 165 mm (45.9 in)
Wheelbase	1 480 mm (58.3 in)
Ground clearance	120 mm (4.7 in)
Seat height	805 mm (31.7 in)
* Curb mass	260 kg (573 lbs)

ENGINE

Type	4-stroke, Liquid-cooled, DOHC
Number of cylinders	4
Bore	81.0 mm (3.189 in)
Stroke	65.0 mm (2.559 in)
Displacement	1 340 cm ³ (81.8 cu. in)
Compression ratio	12.5 : 1
Fuel system	Fuel injection
Air cleaner	Paper element
Starter system	Electric
Lubrication system	Wet sump
Idle speed	1 150 ± 100 r/min

DRIVE TRAIN

Clutch	Wet multi-plate type
Transmission	6-speed constant mesh
Gearshift pattern	1-down, 5-up
Primary reduction ratio	1.596 (83/52)
Gear ratios, Low	2.615 (34/13)
2nd	1.937 (31/16)
3rd	1.526 (29/19)
4th	1.285 (27/21)
5th	1.136 (25/22)
Top	1.043 (24/23)
Final reduction ratio	2.388 (43/18)
Drive chain	RK GB50GSVZ4, 114 links

CHASSIS

Front suspension	Inverted telescopic, coil spring, oil damped
Rear suspension	Link type, coil spring, oil damped
Front suspension stroke	120 mm (4.7 in)
Rear wheel travel	140 mm (5.5 in)
Caster	23° 25'
Trail	93 mm (3.66 in)
Steering angle	30° (right & left)
Turning radius	3.3 m (10.8 ft)
Front brake	Disc brake, twin
Rear brake	Disk brake
Front tire	120/70ZR17M/C (58W), tubeless
Rear tire	190/50ZR17M/C (73W), tubeless


ELECTRICAL

Ignition type	Electronic ignition (Transistorized)
Ignition timing	5° B.T.D.C. at 1 150 r/min
Spark plug	NGK CR9EIA-9 or DENSO IU27D
Battery	12 V 36 kC (10 Ah)/10 HR
Generator	Three-phase A.C. generator
Main fuse	30 A
Fuse	15/15/15/10/10/10/10 A
Headlight	12 V 65 W (H9) High beam
	12 V 55 W (H7) Low beam
Position light	12 V 5 W x 2
Brake/Tailight	LED
Turn signal light	12 V 21 W
License plate light	12 V 5 W
Speedometer light	LED
Tachometer light	LED
Neutral indicator light	LED
High beam indicator light	LED
Turn signal indicator light	LED
Coolant temperature indicator light	LED
Oil pressure indicator light	LED
Fuel level indicator light	LED
FI indicator light	LED
Engine RPM indicator light	LED
Immobilizer indicator light	LED E-02, 19, 24, 51

CAPACITIES

Fuel tank	20.0 L (5.3/4.4 US/Imp gal) E-33
	21.0 L (5.5/4.6 US/Imp gal) Others
Engine oil, oil change	3 100 ml (3.3/2.7 US/Imp qt)
with filter change	3 300 ml (3.5/2.9 US/Imp qt)
overhaul	4 000 ml (4.2/3.5 US/Imp qt)
Coolant	3.0 L (3.1/2.6 US/Imp qt)

Wiring Harness Routing Diagram



<p>16. Gray taping : Fasten the clamp on the gray taping. The width of the gray taping on both the right and left sides of the clamp should be at least 1 mm.</p>	<p>"c": 1 mm (0.039 in) and more.</p>
<p>17. Clamp : Cut off the excess end of the clamp and set the locked part facing downward.</p>	<p>"A": Pass the ignition switch lead wire on the lower side of right handle switch lead wires.</p>
<p>18. Ignition switch lead wire</p>	<p>"B": Do not make a right handle switch lead wire slacked from right handle switch to wiring harness guide.</p>
<p>19. Wiring harness guide</p>	<p>"C": Do not make a ignition switch lead wire twisted.</p>
<p>"b": 10 – 30 mm (0.4 – 1.2 in)</p>	<p>"D": Pass the ignition switch lead wire on the outside of other lead wires.</p>